



Installation, Maintenance and Service Manual LP and PLP


TABLE OF CONTENTS

SECTION 1 NAMEPLATE LOCATION	3	SECTION 3 OPERATOR CONTROLS	9
SECTION 2 SAFETY SUMMARY	4	3.1 Control Basics	9
2.1 Safety Information	4	3.2 Industry Standards	9
2.2 Safety Regulations	4	3.3 Clamp Open Control	9
2.3 Safety Symbols	4	SECTION 4 INSTALLATION & REMOVAL .	11
2.4 Operation Warnings.....	4	4.1 Hydraulics	11
2.5 Hydraulic Hazards	5	4.2 Attachment Installation.....	11
2.6 Electrical Hazards	5	4.3 Attachment Removal.....	12
2.7 Maintenance Warnings.....	5	4.4 Hydraulic Connections	12
2.8 Training	6	SECTION 5 SERVICE PROCEDURE	13
2.9 Labeling.....	6	5.1 Cylinder Removal.....	13
2.10 Pre-start Checks	6	5.2 Cylinder Disassembly.....	13
2.11 Personnel Safety	6	5.3 Cylinder Inspection	14
2.12 Load Handling	7	5.4 Cylinder Assembly	14
2.13 Load Positioning.....	8	5.5 Cylinder Installation.....	14
2.14 Truck Requirements.....	8	SECTION 6 MAINTENANCE	15
		6.1 Schedule	15
		6.2 Torque Specifications	15

SECTION 1 NAMEPLATE LOCATION

Notice

When you receive your attachment, locate the Long Reach nameplate (upper left corner on the body). Copy the information from the nameplate, along with the date received, in the space provided on the bottom of this page. If the nameplate is missing, look for the serial number stamped directly into the metal and consult factory.



Date Received:

□	□	-	□	□	-	□	□
---	---	---	---	---	---	---	---

Long Reach ® A Division of Allied Systems Company					
MODEL NO.:					
SERIAL NO.:					
MAXIMUM HYD. PRESS.:		PSI		WEIGHT: LBS	
CAPACITY:		LBS @		inch LC	
SEE TRUCK NAMEPLATE FOR COMBINED TRUCK & ATTACHMENT NET CAPACITY					
HOR. CG:		VERT. CG:		LOST LOAD /AET:	
inches		inches		inches	
CG AND AET SPECIFICATIONS ARE APPROXIMATE					
Manufactured By Allied Systems Company • 21433 Oregon Street, Sherwood, OR 97140 USA www.alliedsystems.com 2500005 RC					

SECTION 2 SAFETY SUMMARY

2.1 Safety Information

Safety is Everyone's Responsibility

Whether you are new on the job or a seasoned veteran, these safety tips may prevent injury to you, to others, or to the materials you are handling. Always be alert, watch out for others, and follow these suggestions:



Attachments handle material, not people.

Safety starts with common sense, good judgement, properly maintained equipment, careful operation, and properly trained operators.

The safety instructions and warnings, as documented in this manual and shipped with the machine, provide the most reliable procedures for the safe operation and maintenance of your Long Reach attachment. It's your responsibility to see that they are carried out.

2.2 Safety Regulations

Know your company's safety rules. Some companies have site-specific directions and procedures. The methods outlined in your operator's manual provide a basis for safe operation of the machine. Because of special conditions, your company's material handling procedures may be somewhat different from those shown in this manual.

2.3 Safety Symbols

The following terms define the various precautions and notices:



Danger

Indicates a hazardous situation which, if not avoided, WILL result in death or serious injury. Carefully read the message to prevent serious injury or death.



Warning

Indicates a hazardous situation which, if not avoided, could result in death or serious injury. Carefully read the message to prevent serious injury or death.



Caution

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury. Carefully read the message to prevent minor or moderate injury.

Notice

Describes information that is not related to personal injury, but may cause equipment damage or void the warranty.



Caution

All possible safety hazards cannot be foreseen so as to be included in this manual. Therefore, the operator must always be alert to possible hazards that could endanger personnel or damage to the equipment.

Obey the following warnings before using your machine to avoid equipment damage, personal injury or death.

2.4 Operation Warnings

- You must be trained to operate this equipment prior to operation. Be extremely careful if you do not normally operate this machine. Reorient yourself to the machine before starting, then proceed slowly.
- Always operate an attachment from the driver's seat.
- Always lower the attachment if you need to leave the lift truck. A lift truck supporting a load requires your full attention.

2.5 Hydraulic Hazards

Danger

Small hydraulic hose leaks are extremely dangerous, and can inject hydraulic oil under the skin, even through gloves. Infection and gangrene are possible when hydraulic oil penetrates the skin. See a doctor immediately to prevent loss of limb or death.

- Wear personal protective equipment, such as gloves and safety glasses, whenever servicing or checking a hydraulic system.
- Assume that all hydraulic hoses and components are pressurized. Relieve all hydraulic pressure before disconnecting any hydraulic line.
- Never try to stop or check for a hydraulic leak with any part of your body; use a piece of cardboard to check for hydraulic leaks.



2.6 Electrical Hazards

Warning

Remain at least 25 feet from high voltage electrical wires. Failure to do so may result in injury or death and will damage equipment.

- All electrical cables and connectors must be in good condition (free of corrosion, damage, etc). Use caution in wet weather to avoid danger from electrical shock. Never attempt electrical testing or repair while standing in water.



- Do not wear electrically conductive jewelry, clothing, or other items while working on the electrical system.

2.7 Maintenance Warnings

Maintenance, lubrication and repair of this machine can be dangerous unless performed properly. You must have the necessary skills and information, proper tools and equipment. Work in a method that is safe, correct, and meets your company's requirements.

- Do not attempt to make adjustments, or perform maintenance or service unless you are authorized and qualified to do so.
- Include attachments in a scheduled maintenance and inspection program. Tailor inspection steps to the attachment.
- Unless specified in service procedures, never attempt maintenance or lubrication procedures while the machine is moving or the engine is running.
- Always perform all maintenance and lubrication procedures with the machine on level ground, parked away from traffic lanes.

Notice

Local laws and regulations may require that additional safety measures be taken.

- Never rely on the hydraulic system to support any part of the machine during maintenance or lubrication. Never stand under a component that is supported only by the hydraulics. Make sure it is resting on its mechanical stops or appropriate safety stands.

- Use caution when working around hot fluids. Always allow lubricating and hydraulic oils to cool before draining. Burns can be severe.
- Use extreme caution when using compressed air to blow parts dry. The pressure should not exceed 30 psi (208 kPa) at the nozzle. Never use compressed air on yourself. Air pressure penetrating your skin can be fatal.
- Engine exhaust fumes can cause death. If it is necessary to run the engine in an enclosed space, remove the exhaust fumes from the area with an exhaust pipe extension. Use ventilation fans and open shop doors to provide adequate ventilation.



- Before disconnecting hydraulic lines, be sure to lower all loads and relieve all hydraulic pressure. The load could fall on you, or escaping hydraulic oil could cause severe personal injury.
- Prevent personal injury or equipment damage by using a lifting device with a lifting capacity greater than twice the weight of any equipment to be lifted.

2.8 Training

- Make sure all operators are trained in the fork and attachment adaptation, operation, and use limitations. Retrain an operator if a new attachment is added to the forklift. Consult the operator's manual for instructions on how to use the new equipment.
- Know the mechanical limitations of your forklift.
- Modifications or additions that affect capacity or safe operation must have prior written approval from the forklift truck manufacturer. Capacity, operation, and maintenance instruction plates, tags, or decals shall be changed accordingly.
- Never use free rigging for a below-the-forks lift. It could affect the capacity and safe operation of a lift truck.

2.9 Labeling

- Change capacity, operation, and maintenance instruction plates, tags, or decals when a forklift truck is equipped with an attachment. If the truck is equipped with front-end attachments other than factory installed attachments, truck must be marked to identify the attachments and show the approximate weight of the truck and attachment combination at maximum elevation with load laterally centered.

2.10 Pre-start Checks

- Check your equipment before you operate it. If anything looks wrong, unusual or different, report it before using the attachment.
- Do not operate this machine if you know of malfunctions, missing parts, and/or mis-adjustments. These situations can cause or contribute to an accident or damage to the machine. Stop the machine immediately if problems arise after starting.
- Check to make sure the attachment on your truck is the same as on the truck capacity plate.
- Check for hydraulic leaks and cracked hoses or fittings. Check the hydraulic oil level in the lift truck hydraulic reservoir.
- All electrical cables and connectors must be in good condition. Use caution in wet weather to avoid danger from electrical shock.
- Always check the attachment for proper fit and engagement of the truck carriage.

2.11 Personnel Safety

- When removing or installing dismountable attachments always keep hands and feet free from dangerous positions or pinch points. Never leave a dismounted attachment in a dangerous position.
- Keep hands, feet, long hair and clothing away from power-driven parts. Do not wear loose fitting clothing or jewelry while performing maintenance and lubrication in these areas.
- Never jump on or off the machine.

- Never stand on top of material being raised, lowered, or transported. (Figure 1)




Figure 2-1




Figure 2-2




Figure 2-3

- Never use the attachment or its load to support a man-carrying device.
- Never allow anyone under a load or under the carriage. (Figure 2)
- Never stand in front of or beside an attachment that is being operated. Never allow another person to approach an attachment that is being operated. (Figure 3)
- Never leave an attachment or load in an elevated position.
- Never reach through the mast of the truck. Keep all parts of the body within the driver's compartment.

- Always operate an attachment from the operator's seat, never while standing next to the lift truck.
- Do not allow riders on the truck at any time.
- Always use reverse when carrying a load that impedes full vision. Watch for pedestrians when transporting.
- Always use personal protective equipment (PPE) appropriate to the situation.

2.12 Load Handling

- Treat an unloaded forklift with an attachment as partially loaded.
- Never overload the attachment. Refer to the attachment nameplate for the rated capacity of the attachment. Refer to the truck nameplate for the maximum net working capacity of the truck/attachment combination.
- Never use a load to support or move another object. Doing so can easily exceed the holding capacity of the attachment.
- Always check loads to be handled. Correct loads that are broken, unbalanced, loose, or too heavy.
- Never lift, lower, side shift, pivot, rotate, or tilt loads while traveling. Repositioning loads while traveling affects the stability of the truck and may impede vision or clearances.
- Do not use an attachment to open or close boxcar doors. Doing so can severely damage the attachment and cause loss of warranty. Damage to clamp arms may result in product damage.
- Do not carry loose items or unsupported loads on top of a clamped load.
- Never use chains, cables, or other devices in conjunction with an attachment for load handling.
- Never clamp loads other than what the attachment was designed to handle.
- Always carry cylindrically shaped loads in the vertical position, not the horizontal.
- Always clamp loads with the contact pads, if applicable, not the arm or arm base.
- Never rotate a load that is off center to the centerline of rotation. Severe damage to the rotator could result.
- Always ensure that the load is the same width as the pallet and neatly stacked when using a carton clamp.

2.13 Load Positioning

- Be accurate in load placement. It's important to know what the load will do when it's released.
- Always carry loads as close to the floor as possible, consistent with the surface being traversed. Scraping or bumping the floor surface with the load or the attachment can severely damage the attachment and cause product damage. The mast should be tilted back.
- Always keep the load positioned as close as possible to the horizontal center of the lift truck.
- Always back down ramps or inclines. Driving forward down a ramp or incline with a clamped load will lessen the stability of the truck. (Figure 4)




Figure 2-4

- Do not cross dock boards or dock levelers with the attachment or carriage fully lowered. Ramming the front or rear of the attachment against a dock board can cause severe damage.

- Limit lift truck movement to a minimum when high stacking. Limit sideshift movement to a minimum when high stacking.
- Always be observant when high stacking. Look for poorly stacked loads, overhead obstacles, broken cartons, or damaged products in the stack.
- Travel slowly around corners. Sound horn on blind corners. Be careful of tail swing and overhead clearances. Watch in all directions. Avoid sudden stops.

2.14 Truck Requirements

Prior to connecting the truck hydraulic system to the attachment, the truck hydraulic system **must** be cleaned through the filtration system. This will eliminate any contamination that may exist in the auxiliary hydraulic system of the truck.

Warning

The capacity of the truck and attachment combined may be less than the attachment capacity. Consult truck nameplate!

Notice

The dealer and/or the user are responsible for installing any valving required to meet the recommended hydraulic pressures and flow. The required valving can be furnished by the dealer, the truck factory or Long Reach.

SECTION 3 OPERATOR CONTROLS

3.1 Control Basics

Some lift trucks are equipped with a single lever to control both hoist and tilt functions, others have separate levers for each function. Refer to your lift truck manual for more information.

For clarity, the direction of arm movement is shown on the control handle. To move the arms in the direction shown, pull the handle towards the operator. To move the arms in the opposite direction, push the handle away from the operator. (Figure 4-5)




Figure 3-1

Lifting speed is controlled by the speed of the engine and the position of the control lever. Engine speed has no effect on lowering speed.

Before going on the job, shift the truck control levers one way and then the other to determine which direction the attachment moves when the levers are shifted. Make sure the attachment moves smoothly throughout its travel, without binding or pinching hoses.

For push/pulls and load push attachments, check to be sure the faceplate moves in and out smoothly and is not misaligned.

Caution

Do not attempt to pull a load onto the platens with a misaligned faceplate.

Warning

If the attachment does NOT operate smoothly, do not take it on the job. Check with your supervisor about needed repairs.

3.2 Industry Standards

ANSI/ITSDF B56.1-2009 is the published sequence and direction standard for lever- and hand-type controls.

Notice

The chart on the following page shows industry standards. Your equipment may be different. If you do not routinely operate this equipment, refresher training is recommended. You must reacquaint yourself with this manual and the equipment before starting, and then proceed slowly.

Special controls such as automatic devices should be identified, preferably according to the recommendations in Figure 3-2.

When a function is controlled by a pair of push buttons, they should operate in the same sense as the lever controls. For example, pushing a button located to the rear (relative to the operator's position) should serve the same function as moving a control lever to the rear.

3.3 Clamp Open Control

Effective October 7, 2010, a new safety standard (ANSI/ITSDF B56.1, Section 7.25.7) for all lift trucks with a load bearing clamp (paper roll clamp, carton clamp, etc.) requires the driver to make two distinct motions before opening or releasing the clamp. For example, you must press a switch and then move a lever to unclamp the load. This requirement applies to new and used attachments being mounted on new trucks shipping from the factory after October 7, 2010, and is a recommended feature to be installed on dealer orders and existing applications.

Function	Direction of motion	
	Load	Operator's hand on control handle, facing the load*
Hoist	Up	Rearward or up
	Down	Forward or down
Reach	Retract	Rearward or up**
	Extend	Forward or down
Tilt	Rearward	Rearward or up**
	Forward	Forward or down
Sideshift	Right	Rearward or up
	Left	Forward or down
Push-pull	Rearward	Rearward or up**
	Forward	Forward or down
Rotate, lateral	Clockwise	Rearward or up
	Counterclockwise	Forward or down
Rotate, longitude	Rearward	Rearward or up
	Forward	Forward or down
Load stabilizer	Down	Rearward or up
	Up	Forward or down
Swing	Right	Rearward or up
	Left	Forward or down
Slope	Clockwise	Rearward or up
	Counterclockwise	Forward or down
Fork position	Together	Rearward or up
	Apart	Forward or down
Trip	Engage	Rearward or up
	Release	Forward or down
Grip	Engage	Rearward or up
	Release	Forward or down
Truck stabilizer	Raise	Rearward or up
	Lower	Forward or down
Clamp	Clamp	Rearward or up
	Release	Forward or down

* For high lift order picker trucks and center control pallet trucks, predominant motion of the operator's hand when actuating the control handle while facing away from the load.

** The sense of rotation of the control handle is intended to be in the same direction as the desired motion of the mast or load.

**Figure 3-2 ANSI/ITSDF
Sequence of location and direction of motion for lever- or hand-type controls**

SECTION 4 INSTALLATION AND REMOVAL

4.1 Hydraulics

1. Prior to connecting the truck hydraulic system to the attachment, the system must be cleaned through the filtration system. This will eliminate any contamination that may exist in the auxiliary hydraulic system of the truck.
2. Filtering can be accomplished by installing a jumper line and operating each equipped hydraulic function in each direction for a minimum of 30 seconds. (Figure 4-1)

Warning

The capacity of the truck and attachment combination may be less than the capacity shown on the attachment alone. consult truck nameplate!

The lift truck hydraulic system must meet the following specifications:

1. Supply petroleum based hydraulic oil
2. 7-10 GPM (26.5-37.8 LPM)
3. 2200-2300 PSI (150-160 Bar)
4. At least one auxiliary function




Figure 4-1, Jumper Line

Notice

The dealer and/or the user are responsible for installing any valving required to meet the recommended hydraulic pressures and flow. The required valving can be furnished by the dealer, the truck factory or Long Reach.

4.2 Attachment Installation

1. Purging can be accomplished by installing a jumper line and operating each hydraulic function (clamp, rotate, and side shift if equipped) in each direction for a minimum of 30 seconds. (Figure 4-1)
2. Remove the lower bolt-on hooks and, if applicable, make a note of any factory installed shims. If quick change hooks are supplied, simply depress the button on the back of the hooks, allowing the slide plate to drop, Figure 4-2.
3. Center the truck behind the attachment and drive toward the attachment with the mast tilted forward approximately 4°.
4. Line up the locking lug (if applicable) with the appropriate notch on the truck's carriage. If the attachment includes a sideshift function, check that the bronze side-shifting wear strips are in the proper place.
5. Make sure the wear pad is in place and making contact with lower carriage bar.

Warning

Before disconnecting any hydraulic connections, be sure to turn off the truck's power and activate the truck's hydraulic functions in both directions to bleed off the hydraulic pressure. Failure to cycle the hydraulic circuit as described above could cause serious injury.

If hydraulic supply hoses are disconnected, hydraulic fluid will leak out and push plate may drift outward.

4.3 Attachment Removal

1. Disconnect hydraulic connection at the attachment from the truck.
2. Disconnect the quick mounts to remove the attachment. (Figure 4-2)




Figure 4-2 Quick Change Hook




Figure 4-3, Lower Hook Clearance

3. Slightly raise the truck carriage to allow the removal of the bottom mounting hooks. If the attachment is equipped with button-type quick change hooks, press the slide plate release button and drop the slide plate down (Figure 4-2). If the attachment is equipped with pin-type quick change hooks, remove the retaining pin and the quick change hook.

Warning

If the slide plate does not click into place because the truck carriage prevents the slide plate from being raised up high enough, install shims between the attachment and the body of the quick change hooks. Slide plate must click into place.

4.4 Hydraulic Connections

1. Install the lines from the truck hydraulics to the hydraulics of the attachment.

Notice

Any alterations to the original attachment may affect performance or safety and result in loss of warranty.

2. Inspect installation to ensure hoses are not kinked or pinched between the truck carriage and attachment.
3. Operate the attachment continuously for several minutes to determine that all hydraulic connections are secure with no leaks.
4. Activate cylinders fully and check that the truck's hydraulic reservoir oil level is at the recommended level.
5. Before placing the attachment in operation check the following:
 - a. Inspect all hoses and fittings for leaks and routing clearance. Be sure to inspect the clearance of jumper hoses to the mast.
 - b. Check the valve and cylinder for leaks.
 - c. Check cotter pins at each end of the cylinder for security.
6. After completing the installation, operate the attachment without a load for several cycles to remove any air in the hydraulic system. Test the attachment with a load to make sure the attachment operates correctly.

Notice

The dealer and/or the user are responsible for installing any valving required to meet the recommended hydraulic pressures and flow. The required valving can be furnished by the dealer, the truck factory or Long Reach.

SECTION 5 SERVICE PROCEDURE

5.1 Cylinder Removal

1. Disconnect the hydraulic connections.
2. Remove the cylinder rod-end cotter pin and clevis.
3. Remove cotter pin and clevis pin at the base of the cylinder.



Warning

Before disconnecting any hydraulic connections, be sure to turn off the truck's power and activate the truck's hydraulic functions in both directions to bleed off the hydraulic pressure.

Failure to cycle the hydraulic circuit as described above could cause serious injury.

5.2 Cylinder Disassembly

1. Remove the cylinder from the attachment. See Section 5.1 for removal instructions.
2. Clamp the cylinder lightly at the base end using a soft-jawed vise. Use a block or other support under the rod end of the cylinder. (Figure 5-3)




Figure 5-3, Cylinder Vise

3. Use a spanner wrench or similar tool to unscrew the gland cap from the cylinder tube. (Figure 5-4)




Figure 5-4, Cylinder Rebuild

4. Remove the rod assembly from the cylinder tube.
5. Clamp the rod assembly in a soft-jawed vise on the wrench flats, not on the rod surface. If the rod does not have wrench flats use two pieces of wood on both sides of the rod to prevent scarring. (Figure 5-5)




Figure 5-5, Cylinder Shaft

6. Remove the piston retaining nut and remove the piston. (Figure 5-4)
7. Carefully pry up on the piston seals using a blunt tip screw driver being careful not to scratch the seal grooves. Cut the seals to remove from the piston. (Figure 5-6)




Figure 5-6, Remove Piston Seal

- Use the same procedure as above to remove the seals from the gland cap.

5.3 Cylinder Inspection

Inspect the cylinder tube bore for:

- Deep scratches or nicks.
- Signs of galling or excessive wear.
- Out-of-roundness or deformities of the barrel.

Inspect the piston for:

- Scratches or nicks on seal grooves.
- Wear on outside diameter.

Inspect the cylinder rod for:

- Scratches or nicks on the rod surface.
- Straightness of the rod.
- Damaged threads.

Inspect the gland cap for:

- Scratches or nicks in seal grooves.
- Damaged threads or spanner wrench holes.
- Excessive wear in bore.

Replace any component found to be defective.

5.4 Cylinder Assembly

- Spray the piston, gland cap, and seals with WD40 or other similar product to ease seals installation.
- Note the direction of the seal on the piston. Improper installation will result in poor performance. The cupped side or O-ring side of the seal should be facing the gland cap. (Figure 5-7)




Figure 5-7 Piston Seal

- Install the seals and wipers in the gland cap. Note the direction of the seals. The cupped side or O-ring side of the seal should be facing the piston. (Figure 5-8)




Figure 5-8, Gland Cap Seal

- Install the piston on the rod and tighten the locknut to 70-75 ft-lbs.
- Spray the inside of the cylinder tube with lubricant to ease inserting the rod and piston. Insert the rod and piston into the cylinder tube. Tap the rod in with a rubber mallet if resistance is encountered.
- Install the gland cap on the cylinder rod being extremely careful not to cut the rod seal on the threads of the rod or rod shoulder. If available, use a sleeve or plastic electrical tape to cover the rod threads.
- Tighten the gland cap using a spanner wrench.

5.5 Cylinder Installation

- Install the clevis pin and cotter pin into the base end of the cylinder.
- Attach the hydraulic connections to the cylinder.
- Extend the cylinder until the rod end hole lines up with the mounting hole. Install the clevis pin and cotter pin into the end of the cylinder.

SECTION 6 MAINTENANCE

6.1 Schedule

Daily:

1. Visually inspect all hoses, fittings, cylinders, and valves for signs of hydraulic leaks.
2. Inspect hoses for wear/pinching and replace as required.
3. Inspect forks for nicks, dents, rough spots, and repair as required.
4. Visually inspect lower hook installation and check unit for external damage or cracks.

40 Hour Maintenance:

1. Complete the above daily checks.
2. Inspect retaining pins and replace as required.
3. Tighten mechanism pivot retaining pin bolts.
4. Lube bronze top hooks if needed.
5. Lube mechanism if desired. (Use light oil)
6. Check lower hook clearance (3/16" = 5mm maximum) and adjust as required.

500 Hour Maintenance

1. Perform 40 hour inspection.
2. Inspect bushings for excessive clearance (1/32" = 1mm maximum) at all pivots and replace as required.
3. Tighten and torque all bolts.
 - a. Top hooks: 225 N-m
 - b. Lower hooks: 225 N-m
 - c. Fork hooks: 225 N-m

Recommended Grease:

Mobile XHP222 Special, or similar quality EP-2 with Lithium Complex Base.

6.2 Torque Specifications

Metric Capscrews		Torque N-m (Ft-Lbs)	
Nominal Size	Pitch	Class 8.8	Class 10.9
M8	1.25	19 (14)	26 (19)
M10	1.50	38 (28)	52 (38)
M12	1.75	68 (48)	90 (68)
M14	2.00	105 (77)	145 (107)
M18	2.00	185 (122)	225 (168)

$$\text{Ft-Lbs} = (\text{N-m}/1.356)$$

Notes:
