


# FREEMAN

---

## MODEL 1500 BALER



## OPERATOR'S MANUAL

---

*manufactured and distributed by*



**J. A. FREEMAN & SON, INC.**



PORTLAND, OREGON

**INTENTIONALLY BLANK**



## **LIMITED WARRANTY**

J.A. Freeman & Son, Inc. guarantees all new equipment manufactured by them to be free from defects in material and workmanship for one season or part thereof from date of delivery to the retail purchaser. One copy of the "EQUIPMENT DELIVERY AND WARRANTY REGISTRATION" must be correctly completed and returned to J.A. Freeman & Son, Inc. in order to validate the warranty. The obligation under this warranty is limited to the replacement or repair at our Portland, Oregon factory or at a point designated by us of such parts that appear to us upon inspection to have been defective in material or workmanship.

J.A. Freeman & Son, Inc. obligation under this warranty is limited to repairing or replacing, at its option, any part that in the J.A. Freeman & Son, Inc. judgment is defective when returned to the factory.

The provisions of this warranty shall not apply to any equipment which has been subject to misuse, negligence, alteration or accident, or which shall have been repaired with parts other than those obtainable through J.A. Freeman & Son, Inc.

Except as set forth, J.A. Freeman & Son, Inc. shall not be liable for injuries or damages of any kind or nature, direct, consequential, or contingent, to person or property. This warranty does not extend to loss of crops, loss because of delay or loss incurred for labor, supplies, substitute machinery, rental or for any other reason.

J.A. Freeman & Son, Inc. makes no warranties whatsoever in respect to tires, engines, alternators, batteries, or other trade accessories, inasmuch as they are usually warranted by their respective manufacturers.

NOTE: J.A. Freeman & Son, Inc. reserves the right to make improvements in design or changes in specifications without notice at any time and without incurring any obligation to owners of units previously sold.

THE BALER REGISTRATION REPORT MUST BE CORRECTLY COMPLETED AND RETURNED TO J.A. FREEMAN & SON, INC. IN ORDER TO VALIDATE THE LIMITED WARRANTY.

INTENTIONALLY BLANK



## **TO OUR CUSTOMER**

Your decision to buy a Freeman 1500 Big Baler was a wise decision. When it comes to harvesting hay, Freeman equipment is a solid investment. Dollar per dollar, ton per ton, Freeman equipment brings down costs and brings up profits. Freeman equipment has satisfied and will continue to satisfy their owners all over the world for years to come.

You will find your baler has come from the drawing boards of superior engineers who take their ideas to the field for testing and revision before you receive them. Superior engineering coupled with professional craftsmanship makes your Freeman Baler the leader in the industry.

At J.A. Freeman & Son, safety is not just a word, it is a rule. Safety to the operator is of great concern to Freeman engineers. Special care has been taken while designing your Freeman Baler to make it as safe and efficient as possible.

We recommend that you carefully read this entire manual before operating your baler. Time spent in becoming fully acquainted with its performance features, adjustments, and maintenance schedules will be repaid in the long and satisfactory life of the product.



## GENERAL INFORMATION

### INTRODUCTION

The purpose of this manual is to assist the operator in maintaining and operating a Freeman 1500 Big Baler. Read it carefully for it provides information and instructions that will help you achieve years of dependable performance.

**NOTE:** Reference to left-hand and right-hand used throughout the manual refers to the position when seated in the operator's seat facing forward.


### REPLACEMENT PARTS

Only genuine Freeman replacement parts should be used to repair the baler. These parts are available from the local Freeman dealer. To ensure prompt, efficient service when ordering parts or requesting repairs, always remember to give the dealer the following information:

1. Correct part description or part number.
2. Model number of the baler.
3. Serial number of the baler.

### SERIAL NUMBER LOCATION

The serial number is an important piece of information about the machine and it may be necessary to know it before obtaining the correct replacement part. The serial number is located on the forward front center of the brace between the baler drawbar.



**WARNING:** SOME PICTURES AND ILLUSTRATIONS IN THIS OPERATOR'S MANUAL SHOW THE BALER WITHOUT SAFETY SHIELDS TO ALLOW FOR A BETTER VIEW OF THE AREA BEING ADDRESSED. THE BALER SHOULD NEVER BE OPERATED WITH ANY OF THE SAFETY SHIELDS REMOVED.



## **SAFETY**

1. KEEP ALL SHIELDS IN PLACE AND IN SERVICEABLE CONDITION.
2. SHUT OFF TRACTOR BEFORE ADJUSTING, LUBRICATING, CLEANING OR SERVICING BALER.
3. KEEP HANDS, FEET, AND CLOTHING AWAY FROM POWER DRIVEN PARTS.
4. USE APPROPRIATE SIGNS OR WARNING LIGHTS WHEN OPERATING ON PUBLIC ROADWAYS.
5. MAKE CERTAIN EVERYONE IS CLEAR OF AND OFF THE BALER BEFORE ENGAGING P.T.O. OR RUNNING BALER.
6. PERIODICALLY CHECK ALL NUTS AND BOLTS FOR TIGHTNESS.
7. ALWAYS USE LIGHTS FOR NIGHT WORK.
8. AT ALL TIMES CARRY A MINIMUM 2A-10B FIRE EXTINGUISHER AND A FOUR GALLON WATER CONTAINER WITH PUMP ON BALER.
9. AVOID WEARING LOOSE CLOTHING WHICH CAN EASILY BE CAUGHT IN MOVING PARTS.
10. AT ALL TIMES KEEP HANDS AND FEET CLEAR OF PICKUP.
11. AT ALL TIMES KEEP THE MANUAL CONTROL CABLE IN A SAFE LOCATION AWAY FROM POWER DRIVEN PARTS.
12. REMEMBER **SAFETY** IS ONLY A WORD UNTIL IT IS PUT INTO PRACTICE.

**CAUTION:** GENERAL REMINDER OF GOOD SAFETY PRACTICE OR TO DIRECT ATTENTION TO UNSAFE PRACTICE.

**WARNING:** DENOTES SPECIFIC POTENTIAL HAZARD.

**DANGER:** DENOTES MOST SERIOUS SPECIFIC POTENTIAL HAZARD.





## TABLE OF CONTENTS

1. SPECIFICATIONS . . . . .	1
2. PERIODIC MAINTENANCE & LUBRICATION . . . . .	2
3. WALK-AROUND PHOTOS . . . . .	3
4. GENERAL OVERVIEW OF THE FREEMAN 1500 BALER . . . . .	5
5. PREPARATION . . . . .	6
6. OPERATION . . . . .	8
7. ADJUSTMENTS & MAINTENANCE . . . . .	12
A. KNOTTER TIMING ADJUSTMENT . . . . .	12
B. PLUNGER ADJUSTMENT . . . . .	16
C. KNIFE ADJUSTMENT . . . . .	17
D. LIMIT SWITCH ADJUSTMENT . . . . .	19
E. PROPER OPERATING PRESSURES . . . . .	27
F. MISCELLANEOUS . . . . .	30
8. STORING THE BALER . . . . .	34
9. TROUBLE SHOOTING . . . . .	35
10. INDEX . . . . .	38



## **SPECIFICATIONS**

**Overall Length:** 24 feet (7.32 m.)

**Overall Width:** 10 feet (3.05 m.)

**Working Height:** 140 inches (355.6 cm)

**Towing Height:** 117 inches (297.18 cm)

**Hauling Height:** 105¼ inches (267.34 cm)

**Weight:** 19,000 pounds (8,626 kg)

**Capacity:** Up to 40 tons per hour

**Bale Chamber:** 38 inches High, 46 inches Wide (96.52 cm High, 115.84 cm Wide)

**Bale Length:** Adjustable

**Bale Weight:** Up to 1400 pounds (635.6 kg)

**Plunger Speed:** 0-16 S.P.M. 1000 R.P.M. depending upon feed rate

**Plunger Length Stroke:** 30 inches (76.2 cm)

**Pickup Width:** 80 inches (203.2 cm)

**Hitch:** Adjustable Height

**Tires:** 23.1 × 26 (12 ply) or 18.4 × 26 (14 ply)

**Feed System:** Center Line Flow Through

**Drive System:** Hydraulic

**Tension System:** Hydraulic 3-Way Squeeze

# PERIODIC MAINTENANCE AND LUBRICATION

TYPE OF MAINTENANCE OR LUBRICATION	FREQUENCY
Feeder Crank Journals (2)	4 hours
Grease PTO Shaft and U-joints (See Walk-Around)	4 hours
Grease overrunning clutch	4 hours
Grease Feed Fork Journals (Crank Throw Bearings) (4)	4 hours
Grease Feed Fork Link Rear Bearing	4 hours
Check Chain Oilers	8 hours
*Blow Clean with Compressed Air	Daily
Grease Needle Yoke Pivot Bearings (2)	Daily
Grease Needle Yoke Drive Connecting Rod Ends (2)	Daily
Check Oil Level In Knotter Luber Tank	Daily
Grease Plunger Rollers	40 hours
***Grease Sunstrand Pump Coupler	80 hours
Grease Bearings on Upper (Fly Wheel) Drive Shaft (2)	80 hours
**Check Belts	80 hours
Grease Bearings on Lower (Primary) Drive Shaft (2)	80 hours
Knotter Brake Adjustment	80 hours
Change Main Charge Pump Filter	500 hours
Grease Needle Yoke Crank Shaft Bearings (3)	Annually
Grease Feed Fork Crank Main Bearings (2)	Annually
Grease Knotter Shaft Bearings (2)	Annually
Repack Wheel Bearings	Annually
Change System Oil	Annually
Change Oil Tank Filter or as indicated by filter condition indicator	Annually

## SPECIFIC OILS AND GREASES

**Main System Hydraulics:** Standard Oil Co. AW46 Hydraulic or equivalent

**Grease Zerks:** Multi-purpose grease


**Automatic Knotter Luber:** SAE 80 GL5 gear oil

**Coupling:** Special grease

\*Do not steam clean for it can cause problems if contact points are enveloped with moisture.

\*\*Check new belts after first 8 hours of operation.

\*\*\*How to grease coupler on page 33.



### WALK-AROUND (CALL OUTS)

#### R-side / front:


- |                                |                                |
|--------------------------------|--------------------------------|
| 1. Feed Fork Drive Lubr System | 10. Tension Pump Sheave        |
| 2. Feeder Crank Arm            | 11. Oil Tank Filter            |
| 3. Feed Fork Crank Shaft       | 12. Knotter/Feed Fork Manifold |
| 4. Tension Control System      | 13. Knotter Brake              |
| 5. Infeed Chute Guards         | 14. Needle Yoke Drive Sprocket |
| 6. Accumulator                 | 15. Needle Yoke Drive Rod      |
| 7. Tension Pump                | 16. Needle Yoke                |
| 8. Main Drive Sheave           | 17. Tension Unloader Valve     |
| 9. Alternator                  |                                |

#### L-side / front:

18. Sunstrand Pump
19. Infeed Chute
20. Feeder Sprocket
21. Main Control Box
22. Fan Control Box
23. Feeder Crank Arm
24. Twine Tensioner Spring
25. Needle Yoke
26. Needle Yoke Drive Rod
27. Knotter
28. Oil Tank Filter
29. Oil Cooler
30. Fly Wheel
31. Alternator Pulley
32. P.T.O. Drive Line Clutch


#### Rear View:

33. Rear Axle
34. Tension Rails
35. Hydraulic Cylinder
36. Knotter Lubr Tank
37. Halogen Light
38. Warning Light
39. Stop/Signal Light
40. Bale Chute




**P.T.O. SHAFT  
& U-JOINTS**

# WALK-AROUND



L-SIDE / FRONT

# WALK-AROUND



REAR VIEW

# **GENERAL OVERVIEW OF THE FREEMAN 1500 BALER**

The 1500 is a high-density mechanical hay baler operated by an electronically controlled hydraulic power medium. The function of the baler is to bale hay or straw. A group of subfunctions work in a logical order to complete the baling process.

## **Subfunction 1.**

Hay is gathered by the continuously rotating pickup and delivered to the feeder.

## **Subfunction 2.**

Hay is taken by the continuously operating feeder and delivered to the feed fork.

## **Subfunction 3.**

Hay is taken intermittently by the feed fork through the infeed chute to the main chamber.

## **Subfunction 4.**

The hay, when forced to the top of the main chamber, activates the charge sensor. When the sensors are activated the feed fork [3] momentarily stops at the top of the infeed chute. Then the plunger is activated compressing the hay behind the hay dogs clearing the feed opening for more hay.

While a complete plunger stroke takes roughly 3 seconds, the feed fork [3] is stopped for roughly 2 seconds. The feed fork leaves its rest position before the plunger gets back to the home position. Thus, there is no compaction of hay in the infeed chute.

## **Subfunction 5.**

While the baler is operating, bale density is automatically maintained by the self-regulating tension control system which is controlled by the main plunger pressure and the tension control solenoid valve.

## **Subfunction 6.**

The remaining major subfunction of the 1500 baler is the tying process of the knotters. While subfunctions 1,2,3,4,5 are occurring, the knotters are idle until the bale reaches its adjustable preset length. At this time the Knotter Trip switch (LS-11) is activated with the plunger fully extended. Then the plunger retracts a short distance and stops signaling the knotters to tie. After the knotters complete their half cycle, the plunger returns to its home position. The travel of the needles is timed with the travel of the plunger to avoid needle breakage.

# PREPARATION

## Attaching Baler to Tractor

1. Before attaching the baler to the tractor make sure the baler is securely resting on a level surface. The baler must be powered by a tractor with a minimum of 140 Horsepower with a 1000 P.T.O. R.P.M. NOTE: Adverse conditions, such as soft ground and hilly terrain, may require greater horsepower for maximum performance.

2. The front drawbar hitch on the baler is adjustable depending on the height of your tractor drawbar. The drawbar hitch can be adjusted up or down or turned over 180 degrees, see *Fig. 1*, to achieve the proper adjustment. Avoid serious equipment damage by following the S.A.E. Standards in *Fig. 2* and *Table 2*. Different dimensions are required depending on the size of tractor P.T.O. shaft to be used.




Fig. 1




Fig. 2

3. When hitching the baler to the tractor, follow the illustration in *Fig. 1*. The distance from the bottom of the baler hitch mount to the ground should be 17 inches with a 2-inch tolerance. Ensure all fasteners are tightened in their proper position.

DIMENSIONS ASSOCIATED WITH TRACTOR DRAWBAR AND POWER TAKE-OFF

	1 3/8" Diameter	1 1/4" Diameter
K - Hitch pin hole diameter	1 3/16"	1 5/16"
L - Auxiliary hole diameter	1 1/16"	1 1/16"
M - Auxiliary hole spacing	4"	4"
S - Height of drawbar with popular sized tire:		
Preferred	15"	19"
Min.	13"	17"
Max.	17"	21"
T - End of P.T.O. shaft to center of hitch pin hole	16"	20"
U - Top of drawbar to P.T.O. centerline		
Preferred	8"	9"
Min.	6"	8"
Max.	12"	10"

Table 2.

4. Connect the baler pickup lift hydraulic lines to the tractor remote hydraulic ports. Be certain connecting ends are free of foreign matter.

5. Connect the 7-wire trailer cable from baler to the S.A.E. socket on the tractor.

6. Route the STOP/REVERSE control rope and fasten it to a position accessible for the operator during operation.

7a. On a level surface, pull the baler and turn the tractor left or right until the rear wheel of the tractor is touching or nearly touching the baler drawbar. Attach the baler P.T.O. drive line to the tractor P.T.O. shaft. Ensure the drive line does not bind or interfere with the baler hitch.

7b. Disconnect the baler P.T.O. drive line and drive the tractor forward until the baler is straight behind the tractor. Reattach the baler P.T.O. drive line to the tractor P.T.O. shaft. Ensure the drive line does not interfere with the baler hitch.

NOTE: If the P.T.O. drive line binds or interferes with the baler hitch in steps 7a or 7b, consult your authorized Freeman Service Representative.

## Attaching A New Baler

When attaching a baler to the tractor for the first time, be sure to check the following areas:

a. Ensure the wheel lugs are torqued to 320 foot-pounds lubricated. After the lugs have been torqued, tow baler 1/2 mile and recheck the lugs for the proper torque.

- b. Inflate 12 ply tires (23.1 × 26) to a maximum of 22 p.s.i. and 14 ply tires (18.4 × 26) to a maximum of 36 p.s.i. CAUTION: Do not over inflate the tires.

## Twine Installation And Threading

1. Load 18 boxes of twine into the twine boxes, (9 on each side). NOTE: We suggest using Bridon SR-300 Polypropylene baler twine or equivalent.
2. Route twine over the brackets on the inside-top of each row and through the twine guides on the rear of the twine box, see Fig. 3.




Fig. 4

## TWINE INSTALLATION ROUTING




Fig. 3

5. Thread the twine through the needle rollers and needle eyes. The needle rollers are located 22 inches back from the tip of the needles.
6. Tie each twine to the cross member located above the twine tensioners on the bottom of the chamber. Each twine should be individually tied directly above the twine tensioner through which it is threaded.
7. Once the needles have cycled and the knotters are loaded with twine, remove the twine ends from the cross member on bottom of chamber and manually pull the knot sensor fingers to the rear of the baler.

3. Route twine through the three sets of twine guides near the top of the chamber, then down through the twine guide mounted above the baler tire, see Fig. 3.
4. Route the twine through the twine guides located near the twine tensioners. Proceed pulling the twine through the twine tensioners, see Fig. 4. A button hook is useful to pull twine through the twine tensioners.




# OPERATION

## Field Start-Up Procedure

With the baler properly attached to the tractor, proceed with the following steps:

1. Before operating baler, make certain the hydraulic oil tank is filled with Chevron AW 46 hydraulic oil or equivalent. The filter cap on top of the tank maintains 10 p.s.i. on the system. Do not replace the cap with anything else. The oil level can be determined by the sight gauge on the front of the hydraulic oil tank. Appearance of the oil in the sight gauge should be clear, not cloudy or dirty. Coloring agents used by oil manufacturers vary from light brown to purple.
2. Ensure the Knotter Luber Oil Tank is filled with SAE 80 GL5 gear oil.
3. Lower the pickup to the baling position and make sure the pickup fingers do not dig into the ground while operating. Adjust the maximum pickup depth with the depth stop, see *Fig. 5*.



*Fig. 5*

4. Ensure the knotters are properly threaded with Bridon SR-300 Polypropylene baler twine or equivalent and that the twine boxes are full. See Twine Threading, page 7.
5. With the tractor R.P.M. at low speed and with Baler Power Switch "OFF", gently engage the tractor P.T.O. Slowly increase the tractor to 500 P.T.O. R.P.M.

6. Be sure the needle yoke is in home position and if not, return it to home position with the manual control. See Manual Control. **NOTE: DO NOT EXCEED 500 P.T.O. R.P.M. SPEED WHEN OPERATING THE NEEDLE YOKE WITH THE MANUAL CONTROL.**

7. Turn the Baler Power Switch to the "ON" position and set the Control Mode Switch to the "AUTO" position.

## Baler Operating Speeds

When starting the baler, run it at or below 500 P.T.O. R.P.M. speed until the oil temperature reaches a minimum of 32 degrees Fahrenheit (0 degrees Celsius).

The baler should be run at 1000 P.T.O. R.P.M. speed while baling. The ground travel speed should be regulated according to ground conditions and windrow volume of hay.

The windrow volume of hay going into the baler should be regulated according to the work load on the feed system. If the hay is fed at too high of a rate, the pickup and feeder will stall.

**NOTE:** If operating in temperatures below 10 degrees Fahrenheit (-12 degrees Celsius), consult the Freeman factory for oil recommendations.

## Manual Control

The 1500 Big Baler is equipped with a Manual Control System, see *Fig. 6*. This allows the operator to operate the Knotters, Plunger, and Feed Fork independently. This feature is to be used when making adjustments or servicing the baler.

To operate the Manual Control, set the Control Mode switch, see *Fig. 6*, down to the manual position. Plug in the remote cable into one of the six sockets depending on which operation is required. There are two sockets for each of the three components, one for each direction of travel.

Once the manual control remote cable is in the proper socket, the component is activated by depressing the button on the manual control operator.



## MANUAL CONTROL/ REMOTE CABLE





Fig. 6



**CAUTION:** When using the manual control operator, first clear the area of all personnel and check for safe operation before activating component.

**NOTE:** Do not exceed 500 P.T.O. R.P.M. speed when using the manual control to operate the feed fork and knotter. **NOTE:** The knotter will not run with the plunger fully extended.

**CAUTION:** WHEN THE KNOTTERS ARE ACTIVATED THE NEEDLES WILL TURN. DUE TO THE FAST TRAVEL OF THE NEEDLES, STAY CLEAR OF THE MOVING PARTS.

## Stop/Reverse Control Rope

The baler is equipped with a Stop/Reverse Control Rope which is attached to a three-way valve, see Fig. 7. Its function is to reverse the pickup and feeder systems and operates as follows:

**With Rope in the Relaxed Position:** The pickup and Feeder will operate in the normal baling mode.

**With The Rope Pulled Half Way:** The pickup and Feeder will stop.

**With The Rope Pulled Full Distance:** The feeder will reverse while the pickup remains stopped.




Fig. 7

## Unplugging The Feed System

### Unplugging The Feeder

If the Feeder should become plugged, pull the stop/reverse control rope back full distance to reverse the feeder. This allows the hay or foreign material to escape from the baler. It may take two or three cycles of this process to unplug the feeder.

Once the excess hay or foreign material is cleared out of the feeder area, continue to operate the baler at a slower ground travel speed and have foreign material cleared from the path of the baler.

### Unplugging The Feed Fork

If the Feed Fork should become plugged, ensure the needle yoke is in the home position (bottom dead center) and LS-1 is activated as described in LS-1 adjustment, page 19. When unplugging the feed fork with needles in the home position, do the following:

1. Set the Control Mode Switch to Manual.
2. Use the manual control to fully extend the plunger in order to clear the infeed section of the chamber area.
3. Set the Control Mode Switch back to Automatic.
4. Repeat if necessary.
5. After unplugging the feed fork of excess hay or foreign material, operate the baler at a slower ground travel speed.

If the needle yoke is in the travel position, use the remote control and return it to its home position. Then follow the aforementioned procedure.

## Tension Control

The self-regulating Tension Control System is controlled by the main plunger pressure and the tension control solenoid valve. Bale density is determined by plunger pressure which in turn is controlled by the amount of restriction created by the tension control system as the hay moves through the bale chamber.




Fig. 8

The function of the Tension Control Solenoid Valve is to automatically apply hydraulic pressure to the tension control system. Only when the plunger advances is the tension control solenoid valve de-energized, pressurizing the tension control system. At all other times the tension control solenoid valve is energized allowing the tension control pump to feed oil back to the reservoir while a check valve holds the tension control system at the pressure attained during the previous plunger advance stroke.

Example: Assume Bale density setting of 3,500 p.s.i. As the plunger pressure reaches 3,500 p.s.i. on a compression stroke, the tension pressure is automatically regulated to keep the plunger pressure at or near 3,500 p.s.i.

The maximum tension pressure is fixed at 2,150 p.s.i. and CANNOT be adjusted.

### Bale Density Adjustment

Bale density is regulated by the Tension Unloader Valve located on the rear right hand side of the baler, see Fig. 9. The plunger pressure range is usually 3200 to 4000 p.s.i. depending on the condition of the hay.

Bale density is initially adjusted at the factory at 10 turns clockwise after the adjustment screw touches the inner spring.

To increase bale density, turn the adjustment screw clockwise. To decrease bale density, turn the adjustment screw counter-clockwise.




Fig. 9

Bale density pressure is read on the plunger pressure gauge located on front of the baler while baling. The actual pressure is the momentary pressure peak when the plunger is on the compression stroke. NOTE: Several plunger strokes may be necessary to normalize the pressure setting.

### Bale Length Adjustment

Bale length is adjusted by changing the height of the trip bar and stop bolt, see Fig. 10. Raising the bolt decreases bale length and lowering the bolt increases bale length.




Fig. 10

### Cleaning Material From Bale Chamber

For ease of cleaning baled material from the chamber, follow the steps below:

1. Turn the ball valve to the "CLOSED" position, see Fig. 11.
2. Operate the baler for the length of time it takes to produce one soft, light bale that is easy to remove from the bale chamber.
3. Clean out the bale chamber.
4. After cleaning bale chamber, turn the ball valve to the "OPEN" position, see Fig. 11. NOTE: Failure to do so will result in lack of tension pressure.





Fig. 11

## Knot Sensor Operation


The knot sensor alerts the operator of a mistie on any of the six knotters.

While the knotter is cycling, the twine finger sets the knot sensors and the knot sensor indicators will light. After a knotter has completed its tying cycle, the bale advances two or three plunger strokes and a properly tied knot will pull the sensor finger and the indicator located in front of the baler, see *Fig. 12*, will go off.



*Fig. 12*

In the event of a mistie, the appropriate indicator will remain lit. To turn off the indicator, manually pull the knot sensor finger rearward, see *Fig. 13*.



*Fig. 13*

**NOTE:** The knot sensor finger must be manually pulled rearward if a knot has been mistied and/or new twine is being installed or rethreaded through the system or if starting with an empty bale chamber.


# ADJUSTMENTS AND MAINTENANCE

## Knotter Timing Adjustment


NOTE: Knotters are viewed from the left side to the right side of the baler.

### Timing Knotters

1. Use the manual control to advance the knotter until the head of the needle yoke drive rod bolt is centered on the rear edge of the shaft support bracket, see *Fig. 14*.
2. Loosen and disconnect the knotter shaft drive chain.
3. Use a prybar to advance the knotter in order to align the timing pointer located on the sprocket with the timing mark as illustrated in *Fig. 15*.
4. Reinstall the knotter shaft drive chain located on the left side of the baler so that after properly tensioned the timing mark will be within the flat on the end of the timing pointer, see *Fig. 15*.
5. Use the manual control to return needles to home position.



*Fig. 14*




*Fig. 15*

### Twine Needle Adjustment

1. Clear the bale chamber of all baling material. Use the manual control to jog the needles up through the bale


chamber until the needle eye is next to the knotter frame, see *Fig. 16*. NOTE: Check to see that the base of needles are centered with the bottom chamber needle slots. Adjustment is done by sliding the needle brackets on the needle anchors on the needle yoke.

2. With the needle eye next to the knotter frame, the needles should be adjusted left or right so that there is 0 to  $\frac{1}{32}$  inch clearance between the knotter frame and the side of the needle. To adjust the needles can be moved left or right  $\frac{1}{16}$  inch by moving the needle at the needle yoke anchors. DO NOT MOVE THE BASE OF THE NEEDLE MORE THAN  $\frac{1}{16}$  INCH IN EITHER DIRECTION FROM THE BOTTOM NEEDLE SLOT CENTER. If additional adjustment is needed, retract the needles far enough so that they clear the inside of the top needle slots of the bale chamber and pry them left or right with a long leverage bar.




*Fig. 16*

3. With the needle eye directly over the twine disc, the needles should clear the twine disc by  $\frac{1}{8}$  inch, see *Fig. 17*.




*Fig. 17*

To increase the distance between the needle and the twine disc, loosen the front and tighten the rear needle anchor bolts on the needle yoke, see *Fig. 18*. To decrease the clearance, reverse the procedure.



*Fig. 18*


4. Use the manual control to advance the needles to the uppermost position. The distance from the bottom of the needle eye to the twine disc should be  $4\frac{1}{2}$  inches, see *Fig. 19*.



*Fig. 19*

5. Adjust the needle height by loosening the lock nuts on the needle yoke drive rods, see *Fig. 20*. Turn the rods to the right or left for the desired setting. Be sure both are adjusted for equal load at top dead center.

6. Check the twine finger adjustment after adjusting needles.




*Fig. 20*

### Twine Finger Adjustment

The twine finger guides the twine into the twine holder and bill hook.

1. Use the manual control to advance the knotter until the point of the twine finger is just passing the inside edge of the needle. The point of the twine finger should clear the needle  $\frac{3}{16}$  inch, see *Fig. 21*.



*Fig. 21*

This adjustment is made by loosening the twine finger anchor bolt "A" and knot sensor finger pivot bolt "B" and sliding them to the front or back of the slotted holes in the bale chamber top, see *Fig. 22*.

2. Use the manual control to advance the knotter until the twine fingers reach the most rearward point of travel.




Fig. 22

Measure the distance from the tip of the twine fingers back to the chamber brace behind the knotter, see Fig. 22. This measurement should be 6 1/4 inches. Adjustment is made by lengthening or shortening the twine finger drive rods, see "C", Fig. 22.

3. After adjusting the twine fingers, use the manual control to advance the knotter until the twine fingers are in their rest position. Check to see that there is a minimum distance of 1/16 inch from the tips of the twine fingers to the edge of the needle slots, see Fig. 23. Before measuring, push twine finger toward needle slot and make certain to consider any slack in the system.




Fig. 23

4. Adjust the position of the twine fingers at the needle slots with the return stop bolts on each twine finger drive shaft, see Fig. 24. Remember to adjust both sides.




Fig. 24

### Twine Holder Adjustment

The twine holder holds the twine in the twine disc while the bale is being made and tied. The pressure is regulated by bolt "A", see Fig. 25.




Fig. 25

1. Adjust the twine holder tightly to prevent the twine from pulling from the disc or from producing bow knots. Make adjustments on bolt "A" in 1/8 of full turn increments. Proper adjustment is achieved when the knotter is producing a clean and smooth knot.

### Twine Disc

The twine disc receives twine from the needle and places it into the twine holder during the rotation of the knotter.

1. With the knotters in their home position, make certain that the slots in the twine disc cleaner are free of compacted dust and chaff.
2. Adjust the twine disc notch so the left-hand side of the notch is even with the cleaner "B", see Fig. 25. Do this by loosening nut "C" several turns. Tap the nut end of the shaft to loosen the worm.
3. After the disc is set, turn the worm against the spacer washers "D", see Fig. 25, and tighten the nut.
4. After the knotter has completed one cycle, check the notch setting again.




Fig. 26

### Knife Arm

The knife arm cuts the twine and strips it off the bill hook during the tying process.

1. The stripper flange on the knife arm should just touch the knotter bill hook with light pressure as the stripper flange pushes the knot past the end of the knotter bill hook, see Fig. 26. Adjustment is made by bending the knife arm.




Fig. 27

2. The knife arm should be  $\frac{1}{4}$  inch to  $\frac{3}{8}$  inch past the end of the knotter bill hook when the knife arm is in the most extreme position, see Fig. 27. Correct the adjustment of the knife arm by replacing it. NOTE: On knotters with a coiled twine holder spring measurements are  $\frac{3}{4}$  inch to  $\frac{7}{8}$  inch.

### Cam Gear Adjustment

The cam gears are used as timing mechanisms for the knotter tying process.

1. Both flat surfaces of the knotter bill hook and worm gear pinions must be held flat with 0 to .005 interference (when assembled with new parts) on the smooth face of the cam gears, see Fig. 28.




Fig. 28

This adjustment is made with shims between the cam gears and knotter frames. Shimming must be done between the cam gears and knotter frames any time a knotter is assembled.




Fig. 29

2. End play is removed by tightening the nut on the end of the knotter shaft, see Fig. 29. Adjustment should be distributed among all six knotters in the knotter assembly. Do not overtighten. Each knotter should be free enough to raise easily by hand yet not so free as to drop.

**CAUTION:** Failure to keep shaft assembly tight or failure to keep slack from developing between cam gears and pinion gear surfaces will result in knotter frame breakage.

### Twine Tensioner Adjustment

The twine tensioners put enough drag on the twine so that the twine fingers and knotters have a taut twine while working.

1. With the needle yoke in home position, adjust the twine tensioner operating linkage on the left-hand side of the bale chamber until the six operating levers on the twine tensioner drive shaft are parallel with the bale chamber.
2. Adjust the twine tensioners at "A", see *Fig. 30*. Place twine through the tensioners during adjustment, the twine itself serves as a gauge. The correct adjustment is when twine can be PUSHED through the tensioners while having a minimum amount of clearance between the tensioners. If tensioners are worn  $\frac{1}{32}$  inch or more, replace them.




Fig. 30

3. Use the manual control to advance the needle yoke away from home position to completely release the reset lever. For information on operation, see Manual Control, page 8.

**CAUTION:** When using the manual control, first clear the area of all personnel and check for safe operation before activating component.

4. Adjust the twine tensioner drive shaft stop, see *Fig. 31*, until the springs are compressed  $\frac{1}{2}$  inch from relaxed length. The relaxed length is when twine can be pushed through the twine tensioner.




Fig. 31

### Knotter Brake Adjustment

The knotter brake is used to hold the needle yoke and knotter in the rest position and is always applied. To adjust compress the springs on screws "A" AND "B" to  $1\frac{1}{4}$  inches length, see *Fig. 32*.




Fig. 32

### Plunger Adjustment


The plunger is adjustable both vertically and horizontally. It is important that the plunger is adjusted properly to avoid needle breakage and collision of the knives.

Adjustment is done by shimming the roller rails, plunger slide rails, and front plunger rollers.


When adjusting the plunger, follow the sequence below. Depending on the condition of your plunger, not all the steps may be necessary but it is recommended to check all steps to ensure proper plunger adjustment.




**CAUTION:** Avoid serious equipment damage of the knives colliding while adjusting the plunger by ensuring there is adequate clearance between stationary and plunger knives. Do this by removing or inserting shims under the bottom roller rails, see *Fig. 33A*.



*Fig. 33A*



*Fig. 33B*



*Fig. 33C*

**Step 1.** Adjusting plunger to the bale chamber and needle slot alignment:

A. The plunger needle slots need to be aligned with their mating slots on the top and bottom of the bale chamber in order to ensure the proper travel of the needles, see *Fig. 33B*.

If the needle slots in the plunger are orientated at an angle in the chamber, the plunger will have to be raised or lowered on one side or the other by removing or inserting shims under the bottom roller rails, see *Fig. 33A*.

If the bottom plunger needle slots are offset to the left while the top plunger slots are offset to the right, remove shim(s) from under the bottom left roller rail or insert shim(s) under the right plunger roller rail or both, see *Fig. 33C*. Do this until the needle slots in the plunger are aligned to the mating slots on the top and bottom of the bale chamber.

To further adjust plunger horizontally, remove or insert shims behind the plunger slide rails, see *Fig. 33A*. Shim the left side to move plunger to right and visa/versa. Shim the plunger slide rails firm against the side of the bale chamber. Be sure the plunger is not bound or restricted anywhere in its area of travel.

**CAUTION:** Changing the amount or location of shims on the plunger roller rails will have an effect on knife clearance. Make sure there is adequate clearance between the stationary and plunger knife to avoid collision of knives.

**Step 2.** Adjust plunger rollers:

The front plunger rollers are adjusted vertically by shimming, see *Fig. 33A*. Use the manual control to slowly cycle the plunger and observe roller activity to see if all four rollers are touching at one time or another the bottom plunger roller rails. If not, adjust the front rollers by shimming them up or down until all rollers are touching. Rear rollers (on the face end of the plunger) are not adjustable.

**CAUTION:** This can change knife clearance. Be certain there is adequate clearance between the stationary and plunger knives.

**Step 3.** Shim the top plunger roller rails, see *Fig. 33A*, to be approximately a  $\frac{1}{16}$  inch from the four plunger rollers. After adjusting top rollers rails, use the manual control to slowly cycle the plunger to ensure the rollers do not bind anywhere in their area of travel.

**Step 4.** After the plunger is adjusted, readjust the plunger knives as stated in Knife Adjustment.

## Knife Adjustment

The knives are used to shear the hay and should be kept sharp and in good condition for maximum performance. Dull, broken or missing knives will reduce capacity and cause a ragged appearance on the bottom of the bale. There are a total of nine knives on the baler, seven adjustable plunger knives and two stationary knives.

Clearance of plunger knives and stationary knives should be maintained at approximately  $\frac{1}{32}$  inch. Adjustment is made on the plunger knives only. To adjust plunger knives,

move the plunger with the manual control until the cutting edges of the knives are even or overlapping. Shim the knives, see *Fig. 34*. Clearance from knife segment to knife segment may vary, therefore individual adjustments may be required.




Fig. 34

\*\*\*\*\* **WARNING** \*\*\*\*\*

**Knife area is extremely hazardous. All care must be taken to prevent serious injury from occurring. Watch out for sharp knives.**

## Plunger Speed Adjustment

### Decelerated Plunger Return:

1. Disengage tractor P.T.O. and ensure Power Switch in "OFF" position.
2. Open the control box and disconnect white wire from TB3-7. This will cause the plunger to retract at approximately  $\frac{1}{4}$  its full speed.
3. Attach test string to LS-3 (Full Charge Switch) roller arm. Route the string so that the switch can be easily activated and released while standing on the ground.
4. Ensure Power Switch in "ON" position and Control Mode in "AUTO" position. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M.
5. Pull the test string and release when the feed fork stops and the plunger advances.
6. Use a stopwatch to accurately measure plunger return time of 2.4 to 2.8 seconds from plunger full extend to home position.

7. To adjust Auto Retract speed, loosen clamp screw of red wire slider on Plunger Retract resistor. Move slider on the resistor upward to decrease and downward to increase the plunger speed to achieve plunger return time of 2.4 to 2.8 seconds from plunger full extend to home position. When adjusting ensure approximately  $\frac{1}{8}$  inch clearance between green wire slider (Manual) and red wire slider (Auto).

8. Repeat Steps 5 and 6 until Step 7 is achieved.

9. Disengage tractor P.T.O. and ensure Power Switch in "OFF" position.

10. Go to the control box and reconnect white wire to TB3-7.

11. Remove test string.

### Decelerated Plunger Advance:

1. Disengage tractor P.T.O. and ensure Power Switch in "OFF" position.
2. Open the control box and disconnect the white wire in 5 conductor cable from TB3-9 and connect to TB2-1. (Leave other white wire in place.) This will cause the plunger to advance at approximately  $\frac{1}{4}$  its speed.
3. Attach test string to LS-3 (Full Charge Switch) roller arm. Route the string so that the switch can be easily activated and released while standing on the ground.
4. Ensure Power Switch in "ON" position and Control Mode in "AUTO" position. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M.
5. Pull the test string and release when the feed fork stops and the plunger advances.
6. Use a stopwatch to accurately measure plunger advance time of 2.4 to 2.8 seconds from plunger home to full extend position.
7. To adjust Auto Advance speed, loosen clamp screw of orange wire slider on Plunger Advance resistor. Move slider on the resistor upward to decrease and downward to increase the plunger speed to achieve plunger advance time of 2.4 to 2.8 seconds from plunger home to full extend position. When adjusting ensure approximately  $\frac{1}{8}$  inch clearance between yellow wire slider (Manual) and orange wire slider (Auto).
8. Repeat Steps 5 and 6 until Step 7 is achieved.
9. Disengage tractor P.T.O. and ensure Power Switch in "OFF" position.
10. Go to the control box and disconnect the white wire from TB2-1 and reconnect to TB3-9.
11. Remove test string.

## Limit Switch Adjustment

See Fig. 35 for a general outline of the limit switches.

NOTE: The assumption is made that the limit switch arms are set to the specified factory angle, see page 93 of 1987 Parts List. Plunger switches (5,4,6,8,9,10) are viewed from inside the baler looking out to the left, see Fig. 36.




Fig. 35




Fig. 36

### CAUTION:

For all switch functions:

1. Shut off the tractor before making any switch adjustments.

2. It will be necessary to operate the baler while observing the different functions of the machine to determine necessary adjustments.

3. Stay well clear of all moveable parts while observing the machine functions.

## LS-1 "Knotter Stop/Plunger Switch"

### Function:

LS-1 has 2 functions, (1) to stop the knotter when it is completing its cycle and (2) to ensure the plunger will not advance with the needle yoke away from its home position (bottom dead center).

### Adjustment objective:

LS-1 is to be activated when the needle yoke is in the home position.

### Adjustment:

NOTE: Adjustment of LS-1 should be made prior to actual baler operation. Ensure oil at air temperature.

1. Cut twines at knotters.
2. Remove twines completely from the needles.
3. Attach test strings around the switch roller arms of LS-11 (Knotter Trip Switch) and LS-3 (Full charge Switch). Route strings so that the switches can be easily activated and released while standing on the ground.
4. Engage tractor P.T.O. and run baler at less than 500 P.T.O. R.P.M.
5. Use the manual control to position needle yoke at bottom dead center (home position), see Fig. 37.




Fig. 37

6. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

7. Loosen and tighten appropriate clamp bolts "A" and "B" in order to rotate cam as necessary to center it on the switch arm roller, see Fig. 38.




Fig. 38

8. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M. in automatic mode.

9. Pull string from LS-11 (Knotter Trip Switch) and hold.

10. Pull string from LS-3 (Full Charge Switch) and release after plunger starts to advance.

11. Release LS-11 (Knotter Trip Switch) string when knotters start.

12. Plunger and knotters will cycle and return to rest position.

13. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

14. Check needle yoke stopping position. The cam should stop with the switch arm roller near the center or slightly beyond the center of the cam as illustrated in Fig. 38 (Cool and hot oil location).

15. If not, mark the location of the switch roller arm on the switch shaft to indicate the original position.

16. Adjust the needle yoke stopping position by lowering or raising the switch roller arm to either stop the needle yoke earlier or later respectively. NOTE: The switch arm roller should not be moved more than  $\frac{1}{16}$  inch for each trial.

17. Repeat Steps 8-16 omitting Step 15 until the cam is in required location, see Fig. 38.

18. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M. in automatic mode until oil reaches at least 140 degrees Fahrenheit (60 degrees Celsius).

19. Once the oil has reached at least 140 degrees Fahrenheit (60 degrees Celsius), run the baler at 500 P.T.O. R.P.M.

20. Repeat Steps 9-13.

21. Ensure needle tips are completely withdrawn from the chamber bottom. If not, repeat Step 16 to stop the needle yoke later.

22. Repeat Steps 9-13 and Step 21 at 500 P.T.O. R.P.M. until adjustment is achieved.

23. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

24. Remove test strings.

25. Rethread see Steps 5 and 6 of Twine Installation and Threading, page 7.

26. Engage tractor P.T.O. and run baler at less than 500 P.T.O. R.P.M.

27. Use the manual control to cycle the knotter forward to load twine into knotters and return knotters to home position.

## LS-2 "Plunger Delay/Feed Fork Switch"

### Function:

LS-2 delays plunger advance until the feed fork travels to its highest position and stops.

### Adjustment objective:

LS-2 is to have the feed fork stop at its highest point of travel in the bale chamber after LS-3 (Full Charge Switch) has been activated. The switch roller arm must be on the high part of the cam.




Fig. 39

#### Adjustment:

NOTE: Adjustment to be made with oil hot (170 degrees Fahrenheit, 77 degrees Celsius or greater).

1. Attach test string to LS-3 (Full Charge Switch) roller arm and route string so that switch cam can be easily activated and released while standing on the ground.
2. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M. in automatic mode.
3. Pull test string and release when the feed fork stops and the plunger advances.
4. Turn power "OFF" at Control panel.
5. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for movement in baler to cease.
6. Check stopping position of switch arm roller on cam. It should be on the high part of cam, see Fig. 39.
7. If not on high part of cam, mark the location of the switch roller arm on the switch shaft to indicate the original position.
8. If feed fork stops with switch arm roller on forward slope of cam, raise the switch roller arm. If feed fork stops with switch arm roller on rearward slope of cam, lower the switch roller arm.

9. Turn power "ON" at Control panel.

10. Repeat Steps 2 through 5 and Step 8 until the switch arm roller is on the high part of the cam, see Fig. 39.

11. Again turn power "ON" at Control panel and repeat Steps 2 through 5.

12. Measure from rear side of feed fork crankshaft to front side of feed fork tine mounting tube, see Fig. 40. When the feed fork is at its highest point of travel in the chamber, the measurement should be 12½ to 13 inches when switch arm roller is on the high part of the cam.

13. Mark original cam location on feed fork driven sprocket.

14. The feed fork is stopping early if the measurement is more than 12½ to 13 inches. Rotate the cam rearward.

15. The feed fork is stopping late if the measurement is less than 12½ to 13 inches. Rotate the cam forward.




Fig. 40

16. Repeat Steps 2 through 5 until required measurement is achieved.

17. Remove test string from LS-3 (Full Charge Switch).

#### LS-3 "Full Charge Switch"

##### Function:

LS-3 signals the control circuit that the feed chamber has been filled by feed fork, thus causing the plunger to advance when the feed fork has stopped at its highest point of travel in the bale chamber.

**Adjustment objective:**

After raising the feed sensor paddles to operate the switch, LS-3 (Full Charge Switch) should release and come within 1/2 inch of the rubber bumper when lowering the feed sensor paddles.

**Adjustment:**

1. Adjust the cam with the feed sensor paddles down, see Fig. 41.
2. Loosen clamp bolt "A" and rotate cam forward until the switch clicks to operate.
3. Rotate the cam rearward until switch clicks to release.
4. Tighten clamp bolt "A".




Fig. 41

**LS-4 "Plunger Advance Decelerate Switch"**

**Function:**

LS-4 decelerates the plunger to 1/4 of full speed just prior to the end of its extend stroke and ensures the knottor automatic control circuit is activated only with the plunger near its full extension.

**Adjustment objective:**

LS-4 is to ensure the plunger decelerates prior to activating LS-5 (Plunger Return Switch).

**Adjustment:**

1. Ensure LS-5 (Plunger Return Switch) is properly adjusted.
2. Loosen mounting bolt and slide switch and mount as close to LS-5 (Plunger Return Switch) as possible, see Fig. 42.




Fig. 42

**LS-5 "Plunger Return Switch"**

**Function:**

LS-5 signals the plunger to return at the end of its 30 inch extend stroke.

**Adjustment objective:**

LS-5 is to stop and reverse the plunger 1 inch prior to reaching its fully extended position.

**Adjustment:**

**CAUTION:** It will be necessary to have the two large doors on the baler open to observe the plunger operation. At all times keep a safe distance.

1. Ensure proper plunger speed adjustment, see page 18.
2. Engage tractor P.T.O. and run baler at 500 P.T.O. R.P.M.
3. Use the manual control to advance the plunger until it is fully extended.
4. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

5. Mark the location of the plunger fully extended. Also mark 1 inch forward of this position, see *Fig. 43*.

6. Engage the tractor P.T.O. and use the manual control to return the plunger to its home position.

7. Disengage tractor P.T.O. and go to the control box and remove the white wire in 5 conductor cable from TB3-9 and connect to TB2-1. This will cause the plunger to advance at approximately  $\frac{1}{4}$  of its full speed.

8. Attach the test string to LS-3 (Full Charge Switch) roller arm. Route the string so that the switch can be easily activated and released while standing on the ground.

9. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M. in automatic mode.

10. Pull LS-3 (Full Charge Switch) string and release when feed fork stops and plunger advances.

11. Observe the position at which the plunger stops advancing.


12. Reduce baler speed to 500 P.T.O. R.P.M.

13. Use the manual control to advance the plunger to full extension and to rotate the feed fork out of the way. This step will make limit switch adjustment easier.

14. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

15. Loosen the mounting bolt and slide the switch and mount forward or rearward. Position the switch to ensure the plunger returns when it is 1 inch forward from its fully extended position.

16. Repeat Steps 9 through 14 as necessary until Step 15 is achieved.



*Fig. 43*

17. Remove test string and disconnect the white wire from TB2-1 and reconnect to TB3-9.

18. Adjust LS-4 (Plunger Advance Decelerate Switch), see page 22, after LS-5 (Plunger Return Switch) is properly adjusted.


### LS-6 "Plunger Return Delay Switch"

#### *Function:*

When baling (not during a tying cycle) the plunger retracts at its decelerated speed until it reaches LS-6 (Plunger Return Delay Switch), at which point the plunger accelerates to full speed retract. During a tying cycle, the knotter is delayed until the plunger retracts, activates LS-6 (Plunger Return Delay Switch) and stops.

#### *Adjustment Objective:*

The plunger should retract approximately 9 inches, before LS-6 (Plunger Return Delay Switch) is activated to stop the plunger. The plunger has retracted approximately 9 inches when the pin is centered on the rearward edge of the feed fork link block, see *Fig. 44*.



*Fig. 44*

#### *Adjustment:*

**CAUTION:** It will be necessary to have the two large doors on the baler open to observe the plunger operation. At all times stay at a safe distance.

**NOTE:** Adjust LS-6 (Plunger Return Delay Switch) together with LS-8 (Feed Fork Delay/Plunger Switch). For Function and Adjustment Objective of LS-8 (Feed Fork Delay/Plunger Switch) see page 25.

1. Cut twine at all six knotters.

2. Pull twine down through bale chamber and completely remove from needles.

3. Attach test strings to LS-3 (Full Charge Switch) and LS-11 (Knotter Trip Switch) roller arms. Route string so that switch can be easily activated and released while standing on the ground.

4. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M. in the automatic mode.

5. Pull test string from LS-11 (Knotter Trip Switch) and hold.

6. Pull test string from LS-3 (Full Charge Switch) and release when feed fork stops and plunger starts to advance.

7. Release test string from LS-11 (Knotter Trip Switch) as soon as the knotter starts to move.

8. Quickly turn power "OFF" at Control panel before knotter has completed the first half of its cycle.

9. Observe plunger stopping position and make sure feed fork has not yet started and is still at its highest point of travel in the bale chamber.

10. Reduce baler speed to 500 P.T.O. R.P.M.

11. Turn power "ON" at Control panel.

12. The knotter will start and continue through its cycle. Halfway through its cycle, the plunger will start to complete its retract stroke. After approximately 3 inches of plunger forward movement (retracting), the feed fork will start to operate.

13. Use the manual control to advance the plunger to its full extension and to rotate the feed fork out of the way. This will make limit switch adjustment easier.

14. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

15. Slide LS-6 (Plunger Return Delay Switch) forward or rearward as necessary to cause the stopping position observed in Step 9 to be approximately 9 inches from the fully extended position as illustrated.

16. Slide LS-8 (Feed Fork Delay/Plunger Switch) so that the center of the switch shaft is 3 inches forward of the center of the switch shaft on LS-6 (Plunger Return Delay Switch), see Fig. 45.

17. Repeat Steps 4 through 16 as necessary until the plunger stops when it is 9 inches from its fully extended position, see Fig. 44.

18. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.




Fig. 45

19. Remove test strings.

20. Rethread twine, see Steps 5 and 6 of Twine Installation and Threading, page 7.

21. Engage tractor P.T.O. and run baler at less than 500 P.T.O. R.P.M.

22. Use the manual control to cycle the knotter forward to load twine into knotters and return knotters to home position.




Fig. 46

### LS-7 "Knotter Reverse Safety Switch"

#### Function:

LS-7 prevents the knotter from rotating in reverse at those points at which the bill hook would rotate. This prevents possible damage to the knotter due to reverse bill hook rotation.



*Adjustment objective:*

LS-7 is to prevent any reverse rotation of knotter when it has rotated forward to the point where the bill hook has begun to turn.

*Adjustment:*

1. To increase the duration of the non-reversing portion of the knotter cycle, lower the switch roller arm. To decrease this duration, raise the switch roller arm, see Fig. 46.

### **LS-8 "Feed Fork Delay Plunger Switch"**

*Function:*

LS-8 allows the feed fork to start before the plunger has completely retracted to its home position. It also keeps the feed fork stopped to ensure no compaction of hay in the infeed chute while the plunger is stopped during the first half of the tying cycle.

*Adjustment objective:*

Allow the feed fork to operate during approximately the last half of the plunger retract stroke.

*Adjustment:*

1. LS-6 (Plunger Return Delay Switch) must be properly adjusted, see page 23.
2. Loosen the mounting bolt and slide LS-8 (Feed Fork Delay/Plunger Switch) forward or rearward so that the center of the switch shaft is 3 inches forward of the center of the switch shaft on LS-6 (Plunger Return Delay Switch), see Fig. 45.

### **LS-9 "Plunger Return Decelerate Switch"**

*Function:*

LS-9 decelerates the plunger to  $\frac{1}{4}$  of its full speed just prior to stopping on its retract stroke to prevent the plunger from overrunning LS-10 (Plunger Return/Stop Switch).

*Adjustment objective:*

While the baler is running at full speed, LS-9 is to cause the plunger to stop at LS-10 (Plunger Return/Stop Switch).

*Adjustment:*

Ensure LS-10 (Plunger Return/Stop Switch) is properly adjusted.

2. Loosen the mounting bolt and slide the mount and

switch forward as close to LS-10 (Plunger Return/Stop Switch) as possible.

3. Attach the test string to LS-3 (Full Charge Switch) roller arm. Route the string so that switch can be easily activated and released while standing on the ground.

4. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M. in automatic mode.

5. Pull test string and release when the feed fork stops and plunger advances.

6. Observe plunger stopping position.

7. Reduce baler speed to 500 P.T.O. R.P.M.

8. Use the manual control to advance the plunger to full extend and to rotate the feed fork out of the way. This step will make limit switch adjustment easier.

9. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

10. If the plunger stops forward of the LS-10 (Plunger Return/Stop Switch) stopping position, slide LS-9 (Plunger Return Decelerate Switch) rearward  $\frac{1}{2}$  inch.

11. Repeat steps 4 through 10 until the plunger stops at the stopping position of LS-10 (Plunger Return/Stop Switch).

12. At this point a smooth deceleration from full speed retract to a complete stop should be observed. There should be no noticeable slow speed retract between LS-9 (Plunger Return Decelerate Switch) and LS-10 (Plunger Return/Stop Switch).

13. Remove test string.

### **LS-10 "Plunger Return/Stop Switch"**

*Function:*

LS-10 stops the plunger at the end of its 30 inch stroke (home position).

*Adjustment objective:*

To stop the plunger 1 inch prior to reaching its fully retracted position.

*Adjustment:*

CAUTION: It will be necessary to have the two large doors on the baler open to observe the plunger operation. At all times stay at a safe distance.

1. Ensure proper plunger speed adjustment, see page 18.

2. Attach test string to LS-3 (Full Charge Switch) arm roller. Route the string so that the switch can be easily activated and released while standing on the ground.




Fig. 47

3. Engage tractor P.T.O. and run baler at 500 P.T.O. R.P.M. in manual mode.
4. Use the manual control to retract the plunger until it reaches its full retract position.
5. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement to cease.
6. Mark the location the plunger reached fully retracted. Also mark 1 inch rearward of this position, see Fig. 47.
7. Go to the control box and remove the white wire from TB3-7. This will cause the plunger to retract at its decelerated speed ( $\frac{1}{4}$  of its full speed).
8. Engage tractor P.T.O. and run baler at 1,000 P.T.O. R.P.M. in automatic mode.
9. Pull test string on LS-3 (Full Charge Switch) and release when the feed fork stops and plunger advances.
10. Observe plunger stopping position.
11. Reduce baler speed to 500 P.T.O. R.P.M.
12. Use the manual control to advance the plunger to full extend and to rotate the feed fork out of the way. This step will make limit switch adjustment easier.
13. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement to cease.
14. Position LS-10 (Plunger Return/Stop Switch) to ensure the plunger stops when it is 1 inch rearward from its full retract position, see Fig. 47.
15. Loosen the mounting bolt and slide the switch and mount forward or rearward as necessary.

16. Repeat Steps 7 through 13 until Step 13 is achieved.
17. Remove test string.
18. Reconnect white wire onto TB3-7.
19. After LS-10 (Plunger Return/Stop Switch) is properly adjusted, adjust LS-9 (Plunger Return Decelerate Switch), see page 25.

### LS-11 "Knotter Trip Switch"

#### Function:

LS-11 completes the knotter trip circuit to allow the knotter to cycle when the plunger has reached LS-6 (Plunger Return Delay Switch) on its retract stroke.

#### Adjustment objective:

LS-11 is to ensure the knotter trip switch is activated by the meter bar within the last  $\frac{1}{2}$  inch of its upward travel.

#### Adjustment:

1. Push forward on the rear of the meter bar. This will disengage knurled teeth on meter bar from the knurled teeth on friction disc.
2. Raise the meter bar until cam contacts switch arm roller and the switch clicks to operate, see Fig. 48.
3. Release rear of the meter bar allowing knurled teeth to engage.
4. Measure from top of roll pin, "A" to bottom of guide washer, "B".




Fig. 48

5. If measurement is less than  $\frac{1}{4}$  inch, lower the switch roller arm as necessary. If more than  $\frac{1}{2}$  inch, raise the switch roller arm.
6. Return the meter bar to its rest position.

## LS-12 "Plunger Early Start/Knotter Switch"

### Function:

LS-12 has two functions (1) to cause the plunger to complete its retract stroke after the knotter has completed the first half of its cycle and (2) to operate the bale counter.

### Adjustment objective:

LS-12 is to be activated by its cam at approximately the mid-point of the knotter cycle.

NOTE: If the baler is in automatic mode, when the switch operates the bale counter will count.

### Adjustment:

1. Cut twine at all six knotters.
2. Pull twine down through bale chamber and completely remove from needles.
3. Attach test strings to LS-3 (Full Charge Switch) and LS-11 (Knotter Trip Switch) roller arms. Route strings so that the limit switches can be easily activated and released while standing on the ground.
4. Engage tractor P.T.O. and run baler at 500 P.T.O. R.P.M. in the automatic mode.
5. Pull test string from LS-11 (Knotter Trip Switch) and hold.
6. Pull test string from LS-3 (Full Charge Switch) and release when feed fork stops and plunger starts to advance.
7. Release test string from LS-11 (Knotter Trip Switch) as soon as the knotter starts to move.
8. When the knotter is halfway through its cycle, LS-12 (Plunger Early Start/Knotter Switch) should be activated by its cam and the plunger should complete its retract stroke.
9. If the plunger did not retract at the mid-point of the knotter cycle, use the manual control to retract the plunger.
10. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.
11. Rotate the switch roller arm of LS-12 (Plunger Early Start/Knotter Switch) toward the rear of the machine  $\frac{1}{4}$  inch.
12. Repeat Steps 4 through 11 to ensure the plunger returns to its home position.

13. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

14. Remove test strings.

15. Rethread twine, see Steps 5 and 6 in Twine Installation and Threading, page 7.

16. Engage tractor P.T.O. and run baler at less than 500 P.T.O. R.P.M.

17. Use the manual control to cycle the Knotter forward to load twine into knotters and return knotters to home position.

## Proper Operating Pressures

### Main System Extend Pressure:

1. Engage the tractor P.T.O. and run the baler at 700 P.T.O. R.P.M.
2. Set the control mode switch to manual.
3. Insert the remote cable plug into the Plunger advance socket.
4. Depress the remote cable button to extend the plunger through its full stroke.
5. Continue depressing the remote cable button until the plunger stalls.
6. Read the main system pressure on the right side of the front gauge panel of the baler as illustrated. It should read approximately 5,300 p.s.i.




Fig. 49

### Tension Pressure:

1. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.
2. Remove the 1/4 inch JIC cap on gauge port "A", see Fig. 50.
3. Connect a 5,000 p.s.i. hand-held gauge onto the tension gauge port "A".




Fig. 50

4. Engage tractor P.T.O. and run the baler at 500 P.T.O. R.P.M.
5. Ensure the Power Switch is in the "OFF" position.
6. Ensure the Ball Valve is in the "OPEN" position.
7. Read the pressure on the 5,000 p.s.i. hand-held gauge. It should read 2,150 p.s.i.

NOTE: Tension pressure cannot be adjusted.

### Main System Retract Pressure:

1. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.
2. Remove the 1/4 inch JIC cap on gauge port "A", see Fig. 51.
3. Connect a 5,000 p.s.i. hand-held gauge onto the retract gauge port "A".
4. Set the control mode switch to manual.

5. Insert the remote cable plug into the Plunger retract socket.

6. Depress the remote control button until the plunger stalls.

7. Read the pressure on the 5,000 p.s.i. hand-held gauge. It should read 2,500 p.s.i.




Fig. 51




Fig. 52

### Charge Pressure:

1. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

2. Remove the 1/4 inch JIC cap on gauge port "A", see Fig. 52.

3. Connect a 600 p.s.i. hand-held gauge onto port "A".
4. Engage the tractor P.T.O. and run the baler at 700 P.T.O. R.P.M.
5. Read the pressure on the 600 p.s.i. hand-held gauge. It should read 300 p.s.i.
6. Set the control mode switch to manual.
7. Insert the remote cable plug into the Plunger retract socket.
8. Depress the remote cable button and read the pressure on the 600 p.s.i. hand-held gauge. It should read a minimum of 250 p.s.i.

#### Feeder Pressure:

1. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.
2. Remove the 1/4 inch JIC cap from gauge port "A", see Fig. 53.
3. Connect a 5,000 p.s.i. hand-held gauge onto port "A".
4. Use a 3/8 chain and connect it to the feeder crank shaft to prevent the shaft from moving forward.
5. Pull the stop/reverse control rope half-way to prevent the pickup and feeder from rotating and secure the stop/reverse control rope onto the rope anchor.
6. Engage the tractor P.T.O. and in manual mode run the baler at 700 P.T.O. R.P.M.
7. Release the stop/reverse control rope from the rope anchor and allow the rope to return to its relaxed position. NOTE: Feeder will attempt to move forward but will be stalled by the 3/8 chain.
8. Read the pressure on the 5,000 p.s.i. hand-held gauge. It should read 3,200 p.s.i.

**CAUTION:** REMAIN CLEAR OF BALER AT ALL TIMES AND ONLY START BALER AFTER CHAIN IS HOOKED UP.




Fig. 53

#### Knotter and Feed Fork Manifold Main System Pressure (Forward):

1. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.
2. Remove the 1/4 inch JIC cap from gauge port "A", see Fig. 54.
3. Connect a 5,000 p.s.i. hand-held gauge onto port "A".
4. Use a 3/8 chain and connect it to the feed fork to prevent the feed fork from rotating.
5. Set the control mode switch to manual.
6. Insert the remote cable plug into the Feed Fork forward socket.
7. Engage the tractor P.T.O. and run the baler at 700 P.T.O. R.P.M.
8. Depress the remote cable button and read the pressure on the 5,000 p.s.i. hand-held gauge. It should read 3,500 p.s.i.




Fig. 54

#### Feed Fork Pressure (Reverse):

1. Disengage tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.
2. Remove the 1/4 inch JIC cap from gauge port "A", see Fig. 54.
3. Connect a 5,000 p.s.i. hand-held gauge onto gauge port "A".
4. Use a 3/8 chain and connect it to the feed fork to prevent the feed fork from rotating.
5. Set the control mode switch to manual.

6. Insert the remote cable plug into the Feed Fork reverse socket.

7. Engage the tractor P.T.O. and run the baler at 700 P.T.O. R.P.M.

8. Slowly reverse the feed fork with the remote cable until the chain becomes taut. NOTE: The feeder will stall.

9. Depress the remote cable button and read the pressure on the the 5,000 p.s.i. hand-held gauge. It should read 2,000 p.s.i.




Fig. 55

#### Knotter Pressure (Reverse):

1. Engage the tractor P.T.O. and run the baler at or below 500 P.T.O. R.P.M.

2. Set the control mode switch to manual.

3. Insert the remote cable plug into the Knotter reverse socket.

4. Slowly reverse the knotter with the remote control cable until the needle yoke is at mid-stroke, see Fig. 55.

5. Disengage the tractor P.T.O. Shut off tractor and lock tractor brakes and/or transmission. Wait for all movement in baler to cease.

6. Remove the 1/4 inch JIC cap from gauge port "A", see Fig. 54.

7. Connect a 5,000 p.s.i. hand-held gauge onto gauge port "A".

8. Use a 3/8 chain and connect it to the needle yoke at mid-span, see Fig. 56, to prevent the knotter from moving in reverse.

9. Engage the tractor P.T.O. and run the baler at 700 P.T.O. R.P.M.

10. Slowly reverse the knotter with the remote cable until the chain is taut. NOTE: The knotter and needle yoke will stall.

11. Depress the remote cable button and read the pressure on the 5,000 p.s.i. hand-held gauge. It should read 2,000 p.s.i.

**CAUTION: REMAIN CLEAR OF BALER AT ALL TIMES AND ONLY START BALER AFTER CHAIN IS HOOKED UP.**

NOTE: If adjustments are needed, consult your authorized Freeman dealer.




Fig. 56

## Miscellaneous

### Slip Clutches

P.T.O. Shaft Slip clutch adjustment, see Fig. 57:

1. Completely loosen all nuts (8) so that the springs just make contact OR loosen all the way then re-tighten until they just make contact.

2. Tighten each of the eight nuts 7.4 complete turns for required setting.

NOTE: Inside the P.T.O. shaft slip clutch there is an over-running clutch. No adjustment is necessary but it is recommended that it be greased every four hours.




Fig. 57




Fig. 58

Pickup Slip clutch adjustment, see Fig. 58:

1. Tighten bolts to completely compress the springs.
2. Back nuts off one complete turn.

NOTE: Inside the Pickup slip clutch there is a reversible clutch. No adjustment is necessary but it is recommended that the two ball oilers be lightly oiled weekly.

### Oil Cooler




Fig. 59

Operating Temperature:

Baler should not be started lower than 20 degrees Fahrenheit (approx. -6 degrees Celsius). If it is necessary to operate the baler at these temperatures, consult the factory for oil recommendations. At oil temperatures of 20 to 32 degrees Fahrenheit

(-6 to 0 degrees Celsius), operate baler at 500 P.T.O. R.P.M. in automatic mode. Once oil temperature reaches 32 degrees Fahrenheit (0 degrees Celsius), run the baler at 1,000 P.T.O. R.P.M.

NOTE: Feeder and pickup will continue to run for they are independent of electrical control.

CAUTION: Do not attempt to run the baler with oil temperature above 225 degrees Fahrenheit (107 degrees Celsius).

Hot Oil Shutdown:

If the oil temperature reaches 225 degrees Fahrenheit (107 degrees Celsius), determine and correct the cause of overheating. Cooling may be expedited by continuing to run the fan (main switch "ON") and idling the tractor at or below 500 P.T.O. R.P.M. Ensure the pickup and feed systems are running freely.

Low Oil Shutdown:

If the oil level in the tank becomes too low, the baler will shut down and the red light located on the front of the baler will come on. Repair oil leak. Check the sight glass and fill the tank to its proper level.

### Proper Fan Operation

From 32 to 170 degrees Fahrenheit (0 to 77 degrees Celsius), the fan is not running. Once the oil has reached 170 degrees Fahrenheit (77 degrees Celsius) under normal baling conditions, the fan comes on.

1. The fan draws air through the heat exchanger (oil cooler element) for approximately 5½ minutes.
2. The fan shuts down for approximately 10 seconds to allow the motor to stop.
3. The fan runs backward to blow air for approximately 10 seconds to clear chaff and dust from oil cooler grill screens.
4. The fan shuts down once again for approximately another 10 seconds to allow the motor to stop.
5. Repeat the aforementioned procedure several times until oil temperature drops below 170 degrees Fahrenheit (77 degrees Celsius).

### Charge Sensor Adjustment

1. Check for proper limit switch adjustment for LS-3 (Full charge), see page 21.




Fig. 60

## 2. Spring Tension Adjustment:

- (1) Loosen set screw in locking collar, see Fig. 60.
- (2) Slide locking collar on Feed sensor guide rod forward to compress spring 1 inch when the sensor paddle is against the rubber bumper.

## Drive Belt Adjustment

NOTE: It is important to keep drive and driven belt sheave aligned.

1. Adjust to obtain a  $\frac{1}{4}$  inch deflection when a 15 to 19 pound force is applied at the center of the span length, see Fig. 61. Check each of the six main drive belts separately.





Fig. 61




## TAKE-UP PLATE

Fig. 62

2. If adjustment is needed, loosen clamp bolts "A" (front) and "B" (back) and pivot bolts "C" and "D", see Fig. 61 and Fig. 62.

3. NOTE: The rear end of the drive unit belt take-up may be slightly tipped downward in comparison to the front end. Tighten take-up bolt until the rear end of the drive unit belt take-up has moved down approx.  $\frac{1}{4}$  inch, see Fig. 63.

4. Tighten "B", see Fig. 62.



## TAKE-UP BOLT

Fig. 63



5. Keep tightening take-up bolt until the drive and driven sheaves are aligned.

6. Check belts as in Step 1. If too loose, repeat the aforementioned procedure.

7. Tighten clamp bolts "A" and "B" and pivot bolts "C" and "D", see *Fig. 61* and *Fig. 62*.

#### Alternator Belt

Adjust to obtain a  $\frac{3}{16}$  inch deflection when a 2 to 3 pound force is applied at the center of the span length, see *Fig. 61*.

#### Tension Pump Belt

Adjust to obtain a  $\frac{3}{16}$  inch deflection when a 3 to 4 pound force is applied at the center of the span length, see *Fig. 61*.


#### Sunstrand Pump Coupler

To properly grease the coupler, follow the steps below and see *Fig. 64*:

1. Disengage tractor P.T.O. and wait for all movement in baler to cease.
2. Remove plugs.
3. Insert one zerk.
4. Flush zerk with the \*specified grease until clean grease comes out of the opposite hole.
5. Remove zerk.
6. Insert plugs.

#### \*Grease Specifications:

1. N.L.G.I. rating #2 Lithium Base
2. Base oil viscosity 900 to 2,150 SUS at 100 degrees Fahrenheit (200 to 470 CsT at 40 degrees Celsius)
3. Minimum dropping point 374 degrees Fahrenheit (190 degrees Celsius)
4. Maximum thickener content 11%
5. Minimum timken rating 40 lbs. (approx. 18.18 kg.)
6. Recommended additives
  - A. Extreme pressure (E.P.)
  - B. Anti-oxidation
  - C. Anti-rust
7. Should have good resistance to centrifugal oil separation



*Fig. 64*

## **STORING THE BALER**

At the close of the season, remove all material from the bale chamber and thoroughly clean the complete baler. Any hay, chaff, or dust on the baler will collect moisture during the winter and cause unnecessary rusting.

Check the baler for any worn or damaged parts. Replace and order parts from the dealer as needed.

Coat the bale chamber lightly with grease to prevent rusting.

Check and lubricate all grease zerks and chains.

Provide adequate protection from the weather.

To increase tire life during storage, place the baler on blocks to remove the load from the wheels.

Disconnect the battery.

It is good practice to have the baler inspected at the end of the season and the complete machine put in top condition.

## TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	REMEDY
Pickup will not operate but Feeder does operate.	<ul style="list-style-type: none"> <li>a. Pins in overriding clutch stuck and/or broken springs.</li> <li>b. Worn slip clutch disc(s).</li> <li>c. Loose pickup slip clutch.</li> <li>d. Overfeeding.</li> <li>e. Foreign material in pickup.</li> <li>f. Mechanical failure.</li> </ul>	<ul style="list-style-type: none"> <li>a. Clean, inspect and lubricate. See Main Pickup section in parts book.</li> <li>b. Replace worn discs and adjust. See Slip Clutch Adjustment, page 30.</li> <li>c. Adjust pickup slip clutch. See Pickup Slip Clutch Adjustment, page 31.</li> <li>d. Reduce feed rate.</li> <li>e. Check for material in pickup. Remove if necessary.</li> <li>f. Inspect for loose, misadjusted, missing or broken parts.</li> </ul>
Pickup and Feeder stalled.	<ul style="list-style-type: none"> <li>a. Overfeeding.</li> <li>b. Foreign material lodged in feed area.</li> <li>c. Clogged stripper slots.</li> <li>d. Stalled feed fork.</li> <li>e. Feeder valve control mechanism broken.</li> <li>f. Mechanical failure.</li> <li>g. Oil temperature too high.</li> </ul>	<ul style="list-style-type: none"> <li>a. Reduce feed rate.</li> <li>b. Check for foreign material. Remove if necessary.</li> <li>c. Inspect and clean if necessary.</li> <li>d. Refer to stalled Feed Fork.</li> <li>e. Inspect for loose, misadjusted, missing or broken parts.</li> <li>f. Inspect for loose, misadjusted, missing or broken parts.</li> <li>g. Inspect for proper fan operation, see section on Oil Cooler, page 31.</li> </ul>
Feed fork stalled.	<ul style="list-style-type: none"> <li>a. Auto/Manual selector switch in "MANUAL" position.</li> <li>b. Main power switch in "OFF" position.</li> <li>c. Blown fuse.</li> <li>d. Low battery voltage.</li> <li>e. Overfeeding.</li> <li>f. Charge sensor not adjusted properly.</li> <li>g. Stalled Plunger.</li> <li>h. Loose drive belts.</li> <li>i. Mechanical failure.</li> <li>j. Oil temperature too high.</li> </ul>	<ul style="list-style-type: none"> <li>a. Move to "AUTO" position.</li> <li>b. Turn switch to "ON" position.</li> <li>c. Replace fuse and inspect wiring. Use only AGC 10 amp or 3AG 10 amp fuse.</li> <li>d. Correct cause. Example: drive belt, alternator, etc.</li> <li>e. Reduce feed rate. See Unplugging Feed System, page 9.</li> <li>f. See Charge Sensor section, page 31.</li> <li>g. See Stalled Plunger section in Trouble Shooting.</li> <li>h. See Drive Belt Adjustment section, page 32.</li> <li>i. Inspect for loose, misadjusted, missing or broken parts.</li> <li>j. Inspect for proper fan operation, see section on Oil Cooler, page 31.</li> </ul>
Stalled plunger – will not leave retracted position.	<ul style="list-style-type: none"> <li>a. Knotter out of home position.</li> <li>b. Stalled feed fork.</li> </ul>	<ul style="list-style-type: none"> <li>a. Return knotters to home position using the Manual Control. See Manual Control section, page 8. After knotters are returned in the home position, see Unplugging The Feed System, page 9.</li> <li>b. Refer to Stalled Feed Fork.</li> </ul>

PROBLEM	POSSIBLE CAUSE	REMEDY
Stalled plunger – will not leave retracted position – <i>(continued)</i> .	<ul style="list-style-type: none"> <li>c. Plunger Return/Stop switch out of adjustment.</li> <li>d. Oil temperature too high.</li> </ul>	<ul style="list-style-type: none"> <li>c. See Plunger Return/Stop Switch Adjustment section, page 25.</li> <li>d. Inspect for proper fan operation, page 31.</li> </ul>
Stalled plunger – will not retract.	<ul style="list-style-type: none"> <li>a. Charge sensor fails to return.</li> <li>b. Plunger return switch fails to operate.</li> <li>c. Stalled knotter.</li> <li>d. Knotter/Plunger early start switch out of adjustment.</li> <li>e. Loose main drive belts.</li> <li>f. Loose PTO clutch.</li> <li>g. Inspect fuse and replace as needed, use only AGC 10 amp or 3 AG 10 amp fuses.</li> </ul>	<ul style="list-style-type: none"> <li>a. Inspect for foreign material and/or misadjustment, see Charge Sensor Adjustment section, page 31.</li> <li>b. Inspect for foreign material and/or misadjustment, see Plunger Return Switch Adjustment, page 22.</li> <li>c. See Drive Belt Adjustment section, page 32.</li> <li>d. Inspect for foreign material and/or misadjustment, see Knotter/Plunger Early Start Switch Adjustment, page 27.</li> <li>e. See Drive Belt Adjustment section, page 32.</li> <li>f. See PTO Slip Clutch Adjustment section, page 30.</li> <li>g. Inspect and correct.</li> </ul>
Knots hanging on bill hook.	<ul style="list-style-type: none"> <li>a. Dull twine knife.</li> <li>b. Loose tension twine holder.</li> <li>c. Foreign material in twine holder.</li> <li>d. Worn twine disc.</li> <li>e. Twine too light or inferior grade of twine.</li> </ul>	<ul style="list-style-type: none"> <li>a. Sharpen twine knife.</li> <li>b. Tighten springs on twine holder.</li> <li>c. Clean twine holder.</li> <li>d. Replace twine disc and holder.</li> <li>e. Use heavier knot strength twine or better grade of twine.</li> </ul>
Knot on top twine only.	<ul style="list-style-type: none"> <li>a. Improper needle adjustment.</li> <li>b. Improper twine finger adjustment.</li> <li>c. Top hay dog not working.</li> <li>d. Hay dogs worn so they do not hold the hay properly.</li> <li>e. Not enough tension on the twine.</li> <li>f. Plunger Return Switch out of adjustment.</li> </ul>	<ul style="list-style-type: none"> <li>a. See twine needle adjustment, page 12.</li> <li>b. See twine finger adjustment, page 13.</li> <li>c. Replace hay dog spring if broken.</li> <li>d. Replace worn hay dogs.</li> <li>e. Adjust tension on the twine so that twine will not cast out (about 3 pounds pull).</li> <li>f. See Plunger Return Switch, page 22.</li> </ul>
Knot on bottom twine only.	<ul style="list-style-type: none"> <li>a. Uneven twine.</li> <li>b. Not enough tension on twine holder spring.</li> </ul>	<ul style="list-style-type: none"> <li>a. Use a good grade of twine.</li> <li>b. See twine holder, page 14.</li> </ul>
No knot on either end.	<ul style="list-style-type: none"> <li>a. Ends of knot too short and twine knot pulls out.</li> <li>b. Twine breaks between disc and bill hook.</li> </ul>	<ul style="list-style-type: none"> <li>a. Loosen twine holder.</li> <li>b. Twine holder too tight. See twine holder, page 14.</li> </ul>
Knotters fail to operate.	<ul style="list-style-type: none"> <li>a. Knotter trip mechanism malfunctioning.</li> <li>b. Plunger Return Delay Switch out of adjustment.</li> <li>c. Mechanical failure.</li> </ul>	<ul style="list-style-type: none"> <li>a. Inspect for missing or maladjusted parts. Replace and adjust parts as needed.</li> <li>b. See Plunger Return Delay Switch adjustment, page 23.</li> <li>c. Inspect for loose, misadjusted, missing or broken parts.</li> </ul>

PROBLEM	POSSIBLE CAUSE	REMEDY
Knotter fails to stop operating.	<ul style="list-style-type: none"> <li>a. Knotter Stop Switch out of adjustment.</li> <li>b. Knotter Meter Bar fails to reset.</li> </ul>	<ul style="list-style-type: none"> <li>a. See Knotter Stop Switch Adjustment section, page 19.</li> <li>b. Inspect for proper operation of meter bar.</li> </ul>
Improper bale shape.	<ul style="list-style-type: none"> <li>a. Windrow too narrow.</li> <li>b. Feeding to one side of the pickup.</li> <li>c. Overfeeding.</li> </ul>	<ul style="list-style-type: none"> <li>a. Widen windrow to approximately 48 inches by widening out swather shields or raking two windrows together.</li> <li>b. Feed material to center of pickup.</li> <li>c. Reduce feed rate.</li> </ul>
Insufficient bale density.	<ul style="list-style-type: none"> <li>a. Ball valve is in the closed position.</li> <li>b. Loose or missing tension control drive belt.</li> <li>c. Baler running too low R.P.M.</li> <li>d. Plunger pressure too low.</li> <li>e. Overfeeding.</li> <li>f. Windrow too narrow.</li> <li>g. Plunger pressure too low.</li> <li>h. Overfeeding.</li> <li>i. Windrow too narrow.</li> <li>j. Inoperative, regenerative tension unloader valve.</li> </ul>	<ul style="list-style-type: none"> <li>a. Turn ball valve, <i>Fig. 11</i>, page 10, to "OPEN" position.</li> <li>b. Inspect drive belt, replace if necessary and adjust, see tension control drive belt adjustment, page 33.</li> <li>c. Increase baler R.P.M. to PTO speed.</li> <li>d. Adjust tension unloader valve <i>Fig. 9</i>, page 10, in 1 turn increments until desired bale density is achieved. See Bale Density Adjustment, page 10.</li> <li>e. Reduce feed rate.</li> <li>f. Widen windrow to approximately 48 inches by widening out swather shields or raking two windrows together.</li> <li>g. Check for loose PTO Clutch, see page 30. Bale Density Adjustment, see page 10.</li> <li>h. Reduce feed rate.</li> <li>i. Widen windrow to approximately 48 inches by widening out swather shields or raking two windrows together.</li> <li>j. Repair or replace tension unloader valve.</li> </ul>

# INDEX

## ADJUSTMENTS AND MAINTENANCE

Alternator .....	33
Cam Gear .....	15
Charge Sensor .....	31
Drive Belt .....	32
Feed Fork Delay Plunger Switch (LS-8) .....	25
Full Charge Switch (LS-3) .....	21
Knife Arm .....	15
Knotter Brake .....	16
Knotter Reverse Safety Switch (LS-7) .....	24
Knotter Stop/Plunger Switch (LS-1) .....	19
Knotter Trip Switch (LS-11) .....	26
Oil Cooler .....	31
Pickup Slip Clutch .....	31
Plunger Advance Decelerate Switch (LS-4) .....	22
Plunger Delay/Feed Fork Switch (LS-2) .....	20
Plunger Early Start/Knotter Switch (LS-12) .....	27
Plunger Needle Slots .....	17
Plunger Knives .....	17
Plunger Return Switch (LS-5) .....	22
Plunger Return Decelerate Switch (LS-9) .....	25
Plunger Return Delay Switch (LS-6) .....	23
Plunger Return/Stop Switch (LS-10) .....	25
Plunger Rollers .....	17
Plunger Roller Rails .....	17
Plunger Slide Rails .....	17
Plunger Speed .....	18
Proper Fan Operation .....	31
PTO Shaft Slip Clutch .....	30
Sunstrand Pump Coupler .....	33
Tension Pump Belt .....	33
Timing Knotters .....	12
Twine Disc .....	14
Twine Finger .....	13
Twine Holder .....	14
Twine Needle .....	12
Twine Tensioner .....	16

## GENERAL INFORMATION ..... iii

## GENERAL OVERVIEW ..... 5

### OPERATION

Bale Density .....	10
Bale Length .....	10
Baler Operating Speeds .....	8
Cleaning Material from Bale Chamber .....	10
Field Start-up Procedure .....	8
Knot Sensor .....	11
Manual Control .....	8
Stop/Reverse Control Rope .....	9
Tension Control Adjustment .....	9
Unplugging the Feed System .....	9

## PERIODIC MAINTENANCE & LUBRICATION ..... 2

### PREPARATION

Attaching Baler to Tractor .....	6
Attaching New Baler .....	6
Twine Installation & Threading .....	7

### PROPER OPERATING PRESSURES

Charge Pressure .....	28
Feeder Pressure .....	29
Feed Fork Pressure (Reverse) .....	29
Knotter Pressure (Reverse) .....	30
Main System Extend Pressure .....	27
Main System Retract Pressure .....	28
Manifold Main System Pressure Forward .....	29
Tension Pressure .....	28

## SAFETY ..... iv

## SPECIFICATIONS ..... 1

## STORAGE ..... 34

## TABLE OF CONTENTS ..... v

## TO OUR CUSTOMER ..... ii

## TROUBLE SHOOTING ..... 35-37

## WALK AROUND PHOTOS ..... 3-4

## WARRANTY ..... i