

RANGER

F66 / F67 MAINTENANCE INSTRUCTION MANUAL

PUBLICATION R6410

DISTRIBUTOR	PHONE NO
ADDRESS	
DLR/BRCH	
ADDRESS	PHONE NO
SERVICE PHONE NO	
SPARE PARTS PHONE NO	
MACHINE:	
SERIAL NO	
ENGINE TYPE/NO	
HYDRAULIC TRANSM. TYPE/NO	
STARTING KEY NO	
CAB KEY NO	

FOREWORD

The purpose of this manual is to serve as a guide to the proper inspection and maintenance of your machine. Study this manual carefully before performing any preventive maintenance procedures. Become familiar with the instructions and keep this manual in the machine for handy reference. The Maintenance Inspections are divided into two sections: Basic Checks Supplemental Checks. The Basic Checks give an indication of the general condition of the machine, and should be carried out at regular intervals according to the Maintenance Interval chart at the front of the maintenance section. The Supplemental Checks should be combined with the Basic Checks to keep the machine maintained in accordance with its operating conditions. This manual describes how the various points in the maintenance inspections should be carried out, giving procedures, adjustment values, and wear tolerances. The headings and service points are listed in the same order as they appear in the service manual and parts catalogs. Special tools are found in the Service Manual. We retain the right to alter the specifications and equipment without prior notification.

SAFETY REGULATIONS

Each country has its own safety legislation. It is in the operator's own interest to be conversant with these regulations and to comply with them in full. This also applies to local bylaws and regulations in force on a particular worksite.

Should the recommendations in this manual deviate from those in the user's country, the national regulations should be followed.

SAFETY ALERT SYMBOL

The symbol shown above will appear at various points in this manual in conjunction with warning statements. Its appearance means: "WARNING! BE ALERT! YOUR SAFETY IS INVOLVED!"

NOTE: *Make sure that the warning Decals are readable, otherwise accidents may occur.*

KNOW THE CAPACITY AND LIMITS OF YOUR MACHINE!

CONTENTS**MAINTENANCE INTERVALS****BASIC PREVENTIVE
MAINTENANCE****SUPPLEMENTAL
PREVENTIVE MAINTENANCE****SPECIFICATIONS****ALPHABETICAL INDEX**

UNAUTHORIZED MODIFICATION OF ROLLOVER PROTECTIVE STRUCTURE (ROPS)

Do not make unauthorized modifications or alterations to the ROPS such as: welding on fire extinguisher brackets, antenna brackets, or fire suppression systems. Unauthorized modifications will affect the structural limits of the ROPS and will void the certification.

The Rollover Protective Structures (ROPS) have been certified to meet specified test requirements. These certifications are required by the U.S. Department of Labor under OSHA Regulation 1926.1000 and other regulations.

Any planned modification or change must be reviewed in advance by the Engineering Department to determine if the modification or change can be made within the limits of the certifying tests.

It is important that each person in your organization, including management, be made fully aware of these rules involving the ROPS.

Whenever anyone sees a machine ROPS with unauthorized modifications or changes, both the customer and manufacturer should be notified in writing.

SPARK ARRESTER MAY BE REQUIRED

Many states and other governmental entities have adopted laws and regulations which require spark arresters on machines operating on or near forests, brush or grass covered lands within their jurisdiction. The Federal government also has regulations (Forest Services) which require spark arresters on machines operating on National lands.

Use of machines without spark arresters in areas where such use is prohibited by law or regulation can subject the owner or operator of the machine to penal fines or civil damages, including the costs of fire suppression.

Spark arresting equipment complying with the applicable laws and regulations must be installed on any machines which are likely to be operated in such areas. All machines which are converted for woodland use (loggers, harvesters, etc.) should be equipped with approved spark arresting equipment.

The F66 & F67 machines have turbo charged engines which do not require additional spark arresting equipment to comply with currently known laws and regulation.

FIRE; (PREVENTION, EQUIPMENT AND SUPPRESSION)

FIRE PREVENTIVE INSTRUCTIONS

Forest fires are both costly and dangerous. Fire prevention must be foremost in the mind of a log skidder operator. Observe the following instructions to reduce the chance of a fire.

- Fire prevention features provided by the manufacturer should be maintained in operational condition and should be used to supplement the operator's fire prevention efforts. In no case should the features be used or assumed as replacement for operator efforts at preventing fires.
- Keep the machine and all equipment free of dirt, wood, oil etc. This will decrease possible fire hazards and make it easier to find loose or defective parts. This is especially important when working with combustible materials.
- The engine compartment and frame assembly should be inspected and cleaned at least daily. To do a thorough job, remove the access panels. Use regulated compressed air, steam or water with a non-flammable degreasing agent to remove all foreign materials. Maintain the engine cooling system to avoid overheating.
- Remove any debris from the operator's compartment and winch platform after each work shift.
- Check all the electrical wiring and connections for defects. Keep battery terminals clean and tight. If you find a problem, repair or replace immediately.
- Inspect the driveshaft and brakes for debris and remove all traces.
- Inspect all fuel, oil and hydraulic lines and connections. Tighten or replace any that show any leakage.
- Clean up any fuel, oil or hydraulic fluid spills after making repairs or servicing.
- Oily clothes are a serious fire hazard.
- Never perform welding operations until the entire machine has undergone a thorough cleaning. In addition, cover rubber hoses etc. and have at least a fire extinguisher at hand.
- Hydraulic fluid is flammable. Do not weld on pipes or tubes that are filled with fluid. Be careful when welding next to filled pipes or tubes.
- There is always a risk of fire. Find out which type of fire extinguisher to use, where it is and how to use it.
- Gasoline is highly flammable and should never be used as a cleaning fluid. Use an approved solvent for cleaning.
- Some solvents can cause skin rashes and or fire dangers. Do not inhale solvent vapors.
- Store flammable starting aids in a cool, well ventilated location away from combustible materials.
- Smoking, open flames, etc. should not be permitted around any machine during fueling operations and/or when fuel system is open to the atmosphere.

FIRE FIGHTING EQUIPMENT

- Keep your fire extinguishers fully charged and in good working order. Know how to use them.
- Carry an approved fire extinguisher rated for all class of fires.
- A 5 pound rated extinguisher is the minimum size recommended in some areas. Check local laws.
- Install it within reach of the operator in a position that protects it from damage.
- Use only a "quick release" type of mount.
- Service the extinguisher according to the manufacturer's specifications. Service after every use, no matter how short a time and never operate the machine without both in full working order.

FIRE SUPPRESSION

- Do not panic!
- Stop the machine and turn off engine in the clearest area available.
- Lower the blade (and log grapple if applicable).
- Shut off fuel and battery disconnect.
- Take the extinguisher and proceed to the source of the fire calmly.
- Though the manufacturer's instructions may vary, normally aim at the base of the fire.
- Even when the fire seems to be out , stand by with the extinguisher until the fire area is dead cool. Check this by removing any panels and looking for hot spots.
- Locate the cause of the fire and correct it before re-starting the machine.
- Thoroughly inspect the entire machine and recharge or replace the extinguisher(s) before returning to work.

TABLE OF CONTENTS

CONTENTS	1
FOREWORD	1
SAFETY REGULATIONS	1
ROLLOVER PROTECTIVE STRUCTURE	2
SPARK ARRESTER	2
FIRE PREVENTIVE INSTRUCTIONS	3
FIRE FIGHTING EQUIPMENT	4
FIRE SUPPRESSION	4
MAINTENANCE INTERVALS	7
GENERAL INFORMATION	7
MAINTENANCE INTERVAL CHART	8
LUBRICATION INSTRUCTIONS	11
BASIC PREVENTIVE MAINTENANCE	13
SERVICE POSITION	13
NAMEPLATES, WARNING AND INFORMATION DECALS	14
A FEW SIMPLE RULES WHEN SERVICING	17
PRODUCT IDENTIFICATION NUMBER	18
PRODUCT IDENTIFICATION NUMBER LOCATION	18
ENGINE	22
FUEL SYSTEM	23
AIR CLEANER SYSTEM	24
COOLING SYSTEM	25
FAN BELT TENSION	26
ELECTRICAL SYSTEM	27
BRAKE SYSTEM	31
FRONT AND REAR DRIVE AXLES	37
WHEELS AND TIRES	38
WINCH	39
LOG GRAPPLE	40
DRIVESHAFTS	41
HYDRAULIC SYSTEM: Trans./Converter/ Winch	42
HYDRAULIC SYSTEM; Steer, Blade & Grapple	44
SUPPLEMENTAL PREVENTIVE MAINTENANCE	47
CHECKING ENGINE PERFORMANCE	47
CHECK THE CONVERTER STALL RPM	47
CHECK AND ADJUST THE THROTTLE LINKAGE	47
CHECK THE TRANSMISSION / CONVERTER PRESSURES	48
CHECK THE MAIN HYDRAULIC RELIEF PRESSURE	50
SPECIFICATIONS	51
RECOMMENDED LUBRICANTS	51
MAIN HYDRAULIC SYSTEM	51
TRANSMISSION/CONVERTER/WINCH HYDRAULIC SYSTEM	52
FRONT AND REAR AXLE DIFFERENTIALS AND PLANETARY HUBS	52

CHASSIS and DRIVESHAFT LUBRICATION	52
PILLOW BLOCK BEARING LUBRICATION	53
ENGINE SPECIFICATIONS	55
CAPACITIES (F66 MACHINES)	54
CAPACITIES (F67 MACHINES)	61
MACHINE DIMENSIONS (F66)	57
MACHINE DIMENSIONS (F67)	64
TORQUE CHART	68
TIRE PRESSURES	67
ALPHABETICAL INDEX	71

Put the machine in the SERVICE POSITION




TS40011

GENERAL INFORMATION

If the machine is to work as economically as possible, thorough maintenance is necessary. The most important care a machine receives is the preventive maintenance that you perform, which comprises of lubrication, various checks and adjustments. The recommended intervals for maintenance and lubrication refer to normal working and environmental conditions.

Most of the maintenance procedures are simple to perform. The necessary detailed instructions are provided in this manual.

All maintenance and service work should be performed by qualified personnel.



TS16350



WARNING!

When working in the center hinge area the frame locking link must be used.



WARNING!

There is a risk of the machine moving even with the park brake applied.

- When checking fluid levels, the machine should be on level ground.
- Fluid levels should be checked in the morning when the fluids are cold and have drained to the bottom of each component. This does not apply to the hydraulic transmission and the hydraulic tank.
- Schedule servicing to avoid damage to the machine. Keep good records. Read the machine manuals.
- Make a complete visual inspection.
- Check for loose bolts and capscrews, leaks and worn parts. Report everything that needs attention.

8

Put the machine in the SERVICE POSITION

MAINTENANCE INTERVAL CHART


MAINTENANCE INTERVALS OPERATING HOURS

[illegible]

10 MAINTENANCE INTERVALS

Put the machine in the SERVICE POSITION


Lubrication Instructions (F66 & F67)



Put the machine in the SERVICE POSITION

LUBRICATION INSTRUCTIONS (F66 & F67)

ITEM	EVERY 10 HOURS OF OPERATION
1	Utility Blade and Cylinder Pins
2	Steer Cylinder Pins
3	Center Hinge Pins
4	Axle Cradle Pins
5	Arch and Cylinder Pins
6	Boom and Cylinder Pins
7	Grapple and Cylinder Pins
	EVERY 100 HOURS OF OPERATION
8	Driveshaft Slip Joints
9	
	EVERY 500 HOURS OF OPERATION
10	Snubber Pins
11	
12	



12

Put the machine in the SERVICE POSITION


NOTES

[illegible]

Put the machine in the SERVICE POSITION

SERVICE POSITION

Before working on the machine, park it on a level surface and put in the "SERVICE POSITION"



SP-10560

1. Frame locking link connected
2. Blade and grapple assembly (if applicable) on the ground
3. Parking brake applied
4. Stop Engine, key removed except when service requires engine operating.
5. Do not operate tag or Red warning flag on steering wheel or operator's handrail.
6. Fuel shut-off valve OFF
7. Remove all pressure caps slowly to relieve pressure.
8. Allow the machine to cool down.
9. Wheels securely blocked.
10. Battery disconnect switch OFF.



WARNING!

If work must be done on a warm machine, beware of hot fluids and components.

14 BASIC PREVENTIVE MAINTENANCE


Put the machine in the SERVICE POSITION

A FEW SIMPLE RULES WHEN SERVICING



SP-10409

- Do not perform any work on the machine unless you are authorized to do so.
- Maintenance can be dangerous unless performed properly. Be satisfied that you have the necessary skill and information, correct tools and equipment to do the job correctly.
- Standard maintenance procedures should always be observed. Read the manufacturer's manual or find assistance if you do not understand what you are doing.
- Keep the work place clean. Oil or water on the floor makes it slippery and also dangerous in connection with electrical equipment or electrically powered tools. Oily clothes are a serious fire hazard.
- When running a machine indoors, be sure the building is properly ventilated.



SP-10502

- Do not wear loose fitting clothing or jewelry when operating or working on a machine.
- Always wear a hard hat, safety glasses, gloves, boots, or other protective articles as the job requires.
- Keep the machine and all equipment free of dirt and oil. This will decrease the possible fire hazards and make it easier to find loose or defective parts. This is especially important when working with combustible materials.
- Machines should be clean of debris particularly around the engine, exhaust, and drive line components.

Put the machine in the SERVICE POSITION



SP-10412

A FEW SIMPLE RULES WHEN SERVICING (con't)


- Fire prevention features provided by the manufacturer should be maintained in operational condition and should be used to supplement operator's fire prevention efforts. In no case should the features be used or assumed as replacement for diligent operator efforts at preventing fires.
- Prior to welding or brazing on any part of the machine, the part and the surrounding area should be cleaned and a fire extinguisher should be made readily available.
- There is always a risk of fire. Find out which type of fire extinguisher to use, where it is and how to use it.
- In case of fire be prepared to run for safety, but if time permits first, if the engine is operating:

Stop the engine.

Turn off the battery disconnect switch and close the fuel shutoff valve.

Start combating the fire and/or call for help.

- Gasoline is highly flammable and should never be used as a cleaning fluid. Use an approved solvent for cleaning.
- Some solvents can cause skin rashes and or fire dangers. Do not inhale solvent vapors.
- Store flammable starting aids in a cool, well ventilated location.
- Smoking, open flames, etc., should not be permitted around any machine during fueling operations and/or when the fuel system is open to the atmosphere.



SP-10410

- Always be sure the "Frame Locking Link" is connected when working on the machine except when it is necessary to articulate it.
- When lifting or supporting components, use equipment with a weight capacity as great as or greater than the weight of the component.
- Use the correct tool(s) for the job. Repair or replace any broken or defective equipment or tools.
- Make sure that no tool(s) or other object(s) are left inside the machine where they may cause damage.
- Check that there is no damage to electric wires and hoses.

16 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION

A FEW SIMPLE RULES WHEN SERVICING (con't)

- Release all system pressure slowly before working on any part of the hydraulic system. Be alert – There could be high pressure stored in the grapple circuit on units with a grapple accumulator system.




WARNING!

See discharging the grapple accumulator pressure on page 44.

- Remove all pressure caps slowly.
- Be careful of hot fluid when changing oil in the engine, hydraulic system, transmission, etc.
- Before you work on the machine always lower the blade and grapple (If so equipped). If you must work on the machine with the blade or grapple raised, always securely support them.
- Be sure the machine is in the SERVICE POSITION before lifting the machine. Always support an elevated machine using proper blocks and/or cribbing before beginning work on it.
- To find leakage, use cardboard or wood, not your hand.
- Never adjust a pressure relief valve above the manufacturer's recommendations.
- Hydraulic fluid is flammable. Do not weld on pipes or tubes that are filled with fluid. Be careful when welding next to filled pipes or tubes.
- Always inspect the cooling system with the engine stopped. This as a pressurized system, relieve the pressure by slowly turning the cap off.
- Read all nameplates and decals before you operate the machine. Each nameplate and decal has important information about operation or service.
- Always stop the engine before removing inspection covers. Do not let tools or parts fall into the opening.

Decals and plates are installed at specific places on the Skidder to aid the operator or serviceman by warning him of potential hazards and by outlining the procedures that must be followed for proper service. Decals and plates should be inspected frequently for damage and deterioration. Plates should be checked for loose or missing hardware.



18 BASIC PREVENTIVE MAINTENANCE


Put the machine in the SERVICE POSITION

PRODUCT IDENTIFICATION NUMBER


At the time of manufacture, every machine is assigned a product identification (serial) number to identify that machine from all others built by the allied systems co.

Product Identification Breakdown (Current Production)

The following breakdown explains the product identification (serial) numbering system.



00000 X 00000




RP-10884

Always use the complete product identification (serial) number on all correspondence, service reports, literature and parts orders.

Product Identification Breakdown (Earlier Production)

The following breakdown explains the product identification (serial) numbering system.

000 X X 000 XXX




Always use the complete product identification (serial) number on all correspondence, service reports, literature and parts orders.


Put the machine in the SERVICE POSITION

PRODUCT IDENTIFICATION NUMBER LOCATIONS (Serial Number)

Serial Number Plate – Located on the floorboard panel to the left of the operator's seat.




SP-10556



SP-10557

Frame – The machine serial number is stamped into the front and rear frames in the center hinge area on the right hand side of the machine.




SP-10449

Engine serial number and data plate – Located on the left side of the engine in front of the injection pump.

20 BASIC PREVENTIVE MAINTENANCE


Put the machine in the SERVICE POSITION

Transmission serial number and model plate – Located on the metal tag, attached to the rear of the transmission.




SP-10558

Torque converter serial number and model plate – Located on the metal tag on the converter housing.



RP-10882


Drive axle ratio and serial number model plate – Located on the metal tag on the differential housing.




RP-10452

Put the machine in the SERVICE POSITION

Mid-mount brake serial number and model plate (F667 only)



Winch serial number and model plate



SP-10559

22 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION

ENGINE




WARNING!

Be careful if the engine is hot, hot oil can cause severe burns.

Checking Oil Level

The oil level should be checked daily and should be between the high – H and – L marks on the dipstick.



SP-10454


Changing Engine Oil

Drain the engine oil into a suitable container when the engine is hot. Hot oil flows more freely and carries more contaminants with it.

Replace the engine lube oil filter with the filter specified in the Parts Manual for your Skidder.

Choose an oil viscosity that is correct for the ambient operating temperature as recommended in the Cummins Engine Operation and Maintenance Manual.

Engine lube oil capacity is approximately 16 liters (4.4 US gallons.)



SP-10455


Put the machine in the SERVICE POSITION

FUEL SYSTEM

Fuel Filters

Drain any water and sediment from the engine fuel/water separator at the beginning of each work shift


Change the engine fuel filters according to the instructions in the Cummins Operation and Maintenance Manual.



SP-10629

Check The Fuel Strainer

Check the in line fuel strainer for a build-up of foreign material by blowing through it orally. The strainer should be replaced if it is contaminated.



SP-10596

Fuel Tank

Clean fuel is essential for trouble-free operation of the engine. Clean the area around the fuel filler cap before you remove it. Avoid spilling fuel to reduce the chance of a fire and to reduce the build-up of dirt. Fill tank at the end of each work shift to inhibit condensation.




WARNING!

Do not smoke while while refueling.

If the strainer screen in the fuel filler hole becomes clogged or dirty, it should be cleaned in solvent and blow dried with compressed air

Before each shift, open the drain cock on the bottom of the fuel tank and drain sufficient fuel to remove any sediment and water from the tank.

Check and clean vent hole in the fuel cap.



SP-10553

Put the machine in the SERVICE POSITION

AIR CLEANER SYSTEM

Air Cleaner

The air cleaner prevents dust and other impurities from entering the engine. The air first passes through the outer filter element and then through the inner element. Engine wear is largely affected by the cleanliness of the intake air therefore it is very important to check the air cleaner regularly and to service it correctly.

Check Air Cleaner Service Indicator

Check the air cleaner service indicator located on the air intake tube between the air cleaner and turbocharger. When the indicator shows red, the air cleaner elements should be serviced.

Check Air Intake Tubes and Clamps

Check the intake tubes and clamps between the air cleaner and turbocharger and replace any tubes that are cracked or damaged. Tighten any loose clamps.

Service Air Cleaner

Remove the outer element from the air cleaner body and use compressed air (from the inside of the element) to blow any dirt particles from the element. Wash the element in a non-sudsing detergent for about 15 minutes. Rinse with warm tap water from the inside until the water that passes through the element is clean. Air dry the element .

Shine a bright light from the inside of the element and check it for pin holes, ruptures or thin spots. Replace the element if any of these conditions exist.

Note: *Do not remove the inner element except to change it. Replace both elements after the second cleaning of the outer element or every 2000 hours of operation. The frequency of air cleaner servicing depends on the working conditions of the machine.*


Clean the Air Cleaner Vacuator Valve

Tap the rubber vacuator valve to remove dust and dirt on a daily basis.

Note: *It may be necessary to remove the vacuator valve to remove caked particles of dirt from the valve.*

AIR PRE CLEANER (Optional)


When the level of debris in the air pre cleaner reaches the full line on the bowl, remove the pre cleaner and empty it.



SP-10563



SP-10598



SP-10628

Put the machine in the SERVICE POSITION

COOLING SYSTEM

The following measures must be carried out regularly to ensure that the cooling system operates correctly.

Antifreeze:

The cooling system of the machine was shipped with a solution of equal parts of ethylene glycol and water. This concentration is recommended for subsequent fills. The coolant should be changed every 1000 hours of operation.

Checking Coolant

Check the coolant level daily. The level should be up to the bottom of the filler neck in the radiator. Add coolant as required.



WARNING!

The cooling system is pressurized and there is a risk of scalding whenever removing the radiator cap. Remove slowly with gloved hand. Wear safety glasses.

Check Hoses and Clamps

Check hoses and clamps and replace any hoses that are cracked or damaged. Tighten any loose clamps, do not over tighten the clamps.

Cleaning the Radiator


The radiator should be cleaned daily to reduce the chance of possible engine damage caused by improper engine cooling.

Remove the bolts from the top of the grill and lower the grill so that rests on the blade. Use a fire hose or pressure washer to clean the radiator in the opposite direction to the air flow.


Note: *Be careful not to damage the radiator core while cleaning.*

Change Coolant and Flush System


1. Slowly remove the radiator cap.
2. Open the drain cock on the bottom of the radiator.
3. Remove the drain plug from the bottom of the coolant inlet elbow on the engine.
4. Open the bleeder cock on the engine aftercooler to drain system. (F67 only)



SP-10554




SP-10463



SP-10621

26 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION



SP-10599

Change Coolant and Flush System (con't.)

5. Install drain plugs.


Note: See engine manufacture's manual for correct cooling system cleaning procedures.

6. Flush the cooling system by running clean water thru it.
7. Close the drain cocks and install the drain plug (leaving the aftercooler bleeder cock open F667 only).
8. Add coolant to the radiator filler hole to the correct level, (closing the aftercooler bleeder cock when a continuous flow of coolant flows through it (F667 only).
9. Pressure test system and cap for leaks using a cooling system pressure tester.
10. Start the engine and add coolant until the radiator is full and free of air.
11. Check the coolant level when the engine reaches its operating temperature and again when it has cooled.



WARNING!

Never pour cold coolant into a hot engine. This could cause the cylinder head or engine block to crack. The failure to change the coolant can result in the cooling system becoming clogged and the engine can be seriously damaged by overheating.



EL14032

FAN BELT TENSION

Visually check belts for looseness, or worn belts, replace worn belts.

The engine is equipped with a fan belt tensioner that eliminates the need to adjust the belt. Use a belt tensioner gauge to check belt tension every 1000 hours of operation to make sure the tensioner is working properly. See the Cummins Engine Operation and Maintenance Manual.

Put the machine in the SERVICE POSITION

ELECTRICAL SYSTEM

Batteries

The batteries are located in the operator's guard behind the seat.

Check Battery Condition



WARNING!

All lead-acid batteries generate hydrogen gas which is highly flammable. If ignited by a spark or flame, the gas may explode violently, causing spraying of acid, fragmentation of the battery, and possible severe personal injuries. Wear safety glasses when working near batteries.

ANTIDOTE: *EXTERNAL – Flush with water. INTERNAL – Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call physician immediately. EYES – Flush with water for 15 minutes and get prompt medical attention.*

The batteries are connected in parallel in a 12 volt system. Check the electrolyte level weekly (more often in warm weather). The level should be approximately 10mm (3/8 in) above the plates. If necessary add distilled water. Check that the cable terminals and battery posts are clean, tight and coated with an anti-corrosive substance. During cold weather, it is very important that the batteries do not become discharged, because the electrolyte can freeze and damage the battery.




WARNING!


Do not attempt to charge or load test a frozen battery. If frozen it may explode, allow the battery to warm to 15.5° C (60° F) before placing on charge.

Note: *VME Maintenance –Free batteries allow you to use a hydrometer to test the specific gravity of the electrolyte. Individual plugs can be unscrewed allowing access to each cell. Specific gravity of each cell can then be tested. When installing plugs be sure they are properly seated. If the specific gravity, when corrected to 80° F is less than 1.225, the battery is to be charged.*

Note: *When checking battery at temperature other than 80° F, for every 10° above 80° –Add .004 to reading. For every 10° below 80° – Subtract .004 from the reading.*



SP-10565




TS40415

28 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION


STEP-1



STEP-2

CHECK OPEN CIRCUIT VOLTAGE FOR STATE OF CHARGE NOTE: STABILIZE VOLTAGE BY TURNING ON LIGHTS OR 15 AMP LOAD FOR 15 SECONDS.	
STABILIZED OPEN CIRCUIT VOLTAGE	PERCENT CHARGED
12.6 VOLTS OR MORE	100%
12.4	75%
12.2	50%
12.0	25%
11.7 OR LESS	0%
STABILIZED VOLTAGE BELOW 12.4 VOLTS CHARGE BATTERY AND RETEST	STABILIZED VOLTAGE ABOVE 12.4 VOLTS Proceed To STEP-3

STEP-3




VOLTAGE CHART

ESTIMATED ELECTROLYTE TEMPERATURE		MINIMUM REQUIRED VOLTAGE UNDER 15 SEC. LOAD
70° F	(21° C) & ABOVE	9.6
60° F	(16° C)	9.5
50° F	(10° C)	9.4
40° F	(4° C)	9.3
30° F	(-1° C)	9.1
20° F	(-7° C)	8.9
10° F	(-12° C)	8.7
0° F	(-18° C)	8.5

Put the machine in the SERVICE POSITION

Charging Maintenance—Free or Low—Maintenance Batteries



TS20788



WARNING!

When batteries are being charged, explosive gases are formed. A short circuit, open flame or spark near the battery can cause a serious explosion. Provide good ventilation, especially if the battery is being charged in an enclosed area.




WARNING!

Make sure the battery charger is OFF. Connect the positive (+) charger lead to the positive (+) terminal on the battery first. Connect the negative (–) charger lead to the negative (–) terminal on the battery.



WARNING!

Always use a voltmeter or hydrometer to check the battery charge. Never use a metal object across the posts to test a battery. Sparks may cause an explosion.



V50391



WARNING!

Never let fluid be pushed out of the battery or the temperature go above 52° C (125° F). If the battery case feels hot, stop charging for 20 minutes then start the charger at a lower amperage rate. High temperature will prevent the battery from holding a charge. Make sure the battery is a minimum of 16° C (60° F) before charging.

Note: Check the voltage from one terminal to the other on the same battery. Do not connect the voltmeter to the battery cables.

Note: Follow the instructions of the battery charger or the manufacturer.

VOLTAGE OF 12.4 OR ABOVE		VOLTAGE BETWEEN 11.7 AND 12.4		VOLTAGE 11.7 OR BELOW	
Amps of Recharge	Hours of Recharge	Amps of Recharge	Hours of Recharge	Amps of Recharge	Hours of Recharge
5	5	5	14	5	27
10	2.5	10	7	10	14
15	1.5	15	4.5		

Put the machine in the SERVICE POSITION

Check Battery Cables and Connections

Check the battery cables, connections and hold downs for damage, looseness and corrosion. Replace damaged parts as needed. Clean and tighten connections as needed. Disconnect the ground cables first at end remote from battery when removing a battery to avoid causing sparks which could cause an explosion. Connect the ground cable last during installation.


Starting With Auxiliary Batteries

DO NOT connect jumper cables to the battery terminals. Use system voltage to jump start. Connect the positive cable first to the positive starter cable. Connect the negative cable to the machine frame.



WARNING!

Failure to follow this procedure could result in personal injury or damage to the electrical system.



SP-10397

Battery Disconnect Switch

Note: When performing any welding operation on a machine turn off the battery disconnect switch and disconnect the positive and negative cable connections at the battery.

Note: Never connect the arc welder (or cutter) ground cable to the opposite frame to the one being welded on. Connect the ground cable as close as possible to the area to be welded. Thoroughly clean the weld area before welding to reduce the chance of fire and have a fully charged fire extinguisher on hand.

Check Neutral Start Switch

Put the transmission control lever in the FORWARD position. Try to start the engine. If the starter turns the engine, replace the neutral start switch.

Put the transmission control lever in the REVERSE position. Try to start the engine. If the starter turns the engine, replace the neutral start switch.


Note: If the starter will turn the engine with the transmission control lever in the NEUTRAL only position, the neutral start switch is good.

Put the machine in the SERVICE POSITION

BRAKE SYSTEM

Checking the Fluid Levels Master Cylinders


Check the fluid levels in the service brake master cylinders every 50 hours of operation. The master cylinders are located behind the access panel on the side of the firewall. The levels in the reservoirs should be within 6mm (1/2 in) from the top of the filler hole. Add approved automatic transmission fluid to the reservoirs as required.



SP-10569

Checking the Fluid Levels Midmount Brake (F67)

Check the lubricant level in the midmount brake unit. The level should be up to the bottom of the check plug hole. Drain and refill the midmount brake housing every 500 hours of machine operation with approved automatic transmission fluid.



SP-10622

Checking the Secondary Brake Pads (F66)




WARNING!

Operating the secondary brake with excessive brake pad wear can result in unsafe brake operation and damage to the brake disc.

Check the secondary brake retractor pins to determine the amount of wear on the pads. The pads should be replaced if the protrusion of the pins is 3.2 mm (.125 in) or less.

Check the condition of the brake disc. If it is warped or pitted, it should be replaced.




SP-10612

32 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION

Adjusting the Parking Brake Lever


If slack develops when the parking brake lever is applied, release the parking brake lever and turn the acorn nut on the end of the lever to clockwise to tighten the cable.



SP-10570


Adjusting the Service Brake Linkage (F67)

Adjust the brake pedal stops to obtain a dimension of 203mm (8.0 in.) between the master cylinder mounting faces and the center lines of the clevis joints.




SP-10624

Adjust the master cylinder pushrod end play to obtain a 1.5mm (.06 in.) gap between the contact cams and the cam followers.



SP-10625

Put the machine in the SERVICE POSITION




SP-10613

Adjusting the Service Brake, Transmission (F66 - F67)

If the service brake pedal stroke becomes excessive, it may be necessary to adjust the brake units.

Note: *The parking brake lever arm (1) applies only to the transmission mounted brake, not the midmount brake.*

- Loosen locknut (2) on brake adjusting screw (3).
- Disconnect parking brake linkage from brake lever arm (1). Brake lever arm end only.
- Tighten adjusting screw (3) until screw bottoms out (return springs compressed).
- Back adjusting screw (3) out one turn.
- Hold adjusting screw (3) from turning and tighten locknut (2).
- Reconnect parking brake linkage to brake lever arm.



RP-10907

Adjusting the Service Brake, Midmount (F67 Only)

- Loosen locknut (1) on brake adjusting screw (2).
- Tighten adjusting screw (2) until screw bottoms out.
- Back adjusting screw (2) out one turn.
- Hold adjusting screw (2) from turning and tighten locknut (1).


34 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION

Adjusting the Parking Brake Linkage. (F66 - F67)

Before adjusting the clevis at the brake lever arm:


- Adjust the transmission service brake clearance.
- Rotate the adjustment knob on the hand lever to full release position.
- Adjust the clevis until the pin slides freely through the brake lever arm.
- Adjust the knob on the hand lever until the lever force is firm.



SP-10613

Midmount Brake Breather. (F67 Only)

The breather should be cleaned every 250 hours of operation. Remove the breather from the hose on the right hand side of the winch, clean it in a solvent and blow dry it with compressed air.



SP-10623

Bleeding the Brakes



WARNING!

Never reuse fluid that has been collected during bleeding, it could be contaminated and could interfere with the safe operation of the brakes.


NOTE: Both brake units must be correctly adjusted before you begin to bleed the brakes. Correct brake adjustment can correct certain brake conditions.

Put the machine in the SERVICE POSITION

NOTE: Do not use pressure type bleeders for this system. Pressure type bleeders disturb the air bubbles already in the fluid making bleeding more difficult.

NOTE: The F67 uses a single pedal to actuate both brake units, a separate fluid system is used for each system. The F66 has two separate brake pedals.


When bleeding the brake systems it is imperative that the master cylinder reservoirs be kept filled. If a reservoir is allowed to empty air will enter the system and it will have to be rebled. Refill the reservoir after each step. Always remember to close a bleeder screw before the brake pedal is released.



SP-10614


F67

- Hold the service brake fully applied and open the bleeder screw on the inner (transmission) brake master cylinder, close the bleeder screw and release the pedal.
- Repeat the procedure until a clear stream of fluid (free of air) is expelled from the bleeder and close the bleeder screw. To make sure all the air that can be expelled is, bleed several times after a clear stream of fluid has been expelled. If any air is expelled at this time, repeat several times.



SP-10615

- Repeat the procedure with the two bleeder screws on top of the transmission mounted brake unit.
- Hold the service brake fully applied and open the bleeder screw on the outer (midmount) brake master cylinder, close the bleeder screw and release the pedal.
- Repeat the procedure until a clear stream of fluid (free of air) is expelled from the bleeder and close the bleeder screw. If any air is expelled at this time, repeat several times.




SP-10626

- Repeat the procedure with the center bleeder screw under the seat plate. If any air is expelled at this time, repeat several times.

36 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION




SP-10627

- Repeat the procedure with the bleeder screw on top of the midmount brake unit. If any air is expelled at this time, repeat several times.
- Allow the brakes to stand for 20 minutes and recheck the pedal stroke to determine if the brakes have been bled completely.
- Allowing the machine to stand for 8 hours can help to allow any remaining air in the system to be expelled from the system or to collect at the bleeder screws for easy rebleeding

F66 Service Brake

- Hold the service brake pedal fully applied and open the bleeder screw on the service brake master cylinder.
- Close the bleeder when the pedal goes to the floor then release the pedal.
- Repeat the procedure with the two bleeder screws on the transmission mounted brake unit. If any air is expelled at this time, repeat several times.




SP-10523

F66 Secondary Brake

- Hold the service brake fully applied and open the bleeder screw on the secondary master cylinder.
- Close the bleeder when the pedal goes to the floor then release the pedal.
- Repeat the procedure with the bleeder screws on the disc brake unit at the front drive axle. If any air is expelled at this time, repeat several times.

NOTE: If the brakes feel spongy, too long a pedal stroke, brake pedal does not return, or is slow to return when it is released, air could still be in the system or the pedal linkage is binding. Check the linkage for binding and correct condition. If no binding is found the pedal should be returned by hand to continue the bleeding procedure.



SP-10522

Put the machine in the SERVICE POSITION

FRONT AND REAR DRIVE AXLES

Checking the Axle Lubricant Levels


The lubricant in the drive axle differentials and planetary hubs should be checked every 50 hours of operation and changed every 1000 hours. A lubricant change may be needed earlier due to ambient temperatures. The differential level check plugs are located in the center of the differential housings opposite the input flanges. The differential drain plugs are located on the bottom of the differential housings.



SP-10470


Checking the Planetary Hub Level

The planetary hub level check plugs are located in the center of each planetary hub. The arrow on the hub should point down when the level is checked. The planetary drain plugs are located on the outer edge of the hubs and should point down for complete draining.



SP-10568

Note: On some planetary hubs the planetary oil level plugs are higher than the differential plugs. Therefore the differential plug should be used to determine the axle assembly oil level.




SP-10609

Axle Breathers

The axle breather Caps should be rotated every 50 hours of operation to clear the passages. Every 500 hours of operation the breathers should be cleaned with compressed air to remove any debris.

Put the machine in the SERVICE POSITION



RP-10895

WHEELS AND TIRES



WARNING!

When doing any tire service, especially tire inflation, NEVER stand in the TRAJECTORY PATH. Serious injury or death can result if an explosion should occur.

Use a self attaching air chuck with a hose long enough to avoid stranding in the trajectory path when inflating a tire.

Use an inflation cage, safety cables or chains when inflating tires.

Never use air from a compressed air system to inflate a tire if alcohol has been used as antifreeze.

Tire Inflation Pressure

When checking the air pressure of the tires, examine the valves and make sure all valve caps are in place. For the recommended Tire inflation pressures see the specification section of this manual.

Note: Never check tire pressures with a load (of logs) in place.

Check Tire Condition

Check the condition of the tires with the machine empty. Make a report of any damaged tires.




WARNING!

Completely deflate a tire before removing foreign material from the tire tread. Keep your fingers away from bead breakers and rims, and stay out of the trajectory path when removing foreign material. If a bead breaker disengages, it will release with enough force to cause injury or death.



WARNING!

For complete information pertaining to dismounting and mounting the tires on rims, refer to the Tire Manufacturer's Off-Highway Tire Maintenance Manual.



RP-10896


Put the machine in the SERVICE POSITION

WINCH

Adjust the Winch Free-Spool Tension

If the winch cable requires too little effort to pull it from the cable drum, the tension can be adjusted as follows:


- Loosen the lock screw.
- Tighten the adjusting nut to increase the tension and loosen it to decrease it.
- Tighten the lock nut.



SP-10572

Installing The Winch Mainline

Note: *Installing the winch cable this way provides a safety break away if the load should fall down a grade as well as a method of holding the cable under normal operation.*




SP-10573



WARNING!

This break-away feature will help to prevent the machine from being pulled by the load should the load slip down a hillside, but it is imperative that the operator put the winch control lever in the FREE-SPOOL position immediately to allow the cable to unwind from the winch.




SP-10082

Install the winch mainline to the winch cable drum as follows:

- Remove the access plug from the winch housing.
- Start the machine and put the winch in the FREE-SPOOL mode.
- Rotate the cable drum by hand until the two cable anchor wire holes are in the center of the hole.
- Put the winch in the HOLD mode and return the machine to the SERVICE POSITION.
- Choose a gauge of wire that will insert through the holes.

40 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION



SP-10083

- Twist the wire ends together against the cable drum.
- Install the cable into the groove between the ends of the wire so that the cable ferrule is in the ferrule groove.
- Twist the ends of the wire together to hold the cable.
- Start the engine and WINCH-IN the cable onto the cable drum.
- Install the access plug.

LOG GRAPPLE

Checking and Adjusting the Grapple Snubbers

The operation of the snubbers should be checked at the beginning of each work shift as follows:


Pull back the grapple 30 cm (12 in) and release it. It should stop completely just before it reaches the bottom of its swing. If the grapple swing is greater than this, the snubber should be adjusted as follows:

Each set of upper and lower adjusting nuts should be adjusted equally. Tightening only one nut per set can overload the snubber causing premature wear.

- Remove the cotter pins (1) from the top snubber adjusting nuts (2).
- Loosen each adjusting nut and then tighten them until each Belleville washer (3) collapses about halfway.
- Recheck the grapple swing.
- Install new cotter pins to maintain the adjustment. It may be necessary to tighten or loosen an adjusting nut to install the cotter pin.

Check the adjustment of the lower snubbers by pulling the grapple 30mm (12 in) to each side and releasing it. The bottom snubbers are adjusted the same way as the top.

Note: *Keep oil and grease away from the snubbers so they will operate at maximum efficiency.*




SP-10484

Put the machine in the SERVICE POSITION

DRIVESHAFTS

Lubrication


Grease the slip joints of the driveshafts every 100 hours of operation using a hand grease gun. Some of the universal joints used are sealed, non greasing type that require no lubrication maintenance. They can be identified by a hole in the center of the U-joint cross. Greaseable U-joints should be greased every 1000 hours of operation. A needle type grease gun adapter may be required to reach the grease fittings on some U-joints. this may be purchased from a local tool supplier.



SP-10610

Checking the Driveshafts

Check for play in the universal joints, slip joints and loose, missing or damaged bolts.



SP-10611


42 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION

HYDRAULIC SYSTEM

Transmission, Converter and Winch

The fluid in the transmission, converter and winch hydraulic system serves several purposes. It lubricates the transmission, converter and winch, transmits engine power through the torque converter. The fluid also cools the components. It is very important that the oil level is always correct. Too low an oil level will affect the transfer of power and can damage the system. Too much oil will cause foaming and the system will overheat. Damage can also be caused by dirty oil. It is important to keep contaminants away from the dipstick and the system clean.



SP-10567

Checking Fluid Level

The fluid level should be checked daily as follows:

- Park the machine on level ground.
- Apply the parking brake.
- Transmission in neutral.
- Fluid at operating temperature 82° – 93° C (180° – 200° F)
- Start engine and operate it at low idle RPM.
- Check fluid level on dipstick.
- Add fluid to filler tube as required to bring level to between marks on the dipstick.

Note: *If adding a large quantity of oil, it may be poured into the winch through the breather hole on top of the housing.*

Transmission and Torque Converter Fluid Warm-Up Procedure


- Block tires and hold service brake pedal applied.
- Transmission in FORWARD and THIRD.
- Run the engine at two thirds throttle until the fluid reaches its operating temperature.

Note: *Do not apply parking brake as this will declutch the transmission on some models.*

Put the machine in the SERVICE POSITION

Changing Hydraulic Transmission Fluid

The fluid should be changed every 1000 hours of operation. Drain the fluid by removing the plug from the bottom of the transmission housing. Drain with the fluid at 65° – 93° C (150° – 200° F)



SP-10600



WARNING!

Be careful when working with hot fluids

Flushing the Transmission and Torque Converter

In the event of a major failure or when it becomes necessary to change most of the oil in the circuit the following procedure should be followed:

- Drain the transmission oil.
- Clean and replace the suction screen.
- Change the transmission filter.
- Remove lube line at transmission brake (from cooler) and divert into a 10 gallon pail.
- Over fill transmission a few extra gallons until oil comes out the breather.
- Start engine and run at idle until clean oil appears at lube line or oil stops flowing.
- Shut off engine as soon as oil flow stops.


Suction Screen

The suction screen should be cleaned every 1000 hours of operation. It is located on the bottom on the right hand side of the transmission beside the steps. Clean the screen when the fluid in the system is drained for changing. When the cleaned screen is replaced, use a new gasket. It should be tighten just enough to seat the suction screen.

Refill transmission to low mark on the dipstick. Start the engine and run at 500–600 RPM to prime converter and lines. Recheck level with engine running at 500–600 RPM and add oil to bring level to low mark. When the oil temperature is hot 82° –93° (180–200° F) make final oil check bringing oil level to full mark. Check system for leaks.

Changing the Transmission Filter

The filter should be changed after the first 50 hours of operation and every 500 hours of operation thereafter. It is accessible behind the left hand rear engine side panel. The filter cannot be cleaned, it must be replaced. Apply a thin coat of transmission fluid to the gas-




SP-10601

44 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION

ket surface and tighten the filter. Operate the engine for five minutes at 1500 RPM and check for leaks. If leaks appear, remove and replace the filter and repeat the installation. It usually does not help to tighten the filter further.

Note: *Normal drain periods and filter change intervals are for average environmental and duty-cycle conditions. Severe or sustained high operating temperatures or very dusty atmospheric conditions will cause accelerated deterioration and contamination. For extreme conditions judgment must be used to determine the required change intervals.*



SP-10602

Torque Converter and Transmission Vent and Breather

The vent and breather should be cleaned every 250 hours of operation. Remove them from the top of the torque converter and transmission, clean them in solvent and blow dry with low pressure compressed air as not to damage the internal parts.

Note: *Breather – transmission
Vent – converter and winch*

HYDRAULIC SYSTEM; STEER, BLADE & GRAPPLE



WARNING!

If your Skidder is equipped with a grapple hydraulic accumulator System the hydraulic fluid in the accumulator is stored under high pressure. BEFORE doing any service on grapple circuit of the hydraulic system, the accumulator must be discharged COMPLETELY. If the accumulator is to be disassembled, the nitrogen precharge pressure must also be discharged completely.

Discharge the Accumulator Hydraulic Pressure as Follows:

- With the engine running, open the grapple tongs halfway (tip to tip) – do not close the tongs halfway.
- Raise the grapple tips a few centimeters (inches) off the ground.
- Shut down the engine and put the machine in the service position (with the exception of the raised grapple).
- Hold the grapple control lever in the OPEN position for ten seconds.

Put the machine in the SERVICE POSITION


- Check the grapple accumulator system pressure gauge to ensure that the pressure reading is zero.

Note: *If the grapple cannot be opened (because of a problem such as a pump or engine failure) then the above procedure should be done with the closed grapple on the ground. If the pressure still cannot be reduced to zero, loosen the hose 1-2 turns (Do Not Remove) at the pilot operated check valve to the accumulator CAREFULLY at the the check valve until all of the hydraulic pressure is removed. There will be approximately 3.8 liters (1 US gal.) of oil in the accumulator.*

Checking the Hydraulic Fluid Level

Note: *The blade should be on the ground, arch forward, grapple open, and the boom cylinders at mid stroke.*

The hydraulic fluid should be checked daily and be between the add and full mark on the dipstick. Add fluid to the reservoir as required through the filler tube.



SP-10571

Changing the Hydraulic Fluid

Change the hydraulic fluid every 1000 hours of operation or whenever the main hydraulic pump fails and must be overhauled.

- Run the Skidder until the hydraulic fluid reaches its operating temperature.
- Raise the blade, move the arch forward and the boom up (if applicable) and open the log grapple tongs.
- Shut the engine down.
- Raise the floor board to gain access to the hydraulic tank. Remove the pressure cap (4 PSI under pressure) then remove the drain plug on the bottom of the reservoir. Draining the oil into a suitable container.
- Slowly lower the blade, close the grapple arms move the arch back (and lower the boom) to flush the fluid from those cylinders.
- Remove the hydraulic reservoir top plate and clean the inside of the tank using diesel fuel as a solvent and clean the magnet (6).
- Remove and clean the suction screen (4). Replace it if it is damaged.
- Refill the reservoir to the correct level. Start the engine and operate it at Low Idle RPM for a few minutes.

46 BASIC PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION


- Raise the blade, move the arch forward, level boom and open the grapple arms.
- Recheck the level, adding fluid as required.

Note: *Never use flushing oil or compounds to clean the system, use only the recommended operating fluid.*

Changing the Main Hydraulic Filter

Change the filter element (11) after the first 50 hours of operation and every 500 hours of operation thereafter.

See Hydraulic section in Service Manual (6416) for further information on hydraulic system.



RP-10721

Put the machine in the SERVICE POSITION

ENGINE

Checking Engine Performance

The engine performance should be checked every 250 hours of operation to verify that the engine is operating efficiently.

Check the low idle RPM with the engine at its operating temperature and no load on the engine. The acceptable value is 700 - 750 RPM.

Check the High Free Idle RPM under the same conditions. The acceptable value is 2450 - 2550 RPM.

Check the Converter Stall RPM as Follows:

- With the blade lowered apply the parking and service brakes (F66 only). On the F67 apply the service brakes only.
- Accelerate the engine to full throttle with the transmission in FORWARD and THIRD. The acceptable value is 2140 - 2260 RPM for F66 and 2280 - 2400 RPM for the F67 .
- Raise the blade and hold the blade control lever in the raise position with the engine at full throttle and the transmission in FORWARD and THIRD. The acceptable value is 1870 - 2010 RPM for a F66 and 2060 - 2200 for a F67. It is important that the Main Hydraulic Relief Pressure be correct for this check.

If any of these conditions are not met, further troubleshooting will be required.




WARNING!

Do not hold the engine/converter in this stall condition for more than 30 seconds or if the converter oil temperature gauge enters the red area. Serious damage to the converter will result.

Checking and Adjusting the Throttle Control Linkage

The accelerator pedal must be free to operate the engine from Low Idle RPM to High Free Idle RPM with no binding in the linkage. The engine must return fully to Low Idle RPM when the pedal is released. Adjust the linkage if necessary as follows:

- Unhook the throttle return springs.
- Disconnect the ball joint from the engine throttle lever.
- With the accelerator pedal fully applied, and the engine throttle lever halfway through the break-over travel, adjust the ball joint so it is aligned with the throttle lever with no force required.



48 SUPPLEMENTAL PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION

HYDRAULIC TRANSMISSION / CONVERTER


Note: To obtain accurate pressure readings the service brake pedal must not be applied during these procedures.

Checking the Transmission / Converter Pressures


The fluid in the transmission/converter hydraulic system must be at its operating temperature of 82° – 93° C (180° – 200° F).

Check the converter Pressures with a 1000 kPa (150 PSI) pressure gauge.

The converter IN test port is located on the test hose on top of the converter. The maximum acceptable converter in pressure is 825 kPa (120 PSI) at maximum engine RPM.




SP-10603



SP-10604

The converter OUT test port is located on the left hand side of the converter. The minimum acceptable converter OUT pressure is 170 kPa (25 PSI) at 2000 RPM. The maximum acceptable converter OUT pressure is 480 kPa (70 PSI) maximum at maximum RPM.

The transmission/converter lube pressure test port is located on top of the hydraulic brake unit. The maximum acceptable lube pressure is 170 kPa (25 PSI) at maximum RPM.




SP-10605


Put the machine in the SERVICE POSITION

Checking the Transmission / Converter Pressures

The reverse clutch pressure test port is located on top of the modulation valve on the left hand side of the transmission.



SP-10606



SP-10607

REGULATED Clutch Pressure

Spec. 240–280 PSI

1st _____

2nd _____

3rd _____

Winch-in _____

Hold _____

Free Spool _____

- with speed control in neutral
- using 0–300 PSI gauge
- engine is at idle RPM
- oil temperature at operating

DIRECTIONAL Clutch Pressure

Using the "Same" gauge then check the directional clutches.

Forward _____

Checked with the following speed and winch clutches applied.

_____ 1st

_____ Hold

Reverse _____

SPEC. This may be up to 20 PSI less than regulated.

The regulated clutch pressure test port is located on the T-fitting on top of the transmission control valve.


The forward clutch pressure test port is located on the rear of the modulation valve on the left hand side of the transmission.

The acceptable regulated clutch pressure is 1.65 - 1.93 MPa (240 - 280 PSI) in all combinations of speed ranges and winch modes. Regulated clutch pressure should be checked in neutral, the forward and reverse clutch pressures should be taken and the speed mode recorded. Regulated pressure must be recorded in 1st, 2nd, 3rd, free-spool, winch-in and hold with the transmission directional selectors in neutral. There should be no more than 35 kPa (5 PSI) difference between the highest and lowest regulated clutch pressure readings however it is normal for the Forward and Reverse clutch pressure to be up to 140 kPa (20 PSI) lower than the regulated clutch pressures.

50 SUPPLEMENTAL PREVENTIVE MAINTENANCE

Put the machine in the SERVICE POSITION

Note: *There will be a delay of about two seconds before the forward and reverse clutch pressures are shown on the gauge. This is caused by the action of the modulation valve.*



SP-10608

If any of the transmission/ converter pressures are not within the acceptable limits, further troubleshooting will be required.


Check the transmission and winch clutch pressures with a 2000 kPa (300 PSI) pressure gauge. The same gauge should be used to test all circuits.

HYDRAULIC SYSTEM

Transmission, Converter and Winch

Checking the Main Hydraulic Relief Pressure

The main hydraulic pressure check port is located on the pump outlet tube below the floor board.



SP-10619

Put the machine in the SERVICE POSITION

SPECIFICATIONS

RECOMMENDED LUBRICANTS

Main Hydraulic System: (Blade, Steer, Arch, Boom and Grapple Cylinders)

PREVAILING AMBIENT TEMPERATURE	FLUID TO BE USED
-23° C (-10° F) TO 50° C (120° F)	Mobil DTE 13M Premium Grade Hydraulic Oil ISO VG32

Transmission/Converter/Winch Hydraulic System and Midmount Brake

PREVAILING AMBIENT TEMPERATURE	FLUID TO BE USED
-1° C (30° F) and Above	C-3 Grade 30 Transmission Fluid
-23° C (-10° F) and Above	C-3 Grade 10 Transmission Fluid
-34° C (-30° F) and Above	Dextron II D Transmission Fluid
-55° C (-65° F) to -18° C (0° F)	MIL -L-46167 or MIL-L-46167A
-55° C (-65° F) and above	Conoco Polar Start DN-600 Fluid

Hydraulic fluid must be kept clean. Any fluid added to the reservoir must be filtered through a 100 mesh screen. It is important to service filters and breathers at the correct hourly intervals.

Any time oil is added to top off the fluid level, the same oil as is already in the system must be used. If the same fluid is not available, another approved fluid (for the given temperature range) can be added if the fluid is supplied by the same manufacturer and the amount added is not greater than 50% of the system capacity. If these conditions cannot be met, the system must be drained completely and refilled.

When the fluid is changed because of changes in ambient temperature, the system must be drained and the fluid replaced.

Because of the many types and brands of fluids that are available, it is not practical to test each one. Selecting the correct fluid should be done with the help of a reputable oil supplier who is responsible for the quality of the fluid. It is important to change fluids and filter elements at the intervals specified in this manual.

Put the machine in the SERVICE POSITION

Front and Rear Axle Differentials and Planetary hubs

Extreme Pressure Gear Lubricant
Multi-grade Viscosities MIL-L-2105C

PREVAILING AMBIENT TEMPERATURE	LUBRICANT TO BE USED
-12° C (+10° F) and Above	85W -140
-26° C (-15° F) and Above	80W -140
-26° C (-15° F) to 38° C (100° F)	80W -90
-40° C (-40° F) and Above	75W -140
-40° C (-40° F) to 38° C (100° F)	75W -90
-40° C (-40° F) to -18° C (0° F)	75W -80
Below -23° C (-10° F)	Special Polar MIL-L 2105C 75W

Chassis and Driveshaft Lubrication

PREVAILING AMBIENT TEMPERATURE	LUBRICANT TO BE USED
-18° C (0° F) and Above	NLGI Grade 2 Lithium Base Extreme Pressure Multi-purpose Grease with 3% to 5% Molybdenum Disulfide added.
-32° C (-25° F) and Above	NLGI Grade 0 Lithium Base Extreme Pressure Multi-purpose Grease.

Put the machine in the SERVICE POSITION

Pillow Block Bearing Lubrication**PREVAILING AMBIENT TEMPERATURE**

- 18° C (0° F) and Above
- Below -18° C (0° F)

LUBRICANT TO BE USED

- Unirex EP Grease (ESSO-Canada, Mobil-U.S.) Grade 2.
- Unirex EP Grease (ESSO-Canada, Mobil-U.S.) Grade 0.

Fuel Specifications

Fuel: N°. 2 Diesel

Put the machine in the SERVICE POSITION

UNITS OF MEASUREMENT

The new SI units have been used in this Instruction Manual. Previously used units are given within brackets.

The new units used are as follows:

Power is stated in kW (kilowatt) , hp (horse power)

Torque is stated in N.m (newton meter) , lbf. ft (pound force foot)

Force is stated N (newton) , lbf (pound force)

Pressure of liquids and gases are stated in kPa (kilo Pascal) , MPa (mega Pascal) , PSI (pounds per square inch)

CAPACITIES (F66 Machines)

LITERS

GALLONS

Engine Crankcase	16	4.4
Cooling System	45	12
Transmission/Converter/Winch System	40	10.5
Differential – Front	7	1.5
Differential – Rear	12	2.6
Planetary Hubs – Front	5	1.1
Planetary Hub – Rear	9	2.0
Fuel Tank	182	48
Hydraulic System – Cable Skidder	73	19
Hydraulic System – A–Frame Arch Grapple	78	21
Hydraulic System – Parallelogram	87	23
Windshield Washer Reservoir	10	2.6

MACHINE WEIGHTS (Cable Skidder)

Front Axle	6775 kg (14936 lb)
Rear Axle	3072 kg (6773 lb)
Total	9847 kg (21709 lb)

MACHINE WEIGHTS (A–Frame Arch Grapple Skidder)

Front Axle	5552 kg (12240 lb)
Rear Axle	4717 kg (10400 lb)
Total	10269 kg (22640 lb)

MACHINE WEIGHTS (Parallelogram Grapple Skidder)

Front Axle	5534 kg (12200 lb)
Rear Axle	5688 kg (12540 lb)
Total	11222 kg (24700 lb)

TRAVELING SPEEDS

23.1–26 Tires	km/h	mile/h
1st Gear	6.0	3.7
2nd Gear	10.9	6.8
3rd Gear	21.6	13.4

NOTE: The weights and fluid capacities listed are approximates. Weights given are for machines with standard tires and equipment.

Put the machine in the SERVICE POSITION

ENGINE SPECIFICATION (F66 MACHINES ONLY)

Make	Cummins Diesel
Model	6BT-5.9
Configuration	Inline 6 Cylinder-Turbocharged
Gross Power	113 kw (152 hp) @ 2500 RPM (Earlier Production)
.....	110 kw (148 hp) @ 2300 RPM (Earlier Production)
Maximum Torque @ 1500 RPM	576N•m (425 lbf. ft)
Bore	102 mm (4.02 in)
Stroke	120 mm (4.72 in)
Displacement	5.9 liter (359 cu. in)
Low Idle RPM	700-750
High Free Idle RPM	2600-2750 (Current Production)
.....	2650-2700 (Earlier Production)

ENGINE LUBRICATING SYSTEM

Oil Pressure -Low Idle RPM	70- 207 kPa (10-30 PSI)
Oil Pressure-Operating RPM	207- 414 kPa (30-60 PSI)

ELECTRICAL

System Voltage	12 Volt
Batteries	Two 31D Parallel
Battery Voltage	12 Volt
Battery Capacity	625 CCA
Alternator Rating	1765 W (63 A)
Ground	Negative

HYDRAULIC TRANSMISSION

Make	Clark
Model	R28320
Type	Powershift with Forward-Reverse Modulation
Number of Forward Gears	3
Number of Reverse Gears	3

TORQUE CONVERTER

Make	Clark
Model	C-273.1
Stall Torque Ratio	2.728:1

AXLES

Make	Clark
Model	17620 Front/19640 Rear
Differential Type	No-Spin
Differential Ratio	6.333:1
Planetary Ratio	4.125:1
Total Ratio	26.125:1

Put the machine in the SERVICE POSITION**BRAKE SYSTEM**

Service Brake, Type	Enclosed Wet Disc, Transmission Mounted
Secondary Brake, Type	Caliper Disc, Front Drive Axle Mounted
Parking Brake, Type	Transmission Brake Mechanically Applied

HYDRAULIC SYSTEM

Pump	Gear Type
Pump Capacity	106 l/min (28 gal/min) @ 2000 RPM (Current Production)
.....	90 l/min (23.8 gal/min) @ 2000 RPM (Earlier Production)
Cylinders- Steer Blade	Double Acting, 90 mm (3.5 in) diameter
Cylinder- Arch, Boom	
Grapple (A- Frame Arch)	Double Acting, 102 mm (4 in) diameter
Cylinder- Grapple (Parallelogram)	Double Acting, 152 mm (6 in) diameter
Main Relief Pressure	14.5- 15.2 MPa (2100 - 2200 PSI)


Put the machine in the SERVICE POSITION

MACHINE DIMENSION (F66 Cable Skidder)

The following machine specifications are provided for your convenience. All specifications are approximate and are subject to change without notice or obligation.

Turning Radius 5435 mm (17 ft 8 in) Track, Front & Rear 2134 mm (7 ft)
 Width Over Tires 2758 mm (9 ft 0 in) Blade Width 2134 mm (7 ft)

TIRES		A	B	C	D	E	F	G	H	J	K	L	M	N
18.4-34	mm	3221	2968	1313	597	277	6248	3264	1638	508	475	1016	2166	218
	ft in	10'7"	9'9"	4'4"	2'0"	0'11"	20'6"	10'9"	5'5"	1'8"	1'7"	3'4"	7'1"	0'9"
23.1-26	mm	3124	2895	1254	597	335	6248	3264	1638	450	475	1016	2108	218
STD	ft in	10'3"	9'6"	4'1"	2'0"	1'1"	20'6"	10'9"	5'5"	1'6"	1'7"	3'4"	6'11"	0'9"
24.5-32	mm	3254	3000	1360	597	231	6248	3264	1638	554	475	1016	2212	218
	ft in	10'8"	9'10"	4'6"	2'0"	0'9"	20'6"	10'9"	5'5"	1'10"	1'7"	3'4"	7'3"	0'9"
28L-26	mm	3188	2934	1280	597	310	6248	3264	1638	475	475	1016	2134	218
	ft in	10'6"	9'8"	4'2"	2'0"	1'0"	20'6"	10'9"	5'5"	1'7"	1'7"	3'4"	7'0"	0'9"
30.5L-32	mm	3284	3030	1377	597	213	6248	3264	1638	572	475	1016	2230	218
	ft in	10'9"	10'0"	4'6"	2'0"	0'8"	20'6"	10'9"	5'5"	1'11"	1'7"	3'4"	7'4"	0'9"



58 SPECIFICATIONS


Put the machine in the SERVICE POSITION

MACHINE DIMENSIONS (F66 A-FRAME ARCH Grapple Skidder)

The following machine specifications are provided for your convenience. All specifications are approximate and are subject to change without notice or obligation.


Turning Radius 5160 mm (18 ft 2 in) Track, Front & Rear 2134 mm (7 ft)
Width Over Tires 2762 mm (9 ft 11 in) Blade Width 2134 mm (7 ft)

TIRES	A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U
24.5-32 mm STD ft in	3228 10'7"	2987 9'10"	1255 4'1"	597 2'0"	239 0'9"	5476 18'0"	3505 11'6"	1880 6'2"	546 1'9"	869 2'10"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"
28L-26 mm ft in	3170 10'5"	2929 9'7"	1196 3'11"	597 2'0"	180 0'7"	5476 18'0"	3505 11'6"	1880 6'2"	488 1'7"	765 2'6"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"
30.5L-32 mm ft in	3272 10'9"	3030 10'0"	1298 4'3"	597 2'0"	196 0'8"	5476 18'0"	3505 11'6"	1880 6'2"	589 1'11"	886 2'11"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"



SP-10575

LOG GRAPPLE




SP-10500

Put the machine in the SERVICE POSITION


MACHINE DIMENSIONS (F66 Parallelogram Grapple Skidder)

The following machine specifications are provided for your convenience. All specifications are approximate and are subject to change without notice or obligation.

TIRES	A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U
24.5-32 mm STD	3228 10'7"	2987 9'10"	1255 4'1"	597 2'0"	239 0'9"	5476 18'0"	3505 11'6"	1880 6'2"	546 1'9"	869 2'10"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"
28L-26 mm ft in	3170 10'5"	2929 9'7"	1196 3'11"	597 2'0"	180 0'7"	5476 18'0"	3505 11'6"	1880 6'2"	488 1'7"	765 2'6"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"
30.5L-32 mm ft in	3272 10'9"	3030 10'0"	1298 4'3"	597 2'0"	196 0'8"	5476 18'0"	3505 11'6"	1880 6'2"	589 1'11"	886 2'11"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"



LOG GRAPPLE




SP-10577

60 SPECIFICATIONS




Put the machine in the SERVICE POSITION

MACHINE DIMENSIONS (F66 ESCO HI-VIS Grapple Skidder)

The following machine specifications are provided for your convenience. All specifications are approximate and are subject to change without notice or obligation.



RP-10890



RP-10891

Put the machine in the SERVICE POSITION

UNITS OF MEASUREMENT

The new SI units have been used in this Instruction Manual. Previously used units are given within brackets.

The new units used are as follows:

Power is stated in kW (kilowatt) , hp (horse power)

Torque is stated in N.m (newton meter) , lbf. ft (pound force foot)

Force is stated N (newton) , lbf (pound force)

Pressure of liquids and gases are stated in kPa (kilo Pascal) , MPa (mega Pascal) , PSI (pounds per square inch)

CAPACITIES (F67 Machines)

LITERS

GALLONS

Engine Crankcase	14	3.8
Cooling System	47	12.5
Transmission/Converter/Winch System	40	10.5
Differential – Front Cable/Grapple	12	3.3
Differential – Rear Grapple	16	4.4
Planetary Hubs	9	2.4
Fuel Tank–Cable Skidder	182	48
Fuel Tank–Parallelogram Grapple Skidder	254	67
Midmount Brake Housing	10	2.6
Hydraulic System – Cable Skidder	73	19
Hydraulic System – Parallelogram Grapple Skidder	87	23
Windshield Washer Reservoir	10	2.6

MACHINE WEIGHTS (Cable Skidder)

Front Axle	6775 kg (14936 lb)
Rear Axle	3072 kg (6773 lb)
Total	9847 kg (21709 lb)

MACHINE WEIGHTS (Parallelogram Grapple Skidder)

Front Axle	5534 kg (12200 lb)
Rear Axle	5688 kg (12540 lb)
Total	11222 kg (24700 lb)

TRAVELING SPEEDS

23.1–26 Tires	km/h	mile/h
1st Gear	6.0	3.7
2nd Gear	10.9	6.8
3rd Gear	21.6	13.4

NOTE: The weights and fluid capacities listed are approximates. Weights given are for machines with standard tires and equipment.

Put the machine in the SERVICE POSITION**ENGINE SPECIFICATION (F67 MACHINES ONLY)**

Make	Cummins Diesel
Model	6BTA-5.9
Configuration	Inline 6 Cylinder-Turbocharged Aftercooled
Gross Power @ 2500 RPM	132 kw (177 hp)
Maximum Torque @ 1500 RPM	605 N•m (447 lbf. ft)
Bore	102mm (4.02 in)
Stroke	120mm (4.72 in)
Displacement	5.9 liter (359 cu. in)
Low Idle RPM	675-725
High Free Idle RPM	2500-2750

ENGINE LUBRICATING SYSTEM

Oil Pressure -Low Idle RPM	70- 207 kPa (10-30 PSI)
Oil Pressure-Operating RPM	207- 414 kPa (30-60 PSI)

ELECTRICAL

System Voltage	12 Volt
Batteries	Two 31D Parallel
Battery Voltage	12 Volt
Battery Capacity	625 CCA
Alternator Rating	1765 W (63 A)
Ground	Negative

HYDRAULIC TRANSMISSION

Make	Clark
Model	R28320
Type	Powershift with Forward-Reverse Modulation
Number of Forward Gears	3
Number of Reverse Gears	3

TORQUE CONVERTER

Make	Clark
Model	C-273.1
Stall Torque Ratio	2.728:1

AXLES

Make	Clark
Model	Front/ 33640 Rear
Differential Type	No-Spin
Differential Ratio	6.333:1
Planetary Ratio	4.125:1
Total Ratio	26.125:1

Put the machine in the SERVICE POSITION

BRAKE SYSTEM

Service Brake, Type	Enclosed Wet Disc, Transmission Mounted and
.....	Enclosed Wet Disc, Rear Frame Mounted
Secondary Brake, Type	Split system, hydraulically actuated by the service
.....	brake pedal.
Parking Brake, Type	Transmission Brake Mechanically Applied

HYDRAULIC SYSTEM

Pump	Gear Type
Pump Capacity	106 l/min (28 gal/min) @ 2000 RPM (Current Production)
.....	90 l/min (23.8 gal/min) @ 2000 RPM (Earlier Production)
Cylinders- Steer Blade	Double Acting, 90 mm (3.5 in) diameter
Cylinder- Arch, Boom	
Grapple (A- Frame Arch)	Double Acting, 102 mm (4 in) diameter
Cylinder- Grapple (Parallelogram)	Double Acting, 152 mm (6 in) diameter
Main Relief Pressure	14.5- 15.2 MPa (2100 - 2200 PSI)

64 SPECIFICATIONS


Put the machine in the SERVICE POSITION

MACHINE DIMENSIONS (F67 Parallelogram Grapple Skidder)

The following machine specifications are provided for your convenience. All specifications are approximate and are subject to change without notice or obligation.


Turning Radius 6159 mm (20ft 2 in) Track, Front & Rear 2349 mm (7 ft 9 in)
Width Over Tires 3048 mm (10 ft 0 in) Blade Width 2134 mm (7 ft)

TIRES	A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U
24.5-32 mm	3228	2987	1255	597	239	5476	3505	1880	540	823	1298	127	1298	2580	1206	1320	2332	2847
STD ft in	10'7"	9'10"	4'1"	2'0"	0'9"	18'0"	11'6"	6'2"	1'9"	2'8"	4'3"	0'5"	4'3"	8'6"	3'11"	4'4"	7'8"	9'4"
28L-26 mm	3170	2929	1196	597	180	5476	3505	1880	488	765	1298	127	1298	2580	1206	1320	2332	2847
ft in	10'5"	9'7"	3'11"	2'0"	0'7"	18'0"	11'6"	6'2"	1'7"	2'6"	4'3"	0'5"	4'3"	8'6"	3'11"	4'4"	7'8"	9'4"
30.5L-32 mm	3272	3030	1298	597	196	5476	3505	1880	589	886	1298	127	1298	2580	1206	1320	2332	2847
ft in	10'9"	10'0"	4'3"	2'0"	0'8"	18'0"	11'6"	6'2"	1'11"	2'11"	4'3"	0'5"	4'3"	8'6"	3'11"	4'4"	7'8"	9'4"



SP-10620

LOG GRAPPLE



SP-10577


Put the machine in the SERVICE POSITION

MACHINE DIMENSION (F67 Cable Skidder)

The following machine specifications are provided for your convenience. All specifications are approximate and are subject to change without notice or obligation.

Turning Radius 5490 mm (18 ft 0 in) Track, Front & Rear 2182 mm (7 ft 2 in)
Width Over Tires 2817 mm (9 ft 2 in) Blade Width 2134 mm (7 ft)

TIRES		A	B	C	D	E	F	G	H	J	K	L	M	N
18.4-34	mm	3221	2968	1313	597	277	6248	3264	1638	508	475	1016	2166	218
	ft in	10'7"	9'9"	4'4"	2'0"	0'11"	20'6"	10'9"	5'5"	1'8"	1'7"	3'4"	7'1"	0'9"
23.1-26	mm	3124	2895	1254	597	335	6248	3264	1638	450	475	1016	2108	218
STD	ft in	10'3"	9'6"	4'1"	2'0"	1'1"	20'6"	10'9"	5'5"	1'6"	1'7"	3'4"	6'11"	0'9"
24.5-32	mm	3254	3000	1360	597	231	6248	3264	1638	554	475	1016	2212	218
	ft in	10'8"	9'10"	4'6"	2'0"	0'9"	20'6"	10'9"	5'5"	1'10"	1'7"	3'4"	7'3"	0'9"
28L-26	mm	3188	2934	1280	597	310	6248	3264	1638	475	475	1016	2134	218
	ft in	10'6"	9'8"	4'2"	2'0"	1'0"	20'6"	10'9"	5'5"	1'7"	1'7"	3'4"	7'0"	0'9"
30.5L-32	mm	3284	3030	1377	597	213	6248	3264	1638	572	475	1016	2230	218
	ft in	10'9"	10'0"	4'6"	2'0"	0'8"	20'6"	10'9"	5'5"	1'11"	1'7"	3'4"	7'4"	0'9"



Put the machine in the SERVICE POSITION

MACHINE DIMENSIONS (F67 ESCO HI-VIS Grapple Skidder)

The following machine specifications are provided for your convenience. All specifications are approximate and are subject to change without notice or obligation.

TIRES	A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U
24.5-32 mm STD ft in	3228 10'7"	2987 9'10"	1255 4'1"	597 2'0"	239 0'9"	5476 18'0"	3505 11'6"	1880 6'2"	546 1'9"	869 2'10"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"
28L-26 mm ft in	3170 10'5"	2929 9'7"	1196 3'11"	597 2'0"	180 0'7"	5476 18'0"	3505 11'6"	1880 6'2"	488 1'7"	765 2'6"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"
30.5L-32 mm ft in	3272 10'9"	3030 10'0"	1298 4'3"	597 2'0"	196 0'8"	5476 18'0"	3505 11'6"	1880 6'2"	589 1'11"	886 2'11"	1298 4'3"	127 0'5"	1298 4'3"	2580 8'6"	1206 3'11"	1320 4'4"	2332 7'8"	2847 9'4"

Put the machine in the SERVICE POSITION

TIRE PRESSURES –kPa (PSI) F66 & F67

TIRE SIZE	PLY RATING	MINIMUM	MAXIMUM
18.4-34	10	105 (15)	170 (25)
23.1-26*	10	105 (15)	140 (20)
23.1-26	14	105 (15)	205 (30)
24.5-32**	12	105 (15)	170 (25)
24.5-32	16	105 (15)	205 (30)
28L-26	10	105 (15)	140 (20)
28L-26	14	105 (15)	170 (25)
28L-26	18	105 (15)	205 (30)
30.5L-32	12	105 (15)	140 (20)
30.5L-32	16	105 (15)	170 (25)

*Standard F66 Cable and Grapple. Standard F67 Cable.

**Standard F67 Grapple.

68 SPECIFICATIONS

Put the machine in the SERVICE POSITION

BOLT TORQUE CHART - GENERAL

Note: Use this chart only if the torque is not shown on the BOLT TORQUE CHART APPLICATION.

Thread Diameter		GRADE 5 Coarse Fine Thread		Grade 8 Coarse Fine Thread		Socket Head and 12 Point Head Capscrew- Coarse and Fine Thread	
Fraction	Decimal	N•m	lbf. ft	N•m	lbf. ft	N•m	lbf. ft
1/4	0.2500	10	7	12-14	9-10	15-16	11-12
5/16	0.3125	20-22	15-16	24-27	18-20	31-34	23-25
3/8	0.3750	34-38	25-28	50-55	34-40	60-65	45-50
7/16	0.4375	55-60	40-45	80-90	60-65	95-100	70-75
1/2	0.5000	90-95	65-70	125-135	90-100	150-160	110-120
9/16	0.5625	125-135	90-100	170-190	125-140	205-225	150-165
5/8	0.6250	170-190	125-140	240-255	175-190	285-310	210-230
3/4	0.7500	300-330	220-245	405-445	300-330	490-540	360-400
7/8	0.8750	450-490	330-360	645-710	475-525	815-880	600-650
1 in	1.0000	645-710	475-525	985-1085	725-800	1220-1355	900-1000
1-1/8	1.1250	800-975	650-720	1425-1595	1050-1175	1760-1965	1300-1450
1-1/4	1.2500	1220-1355	900-1000	2000-2205	1475-1625	2510-2710	1850-2000
1-3/8	1.3750	1630-1830	1200-1350	2710-2980	2000-2200	3320-3660	2450-2700
1-1/2	1.5000	2035-2235	1500-1650	3523-3865	2600-2850	4270-4680	3150-3450
1-5/8	1.6250	2710-2980	2000-2200	4680-5150	3450-3800	5630-6240	4150-4600
1-3/4	1.7500	3390-3730	2500-2750	5830-6510	4300-4800	6910-7730	5100-5700
1-7/8	1.875	4270-4745	3150-3500	7460-8270	5500-6100	8810-9760	6500-7200
2 in	2.000	5150-5965	3800-4200	8810-9760	6500-7200	10575-11660	7800-8600

Put the machine in the SERVICE POSITION

BOLT TORQUE CHART, APPLICATION (F66 SKIDDERS ONLY)

	Thread	N•m.	lbf.-ft.
Converter to Engine Flywheel Housing	M10	55-60	40-45
Flange to Rear Shaft	1.000-20	339-373	250-275
Front Axle to Cradle	1.00-8	950-1100	685-750
Front Engine Mount to Engine	*M12	85-100	65-75
Front Engine Mount to Frame625-11	230-300	170-220
Front Engine mount to Support625-11	120-155	90-115
Grapple Motor Box Cover to Arch375-24	45-55	35-40
Hinge and Cradle Bushing Retaining Cap Capscrew ...	*.500-20	120-130	90-95
Hinge and Cradle End Plate to Pin Capscrew	*.500-20	123-130	90-95
Hinge and Cradle Pin to Frame Capscrews	*.500-13	110-115	80-85
Lower Driveshaft Mounting Bolts (Early F666- 6C)375-24	45-55	35-45
Lower Driveshaft Mounting Bolts (Late F666- 7C)500-20	120-155	90-115
Midmount Bearing Support to Frame750-10	400-515	290-380
Midmount Bearing to Support625-11	230-300	170-220
Rear Axle to Frame	1.000-8	950-1100	685-750
Rear Engine Mount to Engine	*M12	75-80	55-60
Rear Engine Mount to Frame625-11	120-155	90-115
Secondary Brake Disc to Flange437-20	74-102	55-75
Secondary Brake Head to Support625-18	230-300	170-220
Snubber Adjusting Nut	1.250-12	45-55	35-40
Transmission Mount to Frame	*.750-10	400-515	290-380
Transmission Mount to Transmission750-10	400-515	290-380
Upper Driveshaft- Winch375-24	45-55	35-45
Upper Driveshaft- Conv.375-24	45-55	35-45
Upper Driveshaft Mounting Bolts375-24	45-55	35-45
Wheel Nuts- Rim to Axle (Spherical)750-16	575-645	425-475
Wheel Nuts- Rim to Axle (Flat)750-16	407-408	300-330
Winch to Frame	1.250-7	1150-1355	850-1000

When you install the above mounting bolts, lubricate the threads with SAE NO.30 unless otherwise instructed.

*When you install these mounting bolts, apply Loctite-271 or equivalent to the threads.

BOLTS NOT LISTED ARE TO BE DRAWN UP TIGHT IN A MANNER CONSISTENT WITH GOOD WORKMANSHIP- SEE BOLT TORQUE CHART- GENERAL.

Put the machine in the SERVICE POSITION

BOLT TORQUE CHART, APPLICATION (F67 SKIDDERS ONLY)

	Thread	N•m.	lbf.-ft
Converter to Engine Flywheel Housing	M10	55-60	40-45
Front Axle to Cradle	1.00-8	950-1100	685-750
Front Engine Mount to Engine	M12	85-100	65-75
Front Engine Mount to Frame625-11	230-300	170-220
Front Engine Mount to Support625-11	120-155	90-115
Hinge and Cradle Bushing Retaining Cap Capscrew500-20	120-130	90-95
Hinge and Cradle End Plate to Pin Capscrew500-20	123-130	90-95
Hinge and Cradle Pin to Frame Capscrews500-13	110-115	80-85
Lower Driveshaft-Mech. 7C500-24	120-155	90-115
Midmount Break to Frame750-10	400-515	290-380
Rear Axle to Frame	1.000-8	950-1100	685-750
Rear Engine Mount to Engine	M12	75-80	55-60
Rear Engine Mount to Frame625-11	120-155	90-115
Snubber Adjusting Nut	1.250-12	45-55	35-40
Transmission Mount to Frame750-10	400-515	290-380
Transmission Mount to Transmission750-10	400-515	290-380
Upper Driveshaft- Mech. 5C375-24	45-55	35-45
Wheel Nuts- Rim to Axle (Spherical)750-16	575-645	425-475
Winch to Frame	1.250-7	1150-1355	850-1000

When you install the above mounting bolts, lubricate the threads with SAE NO.30 unless otherwise instructed.

*When you install these mounting bolts, apply Loctite-271 or equivalent to the threads.

BOLTS NOT LISTED ARE TO BE DRAWN UP TIGHT IN A MANNER CONSISTENT WITH GOOD WORKMANSHIP- SEE BOLT TORQUE CHART- GENERAL.

ALPHABETICAL INDEX

A

A Few Simple Rules When Servicing,	14
Axles, Breather,	37
Axles	
Lubricant Levels, Checking The,	37
Planetary Hub Level, Checking The,	37

B

Brakes	
Bleeding The,	34
Fluid Level Master Cylinder, Checking The,	31
Fluid Level Midmount Brake, Checking The,	31
Midmount Brake, Serial Number Location,	21
Midmount Brake Breather,	34
Parking Brake Lever, Adjusting The,	32
Parking Brake Linkage, Adjusting The,	34
Secondary Brake Pads (F666), Checking The,	31
Service Brake Linkage (F667), Adjusting The,	32
Service Brake Midmount (F667), Adjusting The,	33
Service Brake Transmission, Adjusting The	33

C

Converter Stall RPM, Check,	47
---------------------------------------	----

D

Driveshafts	
Checking The,	41
Lubrication,	41

E

Electrical System	
Batteries,	27
Batteries Charging,	29
Battery Cables & Connections, Check The,	30
Battery Condition Check The,	27
Battery Disconnect Switch,	30
Engine	
Air Cleaner,	24

Air Cleaner Intake Tubes & Clamps, Check The,	24
Air Cleaner Service Indicator, Check The,	24
Air Cleaner Service The,	24
Air Cleaner Vacuator Valve, Clean The,	24
Converter Stall RPM, Check,	47
Cooling System	
Antifreeze,	25
Check Coolant,	25
Check Hoses & Clamps,	25
Cleaning The Radiator,	25
Cooling System Change & Flush,	25
Fan Belt Tension,	26
Fuel Filters,	23
Fuel Strainer Check The,	23
Oil Changing The,	22
Oil Level Checking The,	22
Performance Checking The,	47
Starting With Auxiliary Batteries,	30
Throttle Control Linkage, Check and Adjust,	47

F

Fire	
Fire Fighting Equipment,	4
Prevention Instructions,	3
Spark Arrester,	2
Suppression,	4
Forward,	1
Fuel Tank,	23

H

Hydraulic System	
Steer, Blade & Grapple	
Accumulator Discharge Procedure,	44
Filter Changing The,	46
Fluid Changing The,	45
Fluid Level Check The,	45
Transmission & Converter Vent and Breather,	44
Transmission Filter Changing The,	43
Transmission, Converter & Winch,	42
Fluid Changing The,	43
Fluid Level Check The,	42
Fluid Warm-Up Procedure,	42
Flushing The System,	43
Transmission, Suction Screen,	43

L

- Log Grapple, Snubbers, Check & Adjust, . . . 40
- Lubrication Instructions, 10

M

- Maintenance Interval Chart, 8

N

- Name Plates, Warning and Information
 - Decals, 17

P

- Product Identification Number
 - Breakdown
 - Current Production, 18
 - Earlier Production, 18
- Product Identification Number Locations, . . 19
 - Drive Axle, 20
 - Engine, 19
 - Frame, 19
 - Midmount Brake, 21
 - Serial Number Plate, 19
 - Torque Converter, 20
 - Transmission, 20
 - Winch, 21

R

- Recommended Lubricants, 51

S

- Service Position, 13

T

- Table Of Contents, 5
- Tires
 - Condition, Check The, 3 8
 - Inflation Pressure, Check The, 38
 - Pressures & sizes, 67
- Transmission / Converter, Main Hydraulic
 - Relief, Pressure, Checking The, 50
- Transmission / Converter, Pressures,
 - Checking The, 48

W

- Winch
 - Free-Spool Tension, Adjust The, 39
 - Mainline, Install The, 39
 - Serial Number Location, 21