

MANUFACTURED BY

**RAYGO  
WAGNER**



**W-50 & 150-P  
AXLE**

**SERVICE  
INSTRUCTIONS**

**INTENTIONALLY BLANK**

### W-50-P and W-150-P Axle Assemblies

The following instructions cover the complete disassembly and reassembly of the axles. If only portions of the axle assembly require service or repair, such as on axle shafts, wheel bearings, brakes, etc., use only the portion of instructions required covering the parts in question.

The axle assemblies are large and husky; the differential assemblies are heavy. In event the differential has to be removed from the axle housing, it may be advisable to remove the complete axle from the vehicle. This will depend on the vehicle the axle is installed in and the type of shop equipment available. The illustrations used in the instructions are from an axle assembly prior to installation in a vehicle.

It is very essential the exterior of the axle assembly be cleaned before disassembly. Any foreign material falling or entering into the planetary section or any part of the axle assembly and not removed will shorten the life of the assembly drastically.

Rotate the hubs so that the drain plugs for the planetaries are pointing downward, remove the plugs and drain the lubricant.

Illustration #1

Remove the six cap screws from the planetary cover, remove the cover. The sun gear is splined to the axle shaft and retained on the shaft with a snap ring. The sun gear and axle shaft can be removed as a unit.




Illustration #1

Illustration #2

Remove the cap screws from the planetary spider. All but four of the cap screws are used to secure the planetary spider to the hub. Four of the cap screws are shorter in length and are threaded into the planetary spider. Use four of the long cap screws as puller screws, insert the four cap screws in the threaded holes the short cap screws were removed from. As the cap




Illustration #2  
screws are tightened, they will act as pullers and pull the planetary spider away from the hub. Remove the planetary spider.



Remove the outer skein lock nut, the lock nut spacer and the inner lock nut.




Illustration #3

Remove the hub ring gear and the internal tooth ring gear as a unit.




Illustration #4

Illustration #4

The wheel hub can now be removed, lift the assembly off from the skein.

The brake assembly and the skein are secured to the axle housing by the same studs and nuts.




Illustration #5

Illustration #5

Remove the nuts from the studs, remove the brake assembly and the skein from the axle housing. It may be necessary to tap the skein with a lead hammer or block of wood to loosen the skein from the housing.

Illustration #6  
(Differential Removal and Disassembly)

Drain the lubricant from the differential housing. After draining the lubricant, rotate the axle housing so that the pinion is on the top. Remove the cap screws which secure the differential assembly to




Illustration #6

the axle housings. Attach a hoist to the pinion yoke and lift the differential from the axle housing. "Note: Both axle shafts must be removed before attempting to remove the differential assembly on a work bench or other suitable work space.

The pinion assembly can be removed as a unit or partially

disassembled. Remove the cap screws which secure the pinion assembly to the differential carrier. Remove the pinion assembly from the differential carrier.





Illustration #7

If the pinion assembly cannot be removed from the carrier easily, remove the yoke nut, washer and yoke. Remove the pinion bearing cover. The pinion bearing housing has two threaded holes  $180^{\circ}$  from each other. Insert two cap screws into the threaded holes of the pinion cover. Tighten

the cap screws, they will act as a puller to remove the assembly from the differential carrier.

Illustration #8

Disassemble the pinion assembly. The pinion shaft is ground to a slightly smaller diameter at the spline end to promote easy removal of the outer tapered bearing. The inner tapered bearing has a press fit on the pinion shaft;



a puller or a press is required to remove the bearing. To complete the disassembly, drive or press the two bearing cups out of the pinion housing and remove the oil seal from the pinion bearing cover.

#### Differential Disassembly

Loosen the jam nut from the back up plug on the side of the differential carrier, remove the back up plug. The oil scoop assembly is located above the pinion bore, remove the pipe plug, spring and oil scoop from the carrier.

Remove the two capscrews from the side carrier bearing adjusting nut locks, remove the locks. Remove the lock wire from the bearing cap capscrews, remove the capscrews. Remove the bearing caps and adjusting nuts. Lift the differential assembly from the differential carrier.

The pinion pilot bearing is positioned in the differential carrier, a shoulder machined at the differential side of the bearing bore prevents the bearing from moving toward the differential. Drive the pilot bearing out toward the pinion assembly opening of the carrier.





Illustration #9

Press or drive a new pilot bearing in the carrier. If the bearing is driven into the carrier, drive on the outer race only. Make certain the bearing is snug against the retaining flange.

Illustration #9

# Illustration #10

Remove the self-locking nuts and capscrews from the ring gear, remove the ring gear from the differential case. Punch mark both halves of the differential case so that when reassembling the two halves of the case can be reassembled in their original position. Remove the eight long capscrews and the four short cap-



screws from the differential case, separate the two halves of the case.

Remove the spider gears and spider, side gears and thrust washers from the differential case. Clean all parts and inspect them thoroughly; if in doubt about the serviceability of any part, replace it.

## Illustration #11 Differential Reassembly and Adjustments.

Both halves of the differential case are machined separately. If one side or the other is worn or damaged, it is not necessary to replace the complete case assembly, only the damaged part. Both halves of the case are shown in Illustration #11.




Illustration #11

## Illustration #12 (Next Page)

The internal gears and associate parts of the differential assembly consist of four spider gears, four spider gear thrust washers, a spider, two side gears and two side gear thrust washers.



Illustration #12

Illustration #13

Lubricate the spider, thrust washers and all gears. Install all parts in case as shown in Illustration #13.

Illustration #14  
(Next Page)

Place the two halves of the differential case together. If the original case is being used, make certain the punch




Illustration #13

marks on each half line up so that the two halves will be in the same relative position to each other as they were originally. A new case assembly or a new half of a case will fit in four different positions; however, after the case has been bolted together, check the spider and side gears for free movement. If they do not move or revolve freely, remove the bolts, separate the case and reassemble in a different position until the gears move freely.

Torque the capscrews to 160-180 ft. pounds - "Dry Threads" on the W-50-P assembly. Torque the capscrews to 430-460 ft. pounds - "Dry Threads" on the W-150-P Assembly. Secure the capscrews with safety or lock wire. Install the two side carrier bearings. The differential assembly is shown with one side carrier bearing installed in Illustration #14. (See next page)



Illustration #15

Place ring gear over differential assembly and install the Allen head capscrews. (Shown in Illustration #15)




Illustration #14




Illustration #15

Illustration #16

Install the twelve self-locking nuts on the capscrews, torque the nuts to 160-180 ft. pounds - dry threads (Shown in Illustration




Illustration #17

Before assembling pinion into carrier, assemble carrier bearing to differential case and differential case to carrier housing.

Assemble bearing caps, cap bolts, and lock nuts. Tighten cap bolts to snug fit.

Equalize differential assembly (approximately) by having the same amount of thread engagement on both bearing lock nuts.


Tighten the lock nuts until there is a substantial drag on the ring gear. This can be measured by applying a string, wrapped around the differential case, and pulling on the string with a spring scale. Scale should read from 30 to 50 pounds at this stage of assembly.

Loosen the lock nut on one side until drag is just noticeable. If scale is used, it should read from 2 to 8 pounds.

Tighten the cap bolts. Drag will increase due to the compression of the outer bearing races.

A scale reading from 10 to 20 pounds is acceptable. If a gauge \* for checking across the surfaces on the bearing caps that enter the housing backup pads is available, check the dimension across these surfaces. They should not exceed .005" over the original dimension before pre-load was applied. FWD has standard No-Go gauges that are designed for this purpose and are available through the Service Department.

\*The Gauge is not necessary to make correct adjustments. It is used where a large number of carriers are to be assembled.



If dimension exceeds the required amount, back off one of the bearing lock nuts one notch. Loosen the cap bolts to allow the bearing cup to slide and retighten. If no gauge is available, use the housing as a guide. Carrier should not be forced into the axle housing by use of the mounting studs or bolts.

Mark the position of the bearing lock nuts with chalk.



## Illustration #19

Attach a dial indicator to the differential carrier and check the ring gear for run out. Maximum permissible run out is .005". Run out exceeding .005" indicates the differential case has become sprung or distorted and must be corrected by machining or by replacing the case. (Shown in Illustration #19)




Illustration #18





Illustration #19

Illustration #20  
(Next Page)

The pinion assembly consists of the pinion carrier, pinion, two tapered bearings, two bearing cones and a bearing spacer.

Illustration #20

The two tapered pinion bearings and the caps for the bearings in the W-50-P differential



are not the same size. The larger of the two bearings is positioned toward the pinion gear, the large diameter of the bearing toward the pinion gear. A press should be used to install the bearing. The bearing in the W-150-P pinion assembly are the same size.

Illustration #20




Illustration #21

Press the two bearing cups into the pinion carrier. Press the cups into the carrier until they bottom on the flange in the carrier. Place the bearing spacer on the pinion shaft next to the bearing.

Illustration #22

Proper preload on the tapered pinion




Illustration #21

Illustration #22

bearings is extremely important; therefore the bearing spacers are available in various sizes or thicknesses. The following is a suggested method to determine the approximate thickness the spacer must be to obtain the proper preload on the pinion bearings. Place the pinion shaft, bearing and spacer in the pinion carrier.

Illustration #23

Install the outer tapered bearing on the pinion shaft next to the bearing spacer. Install the pinion yoke and nut. Do not install the cover plate and oil seal until after correct preload on pinion bearings has been established. Place pinion assembly in a vise and torque pinion nut to 350-500 ft. pounds. See Illustration #24.




Illustration #23




Illustration #24




Illustration #25

Illustration #25

With the pinion carrier resting firmly on the tapered bearing, adjust the dial indicator so that the pointer rests on "0". Grasp the carrier and lift upward until upper tapered bearing is firmly seated. check the dial indicator reading; the figure the pointer

indicates is the amount of end play between the tapered bearings. Add .002" to the end play reading on the dial indicator; the end play reading on the dial indicator plus .002" subtracted from the thickness of the spacer is the approximate thickness the spacer should be to obtain the correct preload on the pinion bearings. If a spacer of the correct size is not available, the thickness of a spacer can be reduced in a lathe or surface grinder. If a lathe or surface grinder is not available, a few thousandths of an inch can be removed as follows; Place a sheet of emery paper or other abrasive on a flat surface, such as a piece of glass, slide the spacer back and forth across the abrasive until the proper amount of material has been removed. After the spacer has been machined or ground, reassemble the pinion, spacer and bearings in the pinion carrier. Install the yoke and pinion nut, again torque the nut to 350-500 ft. pounds. (Note: Do not install oil seal and cover plate). Place pinion assembly in

free end of the cord to a spring scale, pull on the scale to keep the yoke rotating. Read the pointer on the scale with the yoke rotating.




Illustration #26

The correct preload on the tapered pinion bearings is between 15 and 20 inch pounds. The pinion yoke neck on the W-50-P differential is 3-1/2" in diameter; therefore the reading on the spring scale should be between 8.5 and 11.5 pounds. If the reading on the scale, with the yoke revolving, is less than 8.5 pounds, the spacer is too thick and must be changed or ground. If the scale reading is more than 11.5 pounds, the spacer is too thin and will have to be replaced with a thicker spacer.

The pinion yoke neck on the W-150-P differential is 4" in diameter; therefore the reading on the spring scale should be between 7.5 and 10.0 pounds. If the reading on the scale, with the yoke revolving, is less than 7.5 pounds, the spacer is too thick and must be changed or ground. If the scale reading is more than 10.0 pounds, the spacer is too thin and will have to be replaced with a

thicker spacer.

After the correct pinion bearing preload has been established, the yoke must be removed so that the outer cover and seal can be installed. The yoke can be reinstalled after the cover is in place; again, torque the pinion nut to 350-500 ft. pounds. The following illustrations show the pinion assembly being installed to the differential carrier without the yoke so that the sequence of shims and the gasket can be seen in their respective positions.

Metal spacer shims are installed between the differential carrier and the pinion housing, a gasket between the pinion housing and the outer cover. The total thickness of the shim pack may vary slightly; however, a total of .060 is suggested to start with. Shims may have to be added or removed to obtain a good tooth pattern between the ring gear and pinion.




Illustration #27

Install the pinion assembly and cover gasket.




Illustration #28

Illustration #28

Install the pinion oil seal in the housing cover. The seal is pressed in the cover from the inside face.

Illustration #29

Install the cover and yoke. Torque the cover capscrews to 140-160 foot pounds, dry threads.

Ring Gear and Pinion Adjustment.

The side carrier bearing caps have previously been adjusted to a snug fit against the bearings.




Illustration #29



Attach a dial indicator to the differential carrier so plunger contacts a tooth on the ring gear. Check ring gear back lash. The minimum back lash is marked on the ring gear, the back lash can be several thousandths more than the markings on the ring gear, never less.




Illustration #30

If the back lash between the ring gear is not correct, loosen the four bearing cap capscrews so that the bearing adjusting nuts can be rotated. If there is too much back lash, rotate the bearing adjustment nuts so as to move the ring gear toward the pinion; if not enough back lash, move the ring gear away from

the pinion. Back off the bearing adjusting nut one notch at a time and tighten the opposite adjusting nut one notch at a time so as to retain the side bearing preload. Continue this procedure until the correct ring gear- pinion back lash is established.

After the ring gear-pinion back lash has been adjusted correctly, the next step is to check the tooth contact or pattern. Paint the ring gear with red lead or equivalent, place as much drag




on the ring gear as possible by hand. Rotate the pinion yoke until the ring gear has rotated several turns in each direction.

The following tooth pattern illustrations were obtained from photographs of a ring gear and pinion in a test machine. The braking action produced by the machine is greater than it is possible to produce by hand; therefore, the tooth pattern shown in the illustrations may be longer than those obtained with reduced drag between the gears.

The correct tooth pattern for the drive side or convex side of the ring gear teeth is shown in illustration 31. The bearing or contact pattern starts near the toe and extends approximately 60% of the length of the tooth toward the heel. The bearing pattern will progress toward the heel as load pressure is increased.

Both sides of the ring gear teeth must be checked. The correct pattern for the reverse or concave side of the ring gear teeth is shown in




Illustration#31


Illustration #32. (See next Page) The pattern is similar to the pattern on the drive side of the teeth. Please note, the contact pattern is in the same position on both sides of the ring gear teeth. Similar patterns on both the convex and the concave side of the ring gear teeth can occur only when the adjustment is correct. Checking

the pattern on both sides of the teeth is important and must be done when adjusting the ring gear and pinion tooth contact.


Illustrations #33 and 34 are photos of the type of patterns



Illustrations #32



Illustrations #34



Illustrations #33

resulting from the shim pack between the differential carrier and pinion housing being too thick. The pinion is back .030" from the

true or correct position.

Illustration #33 is the drive or convex side; #34 is the reverse or concave side of the ring gear teeth. Note the difference in the two patterns on opposite sides of the ring gear teeth. The concave side of the teeth has the pattern reversed, compared to the convex side. This is a normal reaction; the tendency is for the patterns on opposite sides of the teeth to reverse or run in opposite directions whenever the pinion is not positioned correctly.

A ring and pinion adjusted as shown in illustrations #33 and 34 would have very short life and would be noisy. The photos were taken under controlled conditions; therefore, knowing the pinion was .030" out or back of the correct position, removing .030" shims from the shim pack will correct the setting. The .030" figure is used only as a guide to make it easier to estimate the amount of shims to be removed when adjusting a differential and comparing patterns from the photos with the pattern of the actual adjustment.

Changing shims in the shim pack will also change the back lash between the ring gear and pinion. Readjust the back lash as described previously; be sure to adjust both side bearing caps to retain the side bearing preload.

Illustrations #35 and 36 are photos of the pattern resulting from the pinion set too far into the differential and ring gear. The pattern on either side of the ring gear teeth is not good; the wear pattern extends too far toward the toe on the drive or convex side and extends too far toward the heel. Illustration#35. The pattern on the reverse or concave side. Illustration #36 extends too far toward the toe, is too long and too narrow. Early failures and noise could be expected if a ring gear and pinion were adjusted so as to have a pattern as shown on Illustrations #35 and 36.




Illustration #35

The pinion in Illustrations #35 and 36 has been extended into the differential assembly .030" beyond the proper setting. The correction is to add .030" shims to the pinion assembly shim pack, to move the pinion back. In actual

practice, it may be necessary to use the trial and error method in adding or removing shims until the proper setting is reached. The .030" figure in the illustrations are meant to assist in estimating how many shims are to be added or removed to obtain a perfect pattern.

We cannot over-emphasize the importance of proper gear adjustment, including both the wear pattern and ring gear-pinion back lash.

Page 23 Continued

At the final adjustment, the carrier bearing lock nuts should be indexed to the same number of notches. Example: When one side indicates the nut was turned in five (5) notches, the opposite nut should be turned out (5) notches from the marks obtained. This will insure the pre-load adjustments made previously on Page 11 will be in the acceptable range.

A recheck across bearing caps with the gauge should indicate the same dimension obtained in previous adjustments.

\*If no gauge is available, use the housing as a guide. Forcing the carrier in the housing by using excessive wrench force on the carrier mounting studs is not recommended. Housing should be withdrawn and pre-load relieved by backing nut on gear side off one notch. The slight shift from this adjustment will not vary the gear pattern or backlash enough to cause incorrect gear mesh. If more than one notch is required, recheck pattern and backlash adjustments.

Tool Gauge Numbers -

40121 - W50P - W30P

40136 - W150P - W100P - W130P

**INTENTIONALLY BLANK**

After all Adjustments are complete, torque the side bearing cap cap-screws to 430-460 ft. pounds - dry threads for the W-50-P differential and 600-630 ft. pounds - dry threads - for the W-150-P Series. Install the safety wire in the




Illustration #36

bearing cap capscrews and install the side bearing cap locks. (See Illustration #37 Below)




Illustration #37

A tubular oil scoop is used to pick up lubricant from the ring gear. The lubricant is forced through the scoop and directed through passages in the carrier to the tapered pinion bearings. The scoop is spring loaded and contacts the ring gear. The scoop is inserted through the drilled opening in the carrier, place the scoop against the ring gear with the slanted end of the scoop against the ring gear, install the spring and secure the assembly with the pipe plug. (See Illustration #38)

Some ring-gear-pinion ratios do not permit the oil scoop to contact the ring gear. A set screw through the side of the oil scoop bore retains the scoop in a fixed position. To adjust the scoop, place a .010" feeler gauge between the scoop and the ring gear, push the




Illustration #38

scoop so that it touches the feeler gauge, tighten the set screw and remove the feeler gauge. Install the pipe plug.


The back-up plug must be adjusted after all other differential adjustments have been made. Adjusting procedure is as follows: loosen the jam nut, screw the plug in until it touches the ring gear. Back the plug off one-half turn and retighten the jam nut. Periodic checks of the plug adjustment must be made to compensate for normal wear. A satisfactory time to re-check the adjustment is at the time



The differential assembly is now ready to be installed in the axle housing. A carrier gasket is used between the axle housing and the carrier in the W-50-P model axle. Coat the carrier and axle housing gasket surface with Permatex Form-A-Gasket Type 3 before installing the gasket. Install the differential assembly and torque the carrier-housing capscrews to 160-180 ft. pounds - dry threads.

The W-150-P axle assembly does not use a gasket between the differential carrier and the axle housing; Lock Tite Plastic Gasket is used. The carrier capscrews are torqued the same as the Model W-50-P, 160-180 ft. pounds.

The axle spindles are to be installed next. A photo of the



spindle is shown in Illustration #39.

Gaskets are not used between the spindle and the axle housing. Use Permatex Form-A-Gasket Type 3 between the spindle and housing on the W-50-P assembly. Plastic gasket is used between spindle and housing on the W-150-P Assembly. Install the spindle

to the axle housing so that the groove for the hub bearing lock washer is at the top.




Illustration #40

Illustration #40

The axle assembly shown in Illustration #40 is lying on the side; therefore, the groove in the spindle is on the side.

Illustration #41

Goodrich hydraulic brakes may be used in both series axles. Service instructions covering maintenance and adjustments are in Section 18 of this manual. A photo of the Goodrich brake assembly is shown in Illustration #41.





Illustration #41

Illustration #42




Install the brake over the same studs to which the skein is attached. The hydraulic inlet port is to be at the top vertical position of the brake assembly. Install the hardened washers and nuts, torque the nuts to 160-180 ft.pounds on the W-50-P assembly, 650 to 680 ft.pounds on the 3W-150-P assembly.

Illustration #42

Illustration #43

The brake drum and dust shield must be removed from the hub if the inner bearing or oil seal is to be replaced. The brake drum and dust



shield have been removed and the seal and bearing are shown in Illustration #43.

Illustration #43

Illustration #44




Illustration #44

Reassemble the dust shield  
and brake drum to the hub.

Torque the brake drum capscrews to  
160-180# ft. for W50P, 290 to 300#  
ft. for W150P. dry threads - in  
either series axle.

Install the hub onto the  
axle spindle.

Illustration #45

The planetary ring  
gear is secured to the ring  
gear hub by four plates and  
eight capscrews. Torque the  
eight capscrews on either  
series axle to 50-58 ft. pounds.  
Secure the capscrews with lock  
wire. Install the outer hub  
bearing. The inner bore of  
the ring gear hub is splined  
to match the splines on the





Illustration #45

axle skein. Line up the splines between the spindle and ring gear hub.  
Slide the assembly into the wheel hub-outer bearing on the ring gear hub  
toward the inside of the axle hub.



A conventional inner  
hub bearing nut with  
locking peg, lock

Illustration #46

washer and outer jam nut are used to secure the ring gear hub assembly and adjust the hub bearings.

Thread the inner adjusting "nut with lock peg toward outside" onto the axle spindle. Adjust the nut so that the hub bearings are snug, check the preload on the bearings by wrapping a cord around the hub, "similar to checking the preload on pinion bearings -

Illustration #26 - Page 16. Attach a spring scale to the free end of the cord and pull on scale. The breakaway force should read between 15 and 20 pounds on either series axle. In other words, the spring scale should indicate a reading of between 15 and 20 pounds before the hub revolves; after the hub starts revolving, the scale reading will be less.

Install the lock washer and outer jam nut, tighten the jam nut and recheck the bearing torque. Readjust if necessary.

Illustration #46 and the above instructions cover the W-50-P axle hub bearing nut and lockwasher. Illustration #46A shows W-150-P hub bearing locknut and keys. Adjustment instruction for the W-150-P are the same as above.




Illustration #46A




Illustration #47

Illustration #47

The outer portion of the planetary assembly for each hub consists of the cover, planetary, the spider planetary, three planet

gears, three planet gear pins, six thrust washers, six bearings, three spacers and three lock balls. All parts, less the planetary cover and the planetary spider, are shown in Illustration #47

Illustration #48

Install two bearings, "one spacer between the bearings", in each planet gear. Place a thrust washer on each side of the gear and insert gear assembly in position in planetary spider. Insert the planet gear pin through the spider from the outside, line the planet gear assembly with




Illustration #48

the pin and tap pin through the gear. Caution must be used so as not to damage the bearings or spacer when tapping pin through the gear assembly. Place the lock ball in the recess for the ball in the pin, tap pin and ball into the spider until the pin is flush with the outside face of the spider. Peen the spider slightly over the lock ball

to secure the pin.

Install the two additional gear and pin assemblies and attach the spider to the hub. Plastic Gasket is used in place of Gaskets in both series axles. Torque the retaining capscrews to 160-180 foot pounds, either axle.

The sun gear is splined to match the splines on the outer end of the axle shaft. The sun gear is secured to the axle shaft with a snap ring. A thrust washer is placed between the sun gear and the planet spider. (See Illustration #49 Below)



Illustration #49

Place the thrust washer over the outer end of the axle shaft, slide the sun gear onto the axle shaft and install the snap ring. Install the axle shaft assembly in through the planetary hub, through the axle housing. Line up the inner axle spline with differential side gear and engage the sun gear with the three planet gears. Slide the axle assembly all the way into the housing and planetary hub. (See Illustration 2 Page 3)

Install the planetary cover plate. A gasket is used in the W-50-P axle and the capscrews are torqued to 50-58 foot pounds. A gasket is also used in the W-150-P series axle and the capscrews are torqued to 80-90 foot pounds.

The axle assembly is now complete and if removed from a vehicle, can be reinstalled. Fill the differential to the level plug with multi-purpose gear lubricant, meeting MIL Spec #MIL-L-2105,

Type SCL. For summer operation, use No. 90 viscosity - for winter.

No. 80

The planetary system and hub bearings use the same type lubricant as the differential and the same viscosity, depending on temperature or season. Rotate the hub so that the level plug in the planet cover is at the low vertical position and fill to the plug.

See Illustration #1 Page 3.

FORM 80-47

RAYGO WAGNER INC.