



Carefully follow these instructions and warnings to help prevent personal injury or damage to your Lumberjack:

1. Park on firm level surface and lower carriage to ground.
2. Engage parking brake and remove key from key switch. Tag key switch "DO NOT START" and follow your company's Lockout Procedure to ensure that the engine is not inadvertently started.
3. Block wheel on opposite side of wheel to be raised.
4. Use jack(s) in location(s) illustrated. Make sure jacks are directly below the corner of tank (where the bulkheads meet). Use pads (anti slip material) that are minimum 4" x 4" in size between jack and Lumberjack to prevent damage.

REAR

Use two jacks when raising rear of Lumberjack. Each jack should be capable of lifting at least 20% of machines weight or 45,000 lbs (20,411 kg). Use one on each side.

FRONT

Use a jack(s) capable of lifting at least 40% of machine's total weight or 90,000 lbs (40,823 kg). Use two jacks when lifting entire front end, one on each side.

5. Place jack stand(s) where illustrated. The jack stand(s) must be capable of holding entire weight of machine. Use pads (anti slip material) that are minimum 4" x 4" in size between jack stand(s) and Lumberjack to prevent damage.

⚠ WARNING

Never rely on a jack or any lifting device to hold the weight of the Lumberjack. Always use jack stands capable of holding the entire weight of the machine.

⚠ WARNING

Do not let any person on or under the Lumberjack while the machine is on a jack or any lifting device.

Please call Allied Systems service department with any questions (503-625-2560).