

Transmission Circuit

Check Points

- A. CLUTCH PRESSURE
- B. CONVERTER INLET
- C. CONVERTER OUTLET
- D. CONVERTER TEMPERATURE CONNECTION
- E. LUBE PRESSURE
- F. COOLER INLET PRESSURE
- G. COOLER OUTLET PRESSURE
- H. COOLER OUTLET TEMPERATURE

