


a division of allied systems company



LUMBERJACK

L120D

OPERATOR'S

MANUAL

Section 1 General



Fig. 1-1 Wagner L120D Lumberjack

1.1 Introduction

This manual is your guide to correct operation of the Wagner L120D Lumberjack. Become familiar with it, understand it, and use it. Read all instructions carefully prior to operation. They will help you understand the unit, its capabilities, and its limitations.

As an operator, it's your responsibility to make certain that your Lumberjack operates at maximum efficiency, with the greatest possible safety. It is also your responsibility to keep it in top operating condition through proper operating techniques and correct operator maintenance. Remember, safe and efficient operation is up to you - the operator.

The Lumberjack, workhorse of the logging industry, has proved itself the world over. It can unload a full truck load or rail car load of logs with a single bite. And...the load may be decked, dumped in mill ponds, or transported directly to the mill, covering every distance with speed and agility. The Lumberjack is also a time and labor saver in splitting loads and sorting within log yards.

Rugged construction and ease of service contribute to the Lumberjack's long life and low maintenance. And the Lumberjack's superior visibility and responsive controls result in a fast, efficient and safe operation.

1.2 Machine Identification

Typical MODEL, SERIAL NUMBER, and LUBRICATION plates are shown in Fig. 1-2. These plates are securely fastened to the cab superstructure on the right side.

The lubrication plate lists the time intervals, specifications, temperature limits, and viscosity requirements of lubricating oils and greases. For further lubrication information, see Section 5 of this manual.




Fig. 1-2 Lubrication and Identification Plates

NOTE: The importance of the machine's model and serial numbers cannot be overstated. Always have these numbers at your fingertips when requesting parts, service, or operation information of any kind. It is from these numbers that our Service Department creates a unit file in which a complete history of your machine is maintained.





a division of allied systems company

SPECIFICATIONS

L-120D (British Columbia)

LUMBERJACK



	n	~	i	n	^
_	n	u	1	11	C

Make and Model						Caterpillar 3408T TA-DI
Max Horsepower						475 @ 2100 RPM
Max Torque						1389 Ft/Lbs
Bore and Stroke						5.4" x 6"
No. of Cylinders						8
Displacement .						1099 Cu/In (18 liters)

Air Cleaner

Donaldson Two Stage Dry Type

Electrical System

Type .									24	٧	olt	Ne	ga	ativ	е	Gr	ou	nd	/24	٧	olt/	Start
Alternator																					75	AMP
Circuit Bre	ak	ers	(li	gh	ts)																30	AMP
Circuit Bre	ak	ers	(a	cc	es:	sor	γ)														20	AMP
Batteries (2)						•				12	V	olt	-8[0	D 2	205	5 A	M	ا د	Hr.	each

Torque Converter

Clark Single Stage, 3 Elements

Transmission

Clark 8421 Series Power Shift - Spur Gear; 4 Speeds Fwd and Rev.

Ra	ng	е				Ratio					Speed (Unladen)
1						. 4.07:1					3.8 mph (6.1 km/h)
2						. 2.26:1					6.6 mph (10.6 km/h)
											11.0 mph (17.7 km/h)
4						71.1					Blocked

Axles

Fabricated												Allie	ed Wagne	r
Make													Clarl	k
Model												.FD-85	000 Series	s
Type														
Brakes .														
Brake Size						1	* x	: 3	7-	Dia	₽.	(25mm	x 940mm)

Tires

Size (Front)								(D	ua	ıl)	24.00	x 35-36PR
Size (Rear)											26.5	x 25-24PR

Hydraulic System

"Power Beyond" hydraulics with total capacity of all pumps in the system for multiple use simultaneously. Function controls are air over hydraulic or optional hydraulic over hydraulic.


Steering Cylinder (2)				4" x	20"	(102mm x 508mm)
Hoist Cylinder (2) .				10" x	123"	(254mm x 3124mm)
Tilt Cylinder (2)				10" x	34.5"	(254mm x 876mm)
Holddown Cylinder (2)				6" x	56"	(152mm x 1442mm)
Kickoff Cylinder (2)				6" x	36"	(152mm x 914mm)

Service Refill Capacities

Fuel Tank							. 450 Gals (1703 liters)
Hydraulic Oil							. 350 Gals (1325 liters)
Crankcase w/Filter							. 13 Gals (49 liters)
Cooling System .							. 24 Gals (91 liters)

L-120D

(British Columbia)



Dimensions (approximate)

Α.	Wheelbase	30,	0" (9144mm)	K.	Distance from Axle to Holddown
B.	Height to Top of Cab	15'	6" (4724mm)		Tip for Reach
C.	Ground Clearance Chassis	2'	6" (762mm)	L.	Turning Radius Tail Swing
D.	Carriage Height	17'	7" (5359mm)	M.	Width Outside Chassis Tires
E.	Mouth Opening	12'	4" (3759mm)		Width w/Optional Wide Track Axle 20' 6" (6248mm)
F.	Tine Length	10'	3" (3302mm)	N.	Inside Turning Radius
G.	Overall Length	50'	0" (15240mm)	Ο.	Carriage Width
H.	Ground to Fork-Hoist Up	18'	0" (5486mm)	P.	Axle to Face of Carriage
J.	Ground to Holddown Tip				Hoist Down
	Carriage Down/Holddown Up	23'	3" (7087mm)	Q.	Width Inside of Tines 6' 7" (2006mm)
				R.	Width Outside of Tines 8' 7" (2616mm)
187-	Tarket and the same of the sam				

Weights and Functions (approximate)

Unit Weight	(73,181 kg)	Forward Tilt @ Ground Level	
Drive End	(45,910 kg)	Forward Tilt @ Max Height	
Tail End 60,000 lbs	(27,216 kg)	Backward Tilt @ Ground Level	
Rated Lift Capacity 54"LC	(54,432 kg)	Backward Tilt @ Max Height	



a division of allied systems company

13985 S.W. Tualatin-Sherwood Road Sherwood, Oregon 97140 U.S.A. Telex 261985 ASCWAGNER MARINE Telephone 503/625-2560 FAX 503/625-5132

Section 2 Safety



2.1 Safety Is Your Business

Why? Because SAFETY, based on knowledge, technical skill, and years of experience has been carefully built into your Wagner Lumberjack. Time, money and effort have been invested in making your machine a safe product. The dividend from this investment is YOUR PERSONAL SAFETY.

However, it must be realized that no power-driven equipment can be any safer than the person behind the controls. If you don't operate and maintain your Lumberjack safely, our efforts will have been in vain.

The safety instructions and warnings, as documented in this manual and shipped with the machine, provide the most reliable procedures for the safe operation and maintenance of your Lumberjack. It's your responsibility to see that they are carried out. The following terms define the various precautions and notices in this manual:

NOTE: Whenever information exists that requires additional emphasis beyond the standard text, the term "NOTE" is used.

IMPORTANT: Whenever information exists that requires special attention to procedures or to ensure proper operation of the equipment or to prevent its possible failure, the term "IMPORTANT" is used.

CAUTION: Whenever potential damage to equipment exists, requiring correct procedures for prevention, the term "CAUTION" is used.

A WARNING

Whenever potential personal injury or death situations exist, requiring correct procedures or practices for prevention, this "WARNING" symbol is used.

This safety alert symbol indicates important safety messages in this manual. When you see this symbol, carefully read the message that follows and be alert to the possibility of personal injury or death.

NOTE: All possible safety hazards cannot be foreseen so as to be included in this manual. Therefore, the operator must always be alert to possible hazards that could endanger personnel or damage the equipment.

2.2 Operation Warnings

- You must be trained in the operation of this machine prior to operation.
- Be extremely careful if you do not normally operate this machine. Re-orient yourself to the machine before starting, and then proceed slowly. However, you must not operate without having received proper training.
- Know your company's log yard rules. Some have specific loading directions and procedures. The methods outlined in this manual provide a basis for safe operation. Because of special conditions, your company's log handling procedures may be somewhat different from those shown in this manual.
- Always face the ladder when going up and down ladders. Use both hands.
- Never jump on or off the machine.
- All walking surfaces (steps, ladders, etc.) must be free of ice, grease, oil, or other materials that could cause or contribute to a slip or fall.
- The only person required on the machine is the operator. Never allow anyone to ride on the machine or its attachments.
- Do not operate this machine if you know of malfunctions, missing parts, and/or mis-adjustments.
 These situations can cause or contribute to an accident or damage to the machine. Stop the machine immediately if problems arise after starting.


- The hydraulic tank heater and/or engine block heater use a 110 or 220VAC external power source. An electrical shock could be fatal.
- All electrical cables and connectors must be in good condition. Use caution in wet weather to avoid danger from electric shock. The hydraulic tank and/or engine block heater must be properly grounded.
- Do not operate the machine before disconnecting hydraulic tank or engine block heaters.
- Do not start the engine if the key has been tagged with a "DO NOT START" or "RED" tag.
- Never operate any of the cab controls from anywhere other than the operator's seat.
- Sound the horn to alert personnel in the area before starting the engine, and make sure everyone is clear.
 Be sure that all controls are in neutral before starting the engine.
- Be aware that several people can stand in the engine compartment, completely out of sight of the operator.
- For maximum visibility and overall safety, travel in reverse whenever possible. Always travel in reverse when the machine is loaded. Keep the load as low as is practical. Be aware that the stability of the machine can vary with changes in slope, load, and the position of the attachments. Do not exceed the rated load of this machine.
- Never allow the binder chains to be removed from the load until it is securely clamped by the holddown arms or secured by some other means provided by your company.
- Never pass a load over the head of anyone. Sound the warning horn and wait for the area to be cleared before moving the machine or load.
- Be accurate in load placement. It's important to know what the load will do when it's released.
- Lower or remove the load before leaving the cab or shutting down the engine.

It is unlawful to operate this equipment within 10' of high voltage lines

 Electrical energy under high voltage can discharge to ground through the machine without direct contact with the machine's structure. Minimum clearances from energized power lines or other power sources must be maintained. If electrical energy does discharge through the machine, Remain In The Cab. Do Not Permit Anyone To Come Into Contact With The Machine's Structure.

2.3 Maintenance Warnings

- Maintenance, lubrication and repair of this machine can be dangerous unless performed properly. Each person must satisfy himself that he has the necessary skills and information, proper tools and equipment, and that his work method is safe, correct, and meets his own company's requirements.
- Do not attempt to make adjustments, or perform maintenance or service unless you are authorized and qualified to do so.
- Unless specified in this manual, never attempt maintenance or lubrication procedures while the machine is moving or the engine is running.
- Keep hands, feet, long hair and clothing away from power-driven parts. Do not wear loose fitting clothing or jewelry while performing maintenance and lubrication.
- Before performing maintenance or service under the machine, move the machine to a level surface, engage the parking brake and stop the engine.
- Tag the key switch with a "DO NOT START" sign, and/or remove the key.
- Block the tires to keep the machine from rolling.
- Perform all maintenance and lubrication procedures with the machine on level ground, parked away from traffic lanes.
- Never rely on the hydraulic system to support any part of the machine during maintenance or lubrication. If necessary, support components with appropriate safety stands. Never stand under a component that is supported only by the hydraulics. Make sure it is resting on its mechanical stops.
- Use caution when working around hot oils. Always allow lubricating and hydraulic oil to cool before draining. Burns can be severe.
- Diesel fuel and hydraulic oil are flammable. Do not smoke when checking levels or filling tanks. Keep open flames and sparks away from the machine.



- Keep the machine free of oil, grease and trash accumulations. Regular steam cleaning is recommended for fire prevention and general safety.
- Never overfill the fuel or hydraulic tanks. Any overflow could cause a fire. Immediately repair any hydraulic or fuel leaks and clean up any spills.
- Use extreme caution when using compressed air to blow parts dry. The pressure should not exceed 30 psi (208 kPa). Never use air to blow yourself off. Air pressure penetrating your skin can be fatal.
- Engine exhaust fumes can cause death. If it is necessary to run the engine in an enclosed space, remove the exhaust fumes from the area with an exhaust pipe extension. Use ventilation fans and open shop doors to provide adequate ventilation.
- DO NOT remove the radiator cap when the engine is hot. The coolant will be under pressure and can flash to steam with explosive force, causing severe burns. To prevent burns, remove the radiator cap only when the engine is cool.
- Before disconnecting hydraulic lines, be sure to lower all loads and relieve all hydraulic pressure.
 The load could fall on you, or escaping hydraulic oil could cause severe personal injury.



- Batteries produce explosive gases. Keep sparks, flame and cigarettes away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries.

 When removing battery cables, always turn the battery disconnect switches OFF first, then disconnect the (-) negative cable.


 When installing a battery, always connect the (+) positive cable first.

 This procedure will help to prevent a spark which could cause an explosion.
- Before making adjustments on the engine or electrical system, disconnect the battery. An electrical spark could cause a fire, explosion or severe burns.
- Batteries contain sulfuric acid which can cause severe burns. Avoid contact with skin, eyes or clothing.
- Due to the extreme height of the upper lube points, it is essential to personnel safety that safe ladders, personnel lifts and/or scaffolding be used while servicing this machine. Always use safety tread walks and hand holds to reach lubrication points or to inspect or adjust the machine. These areas can be dangerously slick under conditions of rain, frost or oil smears.

CAUTION

- Before operating: Know your machine,
 Read the Operator's Manual.
- Operate at low speeds in crowded areas or soft terrain
- Avoid abrupt changes in boom direction.
 Do not drop load.
- Lower hydraulic equipment before leaving operators position.
- Shut power off before lubricating or making equipment adjustment unless otherwise specified in the Operator's Manual.
- Keep hands, feet and clothing away from power driven parts.
- Keep off equipment while operating unless seat or operators platform is provided.
 Keep all others off.
- Make certain everyone is clear of equipment
 before operating.
- .9. This machine is not designed for lifting or moving of persons.

Instruments and Controls



3.1 General

Become thoroughly familiar with the location and use of all instruments and controls before operating this machine. Check all instruments immediately upon starting, again

after reaching operating temperatures, and at frequent intervals during operation to assure proper care through prompt detection of irregularities. If any of the instruments does not register properly, stop the engine, and have the problem corrected as soon as practical.




Fig. 3-1 Instruments and Controls

3.2 Operator's Instruments

Engine Instruments

1. Engine Warning Light (red)

This light comes on and a warning bell sounds whenever engine oil pressure drops below a safe operating level or when engine temperature is excessive. On some models, the engine will shut-down automatically if the problem continues.

The light and bell are activated when the ignition switch is turned to ON. This ensures that the system is working.

2. Tachometer See Fig 3-2

An electrical tachometer indicating engine revolutions per minute (rpm). To read, multiply the indicated number by 100.

Example: indicated 20 x 100 = 2000 rpm.



Fig. 3-2 Tachometer

3. Voltmeter

The voltmeter indicates the voltage condition of the electrical system - whether the alternator is or is not charging. The numbers indicate volts (12Vshown). During operation, the needle should stay within the green area of the dial.



Fig. 3-3 Voltmeter



Fig. 3-4 Fuel Level Gauge

4. Fuel Level Gauge

5. Hour Meter See Fig. 3-5

Activated by engine oil pressure. It records the total elapsed time of actual engine operation.

6. Engine Oil Pressure Gauge See Fig. 3-6

Displays engine lubricating oil pressure. Determines pressure only - not amount. Should this pressure drop below that required by the engine manufacturer's specifications during operation, STOP THE ENGINE IMMEDIATELY AND DETERMINE THE CAUSE.



Fig. 3-5 Hour Meter



Fig. 3-6 Engine Oil Pressure Gauge

7. Engine Coolant Temperature Gauge

Displays engine coolant temperature. If the temperature holds steady at 200° F or higher, discontinue operation, allow the engine to idle for 3 to 5 minutes, and shut it down. Determine the cause before continuing operation. If a coolant hose failure occurs, shut the engine down

immediately.



Fig. 3-7 Engine Coolant Temperature Gauge

8. Air Filter Indicator

Standard location is outside the cab, mounted on the air cleaner housing. It indicates air filter restriction by showing "red" or "green". When the indicator locks into the "red" zone, the element must be serviced as soon as possible. To reset the indicator, press the button on top.

Transmission System Instruments

9. Transmission Circuit Pressure Gauge

Displays the oil pressure that drives the transmission oil clutches. Clutch pressure should be between 180 and 220 psi at engine idle speed. The pressure should not vary more than 5 psi between the four speed ranges.



Fig. 3-8 Transmission Circuit Pressure Gauge

10. Transmission Circuit Temperature Gauge

Displays converter oil temperature. This gauge should read between 200° - 250° F. If the temperature exceeds the maximum allowable, discontinue operation and report to appropriate service personnel.




Fig. 3-9 Transmission Circuit Temperature Gauge

- 11. Forward and Reverse Indicator Lights (optional) Lights indicate whether the transmission is engaged in "forward" or "reverse".
- 12. Converter Lock-up Pressure Gauge (optional)
 Used on units equipped with a "lock-up" converter. This
 gauge indicates pressure when the converter lock-up is
 engaged. Drops to zero when disengaged.

Brake System Instruments

13. Air Pressure Gauge

Displays air system pressure. Operating pressure is 60 to 120 psi. If air pressure drops below this level, a red light within the gauge will come on.



Fig. 3-10 Air Pressure Gauge

14. Low Air Warning Buzzer (Optional)

Buzzer sounds if air pressure drops below 60 psi.

15. Parking Brake Indicator Light (red)

If the key switch is ON and the parking brake is ON, this light will be on.

Hydraulic System Instruments

16. Hydraulic System Return Filter Indicator

Indicates the condition of the in-tank return filters. With the machine running and at operating temperature, the indicator should be in the green (safe) zone.

If the indicator moves into the red zone at operating temperature, the filter elements are restricted and should be changed.




Fig. 3-11 Hydraulic Return Filter Indicator

- 17. Pilot System Supply Filter Indicator Lights*
- 18. Steering System Supply Filter Indicator Lights*
- 19. L H Holddown & Kickoff System Supply Filter Indicator Lights*
- 20. R H Holddown & Kickoff System Supply Filter Indicator Lights*

*These lights indicate the condition of the high pressure supply filters.

With the machine running and at operating temperature, all three green lights should be on.

If the red light(s) flicker occasionally, filter service will be required soon.

If the red light(s) come on and stay on, filter service is required immediately.

NOTE: These lights (items 17, 18, 19, and 20) may come on and flicker until oil reaches operating temperature. This is normal.

3.3 Operator's Controls

Engine Controls

21. Battery Disconnect Switches (not shown)

Located in the battery compartment on the LH side of the machine, mounted to the left and right of the batteries. These switches isolate the batteries from the electrical circuits and should be set to "off" when the machine is not in use, or during maintenance and repair, to prevent unauthorized starting or electrical shorts. Turn the switches counter-clockwise to disconnect the battery.

CAUTION: If any arc welding is to be carried out on the machine's structure, it is extremely important that both disconnect switches be OFF. If the switches are left on, severe damage to the electrical system can result.

NOTE: On machines equipped with a fire the batteries suppression system, automatically disconnected whenever the system is actuated.

22. Cold Start Control

This control applies a measured amount of ether vapor to the intake manifold to ease cold engine starting.

23. Key Switch

The key switch is used to start and stop the engine and to turn the accessories on and off. This is a four position switch: ACC, OFF, RUN, and START.

When turning the key clockwise from the center, or OFF position, the first position to the right is RUN. The second position is START. The START position is spring loaded, and will return the key to the RUN position when released. ACC is to the left of OFF: this position is used for accessories only.

24. Hand Throttle

Manual control, pull for rpm increase. Overrides foot throttle. To lock in the OUT position, turn handle clockwise.

NOTE: Use for engine warm-up only

25. Accelerator Pedal

Foot controlled engine accelerator pedal.

26. Emergency Engine Shutdown

Used only with Caterpillar and Detroit Diesel engines. Use only in emergencies. Pull handle to stop engine.

Steering and Brakes

27. Steering Wheel and Column

28. Tilt Column Release Lever

To tilt steering wheel, pull lever back. To move telescopic wheel in or out, pull center knob to release the lock.

29. Parking Brake Control

To apply the parking brakes, pull the button out. To release the brakes push the button in.

30. Emergency Brake Release

Controls a separate air supply for overriding locked brakes in emergency situations. Button must be held down to release the brakes.

31. Brake Pedal

Will also "declutch" the transmission if the declutch valve (item 37) is ON.

32. Second Brake Pedal (optional)

Brake pedal only - will not declutch the transmission. When this second brake pedal is installed, the "normal" brake pedal (item 31) will always declutch, and the declutch control (item 37) is eliminated.

33. Engine Compression Brake Switch (optional)

Used only with converters with "lock-up" option. This switch actuates an engine brake mechanism to help slow the vehicle. Before the brake will engage, engine compression brake/lock-up clutch pressure must reach 150 psi and the converter "lock-up" switch must be ON. It will remain engaged until engine speed drops below 800 rpm or engine speed is increased.

NOTE: Maximum deceleration is achieved when both the converter "lock-up" and engine compression brake are applied simultaneously.

Transmission Controls

34. Transmission Control Handle See Fig. 3-12

To shift into "forward", release lock (item 35) and push handle forward.

To shift into "reverse", release lock (item 35) and pull handle back.

Neutral is the middle detent position.

NOTE: The transmission will not change directions if the engine speed is above 900 rpm.

To select a gear range, twist the handle until the index detent aligns with the desired speed range.

IMPORTANT: Always release the throttle slightly when shifting speed ranges. This will significantly reduce shock loads to drivetrain components. Also, you should always reduce engine rpm when down-shifting, as you can over-speed the engine.

35. Transmission Control Locking Lever

Prevents accidental transmission shifts. Locks the shift lever in position. Turn counter-clockwise to release. Affects direction only.




Fig. 3-12 Transmission Control Handle

36. Rear Axle Disconnect

Disengages and engages the rear drive axle. To engage, pull the lever back. To disengage, push the lever forward.

CAUTION: Never move the lever while the vehicle is in motion. Severe damage can result.

37. Declutch Control (models with 1 brake pedal)

If the control is ON, the declutch system automatically shifts the transmission into neutral when you apply the brakes. This allows you to perform all hydraulic functions at any rpm smoothly, without causing converter stall or other unnecessary strains on the brakes or drivetrain components.

If downgrades are encountered, the control may be turned to the OFF position, and the transmission will remain in gear when the brakes are applied.

This control should be left in the ON position for normal operations.

38. Converter Lock-up Switch (optional)

Some models are equipped with a "lock-up" clutch in the converter. This feature contributes to vehicle braking by allowing the transmission to be mechanically connected to the engine, eliminating converter slippage.

With this switch ON, the lock-up clutch engages every time the foot throttle is released while the engine is running over 1000 rpm. It will disengage when the engine speed drops below 900 rpm, or if engine speed is increased.

Implement Controls

39. Hoist & Tilt Control

Single lever control for both functions.

Push the lever forward to lower the boom and carriage. Pull the lever back to raise.

Push the lever right to tilt the carriage forward. Push the lever left to tilt it back.

The valve is spring loaded to neutral for both functions and will hold the load in its position at time of release.

40. Holddown Arm Controls, LH & RH

Push the lever forward to open the holddown arm. Pull the lever back to close the holddown arm.

41. Kickoff Arm Controls, LH & RH

Push the lever forward to extend the kickoff arm.

Pull the lever back to retract the kickoff arm.

Holddown and kickoff arms may be operated simultaneously or independently.

42. Auxiliary Holddown Controls, LH & RH

Push the lever forward to open the auxiliary holddown arm. Pull the lever back to close the auxiliary holddown arm.

Cab Controls

43. Circuit Breakers

Electrical circuit protection. Push to reset.

- 44. Front Windshield Wiper ON/OFF Switch.
- 45. Rear Windshield Wiper ON/OFF Switch (optional)
- 46. Defroster Fan Switch (window mounted)
- 47. Defroster Fan Switch (floor mounted)
- 48. Cab Heater Fan Switch
- **49.** Warning Flasher Switch (optional) ON/OFF switch for cab mounted flasher.
- 50. Carriage Mounted Lights Switch
- 51. Tilt Cylinder Mounted Lights Switch
- 52. Rear Lights Switch
- 53. Cab Mounted Lights Switch
- 54. Panel Lights Dimmer Control

55. Dome Light Switch

ON/OFF switch, mounted on light.

56. Stereo Cassette

AM/FM Radio and cassette player.

57. Seat and Controls Rotate Switch

Rotates seat and controls 45° in each direction. Switch is mounted on top of hoist and tilt control lever. To rotate left, press LH rocker. To rotate right, press RH rocker.

58. Seat Height Adjustment Control See Fig. 3-13

Push button to raise seat.

Pull button to lower seat.

59. Seat Forward and Aft Adjustment Release Lever

See Fig. 3-13

60. Seat Swivel Release Lever

Locks seat in forward facing position.




Fig. 3-13 Seat Adjustment Controls

61. Air Horn Pull Chain (not shown)

Suspended above operator's head.

62. Fire Extinguisher (hand held)

Mounted to the chassis to the rear of the boarding ladder.

63. Fire Suppression System (optional)

In case of fire, pull the safety pin on the actuator and strike the button. Fire retardant will be released, the engine will shut down and the batteries will be disconnected from the electrical system.

If possible, take the hand-held fire extinguisher, and **LEAVE THE VEHICLE**. After the system has discharged, watch carefully for flare-ups and spot fires.

Notify the Fire Department and/or service personnel as soon as possible.




Fig. 3-14 Fire Suppression System Actuator

NOTE: Two fire suppression system actuators are provided. Either one can set off the system. One is located behind the operator's seat. The other is mounted outside the chassis at ground level. Memorize the location of each. Some machines are equipped with an optional automatic fire detection and activation system.

64. Air Conditioner Temperature Control

65. Air Conditioner Fan Switch

The fan acts as a cab pressurizer if run without Air Conditioning (item 64 "off").




Fig. 3-15 Air Conditioner Controls

Operation 4

4.1 Introduction

You, the operator, have a key position in your company's log handling operation. Skill and alertness on your part are essential for maximum productivity as well as the safety of yourself and others.

The operating instructions in this manual are here to help you get the maximum use of your Lumberjack, with the greatest possible safety. Become completely familiar with all of the instruments and controls. Learn the unit, its capabilities and limitations. Study the operating techniques given so that through experience, you can develop additional techniques of your own and contribute to the success of your team.

Safety First

Your co-workers depend on you to operate safely. Before operating the Lumberjack, read and observe the safety precautions given in this manual. BE A SAFE OPERATOR. A good safety record can be rewarding.

4.2 General

The Wagner Lumberjack is easy to operate, even though it has the capacity to handle tremendous loads and perform many operations. To get the most production from this unit with the least effort, and in a safe, reliable manner, it's important to become familiar with all the components and their functions.

Drivetrain

The drivetrain consists of a diesel engine, a torque converter combined with a full power shift transmission, drivelines and planetary drive axle.

Engine

The diesel engines are standard industrial units, selected for the power characteristics and operating speeds required for each size model. They are equipped with electric starting motors and cold weather starting aids and will start in the same easy way as your automobile. We want to emphasize the importance of maintaining the correct engine rpm, for maximum engine service life and proper hydraulic pump operation.

Torque Converter

The torque converter is connected directly to the engine flywheel, eliminating a manually operated clutch, thereby simplifying operation and reducing operator fatigue. It also, to a major degree, hydraulically protects the engine, transmission, drivelines and axle from damaging shock loads and harmful engine lugging and stalling provided the correct engine rpm is maintained. It also multiplies engine torque in each transmission gear range, automatically adjusting the power output to the load demand.

Transmission

The transmission is a "full power shift - full reversing" unit.

"Full power shift" means that the transmission can be shifted from one range to the next, either up or down.

When shifting down, the engine rpm must be reduced sufficiently to prevent over-speeding the engine when the lower range engages.

IMPORTANT: Never shift the range selector up or down without momentarily relaxing the throttle pedal. Severe damage to the drivetrain could result.

"Full reversing" means that you have approximately the same speeds forward and reverse in all speed ranges.

CAUTION: Always brake to a full stop when changing directions. Drivelines are simply not strong enough to withstand the forces created when tons of vehicle and load are reversed suddenly.

The transmission uses constant mesh gearing in all ranges, forward and reverse. All gears are engaged by means of hydraulically controlled multiple disc clutches, through the control valve actuated by the shift lever in the cab.

Drivelines

Drivelines transmit the engine torque (after being multiplied by the converter and transmission) to the drive axle.

Drive Axles

The drive axles not only support the unit and load, but also further multiply the engine torque through gear reductions. The first reduction occurs at the ring gear and pinion in the differential. The second reduction is made in the outer planetary ends of the axle.

ear Bogie

The rear bogie provides a mounting for the rear axle. It is fully articulated - hinged for steering, and can swivel to negotiate rough terrain. Steering is accomplished by hydraulic cylinders.

Hydraulic System

The Wagner Lumberjack features advanced principles of hydraulic engineering. Instead of a single pump operating each function, all multiple pump applications have a primary and a secondary function. When any pump output is not being used for its primary function, instead of returning directly to the reservoir, the control valve diverts its flow to its secondary function. This principle is known as "power beyond".

Example 1: When only the hoist circuit is being used, you have the total capacity of three pumps to operate the hoist function. When hoisting and tilting the carriage simultaneously, the flow from the three pumps is divided between the hoist and tilt functions. When maximum power is required for hoist or tilt, operate the functions individually.

Example 2: When the carriage is tilted back (as in cold decking at maximum height), and the kickoff arms are actuated simultaneously, the primary flow of the holddown and kickoff pumps is directed to the kickoff cylinders.

Any remaining flow is diverted to assist the hoist and tilt circuits if required.

Example 3: Since the individually controlled holddown and kickoff arms are actuated by "series" type valves, flow from the RH holddown and kickoff pump will allow actuation of the RH holddown, and the return flow from that cylinder will allow the simultaneous actuation of the RH kickoff. Any remaining flow is diverted to assist the hoist or tilt functions.

Log Handling

An easy way to understand the overall idea of Lumber-




Fig. 4-1

jack operation is to visualize the carriage as a giant hand that can pick up, sort, spread and deck logs. See Fig. 4-1

The carriage functions consist of hoist, lower, and tilt forward or back.

The holddown arms are used to clamp the load against the carriage. They're also used to "rake" logs off a pile.

The kickoff arms push the logs off of the tines. They can also be used to help secure a partial load.

The holddown and kickoff arms can be actuated individually or in unison.

Break-in Period 4.3

The initial break-in period for your unit is limited to engine break-in. The hydraulic system and other components are ready for full operation.

The way you operate your new engine during the first 50 -100 hours will have an important effect on its service life. Its moving parts are closely fitted, and even though most diesel engines are dynamometer run before leaving the factory, an additional period may be required before uniform oil films are established between mating surfaces.

Generally speaking, proceed with a new engine as follows:

- 1. Operate most of the time at one half to three quarters full throttle. Do not operate at maximum horsepower for more than five or ten minutes at a time.
- 2. Don't idle the engine for long periods. This may cause cylinder wall glazing, resulting in excessive oil consumption and loss of power.
- 3. Keep a close watch on the instruments. Reduce rpm if water temperature reaches 200 ° F.
- 4. Operate in a gear low enough so that you can accelerate under any condition.
- 5. Study and follow the engine's operation manual for specific information.

The operator must assume the responsibility of engine care during operation. This is an important job and one that will determine to a large extent the success of the operation. Premature engine failures are very expensive because of lost productivity and the high cost of engine repairs or replacement. Protect your company's investment!

Start and Stop Procedures

Engine Pre-Start

Before operating this machine, the operator must have prior operator training, a familiarity with this manual, and a complete understanding of all the procedures and functions that may be performed with this machine.

Pre-start Inspection

Planned maintenance and inspections are to be performed after the machine has been delivered, and prior to each shift. The operator should be aware of these procedures and be able to perform spot checks during operation.

NOTE: These inspections may be performed by maintenance personnel or by the operator. In either case, it is the operator's responsibility to see that the machine is ready for operation prior to starting.

Refer to the planned maintenance chart, Section 5, for a complete list of the daily checks that are to be performed.

Engine Oil Level

The oil level should be checked prior to starting the engine.




Fig. 4-2 Typical Dipstick

NOTE: A 15 minute drain-back time is recommended (if the engine has been running) to obtain an accurate reading.

The oil level must be maintained between the "L" (low) or "add" mark, and the "H" (high) or "full" mark. Maintain the oil level as close to the "H" or "full" mark as possible.

CAUTION: Never operate the engine with the oil level below the "L" (low) mark, or above the "H" (high) mark. Refer to the engine's Operation and Maintenance manual for detailed engine service information.

CAUTION: Use only approved engine oil (see Lubricant Specifications Chart, Section 5). Do not overfill.



Engine Coolant Level

A WARNING

Never remove the radiator cap if the engine is hot. The coolant will be under pressure and could flash to steam with explosive force, causing severe burns. Remove the radiator cap only when the engine is cool.

Daily inspection of the coolant level is recommended. Cooling systems using anti-aeration baffles restrict visual observation of the true coolant level. If the coolant can be seen, the system may not be full. To gain a true fill, add water slowly up to the bottom of the fill neck and allow a 30 second settling period. Remember to compensate for the loss of anti-freeze when adding water.

NOTE: If the engine is hot, the coolant level will be higher than when it is cold.

Inspect the radiator daily for restriction caused by leaves, paper or other foreign material. Inspect the radiator, cap, hoses, and connectors for any signs of leakage or damage.

Hydraulic Oil Level

Always check the hydraulic oil level prior to operation. The dipstick and fill pipe are located on the RH chassis deck, to the right of the operator's cab.

CAUTION: Always open the tank breather petcock (located on the breather pipe) before removing the dipstick, filler cap, or in-tank filter cover plate. Failure to vent the tank can result in personal injury and/or a substantial oil spill. Be sure to close the petcock before operating the machine.

The oil level should be checked with the hoist cylinder retracted (down). The oil level should be at or near the "H" (high) mark on the dipstick. Fill with approved hydraulic fluid as required (See Lubricant Specifications Chart, Section 5). Do not overfill.

Transmission Oil Level

Always check that the transmission dipstick shows at least some oil prior to starting the engine. The level should be checked after engine warm-up, with the transmission at normal operating temperature. The dipstick and fill tube are located on the chassis deck, near the valve module and hydraulic brake actuators. Always check the level with the engine running, at operating

temperature, with the transmission in neutral. The oil level should be between the "H" (high) and "L" (low) marks. Fill with approved fluid only (See Lubricant Specification Chart, Section 5).

"Walk Around" Inspection

Perform a "walk around" inspection, looking for leaks, loose or missing fasteners, damaged hoses, structural cracks or damage, etc.

Do Not operate the machine until all problems have been corrected.

Tires

Visually inspect the tires for low air pressure and damage to the tread and side walls. If a tire appears suspect, appropriate maintenance personnel should thoroughly check it prior to operation.

Engine Pre-start

- 1. Make sure that oil and coolant levels have been checked before attempting to start the engine.
- 2. Sit in your normal operating position and adjust the seat for your personal comfort. It is recommended that you wear your seat belt.
- 3. Check for emergency/parking brake engagement: Pull the knob to set the brake. `
- 4. Place the transmission range selector in the "neutral" position, "N" on the gear quadrant.

NOTE: All current Wagner units are equipped with a neutral start switch which prevents the engine from starting unless the transmission is in neutral.

5. Give warning that you are going to start the engine. Remember, there is ample space within the engine, transmission, and driveline compartments for several people, and you cannot see them from the cab. Be sure that the area around the machine is clear of all personnel and obstructions.

WARNING

Don't start the engine if the key switch has been tagged with a "Do Not Start" or "red" tag.

6. Turn the key switch to the ON position. The emergency brake light and circuit lights should come on.

- Also, the engine protection system bell and light should come on.
- 7. With Caterpillar and Detroit Diesel Engines, check that the emergency shutdown control is pushed IN.

Engine Start-up

- Turn the key switch to the START position. Release the switch to the RUN position as soon as the engine starts.
 - CAUTION: If the engine does not start within 30 seconds, allow the starter to cool for at least 2 minutes before re-engagement.
 - In cold weather it may be necessary to use the cold weather starting procedure.
- 2. After the engine starts, let it idle. Do not accelerate. Remember, high rpm and full load conditions on cold oil can severely damage the engine, transmission and hydraulic system.
 - The engine warning light and bell should go out within a few seconds after starting. If engine oil pressure fails to rise sufficiently after approximately 40 seconds of running, the engine may automatically shut down.
 - IMPORTANT: Your Lumberjack is equipped with and audiovisual engine protection system. If oil pressure drops below a safe level, or coolant temperature becomes excessive, the engine warning light and bell will come on. With some models, if the condition continues, the engine will shut down automatically. If your unit is not equipped to shut down automatically, it is vitally important that you immediately shut down the engine if the light and bell go on.
- 3. If a rise in oil pressure of the engine or transmission is not observed within 5 seconds, or a rise in air pressure is not observed in 10 seconds, shut down the engine and have maintenance determine the cause of the problem. Do not operate the machine until the problem has been corrected.
- 4. Warm the engine at idle until the air pressure reaches at least 60 psi, then recheck that the transmission is in neutral and that the parking brake is applied.
 - Using the hand throttle, continue to warm the engine at 1000 rpm until the engine temperature reaches at least 130° F, and the air pressure rises to 120 psi.
- 5. Release the hand throttle. Meanwhile, observe the gauges for proper readings and operation. Also, check the operation of all safety equipment and accessories.

Cold Weather Starting Procedure:

NOTE: For maximum engine protection and easier starting:

Keep the batteries fully charged.

Keep the fuel clean and free of water.

Change the engine oil to the recommended viscosity for the air temperature.

- 1. Before cranking the engine, pull the "cold start" handle out. Wait 3 seconds for the valve to fill.
- 2. While cranking the engine, push the handle in to discharge the ether into the engine.
- 3. In extremely cold weather additional shots may be required to keep the engine running.

WARNING

Starting fluid is extremely flammable and toxic. Never smoke while using staring fluid. Never make a hole in the starting fluid container. Do not use near an open flame or put the container into a fire. Use only small amounts of starting fluid. Never store starting fluid in a hot area or the operator's cab.

Temperatures below 32° F (0° C):

- 1. Let the engine idle for approximately 15 to 20 minutes before putting any load on the engine. Check all gauges for normal readings.
- 2. After the engine is warm, move the machine to full work capacity slowly until the hydraulic oil is at operating temperature.

Temperatures below 0° F (-18° C):

CAUTION: If the temperature of the hydraulic oil is below its pour point, do not start the engine. The high oil viscosity could cause immediate pump cavitation, resulting in severe damage. The oil in the hydraulic tank must be heated prior to engine start-up.

If the machine will be shut down for several hours or longer with ambient temperatures below 32° F (0° C), the hydraulic tank heater should be plugged in as soon as the machine is shut down. This will help to maintain hydraulic oil temperature.

A WARNING

The hydraulic tank heater uses a 220 or 110 VAC external power source. An electrical shock could be fatal. Don't forget to disconnect the heater cable before beginning operation. All electrical cables and connectors must be in good condition. Use caution in wet weather to avoid danger from electric shock. The heater must be properly grounded.

Let the engine idle for approximately 10 minutes before putting any load on the engine. Check all gauges for normal readings. In extremely cold temperatures, allow sufficient warm-up time.

Engine Shut-down

- Move the throttle to idle speed, and let the engine idle for at least 5 minutes in order to normalize internal engine temperatures.
 - CAUTION: Except in emergencies, never shut the engine down immediately after operation. Allow the engine to idle for at least 5 minutes. Failure to do this could cause severe engine damage.
- 2. Meanwhile, place all controls in neutral and set the emergency brake.
- 3. To stop the engine, turn the key switch to the OFF position.

Detroit Diesel and Caterpillar engines

Normal shut-down is with the key switch. An emergency shut-down control is provided with these engines. Pull the handle to stop the engine. After the engine stops, push the "stop" control in and turn the key switch to the OFF position. If emergency stop procedures are ever required to stop the engine, make sure that the problem is checked by maintenance personnel before resuming operation.

4.5 Using Booster Batteries

A WARNING

Batteries produce explosive gases. Keep sparks, flame and cigarettes away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries.

If the batteries on the machine are weak or discharged, use booster batteries to start the engine. Never try to start the engine by towing or pushing. Use the following procedures:

- 1. Make sure that the parking brake is applied and that all electrical loads are stopped.
- To prevent damage to the alternator, use care not to reverse the battery connections. Immediate damage to the alternator can be caused by making an incorrect wiring connection during the starting procedure.

A WARNING

Batteries contain sulfuric acid which can cause severe burns. Avoid contact with skin, eyes or clothing.

- Connect one jumper cable to the (+) positive terminal of the booster battery. Connect the other end of the same cable to the (+) positive terminal on the machine's battery.
- 4. Connect the other jumper cable to (-) negative terminal of the booster battery. Connect the other end of this cable to a good ground connection on the machine's frame, away from the battery. This procedure will prevent a spark near the battery which could cause an explosion.
- 5. Start the engine in the normal manner. .
- 6. After the engine has been started, disconnect the negative cable first, then remove the positive cable.

WARNING

When removing battery terminals, always disconnect the (-) negative cable first.

When installing battery terminals, always connect the (-) negative cable last.

This procedure can prevent a spark at the battery which could cause an explosion.

Always make the last cable connection away from the battery, such as on the engine block. Use care to keep the cables clear of the fan or any other moving parts.

4.6 Moving, Stopping and Steering

To move the machine:

1. Make sure that the area is clear of obstructions and/or personnel. It is possible for several people to stand under or near the machine, out of sight of the operator. It is recommended that you sound the horn before moving the machine.

CAUTION: This machine cannot be stopped instantly. A varying distance is required to stop the machine, depending on load and speed. To avoid collisions, be sure to allow ample stopping distance.

- 2. Check that the air pressure gauge reads between 110 and 120 psi
- 3. Release the hand throttle.

CAUTION: Never attempt to operate with the hand throttle instead of the foot throttle. The hand throttle is to be used for warm-up only.

- 4. Place the Declutch control in the ON position.
- . 5. Lift the carriage, if required, to clear any obstructions you might encounter.
- 6. Release the parking brake and put the transmission range selector into 1st gear.

CAUTION: It is recommended that you operate in 1st gear only, until you develop a "feel" for the machine and become familiar with all of its operating characteristics.

- 7. Push the "forward" or "reverse" floor button. Pushing either of these buttons not only selects the direction of travel, but also shifts the transmission from neutral to "in gear".
- 8. Depress the throttle pedal slowly and smoothly. Avoid sudden or jerky starts. Depress the pedal just enough to begin moving slowly.

Steering:


With the operator facing the front, turning the steering wheel clockwise will turn the machine right, while turning the wheel counter-clockwise will turn the machine left.

9. Practice moving the machine around the yard. Make several practice stops to develop a "feel" for the brakes. Practice driving and steering in forward and reverse. Always use the brakes to slow and stop the machine - never gear down.

CAUTION: Keep the speed low until you feel comfortable with the machine.

Always bring the machine to a complete stop before changing direction. Changing direction while in motion will put tremendous loads on drivetrain components, especially drivelines. Premature wear and failure can result.

For maximum visibility and overall safety, travel in reverse whenever possible. Always travel in reverse when the machine is loaded. Keep the load as low as is practical.



NOTE: It is recommended that you keep the declutch control in the ON position for normal traveling. In this position, the transmission is "declutched" or disconnected whenever the brake pedal is depressed. If a downgrade is encountered, the declutch control may be placed in the OFF position, and the transmission will remain in gear while braking.

A WARNING

For maximum visibility and overall safety, travel in reverse whenever possible. Always travel in reverse when the machine is loaded. Keep the load as low as is practical.

4.7 Unloading

- Move the Lumberjack up to a truck or trailer with the carriage in the following position:
 - The holddown arms out raised position.
 - The kickoff arms fully retracted.

 The tines level and just high enough to clear the bottom of the load.
- Move in until the back of the carriage is against the load. Partially clamp the load to prevent logs from rolling off. See Fig. 4-3.
- 3. Raise the boom until the tines begin to make contact with the load.
- 4. Securely clamp both holddown arms before the binder chains are removed. See Fig. 4-4.



Never allow the binder chains to be removed from the load until it is securely clamped by the holddown arms or by some other means provided by your company.

Never allow anyone to walk under the load.

Always try to unload from the binder side of the load. It's very important that you're able to see ground personnel. Never let them out of your sight!

- Hoist the load clear of the truck or trailer and tilt the carriage back slightly to bring the load center closer to the drive wheel axle. See Fig. 4-5.
- 6. With the load clear of the vehicle, back away and lower the load to about 3 feet above the ground or just high enough to clear any obstructions on your way to the point of unloading. See Fig. 4-6.




Fig 4-3




Fig 4-4




Fig 4-5





Fig 4-6

4.8 Load Splitting

- 1. Approach the load with the holddown arms open.
- 2. Raise the carriage and tilt it forward slightly.
- 3. Work the tines through approximately 1/3 of the load. See Fig. 4-7.
- 4. Bring the kickoff arms forward until they make contact with the load and then pull the load in tight with the holddown arms. Tilt the carriage back.
- 5. Continue to tighten with the holddown arms and raise the carriage until the load is free.



4.9 Spreading and Sorting

- 1. To unload the carriage for scaling or sorting, leave the carriage level or tilted slightly back. Lower the boom until the carriage is as close to the ground as possible. See Fig. 4-8.
- 2. While backing the machine, slowly open the holddown arms and gradually push the load forward with the kickoff arms. This way, the logs can be dropped individually rather than all at once. See Fig. 4-9.
- 3. If several logs fall off at once and form a pile, stop the machine, tilt the carriage forward, and using the holddown arms, rake the top logs back into the carriage.
- 4. When retrieving spread logs and the last one is beyond the ends of the tines, extra reach can be gained by tilting the carriage forward. This places the holddown arms in a position to rake the logs onto the tines. The distance the top of the carriage extends forward is the extra reach gained at the tip of the holddown arms. See Fig. 4-10.




Fig 4-8




Fig 4-9




Fig 4-10

4. Fig. 4-11 shows a good example of the Lumberjack's flexibility. The log is under the tines and is held by the holddown and kickoff arms. Partial loads should be held with the holddown and the kickoff arms.




Fig 4-11

4.10 Cold Decking Loose Logs

- In building a cold deck, be sure that all logs are well balanced on the tines.
 This will help to prevent one end of a log from dropping down, resulting in "jack-straw" cold decking.
- Move up to the deck with the load lifted to the necessary height. Place the drive wheel tires tight against the bottom logs, as this firms up the deck and helps prevent logs from shifting when you place the new load on top. See Fig. 4-12.




Fig 4-12

3. When the required decking height is reached, push the load off with the kickoff arms and simultaneously lower the carriage and back away slowly. Keep the tines as close to the pile as possible to prevent logs from rolling down in front of the drive tires. See Fig. 4-13.




Fig 4-13

4. Continue backing and lowering until all the logs are out of the carriage. See Fig. 4-14.

NOTE: If a log becomes "jack-strawed", straighten the pile before bringing in the next load. This will make decking and retrieval much easier.




Fig 4-14

4.11 Retrieving Loose Logs

- 1. To obtain maximum load retrieval of loose logs, raise the holddown arms and tilt the carriage forward slightly before moving into the deck. The tines should be hinged and at around level.
- 2. Move into the deck and simultaneously tilt the carriage fully forward. The logs should roll up into the back of the carriage. Move into the deck as far as possible. See Fig. 4-15.
- 3. Having the carriage tilted forward at this point will allow the holddown arms to gather logs that would be otherwise out of reach. To finish filling the carriage, alternate between clamping with the holddown arms and tilting the carriage back.
- 4. Tilt the carriage back fully and tightly clamp the load. Back away and lower the load. See Fig. 4-16.
- 5. Travel with the load as close to the ground as possible. Raise the load only enough to clear obstacles.
- 5. Occasionally, one log in a bunch will be held by only one holddown arm and will ride on the outside of the other. It's best to drop this log and retrieve it on the next trip. Securely clamp the load with one arm (the side with the log on the outside) and open the other holddown arm. The loose log will fall to the ground. Resecure the load before proceeding.




Fig 4-15




Fig 4-16

4.12 Cold Decking Bundled Logs

 When approaching the deck with a bundle, clamp the bundle with the auxiliary holddown arms and then raise the main holddown arms. This allows the bundle to be placed tightly against the others. See Fig. 4-17.




Fig 4-17

To place the bundle, set the bundle in position, raise the auxiliary holddown arms and push forward with the kickoff arms while backing up. The bundle will slide off of the tines. See Fig. 4-18.



Fig 4-18

- 3. Always stack bundles in vertical piles not interlocking. This will make
 retrieval much easier. Also, when
 stacking one bundle on top of
 another, press down on the lower
 bundle with the carriage. This will
 flatten the lower bundle and make
 the deck much more stable and
 retrieval easier. See Fig. 4-19.
- Depending on bundle size, it may be possible to stack the bundles four high.




Fig 4-19

4.13 Retrieving Bundled Logs

1. Approach the deck with the carriage tilted forward and all holddown arms (main and auxiliary) fully raised.




Fig 4-20

2. Work the tines between the bundles. Take care not to hook logs from the lower bundle. Work the tines as far under the bundle as possible.




Fig 4-21

3. Clamp the bundle with the auxiliary holddown arms and tilt the carriage back.

4. Lower the main holddown arms as soon as they will clear the remaining

5. Lower the bundle to the ground and reclamp if necessary to secure the load. Travel with the load as close to the ground as possible. Raise the load only enough to clear obstacles.

bundles.




Fig 4-22





Fig 4-23

4.14 Operating Tips

- 1. For maximum visibility and overall safety, travel in reverse whenever possible. Always travel in reverse when the machine is loaded. Keep the load as low as is practical.
- 2. Always make sure that the kickoff arms are fully retracted and against their stops when carrying a full load. Leaving them partially extended could result in damage if the load should shift or roll with any force. To obtain the greatest lift capacity, the kickoff arms must be all the way back. This way the load center is as far back as possible.
- 3. WITHOUT FAIL always secure a load before allowing the binder chains to be removed, either by clamping the load with the holddown arms, or by some other means provided by your company.



4. The holddown and kickoff arms can be damaged if they are used in any way that opposes the movement of the machine under power. For example, never use the holddown arms to drag a log while moving in reverse.


4.15 Determining Load Center

The load center is figured at a specific distance from the face of the carriage towards the tips of the tines.

MODEL	LOAD CENTER	MAX LOAD
L-80, L480	48"	80,000 lb
L-90, L490	54"	90,000 lb
L-100, L4100	54"	100,000 lb
L-120, L4120	60"	120,000 lb
L-130, L4130	72"	130,000 lb

4.16 In Case of Fire

1. Pull the safety pin on the actuator and strike the button. Fire retardant will be released, the engine will shut down, and the batteries will be disconnected from the electrical system.



IN CASE OF FIRE:

- 1. Remove Safety Pln
- 2.Strike Button

- 2. Take the hand-held fire extinguisher, if possible, and LEAVE THE VEHICLE. After the system has discharged, watch carefully for flare-ups and spot fires. Call the Fire Department and/or service personnel as soon as possible.
- 3. Any time the system is discharged, the system must be refilled and recharged before resuming operation. Refer to the Service Manual for complete maintenance procedures.

IMPORTANT: Each unit is equipped with two actuators. One is located in the operator's cab behind the seat to the left. The other is located on the chassis near ground level. This way, the system may be actuated by either the operator or by ground personnel.

NOTE: Some models are equipped with a fire detection system that will automatically discharge the system in the event of a fire. See the Service Manual for details.



MAINTENANCE & LUBRICATION

L - 120D

80-368 (1-90) Pri

Printed in USA

CONTENTS

GENERAL	•	•	•	•	•	•	•	•	•	•	•	1
SAFETY PRECAUTIONS	•							•			•	1
WHAT IS PREVENTIVE MAINTENANCE?	•	•	•			•	•	•				1
BENEFITS OF PREVENTIVE MAINTENANCE		•		•					•		•	1
SHIFT MAINTENANCE		•			•		•	•		•	•	2
USING THE MAINTENANCE SCHEDULE CHECK LIST		•	•		•	•	•	•		•		2
OIL ANALYSIS SAMPLING PROGRAM					•							2
SHIFT MAINTENANCE CHECK LIST	•	•								•		3
LUBRICATION CHART		•	•							•		4
LUBRICATION POINTS	•			•		•		•				5
COMPONENT CAPACITIES & LUBRICANTS			•							•		6
MAINTENANCE SPECIFICATIONS	•	•	•									7
MAINTENANCE CHECK LIST - 50 HR, 250 HR, 500 HR		•			• 1			•		•	•	8
MAINTENANCE CHECK LIST - 1000 HR, 2000 HR .			•									9
LUBRICANT SPECIFICATIONS												• ^



GENERAL

The regular care a machine receives by its operators and mechanics is generally rewarded by decreased downtime and greater reliability. With the help of the information in this section, you should be able to maintain your machine at top operating efficiency. The maintenance and lubrication procedures given here can be performed on the job site with a minimum of shop tools.

SAFETY PRECAUTIONS

Before doing any maintenance or lubrication, review the following safety precautions. They are included for your protection.

PERFORM MAINTENANCE ON LEVEL GROUND

The machine should be on level ground and free of traffic lanes whenever possible.

SUPPORT THE BOOM

Before doing any work under a raised boom or bucket, first do the following:

- 1. Empty the load.
- 2. Support the boom with a safety stand don't rely on the hydraulics.
- 3. Shutdown the engine.
- 4. Set the parking brake and block the wheels.

INSTALL SWIVEL LOCKING BAR

A swivel locking bar is provided on 4-wheel drive models. Before working in the hinge area of the machine make sure this bar is installed. Place the machine on a level surface so that the locking bar can be aligned for pin insertion.

TAG KEY SWITCH

Before doing maintenance or lubrication remove the key from the switch, or tag the key switch "DO NOT START", to insure that the engine is not started inadvertently.

WHAT IS PREVENTIVE MAINTENANCE?

Preventive maintenance is a system that is intended to detect problem areas and prevent equipment failure before trouble can develop to a critical point. The system is based on a series of maintenance checks and servicing points. To be effective, a preventive maintenance program demands strict adherence to a planned schedule of maintenance.

BENEFITS OF PREVENTIVE MAINTENANCE

The time that is diligently expended to make the required periodic checks is a real investment in working equipment and efficient use of man-hours. Valuable benefits can be realized; all of which means savings in time and resources.

PREVENTIVE MAINTENANCE:

- IMPROVES EQUIPMENT AVAILABILITY by minimizing the chances of breakdown.
- REDUCES UNEXPECTED DOWNTIME crash repairs are expensive and detract from normal scheduled maintenance.
- REDUCES EQUIPMENT ABUSE provides the ability to predict component life and helps avoid operating equipment to destruction by replacing parts before they fail.
- ALLOWS PLANNING OF DAILY PRODUCTION by knowing the condition of available equipment.
- ALLOWS PLANNING OF MAINTENANCE MAN-HOURS - by distribution of duties and necessary lead time for parts ordering.
- PROVIDES COMPLETE HISTORY OF EQUIPMENTbased on performance, frequency and type of failure and actual man-hours expended on maintenance.
- PROMOTES SAFETY well maintained equipment is more able to operate within its design specifications and react positively to the operator's control.



SHIFT MAINTENANCE

Shift maintenance is where preventive maintenance begins. The operator of the machine normally completes this inspection. It consists of the routine servicing and lubrication of the machines major systems. On a daily basis, the operator is in the best position to identify, remedy and/or record potential problem areas and is able to quickly recognize any change in the performance of his machine. The comments he records on the shift maintenance report become a valuable tool to the maintenance department, and are an important ingredient to the overall success of a preventive maintenance program.

SHIFT MAINTENANCE CHECK LIST & REPORT

A recommended checklist is given here as an aid in developing a practical shift maintenance program if one has not been developed by your company. A shift maintenance report, based on this checklist should be used to report defects found when making maintenance checks at the beginning of each shift.

Your company may have a different reporting method, however, it is usually a necessary requirement that this form be filled out at the end of each shift. Accurate shift maintenance reports can help your company anticipate maintenance problems and take action to prevent costly failures.

USING THE MAINTENANCE SCHEDULE CHECK LIST

The maintenance schedule check list is designed as a guide to be used until adequate experience is obtained in establishing a program to meet your specific operation list of component checks is provided for typical hourly or calendar time periods. The engine manufacturer's maintenance manual should be consulted for additional engine related checks.

Actual operating environment governs the maintenance schedule. Some checks should be performed more often under heavy dust or other special conditions. An oil analysis sampling program may be employed as an aid in establishing the most practical time schedule.

A detailed maintenance schedule should be established using the check list as a guide. The result will be a maintenance program to fit your specific operation.

OIL ANALYSIS SAMPLING PROGRAM

Use scheduled oil sampling (SOS) to monitor machine condition and maintenance requirements. Oil samples from Engine, Transmission, Axles and Hydraulic System should be taken when the oil is hot and well mixed to ensure an accurate analysis.

Consult your dealer for complete information and assistance in establishing a scheduled oil sampling program for your equipment.





SHIFT MAINTENANCE CHECKLIST

EVERY 10 HOURS OR DAILY

Note general vehicle condition. Clear all collected debris - steam clean if necessary. Check for mechanical damage and loose or leaking components. Report faults to maintenance department

аера	arimeni				
	Before Starting Engine - Check	The Following:			
REF	ITEM		OK	ИО	ADD
5	ENGINE (Check oil level - check for leaks)				
4	FUEL TANK (Drain off moisture and sediment)				
11	HYDRAULIC TANK (Check oil level - check for leal	ks)			***************************************
3	RADIATOR (Check coolant level - check for leaks)	•			-
12	AIR CLEANER (Check indicator - clean or change	as required)			
33	ENGINE BELTS (Check for adjustment or wear)				
32	FUEL FILTER (Drain off water & sediment)				
6	AIR TANK DRAINS - IF USED (Drain off water & s	ediment)			
3	RADIATOR & OIL COOLER (Are fins clean and un	obstructed)			
30,34	WHEEL & TIRE ASSEMBLIES (Check condition as	nd pressure)			
7	HYDRAULIC BRAKE FLUID (Check fluid level)				
-	LUBRICATE CHASSIS (Refer to lube chart)				
	After Starting Engine - Check	The Following:			
REF	ITEM		OK	ИО	ADD
-	ENGINE (Does it sound normal)				
13	INSTRUMENTS (Check for normal readings)				
13	CONTROLS (Check for normal operation)				
12	AIR INTAKE SYSTEM (Check for leaks and damage	ge)			
•	EXHAUST SYSTEM (Check for leaks and excessive	ve smoke)			
16	TRANSMISSION (Check oil level - check for leaks)			
	Note Anything Abnormal Or In	Need Of Repair:			·
	DEFROSTERF				
HORN _	WINDSHIELD WIPERSF	IEATER/AIR CONDITIONER			
	FORSUPERVISOR				
MODEL	SERIAL NUMBERHOUR METER				





Due to variations in engine types and models, the indicated location of engine filters(fuel, oil, coolant) may not be exact. Consult your specific engine service manual for exact locations.

Optional Pressurized Axle:

Front axle housing is under 3 psi air pressure. Before checking axle oil level, first shut off air supply to axle, then open air drain cock located on axle housing bulkhead.

WARNING

Due to the extreme height of the upper lube points, it is essential to personnel safety that safe ladders and/or scaffolding be used while servicing. These areas can be dangerously slick under conditions of rain, frost, or oil smears.

Circled numbers indicate lubrication points

Fig. 1 L-120D Lubrication Chart

LUBRICATION POINTS L-120D

10 HOURS					
REF		FITTINGS			
1 & 2	STEERING CYLINDER PINS	4			
14	BOOM TO CHASSIS PIN	2			
(4) (8) (17) & (29)	BOOM TO CARRIAGE PIN *	2			
① & ②	HOIST CYLINDER PINS *	4			
	* WHEN OPERATING IN WATER, LUBRICATE				
	SUBMERGED POINTS MORE FREQUENTLY				
	50 HOURS				
(5) & (18)	TILT CYLINDER PINS	4			
	HOLDDOWN ARM PINS	2			
25 49 49 49 49 49 49 49 49 49 49 49 49 49	KICKOFF ARM PINS	2			
(19 & 29	HOLDDOWN CYLINDER PINS	4			
<u> </u>	KICKOFF CYLINDER PINS	4			
<u>2</u> 2	AUX HOLDDOWN ARM PINS	2			
23 & 27	AUX HOLDDOWN CYLINDER PINS	4			
<u>(31)</u>	SUPPORT BEARING	1			
<u> </u>	DRIVELINE - CONVERTER TO SUPP * *	3			
9	DRIVELINE - SUPP TO TRANS * *	3			
8	DRIVELINE - TRANS TO AXLE * *	3			
	* * USE HANDGUN OR LOW PRESSURE ADAPTER; LUBRICATE SPARINGLY	• •			
	250 HOURS				
33	FAN DRIVE BEARING	. 1			
500 HOURS					
(34)	TAILWHEEL BEARING	2			
34) 35)	TAILPOST	. 1			

COMPONENT CAPACITIES & LUBRICANTS

L-120D

	REFILL	. CAPACITY(APPROX)	LUBRICANT TYPE *
COMPONENT OR SYSTEM	U.S. GAL	LITERS	LUBRICANT TYPE
ENGINE CRANKCASE W/FILTERS	13	49	HD ENGINE OIL
FUEL TANK	450	1703	DIESEL FUEL
COOLING SYSTEM	30	114	WATER/ANTIFREEZE
HYDRAULIC SYSTEM	350	1324	HYDRAULIC OIL
TRANSMISSION SYSTEM			TRANSMISSION OIL
DIFFERENTIAL	50	189	GEAR LUBE
PLANETARY HUBS (Each)	12	45	GEAR LUBE
BRAKE RESEVOIRS		AS REQUIRED	"MINERAL OIL"
CHASSIS GREASE FITTINGS		AS REQUIRED	CHASSIS GREASE

^{*} SEE LUBRICANT SPECIFICATIONS, PAGE 10

MAINTENANCE SPECIFICATIONS

L-120D

		HYDRAULIC PRESSURE RELIEF SETTINGS			
	VALVE	MAIN	CIRCUIT		
(1)	Steering	2250 PSI (15,513 kPa)	2500 PSI(17,237 kPa)		
(2)	Holddown & Kickoff, LH		N/A		
` '	Holddown, LH - Stem		2300 PSI(15,858 kPa)		
	- Base		2300 PSI(15,858 kPa)		
	Kickoff, LH - Stem		2300 PSI(15,858 kPa)		
	- Base		2300 PSI(15,858 kPa)		
(3)		2200 PSI (15,168 kPa)	N/A		
\	Holddown, RH - Stem		2300 PSI (15,858 kPa)		
	- Base		2300 PSI (15,858 kPa)		
	Kickoff, RH - Stem		2300 PSI (15,858 kPa)		
	- Base		2300 PSI (15,858 kPa)		
(4)	Diverter Valve (Aux. Holddown)		2750 PSI (18,960 kPa)		
(5)	Hoist		2300 PSI (15,858 kPa)		
(6)	Tilt		N/A		
(-/	Tilt - Stem		2300 PSI (15,858 kPa)		
	- Base		950-1200 PSI (6550-8274 kPa)		
(7)	Pressure Reducing Valve (Steering)		N/A		
(8)	Pump Port Relief (Bench Set)		2500 PSI (17,237 kPa)		

NOTE: Set main reliefs with engine at 1500 RPM.
Set circuit reliefs with engine at 1000 RPM

WHEE	L LUG NUT TORQUE				
Front		•			300 lb/ft (407 N • m)
TIRE II	NFLATION PRESSURE				
Front	(Driver) 24 x 35 - 36PR				90-95 PSI (620 - 655 kPa)
Rear	(Tail) 26.5 x 25 - 24PR	•		•	60 - 65 PSI (414 - 448 kPa)



MAINTENANCE CHECKLIST

IMPORTANT: Consult engine manufacturer's Maintenance Manual for additional engine related maintenance checks and/or details

EVERY 50 HOURS					
1. REPEAT THE 10 HOUR CHECKLIST	OK	NO			
2. CHECK FOR FLUID LEAKS - OIL, FUEL, WATER	OK	_ REPAIR			
3. CHECK BRAKES FOR ADJUSTMENT & WEAR	OK	_ REPAIR			
4. CHECK WHEEL LUG NUTS & STUDS MECHANICALLY	OK	_ REPAIR			
5. CHECK BATTERY ELECTROLYTE LEVEL	OK	ADD			
6. LUBRICATE CHASSIS (Refer to Lub Chart - Page 4)	OK	NO			
7. RECORD ENGINE RPM	HIGH	STALL			
8. CHECK FOR STRUCTURAL DAMAGE INSPECT CHASSIS AND ATTACHMENTS FOR BENDING, CRACKING AND BROKEN WELDS	OK	REPAIR			
EVERY 250 HOURS	S				
1. REPEAT THE 50 HOUR CHECKLIST	OK	NO			
2. CHANGE ENGINE OIL & FILTERS*	OK	_ ADDED			
3. TAKE ENGINE OIL SAMPLE FOR ANALYSIS*	OK	NO			
4. CHECK AXLE DIFFERENTIAL OIL LEVEL	OK	_ ADDED			
5. CHECK AXLE PLANETARY OIL LEVEL	OK	ADDED			
6. CHANGE ENGINE COOLANT FILTER - IF USED	OK	REPLACE			
7. CHECK COOLING SYSTEM HOSES & COOLANT	OK	RPLACE			
8. CHECK ALL HYDRAULIC PRESSURES & RECORD	OK	NO			
9. CHECK FIRE SUPPRESSION ACTUATOR - IF USED	OK	NO			
EVERY 500 HOURS					
1. REPEAT THE 250 HOUR CHECKLIST	OK	NO			
2. CHANGE FUEL FILTERS*	OK	_ REPLACE			
3. CHANGE HYDRAULIC FILTERS*	OK	REPLACE			
4. CHANGE TRANSMISSION FILTERS*	OK	REPLACE			
5. TAKE OIL SAMPLES FROM TRANSMISSION, AXLE, AND HYDRAULIC SYSTEMS FOR ANALYSIS*	OK	NO			
6. INSPECT BRAKE SYSTEM & COMPONENTS	OK	REPAIR			



MAINTENANCE CHECKLIST

EVERY 1000 HOURS					
1. REPEAT 500 HOUR CHE	CKLIST	OK	NO		
2. CHANGE TRANSMISSIO	N OIL & FILTERS*	OK	ADDED		
3. CLEAN & FLUSH COOLIN		OK	ADDED		
4. CHECK PINS & BUSHING	SS FOR WEAR	OK	REPLACE		
	EVERY 2000 H	OURS			
1. REPEAT THE 1000 HOU	R CHECKLIST	OK	NO		
2. DRAIN, FLUSH & REFILL	. DIFFERENTIALS*	OK	ADDED		
3. DRAIN, FLUSH & REFILL		OK	ADDED		
4. CHANGE HYDRAULIC O		OK	ADDED		
Change intervals should be a dealer for assistance in estal REPAIRS: PROBLEMS	blishing an oil sampling pro	ogram for your equipme	ent.		
PARTS					
		HOURS LABO	R		
REPAIRS:					
PROBLEMS					
PARTS					
		HOURS LABO	R		
OPERATOR:					
SUPERVISOR:					
MODELSEF					

9

LUBRICANT SPECIFICATIONS

CUMMINS SAE 10W-30		MANUFACTURER	RECOMMENDED	PREVAILING AMBEINT TEMPERATURES		
MILL-2104D SAE 15W-40 14 'F and Above (Normal) -10 'C and Above (Normal) AE 20W-40 32 'F and Above 0 'C 0 'C and Above 0 'C 0 'C and Above 0 'C				(FAHRENHEIT)	(CELSIUS)	
API CC/SF) NOTE: Multi-Grade oils are not recommended in Detroit Diesel Engines		MIL-L-2104D	SAE 15W-40	14 ° F and Above (Normal)	-10 ° C and Above (Normal)	
MIL-L-2104D SAE 10W-30	ENGINE	MIL-L-46152	SAE 40	Above 32° F	Above 0° C	
MIL-L-2104D SAE 10W -10 'F to 140 'F (Normal) -23 'C to 60 'C (Normal (API SE) SAE 30 30 'F to 140 'F -1 'C to 60 'C		MIL-L-2104D	SAE 10W-30	-4°F to 104° F		
NOTE: Preheat transmission fluid to Indicated minimum temperature before operating transmission in PEUTRAL for minimum minutes prior to engaging FORWARD or REVERSE ranges TWIN-DISC		MIL-L-2104D (API SE)	SAE 10W	-10 ° F to 140 ° F (Normal)	-23 ° C to 60 ° C (Normal)	
TWIN-DISC SAE 5W-20 -60° F to 0° F -51° C to -18° C	TRANSMISSION	MIL-L-2104D (API SE)	SAE 10W SAE 15W-40	Below 10° F(Normal) Below 30° F	Below -12° C (Normal) Below - 1° C	
MilL-2104D SAE 10W -10° F to 140° F (Normal) -23° C to 60° C			preheating e	quipment is not available, operate transn	nission in NEUTRAL for minimum of 20	
Mill-1-2105C SAE 75W-80 -40 ° F to -0 ° F -40 ° C to -18 ° C		MIL-L-2104D (API SE)	SAE 10W	-10° F to 140° F(Normal)	-23° C to 60° C	
(API CD) SAE 40 Above 100° F Above 37° C RIMPULL MIL-L-2105C (API GL-5) SAE 80W-90 -20° F and Above(Normal) -29° C and Above(Normal) -29° C and Above(Normal) -29° C to 49° C Premium Grade Hydraulic Oil Note: Hydraulic oil must include the following: Anti-wear agents; Rust, foam, and oxidation High demulsibility; High viscosity index; Cold weather properties; Minimum pour poin and minimum viscosity index of 140. Multipurpose NLGI-1 Below 10° F Above 37° C -54° C to -29° C -54° C to -49° C -54° C to -29° C -54° C to -		MIL-L-2105C	SAE 75W-80 SAE 80W-90	-40 ° F to -0 ° F -13 ° F to 100 ° F (Normal)	-40 ° C to -18 ° C -27 ° C to 37 ° C (Normal)	
MIL-L-2105C (API GL-5) SAE 80W-90 -20° F and Above(Normal) -29° C and Above(Normal) -32° C to 49° C Premium Grade Hydraulic Oil Note: Hydraulic oil must include the following: Anti-wear agents; Rust, foam, and oxidation High demulsibility; High viscosity index; Cold weather properties; Minimum pour poin and minimum viscosity index of 140. Multipurpose NLGI-1 Below 10° F Below -12° C	AXLE	MIL-L-2104C	SAE 30	-20° F to 120° F(Normal)	-29° C to 49° C	
Hydraulic Oil Note: Hydraulic oil must include the following: Anti-wear agents; Rust, foam, and oxidation High demulsibility; High viscosity index; Cold weather properties; Minimum pour poin and minimum viscosity index of 140. Multipurpose NLGI-1 Below 10 ° F Below -12 ° C		MIL-L-2105C	SAE 80W-90	-20° F and Above(Normal)	-29° C and Above(Normal)	
Multipurpose NLGI-1 Below 10 ° F Below -12 ° C	JUC		ISO VG32	-10 ° F to 120 ° F	-23 ° C to 49° C	
	HYDRAL		High demul	sibility; High viscosity index; Cold weather		
ច់	CHASSIS	Chassis Grease				



GENERAL MAINTENANCE TIPS

INTRODUCTION

WAGNER originated and manufactures a wide range of heavy lift equipment. Included among many other models are the LUMBERJACK Log Stacker, the CHIP CARRYDOZER and COAL CARRYDOZER, the PORT PACKER and PIGGY PACKER, and the STEEL WORKER.

Each WAGNER machine owned by your employer represents a substantial capital investment, and your management gave it a great deal of thought before making their decision. The WAGNER was selected for its proven record of high availability and for its productivity in your operation. These two points of availability and productivity depend largely on the maintenance crew, and that means you, a good capable mechanic with sound judgment.

WAGNER machines were designed with the mechanic in mind; they are constructed with standard components we are all familiar with. We know that our machine is simply another tool to help get your job done and the prosperity of your operation depends on it doing that job. Because we also know the responsibility of keeping your WAGNER machines working falls on your shoulders, we have prepared this guide to help you meet the challenge.

First, we have to realize that even though these machines are especialy designed for their different jobs, they all share certain systems and needs for basic maintenance, so we are going to take a few minutes to explain some of the basic maintenance procedures common to all these heavy lift machines.

PARTS AND SERVICE DATA

Your best friends in doing basic maintenance are the Parts and Service Manuals that came with your machine, and the Service Bulletins that you receive periodically. These manuals give you the details of each system in your machine including locations of filters, drains and miscellaneous lubrication points. Even though your heavy lift equipment is available with a choice of engines and transmissions, your manual provides the manufacturer's own documents for the exact options you have ordered.

Every machine we produce at WAGNER is treated like it was unique, yet it is a standard production model. The minute it comes off the assembly line, your particular unit becomes the subject of a

complete and running history kept in our files at the factory and at out dealers locations. Every machine has its own file folder describing the entire machine and all its components to help give you fast and accurate parts and service information. To help the dealer give you this special attention, we would like to emphasize that it is vitally important for you to give him the correct model and serial number for your machine when requesting parts or service.

You will find this information in two places; on a plate assembly mounted on the left side of your cab cowl and on the Master Check Sheets of your Parts Manual and Service Manual. Be sure to copy it correctly and keep the information handy to your telephone for ordering from your local dealer. He will provide you with normal and emergency phone numbers.

GENERAL LUBRICATION

Just above the Serial Number Plate you will notice a lubrication plate. It is a handy reminder for the first step of your basic maintenance program: LUBRICATION. And for easy reference we have provided the same information in your Service Manual. When your machine is delivered it has been serviced with top quality lubricants, and any major brand can be depended upon to provide good results. Whatever brand you prefer, be sure that your vendor supplies lubricants with equal specifications. The wrong substitute may cause premature wear throughout your machine.

General lubrication of your WAGNER heavy lift unit is mostly a matter of common sense. Once you become familiar with your unit your good judgment will guide you.

Here are some helpful lubrication tips. First, you should always be safety conscious when lubricating the highest fittings on your machine, such as the Lumberjack's holddown and kickoff arm pivot points. Before lubricating these points, you should lower these high components as close to the ground as they will go. You should also relieve the pressure from these cylinders and the anchor pins by resting the carriage on the ground to allow them to receive adequate grease. When lubing these high points, take care to use the railings provided for you.

You will also notice that several pivot points on your unit may not be equipped with grease fittings such as the throttle linkage ball joints, emergency brake linkage, and so on. To reduce wear, these points should have a drop or two of oil periodically. In all lubrication questions, go back to your lubrication chart in the Service Manual and bulletins for complete details.

FILTER MAINTENANCE

While there is nothing very complicated about general lubrication, filters in particular, tend to be "out of sight, out of mind", and are often overlooked with resulting serious damage. We realize you will not be working under ideal conditions -- so take the precaution of making sure your filters are clear of dirt and possible contamination when changing them. There are five critical filter areas to be concerned with, the hydraulic tank screens, hydraulic return filters, engine oil filters, transmission filters, and finally, the air cleaners. Proper care of all these filters is essential to a good basic maintenance program.

Starting with the hydraulic tank screens, let's see what proper care means. You will find these screens in the hydraulic tank on the right side of your machine under a hinged section of the catwalk. All the oil returning from your unit's hydraulic system passes through these screens and they should be removed and checked every thousand hours.

Maintenance for these screens is done in four steps: First, remove the capscrews from the tank cover. Slide this cover to the rear so you can get at the screens. Second, grasp the lifting bail on the screen and slowly lift it out of the tank. This is the time to visually inspect the screen for contamination or damage to the mesh. Third, clean the screen by removing the inner section, flush it with fuel oil and blow it dry with compressed air. Return the screens to the tank and secure the cover. Make sure you get a tight seal.

Now let's look at the hydraulic return filters. These return filters are the full flow type, located in the return line next to the reservoir. Filter elements should be replaced periodically to prevent clogging. The system itself is designed to protect against the results of clogging, such as pressure build-ups or blowouts that can let all the impurities collected by the filter flow into the reservoir. Even though the bypass valves are meant to protect the system from pressure overloads, they offer no filtration and let all the impurities circulate freely. Therefore, filters should never be allowed to go unchanged beyond their service specifications.

The procedures for changing these filters are: First, place a suitable container under the filter to be changed capable of holding 20 to 25 gallons. Begin by loosening the square head center bolt and allowing the filter shell to drain. Now unscrew the center bolt while holding the filter shell. If you don't hold the shell, gravity will take over when the bolt is loose and

you will get an oil bath. Next, remove the O-ring and top gasket. Set them to one side. Remove and discard the old element. Disassemble the remaining gaskets and spring and thoroughly clean all the parts. Once you have everything clean, begin reassembling the return filter by placing the bottom gasket in position on the center bolt. Then place the center bolt itself in the filter shell. Insert the spring, bottom back-up washer, and bottom gasket, in that order. Insert a dry filter element, place the top gasket and O-ring into place. Carefully position the filter shell into the filter head, and finally, tighten the center bolt with a torque wrench to 20 foot pounds maximum. Before putting the machine back into service again, check the filter can for leaks while the machine is running. Most of the engines in WAGNER machines have a primary lube oil filter. Detroit Diesel engines have their filter mounted on the sidewall next to the engine, and the Cummins and Caterpillar oil filters are mounted on the engines. Procedures for changing all these filters are similar and we will use the Cummins as an example.

First, place a suitable container under the filter shell; remove the drain plug and let the oil flow out. Remove the hex head bolt and pull the shell off. Then remove the old element and discard it. Clean the shell as on other filters, then install a new factory filter element and seals and remount the shell on the engine. Be sure to put the drain plug back in. Finally, torque the hex head bolt to 25 to 35 foot pounds as indicated on the shell.

The Cummins diesel is also equipped with a secondary lube filter element, which is to be changed along with its primary filter. To change this secondary filter, first place a suitable container under the filter shell, remove the drain plug and allow it to drain. Loosen the clamps on top of the filter and remove the top cover. Now, remove the filter tension nut, then the filter element and discard it. Clean the filter shell with fuel oil and wipe it dry. Be sure all foreign material is out of the shell before installing a new element. Now install the new factory element, replace the filter tension nut and install a new gasket where required. Replace the top cover and drain plug and fill the engine with new oil.

It is vitally important to check your oil level twice after changing filter elements. The reason for this is that the new filters will absorb several quarts of oil as soon as you start up the engine and thus lower the oil level. To make sure you have enough oil, start the engine and idle it for 2 to 3 minutes, then shut the engine down and recheck the level. Now go through the check once more, starting the engine and letting it idle and then shutting down to make certain of the oil level. You should also check all oil filters for leaks.

For all engines, check the oil level with the dipstick daily. Drain the crankcase and change the filters every 250 hours for maximum life and efficiency.

The transmission filters on WAGNER machines are full flow with replaceable elements held in the filter shell by a hex head bolt on the bottom. You begin replacement of the elements by placing a suitable container under the filter, removing the hex head bolt and allowing the oil in the shell to drain out. Now remove the filter shell and discard the element. Clean the shell with fuel oil and dry with a cloth or compressed air. Replace the 0-ring gaskets in the filter head, install a new element, then press the shell and element assembly into position and tighten the bolt to 55 to 65 foot pounds of torque. Last, start the engine to operate the transmission oil pump so you can check for leaks and check the transmission oil level.

Here are a few general tips for dealing with filters; whenever it is possible, fill the filter shell and new element with clean oil of the proper type to shorten the time it takes to prime the system. When servicing filters, replace any gaskets that show signs of wear. Some gaskets and O-rings can be used only once, due to distortion caused by pressure.

The last type of filter we are going to cover is the air cleaner. If an air cleaner or intake system is clogged and not doing its job, extensive ring and cylinder wear can result under severe conditions in just a few hours. So it is important to see that they are functioning properly. Your own operating schedule and dust conditions will determine how often you should service the air cleaner and intake system. You should make a habit of visually checking the entire intake system for dirt and leaks when servicing the air cleaner. All WAGNER units are equipped with dry type of air cleaners. By using the restriction indicator, sometimes called the service gauge, you can tell at a glance the condition of the filter element. Anytime the service gauge shows red you should investigate the air cleaner. recommend daily inspections of the air cleaner, but in severe dust conditions, we must emphasize that once a day may not be enough. If you have the Donaldson type air cleaner, the dust cup should be emptied when needed as a normal part of an air filter inspection.

COOLING SYSTEM

Now we can go from filters to some other basic maintenance tasks. The cooling system in todays diesel engines requires little maintenance, and you need to follow only three pointers. One, keep the radiator filled. Be sure you remove the cap only after

the engine has stopped and cooled down. The system is pressurized - and loosening a cap with the engine running could result in burns. Second, keep the water pump belt at its correct tension. Third, keep the radiator core clean and make sure that antifreeze has been installed during freezing weather. You can find more information on engine cooling systems in your Service Manual.

AXLES

The axles of your WAGNER machine should be checked periodically for lubrication in the differentials and planetaries. To do this, slowly roll your machine until the planetary oil level plug is in the proper position and check the oil. Then remove the oil level plug in the differential and check its oil level. Your service manual or the lubrication placard will tell you everything you need to know about oil types, time between changes and so forth.

WHEELS AND TIRES

Next is the wheel and tire maintenance, because they are not usually given the recognition they need; lets see just how important they are from the assembly line on out to your service conditions.

Before the wheels are installed all studs and locknuts on the axle are checked for proper torque. The outside diameter of the pilot hub and bounce ring is miked on each hub and the inside diameter is miked on each wheel to insure no more than 10 thousandths tolerance overall. That means it can be out no more than 5 thousandths on both sides of the wheel, not 10 thousandths on each side. This is necessary to carry your machines weight properly and eliminate excessive stress on the mounting studs and nuts. Next, the wheels are mounted on their hubs and the nuts torqued up to specifications (found in Service Manual). During final inspection the stud nuts are rechecked for proper torque. It is extremely important that studs not be overtorqued.

When you receive the new unit, it is important to visually check for loose and missing studs or nuts twice every day for the first four or five days of service. Check these studs and nuts for proper torque every 50 hours for the first two weeks. You should always use a torque wrench on these studs and stud nuts, since an overtorqued nut will stretch the stud and eventually break it, or nuts can become stripped.

A torque wrench can avoid the process of one man checking the nut until it moves, the next man tightening it until it moves some more, and finally, the last man ending up with a broken stud and wondering why. Remember, every time you tighten the nut down, it pulls the stud a little bit tighter and stretches it a little bit farther. A stud only has so much give before it breaks, and a torque wrench is the only tool that will let you know for sure what you are doing.

In the event you ever have to remove a wheel, you should center punch a reference mark on it and the hub, so you can remount it in the original position. Be sure both mounting flanges on the hub and wheel are clean so a positive fit can be obtained when remounting. If you ever have to replace an axle hub or wheel, both should be miked as in the factory, even if this requires the rental of inside-outside micrometers. The cost will be more than justified by longer wheel and stud life. Your Service Manual will give you more information on wheel care and inspection.

The tires on our heavy lift machines are designed to operate with a certain sidewall deflection, or bulge. Proper inflation is very important to tire life. An underinflated tire flexes excessively every time you turn the wheel, which generates high internal heat and causes premature failure. Overinflation causes excessive center tread wear. A correctly inflated tire permits all the tread to contact the ground and insures proper operation and maximum life. All your recommended tire pressures are cold readings. Hot pressures, taken while a tire is in use will not give you the proper reading. Maintenance pressure checks should be taken only when the machine has been idle long enough for the tires to cool down to the surrounding temperature.

HYDRAULICS

Lets examine one of the most important systems in any WAGNER heavy lift machine - HYDRAULICS. Your unit employs the most advanced principles of hydraulic engineering. Instead of using the old single function hydraulic circuits -- ones that use a single pump for each separate function and have no way of contributing their spare power to other functions, our system employs three pumps, each having a primary function and one or more secondary functions.

When any pump is not being used for its primary function a control valve diverts the oil to the secondary function instead of just returning it to the reservoir as in the single function system. When all our functions are operating, the power is divided up like this: On Lumberjacks the hydraulics are divided into three basic systems. Whenever a steering pump's power is

not being used for its primary function, it is diverted to the hydraulic system. It has many advantages over the single function system, one, for example, is greater effeciency. Hoisting can be done much faster with the combined power of three pumps than it could with a larger single pump. Also, because of the multiple relief valves in the "power beyond" system, it provides greater protection for pumps, valves and hoses.

For further protection, your unit is equipped with circuit relief valves in the circuits themselves. These also function when the circuit control valves are not being operated. This advanced hydraulic design is not complicated and will be easy to work with by keeping this one principle in mind: Because the circuits are interconnected, any problem that shows up downstream may be caused by a malfunction upstream. Therefore, solving any problem depends on following your checks and pressure settings in a logical sequence beginning upstream at the highest pressure and going downstream to the lowest pressure. Follow the sequence from upstream to downstream and maintenance is easy. Fail to follow it, and you are asking for problems.

The sequence begins at the steering valve, which is all the way upstream on all machines, and then, using the Lumberjack as an example, goes downstream to the hoist and tilt valve, the farthest downstream and the lowest pressure. You can trace the system on all machines by the schematics in your service manual. Be sure to check your service manual for the proper pressure settings on your unit. Keeping this in mind, gather all the tools you will need to test and adjust pressure settings on your machines.

You will need two end wrenches each of 9/16ths, 3/4 and 7/8th inch size. You will also need a medium flat head screwdriver, several rags and the pressure gauge provided with the units tool kit. You should have the gauge calibrated from time to time to maintain its accuracy.

Using the Lumberjack again as our example, testing and adjustment of pressure settings begins by starting up your unit and operating several functions to allow the hydraulic oil to warm up to operating temperature. Relief pressures will not be accurate if adjusted and set while the oil is cold.

We will begin pressure relief setting at the farthest point upstream, that is, at the highest pressure, which is the steering valve. You should first notice that it is operated by a slave cylinder that receives oil from the converter pump. Make sure the slave cylinder is operating, then proceed with setting the pressure relief on the steering valve. First, install a pressure gauge supplied in your units tool kit. Install it on the quick

disconnect. Bottom the steering by removing the slave cylinder from the walking beam. Manually push or pull the walking beam until the steering relief bypasses. With the engine at 1500 RPM adjust the steering relief valve to the pressure specified in your units service manual. The manual will give you proper settings and sequences to follow. Adjustment is made by removing the acorn nut, and loosening the jam nut on the relief adjusting screw, turn it clockwise to increase pressure and counterclockwise to decrease pressure. double check relief settings at maximum RPM. Usually override should be only 50 to 100 psi over normal.

Now we go downstream to the Lumberjacks left holddown and kickoff valve. Install the pressure gauge on the quick disconnect located on top of the valve. Move the kickoff arms to their back position and hold until the relief bypasses. Now with the engine at 1500 RPM, set it to the specified pressure in your manual the same way you did the steering valve.

The right holddown and kickoff valve is adjusted in the same manner. Install the pressure gauge and follow the procedure used for the left hand valve.

At the downstream end of the system you will set the hoist and tilt valve. You will notice that it is not equipped with a quick disconnect. Instead, on top of each junction manifold is a hex plug. While raising the boom, shut down the engine and keep the hoist lever open, this will cause the hoist cylinder to partially cavitate, allowing you to remove the hex plug with no oil present. Now, remove the hex plug from the downside hoist manifold and install a 90 degree 0-ring adapter, supplied with your units tool kit. Install a quarter inch hose which has a quick disconnect on the other end, and snap on the pressure gauge. Move the hoist control lever to bring the hoist up or down to its highest or lowest position and hold until the relief bypasses. With the engine at 1500 RPM adjust it to the specified pressure just as you did on the other valves. Remove the pressure gauge and adapter in the same manner as you installed it and no oil will be present.

On units without loadlocks, push the hoist lever forward until the cylinders fully retract and shut the engine off. Remove the gauge plug on the stem end manifold block. CAUTION: $\frac{DO}{NOT}$ remove the base end manifold gauge plug with hoist cylinders extended on units without loadlocks or be prepared for an oil bath!

On early units with the air assist system you relieve the pressure by moving the control lever in both directions while the engine is off.

Now, lets move on to the circuit relief pressure checks. All reliefs are preset at the factory, however, they can be set on the machine in the following manner. You must raise the main pressure relief higher than the specified circuit relief setting. Install your pressure gauge. Screw the main relief adjustment clockwise several turns without bottoming in the same manner as described for setting the operating pressures. DO NOT BOTTOM any relief at any time or complete destruction of the pump can result!

There are circuit reliefs on each port of the holddown and kickoff valves and one each on the downside of the hoist and tilt. Operate each function until the main relief bypasses either on the stem or anchor end of each cylinder. Slowly raise the main relief until it no longer reads higher than the specified circuit relief setting which should be about 2300 psi on all circuit relief except the tilt on some models that specifies 950 psi and 1050 psi on base end of cylinder.

If the pressure is not right, adjustments can be made by adjusting the circuit relief valves on both ends of each spool of the kickoff and holddown valves, as you did all the other relief valves, clockwise to increase, counterclockwise to decrease. Parker and Commercial valves use shims to control the pressure bypass. Most thin shims raise or lower pressure about 50 psi and thick shims approximately 300 psi. In an emergency a 1/4" flat washer raises the pressure about 600 psi. You have now completed your pressure settings. Remember, the same basic principles apply to all WAGNER heavy lift machines, whether the Lumberjack or most other members of this large family.

Here are a few tips in case you should run into problems completing these pressure settings; If you should find a valve that will not adjust to the recommended relief pressure, either the relief valve assembly or the pump may be malfunctioning and should be corrected before proceeding further downstream. Make sure your control system is functioning properly. Check for loose oil cylinder clevises, pinched oil lines, sticky valve spools or loose valve tie bolts. You will also find pointers in the Service Manual listed under Pump and Mechanical Problems in Hydraulic Systems.

IN CONCLUSION ---

You have just completed a solid basic maintenance routine. Of course there are many more details you will have to work with to keep your machine in top condition, but this coverage of lubrication, filters, wheel and tire care and hydraulic pressure settings was meant to give you the essentials of a sound day to day maintenance program to be used along with common sense items like daily visual inspection of structure for cracks and broken parts, etc.

By now you realize the help your service manual and bulletins can be to you, but when the problems go beyond regular maintenance and you feel like you are in over your head, remember that you didn't just get a machine for your hard earned money, you also have the service of a strong dealer organization and WAGNER at your disposal twenty-four hours a day. We are no further away than your telephone at any time. Dial our number and you will get the fastest nationwide service there is.

We want the WAGNER heavy lift machine you use to be the best machine there is. Your good judgment and these tips we have just presented can make it the best and keep it that way.