




# Liquid Cooled Brake Friction Disc Lining Wear Check Procedure

*NOTE: The brake must be applied before making the wear indicator check.*

1. Clean thoroughly the area around the wear indicator.
2. Remove cap.
3. Push wear indicator pin in against reaction plate.
4. When the wear indicator pin becomes flush with the spot-faced casting surface, the friction discs must be inspected, see figs. A&B.
5. The wear pin in illustration "C" has no factory set standout. Inspect discs when wear pin becomes flush with the spotface.
6. Replace cap and torque to 25 lb/ft [27-34 Nm] as required.



When this distance becomes zero inspect friction discs.