



520300

MAKE FROM ALLISON # 6834821 FWD # 214188

REMOVE SELECTOR VALVE ALLISON # 6838537 FWD # 201947  (B)


 AND INSTALL THE FOLLOWING:

203277 1 Valve Body Kit
Allison # 6773918

202015 1 Name Plate
Allison # 6832918
) OPTION
) STAMP OUT ALLISON NO.

201587 4 Screw
Allison # 142862
) AND
) STAMP IN RW NO.
) 520300

NOV 11 1996

 Note: Can be Purchased under Allison # 6880545

C. N. No.	REVISIONS	NO.	DATE	SUB ASSY.	QUAN.	MODEL	GROUP	USAGE	WT.
3900	C		26 July 73						
NCN	B		4 Apr 73						
NCN	A		1-26-70	FINAL	1	90	24		
NCN									
Material SEE SPECS ABOVE FWD WAGNER INC. PORTLAND, OREGON DRAWN: _____ DATE: _____ CHK: _____ SCALE: _____ TITLE: TRANSMISSION - REWORK DRWG. NO. 520300									