

Air System - Vehicle



CONNECT TO SEAT
 SUPPLY TO IMPLEMENT CONTROLS

Air System - Vehicle

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	577532		Air System-Vehicle				
1	219502	1	. Fitting	30	217479	1	. Hose Assembly
2	* 580823	1	. Air Valve Module	32	209441	2	. Fitting
3	219170	1	. Hose Assembly	33	216907	1	. Hose Assembly
4	561535	1	. Button Assembly	34	234112	1	. Hose Assembly
5	* 572227	1	. Valve Assembly, Treadle	35	216774	2	. Hose Assembly
6	220987	1	. Switch, Pressure	36	209934	1	. Fitting
7	* 543583	1	. Brake Valve Assembly, Emerg	37	221283	1	. Hose Assembly
8	225108	1	. Fitting	38	216454	1	. Hose Assembly
9	225048	1	. Fitting	39	216455	1	. Hose Assembly
10	* 577742	1	. Air Tank Assembly	40	209086	2	. Fitting
11	579694	1	. Air Tank II W/Ftgs	41	217430	1	. Hose Assembly
12	579693	1	. Air Dryer Assembly	42	216481	1	. Hose Assembly
13	* 570028	1	. Brake Relay W/Ftgs, Lh	43	216458	2	. Hose Assembly
14	* 570027	1	. Valve Assembly, Rh Relay	44	216450	2	. Hose Assembly
15	* 545557	1	. Air Tank,Failsafe W/Ftgs	45	216778	2	. Hose Assembly
16	* 544996	1	. Air Governor W/Ftgs	46	216453	1	. Hose Assembly
17	20859	1	. Fitting	48	232981	2	. Hose Assembly
18	209085	1	. Fitting	50	215092	1	. Hose Assembly
19	216471	1	. Hose Assembly	51	526313	1	. Tube Assembly
20	209393	2	. Fitting	52	220351	1	. Hose Assembly
21	248264	1	. Hose Assembly	53	538477	1	. Tube Assembly
22	209109	1	. Fitting	54	217432	1	. Hose Assembly
23	216480	1	. Hose Assembly				
24	216457	2	. Hose Assembly				
27	216479	6	. Hose Assembly				* See Separate Coverage
28	209304	1	. Fitting				