


Air Valve Module



- 3 FROM TREADLE VALVE
- 4 TO PARK BRAKE SWITCH ON PANEL
- 5 TO BRAKE RELAYS
- 6 CONNECT TO SEAT
- 7 CONNECT TO PILOT CONTROLS
- 9 TO RIGHT BRAKE BUTTON
- 10 TO SUPPLY PRESSURE/AIR TANK
- 11 TO TREADLE VALVE

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	577610		Air Valve Module				
2	* 201352	2	. Holdback Valve	13	209500	1	. Fitting
3	219150	1	. Switch, Pressure	14	215197	1	. Fitting
4	207902	1	. Manifold	15	-----	1	. Hose Assembly
5	* 239444	1	. Valve, Solenoid 24V	16	222321	1	. Fitting
6	209952	1	. Fitting	17	541732	1	. Bracket
7	209317	1	. Fitting	18	209920	1	. Fitting
8	209512	6	. Fitting	20	577578	1	. Plate, Air Valve
9	209394	1	. Fitting	21	545588	2	. Bracket
10	209921	2	. Fitting	28	229944	1	. Fitting
11	210299	1	. Air Cleaner				
12	216477	2	. Hose Assembly				* See Separate Coverage