


Switch Box Assembly



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	<b>579407</b>		<b>Switch Box Assembly</b>				
1	579397	1	. Box	12	16719	1	. Outlet
2	23595	5	. Contact Block	13	237532	1	. Gasket
3	23594	5	. Knob, Selector	14	220579	2	. Connector, Cord
4	23593	5	. Switch	15	219517	5	. Connector, Cord
5	241312	5	. Legend Plate	16	22623	1	. Panel
6	579398	1	. Decal	17	17175	2	. Grounding Bar
7	579399	1	. Decal	18	222793	9	. Terminal
8	579400	1	. Decal	19	222794	4	. Amp, End
9	579404	1	. Decal	20	222795	4IN	. Track
10	579405	1	. Decal	21	227592	2	. Jumper
11	237529	1	. Cover, 1-Gang	22	230640	4	. Machine Screw