


Handle Assembly, Joystick



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	580098		Handle Assembly, Joystick				
1	*a 252282	1	. Faceplate Assy, w/Wire Harness	14	249911	1	. Adapter Bushing
2	*a 249900	1	. . Faceplate Assy, 2 Button	15	249912	1	. Flex Button Repair Kit
3	*a 249901	1	. . . Faceplate	16	*a 249154	1	Plug
4	*a 249902	1	. . . 2 Button Overlay	17	*a 249155	1	Wedge, Lock
5	*a 250627	2	. . . Momentary Switch	18	*a 243236	3	Socket
6	*a 249904	4	. . . Capscrew	19	*a 249280	3'	Loom, Woven Pet
7	*a NSS	1	. . Wire Harness (Not Illustrated)				
8	250062	1	. Handle Case, Right				
9	250063	1	. Handle Case, Left				
10	249907	1	. Trigger Insert				
11	249908	1	. Mounting Pin				
12	249909	5	. Capscrew				
13	249910	1	. Grommet				

*a Included in 582024, Button & Harness Kit.

*b Note: Joystick 580098 is shipped with proportional switches (Item 5). On these units, if any of the items marked "*a" are to be replaced, order kit 582024, which retrofits the joystick to have momentary switches.