

Cowl Assembly



Cowl Assembly

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	580300		Cowl Assembly				
1	240158	4	. Capscrew	26	* 580594	1	. Panel Assembly, Terminal
2	521106	8	. Pad	27	201634	2	. Capscrew
3	521125	4	. Spacer	29	222598	2	. Washer
4	224121	8	. Nut	32	229186	2	. Capscrew
5	230893	4	. Capscrew	35	00179866	8	. Capscrew
6	533716	4	. Pipe, Support	36	09428830	4	. Washer
8	562366	16	. Gusset	37	224119	4	. Nut
9	* 577625	1	. Column ,Strg	38	570639	1	. Mounting Plate
10	* 580322	1	. Panel Assembly,Dash	39	234868	2	. Capscrew
11	* 580598	1	. Shifter, Trans	40	580640	1	. Plate Guard
12	* 577143	1	. Pedal Assembly	41	232182	1	. Knob, Spinner
13	200301	4'	. Molding	42	R13806980	14	. Washer
14	580223	1	. Floor, Cowl	43	00103339	6	. Washer
15	222441	4	. Nut	44	223654	10	. Nut
16	* 580589	1	. Junction Box Assembly	45	201602	2	. Capscrew
17	* 580323	1	. Instrument Panel Assembly	46	540528	2	. Step Assembly
18	223146	18	. Capscrew	47	560858	4	. Bar,Spacer
19	576834	1	. Superstructure	48	574056	4	. Plate
20	580226	1	. Cowl	49	571495	4	. Bolt, Step
21	231931	2	. Capscrew	50	242377	4	. Capscrew
22	* 580327	1	. Pedal Assembly, Lh	51	R13808536	2	. Capscrew
23	244506	1	. Steering Wheel	52	577424	1	. Spacer
24	580583	1	. Bracket				
25	230496	1	. Cap, Horn				

* See Separate Coverage