

Hydraulic System - Cowl to Valves



- 1 ▲ FOR THE SUPPLY AND RETURN PLUMBING, REFER TO THE UNIT MASTER SHEET FOR THE HYD. SYSTEM - IMPL. CONTROL, SUPPLY & RETURN DRAWING.
- 2 ▲ REFER TO CONTROLS IMPL. - SEAT MTD. HYD. ON THE UNIT MASTER SHEET FOR REMOTE CONTROLLER INSTALLATION AND COWL RELATED PLUMBING.
- 3 ▲ WHEN PRESSURIZING EITHER PILOT PORT, OPPOSITE WORK PORT IS ENERGIZED, WHEN NO PRESSURE IS APPLIED VALVE SENSES NEUTRAL AND HOLD.

CIRCUIT FOR SWIVEL TYPE SEAT

Hydraulic System - Cowl to Valves

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	580688		Hydraulic System - Cowl To Valves				
1	230860	4	. Hose Assembly	5	227979	2	. Hose Assembly
2	223784	8	. Fitting	6	250444	2	. Hose Assembly
3	248284	4	. Fitting	7	250445	2	. Hose Assembly
4	250443	2	. Hose Assembly				