


Door Panel Assembly



1 NOTE: LABEL AS SHOWN.  
SEE WIRING DIAG. ON M/S FOR  
CIRCUIT BREAKER CALLOUT.

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
<b>580718 Door Panel Assembly</b>							
1	246932	4	. Fuse Holder	13	00103339	1	. Flat Washer
2	223062	1	. Circuit Breaker	14	209702	1	. Clamp
3	223065	1	. Circuit Breaker	15	578962	1	. Decal
4	229306	2	. Circuit Breaker	16	219383	10'	. Wire
5	223067	4	. Circuit Breaker	17	209706	1	. Clamp
6	223377	4	. Circuit Breaker	18	578960	1	. Wire Harness
8	229301	2	. Relay	19	219404	4'	. Wire
9	234495	4	. Capscrew	20	578961	2	. Bar
10	224191	4	. Nut, Esna	21	246930	2	. Latch, Compression
11	00103338	4	. Flat Washer	22	243609	1	. Fuse
12	224209	1	. Nut, Esna	23	246933	3	. Fuse