

Hydraulic System - Cowl to Valves



FOR THE SUPPLY AND RETURN PLUMBING, REFER TO THE UNIT MASTER SHEET FOR THE HYD. SYSTEM - IMPL. CONTROL, SUPPLY & RETURN DRAWING.

REFER TO CONTROLS IMPL. - SEAT MID. HYD. ON THE UNIT MASTER SHEET FOR REMOTE CONTROLLER INSTALLATION AND COWL RELATED PLUMBING.

WHEN PRESSURIZING EITHER PILOT PORT, THE OPPOSITE PORT IS ENERGIZED. WHEN NO PRESSURE IS APPLIED VALVE SENSES NEUTRAL AND HOLD.



Hydraulic System - Cowl to Valves

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	580859		Hydraulic Sys.- Cowl to Valves				
1	14826	4	. Hose Assembly	5	250440	2	. Hose Assembly
2	223784	8	. Fitting	6	250441	4	. Hose Assembly
3	209488	4	. Fitting	7	250442	2	. Hose Assembly
4	250439	2	. Hose Assembly				