



Air Cleaner Installation

Air Cleaner Installation


Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	583113		Air Cleaner Installation				
1	* 224214	1	. Air Filter	14	209317	1	. Fitting
2	579593	1	. Tube,Air	15	207856	1	. Hose Assembly
3	563892	1	. Tube,Air	16	225132	1	. Fitting
4	556944	1	. Tube	17	224226	2	. Elbow
5	583333	1	. Tube Weldment,Air Intake	18	208234	2	. Elbow
6	210631	11	. T-Bolt Clamp	19	207148	1	. T-Bolt Clamp
7	241059	4	. Insert	20	211601	1	. Air Inlet Hood
8	221499W	5	. Capscrew	21	239531	1	. Elbow
9	223654	5	. Locknut	22	570696	2	. Bracket Weldment
10	201570	4	. Spring Washer	23	205274	1	. Band, Mounting
11	208136	1	. Indicator	24	236572	4	. Stud, Weld
12	208137	1	. Filter, Restriction	25	216609	4	. T-Bolt Clamp
13	508790	1	. Bracket Assembly	26	R13806980	6	. Flat Washer

* See Separate Coverage





SECTION C-C



SECTION D-D
STUD LOCATIONS