

Wheels & Tires




Front Wheel Assembly

Wheels & Tires

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
583114 Wheels & Tires							
1	*a 206745	2	. Adapter	8c	???	2	.. Lock Ring
2	249519	2	. Tire	8d	???	2	.. Driver Key
3	249520	2	. Tire	8e	206062	2	.. O-Ring
4	221834	4	. Spud Assembly	14	511428	2	. Rim Base Assembly
5	221835	4	. Housing, Core	14a	204602	2	.. Cup, Bearing
6	221836	2	. Stem, Valve	14b	204639	2	.. Cup, Bearing
7	222244	2	. Stem, Valve	15	202941	4	. Flange
8	583120	2	. Wheel Assembly	16	202959	2	. Bead Seat
8a	???	4	.. Side Ring	17	202960	2	. Ring, Lock
8b	???	2	.. Bead Band	18	225495	2	. O-Ring

*a Use as required



Rear Wheel Assembly