

Load Indicator


Load Indicator

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	584847		Load Indicator				
1	231286	1	. Box, Electrical	13	227374	1	. Connector, Cord
2	574234	1	. Panel	14	241761	1	. End Stop
3	237620	4	. Leveler	15	224065	1	. Light, Green Indicator
4	18461W	4	. Capscrew	16	219404	30'	. Wire
5	R13811443	4	. Washer	17	219410	2'	. Wire
6	R13811181	4	. Locknut	18	219406	30'	. Wire
7	22631	2	. Relay	19	219408	30'	. Wire
8	22632	2	. Relay Socket	20	200247	8	. Terminal Ring
9	236924	4	. Terminal Block	21	200248	8	. Terminal Ring
10	236925	4	. Plate	22	213257	12	. Tie Strap
11	236926	2	. Jumper, Horizontal				
12	22628	1 m	. Rail, Din				

SYSTEM WIRING



INSTRUMENT PANEL



NOTE:

INSTALL COMPONENT BOX (LEVEL SENSOR), HORIZONTAL, ON CARRIAGE.

LOCATE AND DRILL INSTRUMENT PANEL FOR LAMP.

WIRE RELAYS NC., SO LAMP IS ON IN OK. TO RUN POSITION (LEVEL).

