




Panel Assembly, RH Gauge



NOTES:  
1: ITEM 6 INSTALLED FROM GAUGE "A" SOCKET TO NEXT GAUGE "B" SOCKET

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	<b>587924</b>		<b>Panel Assembly, RH Gauge</b>				
1	588135	1	. Plate, RH Gauge Panel	9	590164	1	. Decal, Trans Press (Visual)
2	254935	1	. Gauge, Aux Oil Pressure	10	590162	1	. Decal, Trans Temp (Visual)
3	254934	1	. Gauge, Aux Oil Temperature	11	590163	1	. Decal, Trans Temp
4	258707	1	. Gauge, Fuel Level	12	590160	1	. Decal, Trans Pressure
5	251326	1	. Voltmeter Gauge	13	590177	1	. Decal, Fuel Level
6	251338	4	. Wire Harness, Powerview Jumper	14	590178	1	. Decal, Voltage
7	255254	1	. Alarm, Audible	15	590182	1	. Decal, Alarm
8	249694	1	. Plug				