


Joystick, 4 Button



| Item | Part No.      | Qty | Description                       | Item | Part No. | Qty | Description                 |
|------|---------------|-----|-----------------------------------|------|----------|-----|-----------------------------|
|      | <b>589214</b> |     | <b>Handle, Joystick, 4 Button</b> |      |          |     |                             |
| 1    | 589570        | 1   | . Switch Pack Assembly            | 3    | 589565   | 1   | . Microswitch Kit           |
| 2    | 589563        | 1   | . Case Kit                        | 4    | 589569   | 1   | . Wire Harness with Grommet |