

LH Service Bay Assembly

LH Service Bay Assembly

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	591828		Service Bay Assembly, LH				
1	591823	1	. Service Bay Weldment, LH	18	591792	1	. Sending Unit, Fuel
2	* 592344	1	. Door Assembly	19	593922	1	. Weldment, Pipe Nipple W/Baffle
3	591764	1	. Door Weldment	20	592034	1	. Coupling, Reducer
4	590815	4	. Door Hinge Weldment	21	253085	1	. Breather
5	590826	4	. Plate, Washer	22	* 582937	1	. Battery Box Installation
6	591711	4	. Bolt, Shoulder	23	Y19C-M1625	4	. Capscrew
7	293646W	8	. Capscrew	24	906182	1	. Switch, Rocker
8	296422W	10	. Hard Washer	25	594118	1	. Cover Plate
9	591777	1	. Cover Weldment, Exhaust	26	293628W	9	. Capscrew
10	296027W	10	. Capscrew	27	594138	1	. Cover Plate
11	592532	5	. Bumper, Threaded	28	561316	1	. Bracket Weldment, Fuel Filter
12	251199	5	. Capscrew	29	209759	1	. Fitting
13	587034	5	. Jam Nut	30	R13804109	1	. Fitting
14	592055	1	. Cover Plate	31	302401W	1	. Locknut
15	296420W	16	. Hard Washer	32	594222	1	. Hose Assembly, Fuel
16	236805	6	. Capscrew				
17	587278	1	. Fill, Fuel Tank				

* See Separate Coverage



E