


Handle, Joystick, 2 Button, 1 Trigger, 1 Slider



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	<b>594234</b>		<b>Handle, Joystick, 2 Button, 1 Trigger, 1 Slider</b>				
2	593520	1	. Switch Pack Assembly	11	NSS	1	. Mounting Pin
3	NSS	1	. Faceplate	12	256874	5	. Capscrew
4	250627	3	. Switch	13	249910	1	. Grommet
5	NSS	1	. Button Overlay	14	593476	1	. Adapter Bushing
6	249904	8	. Screws	15	593521	1	. Wire Harness
7	593475	1	. Handle Case, Black	16	253037	2	. Screws, Trigger Switch
9	589571	1	. Single Trigger, Black	17	256875	5	. Washer, Lock
10	253042	1	. Leaf Spring For Trigger				

NSS Not sold separately