


Handle, Joystick; 2 Button



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	594550		Handle, Joystick; 2 Button				
2	596642	1	. Switch Pack Assembly	12	256874	6	. Capscrew
2.1	NSS	1	.. Empty Faceplate	13	249910	1	. Grommet
2.2	250627	2	.. Switch	14	591978	1	. Adapter Bushing
2.3	NSS	1	.. Button Overlay	15	259044	1	. Wire Harness
2.4	249904	4	.. Screw	16	256875	6	. Washer, Lock
11	NSS	1	. Mounting Pin	17	591976	1	. Kit, Handle

NSS Not Sold Separately