



Hydraulic Oil Level Sender Installation



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	600433		Hydraulic Oil Level Sender Inst				
2.1	600267	1	. Sending Unit, Fuel/Oil				
2.2	Y26G-(1032)16	5	. Capscrew				