



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 02-Dec-03

REVISED: 14-Oct-16

Revision Level : M

PAGE: 1 of 6

MODEL: L490S

SERIAL NO: 057135

GENERAL INFORMATION

SECTION 1

1-1	General
-----	Master Check Sheets
80-035	How to Read Your Master Check Sheet
800137	Alphabetical Index
80-007A	Procedure For Ordering Parts (WAGNER)
1-2	Operation
580314	Decal Locations

POWER UNIT

SECTION 2

2-1	Engine
580302	Power Unit
249545	Engine - Cummins QSX15-C525 S/N: 39044666 (Replacement) S/N: 79019982 (Original Engine)
2-3	Lubrication
580644	Engine Oil Fill
2-4	Fuel
577195	Fuel System
2-5	Air Intake & Exhaust
580743	Exhaust Installation
580304	Air Cleaner Installaion
224214	Air Cleaner
2-6	Cooling
246855	Radiator/Oil Cooler/After Cooler Assembly

DRIVETRAIN

SECTION 3

3-1	General
580303	Driveline Installation
3-2	Transmission and Converter
590660	Transmission
580585	Transmission Installation
580305	Transmission Circuit
578293	Shift Valve, 24V
248962	Converter



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 02-Dec-03

REVISED: 14-Oct-16

Revision Level : M

PAGE: 2 of 6

MODEL: L490S

SERIAL NO: 057135

DRIVETRAIN

SECTION 3

3-3

Drivelines

249854	Driveline Assembly
249853	Driveline Assembly
249667	Driveline Assembly
249303	Driveline Assembly
249020	Driveline Assembly
248963	Driveline Assembly

3-4

Axles

587932	Disc Brake Caliper
580700	Differential & Carrier
580699	Wheel End & Differential Kit
580231	Drive Axle Installation
579881	Shield Assembly, Axle Seal
577281	Parking Brake Installation
576705	Differential & Carrier Assembly
576367	Rear Axle Installation
243270	Axle Assembly
211953	Planet Carrier Assembly

3-5

Wheels & Tires

576990	Wheel Assembly, Rear
547331	Wheel Assembly, Drive
	Rear Tires: 29.5 x 29 22 Ply Toyo G-18 E-3
	Front Tires: 33.5 x 33 44 Ply Toyo G-18 L-3/G-3

BRAKE SYSTEM

SECTION 4

4-1

Systems

580317	Air System - Chassis
580306	Hydraulic Brake System
577365	Air System - Cab

4-3

Supply Components

245411	Accumulator; Pre-Charge 1500 psi
--------	----------------------------------

4-4

Control Components

246929	Charge Valve
246199	Brake Valve
236261	Solenoid Valve
229042	Shuttle Valve



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 02-Dec-03

REVISED: 14-Oct-16

Revision Level : M

PAGE: 3 of 6

MODEL: L490S

SERIAL NO: 057135

BRAKE SYSTEM

SECTION 4

4-5 Actuator Components

244409 Parking Brake Caliper
220326 Air Cylinder

4-6 Miscellaneous

509574 Air Hose Kit

HYDRAULIC SYSTEM

SECTION 5

5-1 Systems & Circuits

580549 Hydraulic System - Cooler
580310 Hydraulic System - Chassis
580308 Hydraulic System - Hoist & Tilt
580307 Hydraulic System - Steering
575661 Hydraulic System - Boom
569364 Hydraulic System - Carriage

5-2 Pumps

580637 Remote Pump Compensator
249546 Hydraulic Pump
249406 Hydraulic Pump

5-3 Valves

580309 Valve Module
578473 Manifold Assembly
249588 Control Valve
234990 Steering Flow Amplifier
234291 Steering Control Unit

5-4 Cylinders

W5162 Hydraulic Cylinder, Holddown
W5161 Hydraulic Cylinder, Kickoff
W10708 Tilt Cylinder Installation
W10390 Hydraulic Cylinder - Hoist
576513 Cylinder Assembly
576503 Steering Cylinder Installation
566290 Hydraulic Cylinder, Tilt
558685 Hydraulic Cylinder

5-5 Filters

243457 Return Filter (In-Tank)
228201 High Pressure Filter (100 GPM)



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 02-Dec-03

REVISED: 14-Oct-16

Revision Level : M

PAGE: 4 of 6

MODEL: L490S

SERIAL NO: 057135

HYDRAULIC SYSTEM

SECTION 5

5-6 **Miscellaneous**
566262 Oil Cooler Assembly

ELECTRICAL SYSTEM

SECTION 6

6-1 **Systems & Circuits**
577643 Reverse Alarm

6-2 **Components**
580594 Terminal Panel Assembly
580589 Junction Box Assembly
580544 Main Valve Junction Box Assembly
580543 Chassis Wiring
576827 Carriage Lights
576826 Rear Cab Lights
576825 Cab Lights
576822 Light Bar Installation
234183 Alternator

CAB & COWL

SECTION 7

7-1 **Basic Structure**
580300 Cowl Assembly
579950 Cab Assembly
572039 Door Assembly, LH
572038 Door Assembly, RH
570421 Cab & Cowl Insulation
568456 Door Latch, RH
568431 Door Latch, LH



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 02-Dec-03

REVISED: 14-Oct-16

Revision Level : M

PAGE: 5 of 6

MODEL: L490S

SERIAL NO: 057135

CAB & COWL

SECTION 7

7-2

Instruments & Controls

580598	Electric Shift Controller
580327	Pedal Assembly, LH
580323	Instrument Panel Assembly
580322	Dash Panel Assembly
577625	Steering Column
577143	Pedal Assembly
572904	Adjustable Arm Assembly
572858	Wiper Delay Installation
249549	Joystick Handle
249548	Joystick Handle
249547	Joystick w/o Handle

7-3

Miscellaneous

580676	Armrest Assembly, RH
580672	Armrest Assembly, LH
580546	Stereo/Cassette Installation
580313	Air Conditioner / Heater Installation
580301	Seat Assembly
579756	Wiper Assembly, Rear
579755	Wiper Assembly, Front
578077	Brake Buttons Kit
573463	Defroster Fan Installation
240063	A/C Condenser, Remote Mount
238382	Air Conditioner/Heater
236982	Seat Assembly
231800	Seat Suspension

FRAME & ATTACHMENTS

SECTION 8

8-1

Frame & Attachments

580299	Chassis Assembly
580058	Swivel Box Installation
570709	Boom Assembly
561058	Carriage Assembly

8-2

Miscellaneous

580721	Battery Box Installation
--------	--------------------------



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 02-Dec-03

REVISED: 14-Oct-16

Revision Level : M

PAGE: 6 of 6

MODEL: L490S

SERIAL NO: 057135

ACCESSORIES & OPTIONS

SECTION 9

9-1

580312

575669

Accessories & Options

Fire Suppression System

Fire Suppression System, Cab