



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 15-Apr-11

REVISED: 13-Jul-12

Revision Level : #3

PAGE: 1 of 4

MODEL: L100

SERIAL NO: 093202

GENERAL INFORMATION

SECTION 1

1-1	General
-----	Master Check Sheets
80-035	How to Read Your Master Check Sheet
79-245	Manufacturer's Warranty (Wagner)
1-2	Operation
80-103	Heavy Lift Vehicle Start & Stop Procedures
1-3	Service
WSB0130	Capscrew Grades & Torque Ratings
1-4	Safety
80-508	Safety

POWER UNIT

SECTION 2

2-5	Air Intake & Exhaust
80-986	Air Cleaner Service Instructions
2-6	Cooling
E0124	Radiator Fill Procedures
80-976	Digital Fan Controller Unit Troubleshooting
80-970	Service Manual, RTTS Tube & Shell Cooler
80-967	Service Manual, Mesabi Copper Tube RAD/CAC

DRIVETRAIN

SECTION 3

3-2	Transmission and Converter
E0017	Breather Maint for Converters & Trans.
80-981	Maintenance & Service Manual - 8000 Transmission
80-900	Maintenance & Service Manual - C8000 Converter
80-487	Electric Shift Control - Plumbing Diagram
80-486	Engine Flywheel Indicator Set-Ups
80-469	Transmission Circuit Plumbing
3-3	Drivelines
WSB0386	Lumberjack Speed Warning
E0054	Driveline Installation & Lubricants
80-627	Driveline Service & Maintenance



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 15-Apr-11

REVISED: 13-Jul-12

Revision Level : #3

PAGE: 2 of 4

MODEL: L100

SERIAL NO: 093202

DRIVETRAIN

SECTION 3

3-4	Axles
SM25D	Maintenance & Service Manual - 25D Series Axle
80-538	Differential Service - 25D
80-119	Tailpost Service & Inspection
3-5	Wheels & Tires
80-510	Wheels & Tires

AIR & BRAKE SYSTEMS

SECTION 4

4-1	Systems
80-994	Wet Disk Brake Maintenance Manual
80-588	Duo-Cone Seal Installation
80-513	Brake System Operation - Wet Disc
4-4	Control Components
80-895	Service Instructions - MICO 466 Series Single Power Brake Valve
80-893	Service Instructions - MICO Brake Valve Pedal Assembly
4-5	Actuator Components
80-767	SCL25 Dry Disc Park Brake Calipers Maint Manual
4-6	Miscellaneous
80-305	Basic Declutch System w/ Magnetic Pickup

HYDRAULIC SYSTEM

SECTION 5

5-1	Systems & Circuits
E0087	Troubleshooting Hydraulic Systems
80-421	DANFOSS Steering System Operation & Troubleshooting
80-187	Basic Lumberjack Hydraulic Troubleshooting
586169	Hydraulic Schematic
5-2	Pumps
WSB0079	Gear Pump Failures
80-983	Oilgear Type "PVWJ" Pumps
80-679	Hydraulic Pump Service Instructions



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 15-Apr-11

REVISED: 13-Jul-12

Revision Level : #3

PAGE: 3 of 4

MODEL: L100

SERIAL NO: 093202

HYDRAULIC SYSTEM

SECTION 5

5-3	Valves
80-568	Service - Husco Port Relief / Anti-Cav
80-423	Steering Control Unit Service
80-422	Flow Amplifier Service
80-271	Service Manual for HUSCO Control Valves
5-4	Cylinders
W10615	Hoist Cylinder Installation
80-044	Wagner Hydraulic Cylinder Repair
5-5	Filters
80-553	Hydraulic In-Tank Return Filter - Maintenance
80-244	High Pressure Filter Service
5-6	Miscellaneous
80-236	Pressurized Hydraulic Tank Warning

ELECTRICAL SYSTEM

SECTION 6

6-1	Systems & Circuits
586170	Electrical Schematic
6-2	Components
E0161	Alternator Servicing Precautions
80-092	Battery Maintenance

CAB & COWL

SECTION 7

7-1	Basic Structure
80-512	Service Manual - HD Vehicle HVAC Systems

FRAME & ATTACHMENTS

SECTION 8

8-1	Frame & Attachments
80-850	Structural Welding Repair - Wagner

ACCESSORIES & OPTIONS

SECTION 9

9-1	Accessories & Options
80-902	Owner's Manual - Ansul Fire Suppression/Detection Systems



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 15-Apr-11

REVISED: 13-Jul-12

Revision Level : #3

PAGE: 4 of 4

MODEL: L100

SERIAL NO: 093202

MAINTENANCE & LUBRICATION

SECTION 10

10-1

80-683

80-257

80-1014

Maintenance and Lubrication

Maintenance & Lube Manual, Logstackers

Lubricant Selection & Specifications

2 Wheel Drive Jack Locations