



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 28-Jun-05
REVISED: 14-May-10

Revision Level : M

PAGE: 1 of 6
MODEL: L120D
SERIAL NO: 101219

GENERAL INFORMATION

SECTION 1

1-1	General
-----	Master Check Sheets
80-035	How to Read Your Master Check Sheet
800137	Alphabetical Index
80-007A	Procedure For Ordering Parts (WAGNER)
1-2	Operation
580148	Decal Locations

POWER UNIT

SECTION 2

2-1	Engine
581804	Power Unit
251535	Engine, Caterpillar C15 Serial Number: JRE00215 Perf.-Spec.: OK-5581 Arrangement Number: 254-3835
2-3	Lubrication
581670	Dipstick & Housing Installation
576920	Engine Oil Fill
2-4	Fuel
577195	Fuel System
2-5	Air Intake & Exhaust
582126	Exhaust Installation
582122	Air Filter Indicator - In Cab
578210	Engine Intake System
226636	Air Filter
2-6	Cooling
581376	Radiator/Aftercooler/Surge Tank
249984	Transmission Cooler

DRIVETRAIN

SECTION 3

3-1	General
582084	Driveline Installtion



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 28-Jun-05
REVISED: 14-May-10

Revision Level : M

PAGE: 2 of 6
MODEL: L120D
SERIAL NO: 101219

DRIVETRAIN

SECTION 3

3-2	Transmission and Converter
581809	Transmission Circuit
581805	Torque Converter
579954	Transmission Installation
578293	Shift Valve, 24V
247471	Transmission
228640	Pressure Regulating Valve
3-3	Drivelines
249022	Driveline Assembly
249017	Driveline Assembly
3-4	Axles
580700	Differential & Carrier
580006	Axle w/3 Calipers
577281	Parking Brake Installation
574669	Tailpost Installation
570733	Disc Brake Caliper Assembly
569926	Disc Brake Caliper Assembly
249162	Wheel End & Differential Carrier
211953	Planet Carrier Assembly
3-5	Wheels & Tires
574681	Wheel Assembly, Rear
229546	Wheel Assembly, Drive
	Rear Tires: 26.5 X 25 Michelin Radial
	Front Tires: 24.00 X 35 Michelin XDT Radial

AIR & BRAKE SYSTEMS

SECTION 4

4-1	Systems
581808	Hydraulic Brake System
577747	Air System - Chassis
577365	Air System - Cab
4-2	Modules
577407	Air Governor
4-3	Supply Components
577408	Air Tank Assembly
245411	Accumulator
232914	Expello Valve - 24V



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 28-Jun-05
REVISED: 14-May-10

Revision Level : M

PAGE: 3 of 6
MODEL: L120D
SERIAL NO: 101219

AIR & BRAKE SYSTEMS

SECTION 4

4-4 Control Components

581242 Manifold Assembly
537346 Pressure Switch
244868 Brake Valve
229042 Shuttle Valve

4-5 Actuator Components

244409 Parking Brake Caliper

4-6 Miscellaneous

509574 Air Hose Kit

HYDRAULIC SYSTEM

SECTION 5

5-1 Systems & Circuits

582102 Hydraulic System - Steering
582005 Hydraulic System - Seat Mounted Controls
581806 Hydraulic System - Chassis
577418 Hydraulic System - Cowl To Valves
577416 Hydraulic System - Carriage
574671 Hydraulic System - Hoist And Tilt

5-2 Pumps

581804PA Pump Arrangement
252407 Hydraulic Pump
248990 Pump, Brake/Pilot
245931 Hydraulic Pump
245520 Hydraulic Pump

5-3 Valves

581807 Valve Module
581404 Manifold Assembly
572071 Pressure Relief Valve
250637 Hoist & Tilt Valve
249361 Remote Control Valve
236764 Remote Control Valve
236721 HD/KO Valve, LH & RH
234990 Steering Flow Amplifier
234081 Steering Control Unit



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 28-Jun-05
REVISED: 14-May-10

Revision Level : M

PAGE: 4 of 6
MODEL: L120D
SERIAL NO: 101219

HYDRAULIC SYSTEM

SECTION 5

5-4	Cylinders
W11033	Hoist Cylinder
W10970	Steering Cylinder
574896	Tilt Cylinder, RH
574895	Tilt Cylinder, LH
574894	Tilt Cylinder Installation
574867	Hydraulic Cylinder, Holddown
574010	Tilt Cylinder Sub-Assembly
569848	Hydraulic Cylinder
558313	Hydraulic Cylinder, Auxiliary HD
534397	Kickoff Cylinder
5-5	Filters
243457	Return Filter (In-Tank)
228201	High Pressure Filter (100 GPM)
228200	High Pressure Filter (40 GPM)
5-6	Miscellaneous
578843	Low Hydraulic Oil Warning
543268	Heater, Hydraulic Tank

ELECTRICAL SYSTEM

SECTION 6

6-1	Systems & Circuits
577753	Reverse Alarm Circuit
6-2	Components
582216	Light, Warning Amber
582107	Junction Box Assembly
582006	Engine Brake System
581933	Terminal Panel Assembly
576827	Carriage Lights
576826	Rear Cab Lights
576825	Cab Lights
576822	Light Bar Installation
574193	Chassis Wiring



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 28-Jun-05
REVISED: 14-May-10

Revision Level : M

PAGE: 5 of 6
MODEL: L120D
SERIAL NO: 101219

CAB & COWL

SECTION 7

7-1	Basic Structure
581803	Cowl Assembly
581076	Cab Assembly
572039	Door Assembly, LH
572038	Door Assembly, RH
570581	Floor Mat Installation
570421	Cab & Cowl Insulation
568456	Door Latch, RH
568431	Door Latch, LH
7-2	Instruments & Controls
582117	Instrument Panel Assembly
580598	Electric Shift Controller
579408	Steering Column
572904	Adjustable Arm Assembly
572858	Wiper Delay Installation
561565	Low Air Buzzer
7-3	Miscellaneous
581110	Cab Pressurizer
581107	Air Conditioner/Heater Installation
579756	Wiper Assembly, Rear
579755	Wiper Assembly, Front
573463	Defroster Fan Installation
573234	Stereo Cassette Installation
570875	Training Seat Installation
240063	A/C Condenser, Remote Mount
238382	Air Conditioner/Heater
236982	Seat Assembly
231800	Seat Suspension

FRAME & ATTACHMENTS

SECTION 8

8-1	Frame & Attachments
582419	Chassis
581801	Carriage Assembly
573882	Boom
8-2	Miscellaneous
582455	Battery Box Installation



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 28-Jun-05
REVISED: 14-May-10

Revision Level : M

PAGE: 6 of 6
MODEL: L120D
SERIAL NO: 101219

ACCESSORIES & OPTIONS

SECTION 9

9-1	Accessories & Options
581811	Fire Suppression System
578987	Fire Detection System
577637	Remote Lube System