



# MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 19-May-09

REVISED: 16-Dec-09

Revision Level : N

PAGE: 1 of 3

MODEL: CHD100

SERIAL NO: 103288

---

## GENERAL INFORMATION

## SECTION 1

<b>1-1</b>	<b>General</b>
-----	Master Check Sheets
80-035	How to Read Your Master Check Sheet
79-245	Manufacturer's Warranty (Wagner)
<b>1-2</b>	<b>Operation</b>
80-103	Heavy Lift Vehicle Start & Stop Procedures
<b>1-3</b>	<b>Service</b>
WSB0130	Capscrew Grades & Torque Ratings
<b>1-4</b>	<b>Safety</b>
80-508	Safety

---

## POWER UNIT

## SECTION 2

<b>2-5</b>	<b>Air Intake &amp; Exhaust</b>
80-045A	Air Intake System (Service)
<b>2-6</b>	<b>Cooling</b>
E0124	Radiator Fill Procedures
80-691	Transmission Cooler Tube Removal & Replacement
80-287	Radiator & Oil Cooler Service

---

## DRIVETRAIN

## SECTION 3

<b>3-2</b>	<b>Transmission and Converter</b>
SM84	Maintenance & Service Manual - 8000 Transmission
E0017	Breather Maint for Converters & Trans.
80-900	Maintenance & Service Manual - C8000 Converter
80-487	Electric Shift Control - Plumbing Diagram
80-486	Engine Flywheel Indicator Set-Ups
80-469	Transmission Circuit Plumbing
<b>3-3</b>	<b>Drivelines</b>
E0054	Driveline Installation & Lubricants
80-627	Driveline Service & Maintenance



# MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 19-May-09

REVISED: 16-Dec-09

Revision Level : N

PAGE: 2 of 3

MODEL: CHD100

SERIAL NO: 103288

---

## DRIVETRAIN

## SECTION 3

<b>3-4</b>	<b>Axles</b>
80-854	2050 Series Posi-Torq Limited Slip Differential Service Manual
80-853	53R300 Drive Axle Service Manual
80-819	Friction Disc Lining Wear Check Procedure
80-790	Dana 53R Wheel End and Brake Service Manual
<b>3-5</b>	<b>Wheels &amp; Tires</b>
80-510	Wheels & Tires

---

## AIR & BRAKE SYSTEMS

## SECTION 4

<b>4-1</b>	<b>Systems</b>
80-873	Wagner Chip/Coal Dozer Brake System
<b>4-4</b>	<b>Control Components</b>
80-895	Service Instructions - MICO 466 Series Single Power Brake Valve
80-893	Service Instructions - MICO Brake Valve Pedal Assembly

---

## HYDRAULIC SYSTEM

## SECTION 5

<b>5-1</b>	<b>Systems &amp; Circuits</b>
E0087	Troubleshooting Hydraulic Systems
80-421	DANFOSS Steering System Operation & Troubleshooting
586077	Hydraulic Schematic - 7130 Valve Kit
585989	Hydraulic Schematic
<b>5-2</b>	<b>Pumps</b>
WSB0079	Gear Pump Failures
80-679	Hydraulic Pump Service Instructions
<b>5-3</b>	<b>Valves</b>
80-568	Service - Husco Port Relief / Anti-Cav
80-423	Steering Control Unit Service
80-422	Flow Amplifier Service
80-271	Service Manual for HUSCO Control Valves
80-241	Remote Control Valve Service
<b>5-4</b>	<b>Cylinders</b>
80-044	Wagner Hydraulic Cylinder Repair



# MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 19-May-09

REVISED: 16-Dec-09

Revision Level : N

PAGE: 3 of 3

MODEL: CHD100

SERIAL NO: 103288

---

## HYDRAULIC SYSTEM

SECTION 5

<b>5-5</b>	<b>Filters</b>
80-553	Hydraulic In-Tank Return Filter - Maintenance
80-244	High Pressure Filter Service
<b>5-6</b>	<b>Miscellaneous</b>
80-236	Pressurized Hydraulic Tank Warning

---

## ELECTRICAL SYSTEM

SECTION 6

<b>6-1</b>	<b>Systems &amp; Circuits</b>
586078	Electrical Schematic - 7130 Valve Kit
585219	Electrical Schematic
<b>6-2</b>	<b>Components</b>
E0161	Alternator Servicing Precautions
80-092	Battery Maintenance

---

## CAB & COWL

SECTION 7

<b>7-1</b>	<b>Basic Structure</b>
80-512	Service Manual - HD Vehicle HVAC Systems

---

## FRAME & ATTACHMENTS

SECTION 8

<b>8-1</b>	<b>Frame &amp; Attachments</b>
80-850	Structural Welding Repair - Wagner
80-222	Center Swivel Bearing Adjustment Procedure

---

## ACCESSORIES & OPTIONS

SECTION 9

<b>9-1</b>	<b>Accessories &amp; Options</b>
80-902	Owner's Manual - Ansul Fire Suppression/Detection Systems

---

## MAINTENANCE & LUBRICATION

SECTION 10

<b>10-1</b>	<b>Maintenance and Lubrication</b>
80-497	Maintenance & Lube, CHD100/CD1000
80-257	Lubricant Selection & Specifications