



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE:
REVISED: 06-May-08

Revision Level : J

PAGE: 1 of 3
MODEL: HLT280
SERIAL NO: 613

GENERAL INFORMATION

SECTION 1

1-1	General
-----	Master Check Sheet
80-858	General Information, HLT Service Manual
80-035	How to Read Your Master Check Sheet
79-245	Manufacturer's Warranty (Wagner)
1-2	Operation
80-859	HLT Operator Instructions
80-103	Heavy Lift Vehicle Start & Stop Procedures
1-3	Service
WSB0130	Capscrew Grades & Torque Ratings
1-4	Safety
80-860	Safety Information - HLT 185/280
80-508	Safety

POWER UNIT

SECTION 2

2-1	Engine
80-830	QSX Engine Diagnostics and Troubleshooting
2-5	Air Intake & Exhaust
80-045A	Air Intake System (Service)

DRIVETRAIN

SECTION 3

3-2	Transmission and Converter
SMC8000	Maintenance & Service Manual - C8000 Converter
SM84	Maintenance & Service Manual - 8000 Transmission
E0017	Breather Maint for Converters & Trans.
80-487	Electric Shift Control - Plumbing Diagram
80-486	Engine Flywheel Indicator Set-Ups
80-469	Transmission Circuit Plumbing
3-3	Drivelines
E0054	Driveline Installation & Lubricants
80-627	Driveline Service & Maintenance
3-5	Wheels & Tires
80-891	Wheels & Tires



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE:
REVISED: 30-Apr-08

Revision Level : J

PAGE: 2 of 3
MODEL: HLT280
SERIAL NO: 613

AIR & BRAKE SYSTEMS

SECTION 4

4-3	Supply Components
80-194	Expello Valve Service
4-5	Actuator Components
80-248	Park Brake Caliper Service

HYDRAULIC SYSTEM

SECTION 5

5-1	Systems & Circuits
E0087	Troubleshooting Hydraulic Systems
80-421	DANFOSS Steering System Operation & Troubleshooting
584731	Hydraulic Schematic
5-2	Pumps
WSB0079	Gear Pump Failures
80-557	Service Manual - Hydraulic Pump/Motor
5-3	Valves
80-423	Steering Control Unit Service
80-422	Flow Amplifier Service
5-4	Cylinders
80-861	Hydraulic Cylinders - HLT 185/280
80-044	Wagner Hydraulic Cylinder Repair
5-5	Filters
80-553	Hydraulic In-Tank Return Filter - Maintenance
80-244	High Pressure Filter Service
5-6	Miscellaneous
80-862	Hydraulic Troubleshooting - HLT 185/280
80-236	Pressurized Hydraulic Tank Warning

ELECTRICAL SYSTEM

SECTION 6

6-1	Systems & Circuits
80-863	Electrical System - HLT 185/280
584813	Electrical Schematic
6-2	Components
E0161	Alternator Servicing Precautions
80-092	Battery Maintenance



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE:
REVISED: 01-May-08

Revision Level : J

PAGE: 3 of 3
MODEL: HLT280
SERIAL NO: 613

CAB & COWL

SECTION 7

7-1	Basic Structure
80-888	Cab & Cowl - HLT 280
80-512	Service Manual - HD Vehicle HVAC Systems

FRAME & ATTACHMENTS

SECTION 8

8-1	Frame & Attachments
80-889	Installation for the Optional Expander Pivot Pin System
80-850	Structural Welding Repair - Wagner

MAINTENANCE & LUBRICATION

SECTION 10

10-1	Maintenance and Lubrication
80-887	Maintenance & Lubrication, Schedule and Specifications - HLT280