



1968 PARTS LIST

for

Model 200W and 200T

Model 300W and 300T

Model 330W



POLICY

1. It is the policy of J. A. Freeman & Son to constantly improve its products whenever it is practical to do so.
2. J. A. Freeman & Son reserve the right to redesign or change its equipment or component parts thereof without incurring any obligation to install or furnish such changes on equipment previously delivered.
3. Unauthorized changes or additions to equipment manufactured by J. A. Freeman & Son relieves the company of further responsibility for warranted operation and breakage replacement.

INSTRUCTIONS FOR ORDERING PARTS

1. Part number and description of part.
 - (a) Parts should NOT be ordered from illustration only.
 - (b) Parts should NOT be ordered from numbers on castings.
2. Order by baler serial number and model.
3. Much delay and confusion can be avoided if parts numbers are arranged in sequence on all orders.
4. State how to ship: whether by truck, stage, mail, rail, express or freight, air express or air freight.
5. Claims for shortage or error in handling of an order for parts must be made upon receipt of goods.
6. Address all orders for parts as follows:

J. A. Freeman & Son
Parts Department,
2034 N. W. 27th Avenue,
Portland, Oregon 97210

Place serial number of machine here for your convenience:

Baler Serial No.

Motor Serial No.

Left and right of machine are understood to mean from a position facing in the direction of baler travel.

Permission must be secured before any parts are returned for credit. When parts are returned, the freight must be prepaid or arrangements made so that they can be brought in by our trucks.

"NOTE"

Parts are identified by reference numbers. See parts list for correct part numbers. DO NOT USE REFERENCE NUMBERS AS PART NUMBERS.

Table of Contents

	Page
Drawbar and engine mount	1
Flywheel and pinion shaft assembly	2
Bull gear assembly	3
Plunger connecting rod assembly	4
Model 200 plunger	5, 6
Model 300 & 330 plunger	7, 8
Bale chamber	9
Knotter trip assembly	10
Axle assembly	11
Pickup feeder house	12
Pickup cylinder assembly	13
Pickup drive	14
Feed arm drive	15
Feed arm and feed fork	16
Feed arm pivot shaft	17
Knotter brake assembly	18
Wire knotter	19, 20
Wire box and guides	21
Needles and needle yoke	22
Twine knotter, clutch and mounts	23, 24
Twine fingers, guides and box	25
Bale chute and weight indicator	26
Throttle and tension control stand	27
Tension control ram assembly	28
Tension control bypass assembly	29
Tension control pump assembly	30
P.T.O. gear box	31
P.T.O. drive sheave and clutch	32
P.T.O. drive line	33
P.T.O. ball slip drive line	34
Extra items	35
Fuel tank, battery and lights	36
Multi luber centralized lubrication system	37

Index

Part No.	Page No.	Part No.	Page No.	Part No.	Page No.	Part No.	Page No.
F 7	14	F 494	9	F 898	22	F 1105	33
F 8A	14	F 497	9	F 901	32	F 1106	33
F 9A	3	F 498	2	F 934	11	F 1107	33
F 34	2	F 524	25	F 942	35	F 1108	33
F 46	4	F 525	23, 25	F 944	11	F 1129	27
F 55	4	F 543	24	F 946	21	F 1130	27
F 72	2	F 570	24, 25	F 951	32	F 1131	27
F 73	2	F 598	4	F 952	32	F 1132	2
F 83	24	F 600	9	F 954	32	F 1134	4
F 97	13	F 602	24	F 955	32	F 1151	9
F 98	13	F 604	9	F 956	32	F 1153	9
F 99	14	F 635	35	F 958	32	F 1161	32
F 100	13	F 636	35	F 959	32	F 1165	32
F 101	13	F 637	35	F 960	32	F 1189	16
F 108	26	F 638	35	F 961	32	F 1191	16
F 117	13	F 649	35	F 962	32	F 1193	16
F 122	14	F 657	24	F 963	32	F 1195	16
F 126	14	F 658	24	F 967	2	F 1221	32
F 129	14	F 659	24	F 967A	2	F 1222	32
F 153	22, 25	F 664	35	F 967B	2	F 1226	13
F 172	19, 22	F 667	11	F 979	6, 8	F 1235	16
F 181	25	F 668	11	F 985	26	F 1239	17
F 183	1	F 669	14	F 986	6, 8	F 1244	17
F 188	9	F 671	14	F 987	26	F 1245	17
F 211	11	F 672	14	F 988	26	F 1246	17
F 212	11	F 698	2	F 990	26	F 1247	17
F 213	11	F 731	11	F 993	26	F 1248	17
F 214	11	F 732	35	F 994	26	F 1250	17
F 215	11	F 733	35	F 995	26	F 1251	17
F 220	9	F 734	35	F 997	26	F 1259	15
F 221	2	F 735	35	F 998	26	F 1260	15
F 225	3	F 736	35	F 999	26	F 1261	15
F 226	3	F 747	25	F 1002	27	F 1264	14
F 227	6, 8	F 751	6, 8	F 1003	27	F 1267	3
F 246	18, 24, 31, 20, 30	F 753	3	F 1004	27	F 1290	25
F 247	24	F 755	20, 24	F 1005	27	F 1294	25
F 248	24	F 765	2	F 1006	27	F 1295	25
F 249	24	F 766	24	F 1007	27	F 1306	15
F 268	26	F 770	35	F 1008	27	F 1343	25
F 278	10	F 772	6, 8	F 1011	27	F 1344	25
F 281	16	F 773	6, 8	F 1012	27	F 1345	25
F 298	6, 8	F 774	6, 8	F 1013	27	F 1346	25
F 299	6, 8	F 775	6, 8	F 1014	27	F 1347	25
F 304	35	F 776	6, 8	F 1015	27	F 1370	3
F 312	3	F 777	6, 8, 35	F 1016	27	F 1371	27
F 318	14	F 778	5, 6, 8	F 1017	27	F 1382	11
F 321	11	F 779	6, 8	F 1018	27	F 1383	11
F 322	11	F 780	6, 8	F 1019	27	F 1385	15
F 323	11	F 781	6, 8	F 1020	27	F 1386	15
F 324	11	F 800	35	F 1021	27	F 1392	9
F 325	11	F 802	15	F 1025	27	F 1407	31
F 326	11	F 817	2	F 1026	27	F 1409	31
F 327	11	F 822	16	F 1063	32	F 1410	31
F 333	22	F 837	9	F 1064	33	F 1411	31
F 334	11	F 840	14	F 1065	33	F 1412	31
F 335	11	F 841	9	F 1066	33	F 1413	31
F 354	15	F 853	3, 12	F 1071	15	F 1414	31
F 418	14	F 856	21, 25	F 1075	29	F 1415	31
F 433	11	F 857	21, 25	F 1076	31	F 1416	31
F 440	10, 20	F 862	36	F 1078	31	F 1417	31
F 462	11	F 874	35	F 1083	31	F 1418	31
F 466	24	F 878	1	F 1084	31	F 1419	31
F 480	15	F 883	9	F 1085	31	F 1420	31
F 481	15	F 884	11	F 1087	31	F 1421	31
F 482	15	F 886	2	F 1093	31	F 1427	17
F 484	15	F 889	33, 34	F 1095	31	F 1428	17
F 485	15	F 890	33, 34	F 1101	33	F 1433	27
F 486	15	F 891	33, 34	F 1102	33	F 1436	4
F 493	9	F 892	33, 34	F 1103	33	F 1441	6, 8
		F 893	36	F 1104	33	F 1446	27

Index


II

Part No.	Page No.	Part No.	Page No.	Part No.	Page No.	Part No.	Page No.
F 1447	27	F 1620	20, 24	F 1761	37	F 5941	36
F 1450	15	F 1622	20, 24	F 1762	37	F 5922	35
F 1451	27	F 1623	20, 24	F 1763	37	F 7000	2
F 1452	27	F 1624	11	F 1764	37	F 7001	1
F 1453	27	F 1625	11	F 1865	37	F 7002	1
F 1454	27	F 1626	11	F 1766	37	F 7003	1
F 1455	27	F 1627	11	F 1767	37	F 7004	1
F 1456	27	F 1628	11	F 1768	37	F 7005	1
F 1458	27	F 1629	6, 8	F 1769	37	F 7006	1
F 1459	27	F 1632	10	F 1770	37	F 7007	1
F 1465	25	F 1633	20, 24	F 1771	37	F 7010	1
F 1497	36	F 1634	16	F 1772	37	F 7012	1
F 1499	36	F 1635	16	F 1773	37	F 7013	27
F 1505	36	F 1636	6, 8	F 1774	37	F 7014	2
F 1511	35	F 1638	26	F 1775	37	F 7015	2
F 1512	6, 8	F 1639	26	F 1776	37	F 7016	2
F 1513	10	F 1643	16	F 1777	36	F 7025	2
F 1514	10	F 1644	36	F 1778	31	F 7031	3
F 1515	10	F 1645	36	F 1779	31	F 7032	3
F 1517	10, 22	F 1648	16	F 1780	31	F 7033	3
F 1520	4	F 1649	16	F 1781	31	F 7034	3
F 1521	4	F 1653	11	F 4014	21, 22	F 7035	3
F 1522	4	F 1654	11	F 4015	21, 22	F 7036	3
F 1523	4	F 1658	27	F 4016	22	F 7037	3
F 1524	4	F 1660	22	F 4024	19	F 7038	3
F 1525	4	F 1661	3, 17	F 4030	20	F 7039	3
F 1526	4	F 1662	9	F 4046	19	F 7040	3
F 1527	4	F 1667	36	F 4050	16	F 7042	4
F 1528	4	F 1672	25	F 4067	21, 26	F 7046	36
F 1529	4	F 1673	16	F 4068	21, 26	F 7048	36
F 1530	4	F 1675	35	F 4069	21	F 7049	36
F 1531	10	F 1676	35	F 4076	24	F 7051	14
F 1537	6, 8	F 1677	35	F 4077	24	F 7052	14
F 1548	22	F 1678	24	F 4078	24	F 7053	14
F 1549	22	F 1679	24	F 4081	22	F 7055	9
F 1550	22	F 1680	24	F 4115	20, 24	F 7056	9
F 1551	22	F 1686	10	F 4133	20	F 7062	19
F 1552	22	F 1687	10	F 4134	20	F 7063	20
F 1556	16	F 1688	36	F 4135	20	F 7064	19
F 1557	16	F 1689	36	F 4136	14, 20	F 7065	19
F 1558	16	F 1691	36	F 4137	20	F 7066	19
F 1559	16	F 1697	35	F 4138	20	F 7069	20
F 1561	16	F 1698	35	F 4150	22	F 7072	20
F 1563	16	F 1699	35	F 4159	20	F 7075	19
F 1564	10	F 1700	24	F 4160	20	F 7076	19, 20
F 1568	10	F 1701	22	F 4161	20	F 7077	19
F 1571	10	F 1702	22	F 4163	21	F 7078	19
F 1572	10, 18	F 1720	31	F 4190	21	F 7079	19
F 1574	22	F 1721	2	F 4191	21	F 7080	19
F 1575	10	F 1727	33, 34	F 4193	35	F 7081	19
F 1576	20, 24	F 1728	33, 34	F 4203	21	F 7084	19
F 1577	20, 24	F 1735	15	F 4204	21	F 7085	19
F 1579	10	F 1736	36	F 4205	21	F 7086	19
F 1581	9	F 1739	15	F 4210	21	F 7087	19
F 1586	1	F 1743	34	F 4222	21	F 7089	19
F 1587	10	F 1744	34	F 4223	21	F 7121	9
F 1589	9	F 1745	34	F 4224	21	F 7122	9
F 1590	9	F 1746	34	F 4225	21	F 7123	9
F 1601	31	F 1747	34	F 5080	27	F 7127	12
F 1603	16	F 1749	34	F 5159	21	F 7136	25
F 1605	1	F 1751	34	F 5232	36	F 7142	12
F 1607	1	F 1752	34	F 5233	36	F 7143	12
F 1608	10	F 1753	34	F 5264	27	F 7145	12
F 1609	6, 8	F 1754	34	F 5445	17	F 7146	13
F 1611	22	F 1755	34	F 5446	17	F 7148	13
F 1613	2	F 1756	34	F 5499	36	F 7149	13
F 1614	2	F 1757	34	F 5545	27	F 7151	13
F 1617	10	F 1758	34	F 5554	27	F 7152	12
F 1618	10	F 1759	34	F 5559	27	F 7154	13
F 1619	10	F 1760	37	F 5842	36	F 7155	13

Index


Part No.	Page No.	Part No.	Page No.	Part No.	Page No.	Part No.	Page No.
F 7156	13	F 7348	19	F 7535	14	F 7628	3
F 7157	12	F 7349	20	F 7536	1	F 7629	3
F 7158	12	F 7353	19	F 7537	1	F 7630	3
F 7159	12	F 7354	3	F 7538	1	F 7631	3
F 7160	12	F 7355	13	F 7539	1	F 7632	3
F 7163	12	F 7356	13	F 7540	1	F 7633	12
F 7164	12	F 7358	3	F 7540	1, 25	F 7634	12
F 7166	12	F 7361	33	F 7542	4	F 7635	12
F 7176	13	F 7363	1	F 7543	4	F 7636	11
F 7177	13	F 7364	1	F 7546	14	F 7637	21
F 7179	13	F 7365	33	F 7547	22	F 7638	21
F 7180	13	F 7366	33	F 7548	3	F 7639	21
F 7181	13	F 7367	33	F 7549	3	F 7640	21
F 7182	13	F 7368	33	F 7550	3	F 7641	21
F 7183	13	F 7369	33	F 7551	12	F 7642	21
F 7184	13	F 7370	33	F 7552	22	F 7643	21
F 7185	13	F 7371	33	F 7554	22	F 7644	21
F 7186	13	F 7372	33	F 7555	21	F 7645	21
F 7187	13	F 7374	33	F 7556	21	F 7650	4
F 7188	13	F 7375	33	F 7557	21	F 7651	4
F 7189	13	F 7376	33	F 7558	22	F 7652	22
F 7190	13	F 7377	33	F 7559	18	F 7653	4
F 7193	13	F 7378	33	F 7560	18	F 7654	12
F 7194	1, 13	F 7379	33	F 7561	18	F 7655	26
F 7207	27	F 7382	13	F 7562	9	F 7656	26
F 7210	2	F 7387	19	F 7563	9	F 7657	26
F 7212	36	F 7388	19	F 7565	1	F 7658	26
F 7213	1	F 7391	35	F 7566	1	F 7659	26
F 7220	6, 8	F 7394	12	F 7567	1	F 7660	16
F 7227	10, 19	F 7397	9	F 7568	22	F 7661	26
F 7236	26	F 7430	1	F 7569	22	F 7662	11
F 7239	3, 16	F 7431	20	F 7570	20	F 7663	11
F 7241	2	F 7432	20	F 7571	20	F 7668	9
F 7247	20	F 7437	2	F 7572	13	F 7669	9
F 7248	19	F 7438	3	F 7573	13	F 7670	9
F 7257	20	F 7439	6, 8	F 7574	24	F 7671	35
F 7264	16	F 7448	18	F 7577	16	F 7673	35
F 7265	16	F 7449	18	F 7578	15	F 7674	35
F 7275	16	F 7450	18	F 7579	12	F 7676	35
F 7276	16	F 7451	18	F 7583	13	F 7677	35
F 7277	16	F 7452	18	F 7584	13	F 7681	1
F 7279	1	F 7453	18	F 7585	18	F 7682	1
F 7280	1	F 7454	18	F 7586	18	F 7690	25
F 7281	1	F 7456	20	F 7587	18	F 7691	25
F 7283	1	F 7457	20	F 7588	22	F 7692	33
F 7285	2	F 7461	20	F 7590	1	F 7694	33
F 7294	9	F 7462	3	F 7591	1	F 7695	33
F 7295	36	F 7463	3	F 7592	1	F 7696	1
F 7299	12	F 7472	12	F 7593	4	F 7699	2
F 7300	14	F 7482	12	F 7594	4	F 7704	2
F 7301	14	F 7485	25	F 7595	4	F 7705	21
F 7302	14	F 7488	2	F 7597	13	F 7706	14
F 7304	14	F 7507	9	F 7598	13	F 7707	1
F 7305	14	F 7515	21	F 7599	13	F 7708	4
F 7311	19	F 7516	9	F 7600	26	F 7709	4
F 7312	19	F 7517	12	F 7601	26	F 7710	16
F 7313	19	F 7519	20	F 7602	15	F 7711	22
F 7315	19	F 7520	22	F 7603	15	F 7713	12
F 7316	19	F 7521	22	F 7604	16	F 7714	12
F 7317	19	F 7522	22	F 7605	16	F 7715	1
F 7318	19	F 7523	22	F 7606	16	F 7716	21
F 7329	19	F 7524	22	F 7607	16	F 7717	21
F 7330	19	F 7526	22	F 7608	21	F 7721	35
F 7332	20	F 7527	22	F 7609	35	F 7722	35
F 7333	20	F 7528	18	F 7610	16	F 7723	35
F 7334	20	F 7529	16	F 7612	15	F 7725	1, 34
F 7335	20	F 7530	16	F 7617	35	F 7727	35
F 7337	2	F 7532	16	F 7624	26	F 7728	35
F 7345	20	F 7533	16	F 7626	35	F 7730	13
F 7346	20	F 7534	16	F 7627	3	F 7729	35

Part No.	Page No.	Part No.	Page No.	Part No.	Page No.	Part No.	Page No.
F 7731	13	F 7826	8	F 7897	18	FT 200	28
F 7732	13	F 7827	9	F 7898	25	FT 201	28
F 7734	13	F 7828	9	F 7899	22	FT 202	28
F 7735	6,8,33,35	F 7829	14	F 7901	11	FT 208	29
F 7737	2	F 7830	4	F 7902	11	FT 209	29
F 7738	6, 8	F 7831	4	F 7903	22	FT 210	29
F 7739	6, 8	F 7832	4	F 7904	18, 24	FT 211	29
F 7741	13	F 7833	4	F 7905	24	FT 500	30
F 7742	36	F 7834	4	F 7906	24	FT 504	30
F 7743	36	F 7835	4	F 7907	24	FT 503	30
F 7746	9	F 7836	4	F 7909	24	FT 505	30
F 7749	11	F 7837	6	F 7910	33	FT 506	30
F 7750	11	F 7838	4	F 7911	9	FT 507	30
F 7751	11	F 7839	6			FT 508	30
F 7752	11	F 7840	6	FT 10	28	FT 509	30
F 7753	11	F 7841	4	FT 11	28	FT 510	30
F 7754	11	F 7842	4	FT 12	28	FT 511	30
F 7755	11	F 7843	8	FT 13	28	FT 512	30
F 7756	11	F 7844	8	FT 14	28	FT 513	30
F 7757	11	F 7845	22	FT 15	28	FT 514	30
F 7758	11	F 7847	1	FT 16	28	FT 517	30
F 7759	6, 8	F 7848	1	FT 18	28, 30	FT 518	30
F 7760	13	F 7849	1	FT 19	28	FT 519	30
F 7761	8	F 7850	24	FT 25	32	FT 521	30
F 7763	6, 8	F 7851	24	FT 50	29	FT 523	30
F 7764	6, 8	F 7852	24	FT 53	29	FT 524	30
F 7765	8	F 7853	24	FT 54	29	FT 525	30
F 7766	6, 8	F 7854	24, 25	FT 55	29	FT 527	30
F 7767	8	F 7855	24	FT 58	29	FT 528	30
F 7768	8	F 7856	24	FT 61	29	FT 529	30
F 7769	6, 8	F 7857	24	FT 62	29	FT 530	30
F 7776	8	F 7858	24	FT 63	29	FT 533	30
F 7777	6, 8	F 7859	24	FT 65	29	FT 534	30
F 7780	11	F 7860	24	FT 67	29	FT 535	30
F 7782	11	F 7861	24	FT 68	29	FT 536	30
F 7789	12	F 7862	24	FT 72	29, 35	FT 537	30
F 7792	19	F 7863	24	FT 73	28	FT 538	30
F 7793	19	F 7864	24	FT 74	28, 29, 35	FT 539	30
F 7794	19	F 7865	24	FT 75	28	FT 541	30
F 7795	1	F 7866	24	FT 82	30	FT 542	30
F 7796	19	F 7867	24	FT 87	29		
F 7797	9	F 7868	24	FT 101	30		
F 7798	9	F 7869	24	FT 107	29, 30		
F 7799	1	F 7870	24	FT 113	30		
F 7800	1	F 7871	24	FT 114	30		
F 7801	6	F 7872	24	FT 123	29		
F 7802	8	F 7873	24	FT 136	28, 29		
F 7803	8	F 7874	24	FT 137	28		
F 7804	8	F 7875	24	FT 150	29, 30		
F 7805	8	F 7876	24	FT 153	28		
F 7896	8	F 7877	24	FT 157	2, 30		
F 7897	8	F 7878	24	FT 163	28		
F 7808	6	F 7879	24	FT 177	29		
F 7809	6	F 7880	24	FT 178	29		
F 7810	6	F 7881	24	FT 179	29		
F 7811	6	F 7882	24	FT 180	28		
F 7812	8	F 7883	24	FT 181	28		
F 7813	8	F 7884	24	FT 182	28		
F 7814	8	F 7885	25	FT 183	28		
F 7815	8	F 7886	24	FT 184	29		
F 7816	8	F 7887	25	FT 185	29		
F 7817	8	F 7888	25	FT 187	29, 30		
F 7818	8	F 7889	25	FT 188	29		
F 7819	8	F 7890	25	FT 191	29, 30		
F 7820	8	F 7891	25	FT 192	29		
F 7821	8	F 7892	24	FT 193	29, 30		
F 7822	8	F 7893	24	FT 194	29		
F 7823	8	F 7894	24	FT 197	30		
F 7824	8	F 7895	25	FT 198	28		
F 7825	8	F 7896	25	FT 199	28		




DRAWBAR AND ENGINE MOUNT

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7799	Engine mount, R.H.	15	F 7001	Drawbar for engine baler
	F 7847	Engine mount, R.H. for VH4D and V461D engine on Model 200 only		F 7696	Drawbar for PTO baler
	F 7848	PTO Gear box mount, R.H.	16	F 7002	Drawbar locking pin
2	F 7800	Engine mount, L.H.	17	F 7004	Set collar, drawbar locking pin
	F 7849	PTO Gear box mount, L.H.	18	F 7003	Spring, drawbar locking pin
3	F 7279	Engine base plate, for VH4D on Model 200	19	F 7283	Actuating lever, drawbar locking pin
	F 7707	Engine base plate, for all balers using VG4D and V461D engine	20	F 7795	Link, drawbar locking pin
	F 7364	PTO Gear box plate, 2 tie only	21	F 183	Front end hitch
	F 7363	PTO Gear box plate, 3 tie only	22	F 7430	Front end jack complete for engine balers
4	F 7280	Hitch base plate 18" chamber		F 1586	Front end jack complete for PTO balers
	F 7537	Hitch base plate with pickup quadrant 22" chamber		F 878	Jack handle assembly
	F 7536	Hitch base plate with pickup quadrant 23" chamber		F 1605	Ram only for jack
	F 7012	Hitch base plate, PTO, 23" chamber		F 1607	Thrust bearing for jack
	F 7213	Hitch base plate, PTO, 22" chamber	23	F 7567	Cable connecting link for cushion spring
5	F 7010	Engine adjusting bolt (2 Used)	24	F 7566	Cushion spring (pickup cable)
6	F 7538	Pickup lift lever cross rod 300 and 330 only	25	F 7565	Pickup lift cable with ends
	F 7539	Pickup lift lever	26	F 7590	Sheave clip, pickup lift roller
	F 7725	PTO pickup lift lever 300 and 330 only	27	F 7591	Roller for pickup lift
8	F 7541	Spring for F 7540 pin	28	F 7592	Bushing for F 7591 roller
9	F 7540	Pickup lift lever adjusting pin	29	F 7194	Pickup lift bracket
10	F 7281	Pickup lift lever 200 only	30	F 7005	Rope, drawbar pin, 9'
	F 7715	PTO pickup lift lever 200 only	31	F 440	Ferrule for F 7283 lever
11	F 7681	Pickup lift crank 200 only	32		1/2" x 4" Square head set screw, 300 & 330 only
12	F 7682	Pickup lift lever stop bracket, 200 only	33		1/4" x 1/4" x 2-1/2" Key
13	F 7007	Pivot pin bracket	34		5/8" x 2-1/2" N.C. Cap screw
14	F 7006	Drawbar pivot pin	35		1/2" x 2" N.C. Cap screw
			36		1/2" x 1-1/2" Square head set screw, 200 only
			37		1/2" x 1-1/4" N.F. Cap screw
			38		1/2" x 1-1/4" Button head bolt
			39		1/4" x 1-1/4" N.C. Cap screw




FLYWHEEL AND PINION SHAFT ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7704	Flywheel with bushings, motor drive	13	F 498	Set screw for F 34 bearings, rear, 1/2" x 2" (2 used)
	F 1613	Flywheel with bushings, PTO drive	14	F 73	Set screw for F 34 bearings, front, 1/2" x 4" (2 used)
2	F 1614	Shear bushing in flywheel, flanged	15	F 7437	Pinion gear, 12 tooth
3	F 886	Bushing for F 7704 and F 1613 flywheel	16	F 7025	Pinion shaft, 23" chamber
4	F 221	Set collar, pinion shaft, 2-1/8"		F 7210	Pinion shaft, 22" chamber
5	F 7000	Drive belt, D-165, for VG4D engine and Twin engine S. P. balers		F 7285	Pinion shaft, 18" chamber
	F 7337	Drive belt, D-162, for VH4D engine and PTO	17	F 34	Bearing complete for pinion shaft, (2 used)
6	F 7014	Motor pulley 10" OD for VG4D	18	F 967	Shim for F34 bearing, 16 ga.
	F 7241	Motor pulley 8" OD for VH4D		F 967A	Shim for F34 bearing, 20 ga.
	F 7699	Motor pulley 10" OD for V461D (1-3/4" bore)		F 967B	Shim for F34 bearing, 10 ga.
7	F 817	Shear hub for flywheel	19	FT 157	Sprocket, drive for hydraulic pump
8	F 1132	Shear bushing in flywheel shear hubs	20	F 7488	Tapered key for pinions 3-1/2" (2 used)
9		1/2" x 3-1/4" heat treated cap screws with lock nuts	21	F 72	Key for shear hub 1/2" x 1/2" x 3-1/2"
10	F 7015	Shear bolt 1/2" x 5" N.C. grade 2 bright cap screw	22	F 7737	Bracket, drive belt shield with battery box
11	F 698	Bearing insert for F 765 cage	23	F 7016	Drive belt shield
12	F 765	Bearing cage for F 34 bearing	24	F 1721	Lock pin for F 698 bearing insert
			25		1/4" x 3/4" round head machine screw
			26		1/2" x 1-1/2" NC Cap screw
			27		5/8" x 2-1/4" NC Cap screw




BULLGEAR ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7038	Locking washer	15	F 7631	Bullgear shield access door 300 and 330 only
2	F 7037	Adjusting nut for side plate bearing		F 7632	Bullgear shield access door 200 only
3	F 7035	Seal for side plate #255833 (4 used)	16	F 853	Catch for bullgear shield
4	F 7033	Bearing for side plate, #33287 (4 used)	17	F 7548	Bullgear shield complete with door 300 and 330 only
5	F 7034	Bearing cup for side plate # 33462 (4 used)		F 7549	Bullgear shield complete with door 200 only
6	F 7354	Side plate, R.H. with bearing cups	18	F 9A	Sheave, pickup drive
	F 7462	Side plate, L.H. with bearing cups	19	F 753	Sprocket, knotter drive (32T #60)
7	F 7036	Seal race	20	F 1370	Crank arm
8	F 1661	Hydraulic shut-off fitting	21	F 7550	Rubber grommet (4 used)
9	F 7031	Shaft, feed fork drive	22	F 7438	Bullgear 88 tooth for F 7437 pinions (2 used)
	F 7032	Shaft, knotter drive	23	F 225	Key, knotter drive shaft, 1/2" x 1/2" x 2"
10	F 7039	Screw for locking washer, 8-32 x 1/2" H. H. C. S. (4 used)		F 226	Key, feed arm drive shaft 1/2" x 1/2" x 2-1/4"
11	F 7040	Lock washer for F 7039 screw, # 8 medium (4 used)	24		1/2" x 2-1/4" N.C. Cap screw
12	F 7358	Side plate, R.H. w/bearing and shaft, incl. Ref. 1-11	25		1/2" x 2-3/4" N.C. Cap screw
	F 7463	Side plate, L.H. w/bearing and shaft, incl. Ref. 1-11	26		5/8" x 2" N.F. Cap screw
13	F 7627	Bullgear shield less access door 300 and 330 only			5/8" x 3" N.F. Cap screw
	F 7628	Bullgear shield less access door 200 only	27	F 312	1/2" x 3-1/4" N.F.H.T. Cap screw w/fiber lock nuts
14	F 7629	Bullgear shield hinge pin 300 and 330 only	28		1/2" x 1/2" Hollow head set screw, (3 used)
	F 7630	Bullgear shield hinge pin 200 only	29	F 7239	Roll pin 3/8" x 1-1/2" for bullgear
			30	F 1267	Shim for aligning side plate
			31		1/4" x 1-1/4" N.C. Cap screw (4 used)




PLUNGER CONNECTING ROD ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7594	Conn. rod complete with heads 23" chamber, Model 300	8	F 1530	Grease seal for F 1520, F 1522 and F 1524 heads 1-15/16" #50409
	F 7595	Conn. rod complete with heads 18" chamber, Model 200	9	F 1529	Grease seal for F 1521, F 7838 and F 1523 heads 1-11/16" #471812
	F 7650	Conn. rod complete with heads 22" chamber, Model 300	10	F 7708	Plunger pin 200 only
	F 7842	Conn. rod complete with heads, 22" chamber, Model 330		F 7709	Plunger pin 300 only
2	F 7593	Conn. rod channel L.H.		F 7841	Plunger pin, 330 only
3	F 7042	Conn. rod channel R.H.	11	F 46	Crank pin, gear end 200 only
4	F 1520	Conn. rod head with bushings and seals, gear end, 200 only		F 598	Crank pin, gear and 23" chamber
	F 1522	Conn. rod head with bushings and seals, gear end, 23" chamber		F 1134	Crank pin, gear end, 22" chamber
	F 1524	Conn. rod head with bushings and seals, gear end, 22" chamber	12		5/8" x 4-1/2" NF HT cap screw
5	F 1521	Conn. rod head with bushings and seals, plunger end, 200 only	13	F 7830	Elbow for conn. rod grease tube (2 used)
	F 1523	Conn. rod head with bushings and seals plunger end, 300 only		F 7835	Steel sleeve for F 7830 & F 7833
	F 7838	Conn. rod head with bushings and seals, plunger end, 330 only	14	F 7831	Grease tube, 3/8", crank pin to F 7542 bracket, 36"
6	F 1526	Bushing for F 1521 head, plunger end, 200 only	15	F 7832	Grease tube, 3/8" plunger pin to F 7542 bracket, 7"
	F 1528	Bushing for F 1523 head, plunger end 300 and 330 only	16	F 7653	Clip for grease tube
7	F 1525	Bushing 1520 head, gear end, 2 tie only	17	F 7833	Connector, grease tubes
	F 1527	Bushing for F 1522 and F 1524 heads, gear end, 3 tie only		F 7835	Steel sleeve for F 7830 & F 7833
			18	F 7651	Grease fitting on conn. rod (2 used)
			19	F 7542	Bracket for grease tubes on conn. rod channel
			20	F 7834	Protector tube for grease tube
			21	F 1436	Clip for grease tube protector
			22	F 55	Key for crank pin (2 used)
			23	F 7543	Spring loaded grease cup for F7542
				F 7836	Conn. rod ends greasing kits, including ref. No.13 to 21




MODEL 200 PLUNGER

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7837	Plunger roller rail, top L.H.	25	F 772	Roller mounting angle R.H. front
2	F 7763	Plunger guide rail, top & bottom	26	F 777	Adapter for grease tube (4 used)
3	F 7738	Adjusting pad for plunger face, center	27	F 778	Connector for grease tube (4 used)
4	F 7739	Adjusting pad for plunger face, R.H.	28	F 7439	Knife guide under feed opening
5	F 1537	Hard slide for roller plunger (4 used)	29	F 299	Plunger slide, flat, upper R.H. side
6	F 7766	Hard slide mounting rail, L.H. top	30	F 298	Plunger slide, flat, lower R.H. side
7		5/16" x 1/2" F.H. machine screw (12 used)	31	F 7840	Plunger roller rail, R.H. Bottom
8		5/16" x 1" F.H. machine screw for plunger rail	32	F 979	Manifold for grease tubes
		5/16" x 1-1/2" F.H. machine screw for plunger rail	33		5/16" x 1-3/4" N.C. cap screw (2 used)
9	F 7839	Plunger roller rail, L.H. bottom	34	F 1441	Elbow, grease tube (4 used)
10		1/2" x 4" square head set screw, top rail (2 used)	35	F 780	Grease tube, right rear, 36"
		1/2" x 2-1/2" square head set screw bottom rail (2 used)	36	F 781	Grease tube, left front, 14"
		3/4" x 1-3/4" square head set screw (2 used) Plunger pin lock	37	F 779	Grease tube, left rear, 30"
11		Roller for top of plunger, 3/4" shank left	38	F 779	Grease tube, right front, 30"
12	F 1636	Adjusting pad for plunger face, L.H.	39	F 7735	Grommet, grease tube protector (6 used)
13	F 7769	Adjusting pad for plunger face, L.H.	40	F 7764	Plunger knife
14	F 7777	3/8" x 1" N.C. cap screw (3 used)	41	F 227	Bolt for plunger knife (3 used)
15		Roller and slide mounting angle, L.H. bottom	42	F 1609	Knife, stationary with square holes
16	F 7761	3/8" x 3-3/4" N.C. cap screw (12 used)	43	F 1629	Bolt for F 1609 knife (4 used)
17		1/4" x 3/8" Allen head set screw (4 used)	44	F 751	Shim for F 1609 knife, 14 ga.
18		Roller for plunger (4 used)	45	F 1512	Shim for F 1609 knife, 20 ga.
19	F 775	Pin, plunger roller (4 used)	46	F 7801	Plunger complete, less knife 16" x 18" chamber
20	F 776	Wiper, rear (2 used)	47		1/8" P.T. grease fitting
21	F 986	Wiper, front (2 used)	48	F 7808	Bale chamber bottom, 18" chamber
22	F 774	1/4" x 1-1/4" F.H. machine screw (8 used)	49	F 7809	Liner extension for bale chamber bottom, R.H., 18" chamber
23		Roller mounting angle R.H. Rear	50	F 7810	Liner extension for bale chamber bottom, center, 18" chamber
24	F 773		51	F 7811	Liner extension for bale chamber bottom, L.H., 18" chamber
			52	F 7220	Liner for bale chamber side, R.H.
			53	F 7759	Liner for bale chamber, L. H., 16" chamber
					3/8" x 1-1/4" # 3 Plow bolt
					3/8" x 1-1/2" # 3 Plow bolt




MODEL 300 & 330 PLUNGER

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7765	Plunger roller rail, top L.H.	44	F 751	Shim for F 1609 knife, 14 ga.
2	F 7763	Plunger guide rail, top & bottom		F 1512	Shim for F 1609 knife, 20 ga.
3	F 7738	Adjusting pad for plunger face, center 300 T only, (2 used)	45	F 7802	Plunger complete, less knife 16" x 22" chamber, 300,
4	F 7739	Adjusting pad for plunger face, R.H., 300T only		F 7804	Plunger complete, less knife 16" x 23" chamber, 300,
5	F 1537	Hard slide for roller plunger (4 used)		F 7803	Plunger complete, less knife 17" x 22" chamber, 300,
6	F 7766	Hard slide mounting rail, L.H. top		F 7806	Plunger complete, less knife, 16" x 22" chamber, 330,
7		5/16" x 1/2" F.H. machine screw (12 used)		F 7807	Plunger complete less knife, 17" x 22" chamber, 330,
8		5/16" x 1" F.H. machine screw for plunger rail	46		1/8" P.T. grease fitting
		5/16" x 1-1/2" F.H. machine screw for plunger rail	47	F 7843	Bale chamber bottom, 22" chamber model 300,
9	F 7762	Plunger roller rail, L.H. bottom		F 7844	Bale chamber bottom, 23" chamber, model 300,
10		1/2" x 4" square head set screw, top rail (2 used)		F 7824	Bale chamber bottom, 22" chamber, model 330.
		1/2" x 2-1/2" square head set screw, bottom rail (2 used)	48	F 7813	Liner extension for bale chamber bottom, R.H., Model 330, 22" chamber
11		3/4" x 1-3/4" square head set screw (2 used) Plunger pin lock		F 7814	Liner extension for bale chamber bottom, R.H., Model 300 22" chamber
12	F 1636	Roller for top of plunger, 3/4" shank		F 7815	Liner extension for bale chamber bottom, R.H., Model 300, 23" chamber
13	F 7769	Adjusting pad for plunger face, top left, model 300	49	F 7816	Liner extension for bale chamber bottom, R.H. center, Model 330, 22" chamber
14	F 7768	Adjusting pad for plunger face, L.H. (22" chamber) model 300		F 7817	Liner extension for bale chamber bottom, R.H. & L.H. center, Model 300, 22" & 23" chamber
	F 7777	Adjusting pad for plunger face, L.H. (23" chamber) model 300	50	F 7818	Liner extension for bale chamber bottom, L.H. center, Model 330, 22" chamber
15		3/8" x 1" N.C. cap screw (3 used)		F 7817	Liner extension for bale chamber bottom, R.H. & L.H. center, Model 300, 22" & 23" chamber
16	F 7761	Roller and slide mounting angle, L.H. bottom	51	F 7819	Liner extension for bale chamber bottom L.H. Model 330 22" chamber
17		3/8" x 3-3/4" N.C. cap screw (12 used)		F 7820	Liner extension for bale chamber bottom, L.H., Model 300, 22" chamber
18		1/4" x 3/8" Allen head set screw (4 used)		F 7821	Liner extension for bale chamber bottom, L.H., Model 300, 23" chamber
19	F 775	Roller for plunger (4 used)	52	F 7220	Liner for bale chamber side, R.H. Model 300
20	F 776	Pin, plunger roller (4 used)		F 7812	Liner for bale chamber side, R.H., Model 330
21	F 986	Wiper, rear (2 used)	53	F 7759	Liner for bale chamber, L.H., 16" chamber, Model 300
22	F 774	Wiper, front (2 used)		F 7776	Liner for bale chamber, L.H., 17" chamber, Model 300
23		1/4" x 1" F.H. machine screw (8 used)		F 7825	Liner for bale chamber, L.H., 16" chamber, Model 330
24	F 773	Roller mounting angle R.H. rear		F 7826	Liner for bale chamber, L.H., 17" chamber, Model 330
25	F 772	Roller mounting angle R.H. front	54	F 7822	Wire track block, bottom
26	F 777	Adapter for grease tube (4 used)	55	F 7823	Wire track block, top
27	F 778	Connector for grease tube (4 used)	56	F 7805	Adjusting pad for plunger face, left side, model 330
28	F 7439	Knife guide under feed opening	57		3/8" x 1-1/4" # 3 Plow bolt
29	F 299	Plunger slide, flat, upper R.H. side			3/8" x 1-1/2" # 3 plow bolt
30	F 298	Plunger slide, flat, lower R.H. side			
31	F 7767	Plunger roller rail, R.H. bottom			
32	F 979	Manifold for grease tubes			
33		5/16" x 1-3/4" N.C. cap screw (2 used)			
34	F 1441	Elbow, grease tube (4 used)			
35	F 780	Grease tube, right rear, 36"			
36	F 781	Grease tube, left front, 14"			
37	F 779	Grease tube, left rear, 30"			
38	F 779	Grease tube, right front, 30"			
39	F 7735	Grommet, grease tube protector (6 used)			
40	F 7764	Plunger knife			
41	F 227	Bolt for plunger knife (3 used)			
42	F 1609	Knife, stationary with square holes			
43	F 1629	Bolt for F 1609 knife (4 used)			




BALE CHAMBER

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7507	Solid side (2 used)	18	F 7397	Sprocket for chain divider (1/2" bore) (2 used)
2	F 7121	Side tension rail (2 used)	19	F 841	Tightener bracket, knotter drive chain
3	F 1590	Top tension rail, 200 only	20	F 7670	Chain tightener adjusting bolt
	F 7122	Top tension rail, 300 only (2 used)	21		3/8" x 3/4" NC Button head bolt (8 used)
4	F 7827	Top tension rail, 330 only (2 used)	22	F 1581	Bracket for knotter drive chain shield
	F 493	Top tension angle, 18" chamber	23	F 7516	Idler roller mounting plate
	F 7668	Top tension angle, 17" x 22" chamber	24	F 883	Tightener and idler pulley for knotter drive chain
	F 7746	Top tension angle, 16" x 22" chamber	25	F 7056	Shield, knotter drive chain
5	F 7669	Top tension angle, 16" x 23" chamber	26		1/2" x 5" NC Cap screw-top & bottom tension rail 300
	F 494	Bottom tension angle, 18" chamber			1/2" x 5-1/2" NC Cap screw-top & bottom tension, 200
	F 1153	Bottom tension angle, 17" x 22" chamber			1/2" x 4" NC Cap screw-top & bottom tension, 330
	F 1151	Bottom tension angle, 16" x 22" chamber	27		1/2" x 5-1/2" NC Cap Screw-Side tension rail (2 used)
	F 604	Bottom tension angle, 16" x 23" chamber	28		1/2" x 1-1/4" NC cap screw-Tension link linkage (8 used)
6	F 1662	Spacer shim, 1 used on 200, 2 used on 300 & 330	29		3/8" x 2-1/2" NC Cap screw-Bottom tension rail (2 used-3 tie)
7	F 497	Flat linkage bar (8 used)	30		3/8" x 1-1/4" NC Cap screw-Top tension rail (2 used 3 tie - 1 used 2 tie)
8	F 600	Tension bolt, 3/4" x 27-3/4" (2 used)	31		1/2" x 2-3/4" N.C. Cap Screw (2 used)
9	F 7294	Bottom tension rail, 200 only	32		1/2" x 3" N.C. Cap screw
	F 7123	Bottom tension rail, 300 only (2 used)	33	F 7797	Front Knotter chain shield
	F 7828	Bottom tension rail, 330 only (2 used)	34	F 7798	Front knotter chain shield bracket
10	F 7563	Hay dog, R.H., 200 only			
11	F 837	Hay dog, top and bottom			
	F 7911	Hay dog, long, top, twine only			
12	F 188	Hay dog spring			
13	F 7562	Hay dog, L.H., 200 only			
14	F 220	Hay dog pin			
15	F 1589	Rubber pads for hay dogs, w/screws			
16		3/8" x 3/4" NC Cap screw			
17	F 1392	Knotter drive chain, twine tie balers (238P#60)			
	F 7055	Knotter drive chain, wire tie baler (239P#60)			
	F 759	Offset link, RC60			
	F 760	Connecting link, RC60			
	F 761	Roller link, RC60			




KNOTTER TRIP ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1617	Meter wheel shaft bracket (2 used)	13	F 7227	Bushing 3/4" x 7/8" x 3/4" oilite
2	F 1618	Meter wheel shaft bearing complete (2 used)	14	F 1514	Reset lever
	F 1619	Meter wheel shaft bearing only RAO12N.P.P.B.,	15	F 1568	Bushing, rest lever 1/2" x 5/8" x 1" oilite
3	F 1531	Meter wheel adjustable trip, 10"	16	F 1515	Clutch stop lever
4	F 1564	Meter wheel shaft w/guide washer 23" chamber	17		1/2" x 7/8" - 14 ga. machine bushing
	F 1587	Meter wheel shaft w/guide washer, 22" chamber	18	F 1517	Trip spring
	F 1575	Meter wheel shaft w/guide washer, 18" chamber	19	F 1632	Meter tripbar stop with bolt
5	F 1686	Meter trip bar	20	F 1579	Shield for meter wheel, 3 tie
6	F 1687	Knurled friction disc		F 1608	Shield for meter wheel, 2 tie
7	F 1571	Guide washer	21		1/2" x 1-1/4" N.C.C.S. trip bar stop
8	F 278	Spring	22		1/2" x 1-1/4" N.C.C.S. clutch stop
9	F 440	Ferrule	23		5/16" x 2" N.F.C.S. clutch stop clamp
10	F 1572	Cam follower bearing	24		3/8" x 1-1/4" N.C.C.S. knurled roller and washers
11	F 1513	Knotter trip mount	25		5/16" x 3/4" N.C.B.H. bearing to bracket
12		3/4" x 1-1/4" - 10 ga. machine bushing	26		3/16" x 3/4" Cotter key
			27		1/8" x 1" Cotter key




AXLE ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7749	Tubular axle, 23" chamber	12	F 884	Washer for F 7752 spindle
	F 7750	Tubular axle, 22" chamber		F 327	Washer for F 7753 dual wheel spindle
	F 7751	Tubular axle, 18" chamber	13	F 934	Nut for F 7752 spindle
2	F 944	Wheel, flat base for F 1624 hub		F 326	Nut for F 7753 spindle
	F 322	Wheel, flat base for F 321 dual wheel hub	14	F 1628	Hub cap for F 1624 hub (46749)
	F 211	Wheel, drop center for F 1624 hub		F 334	Hub cap for F 321 dual wheel hub (07347)
3	F 7901	Flat base single wheel with 8 ply tire, tube and flap, mounted	15	F 462	Lug bolt for F 1624 hub
	F 731	Dual wheel with 8 ply tire, tube and flap, mounted		F 335	Lug bolt for F 321 dual wheel hub
4	F 212	Tire, 7:50 x 16 - 4 ply, R.H.	16	F 214	Lug nut for F 462 bolt (15085)
	F 213	Tire, 7:50 x 16 - 8 ply, L.H.		F 433	Lug nut for F 335 dual wheel bolt
	F 215	Inner tube, 7:50 x 16 for F 212 tire	17	F 7756	Mounting channel, R.H. wheel, 5/8" hole
	F 667	Inner tube, 7:50 x 16 T.B. for flat base rim	18	F 7636	Spacer plate, used w/Tandem wheel plate on right side
	F 668	Flap for flat base rim	19	F 7757	Tandem wheel plate, L. or R.
5	F 7752	Spindle for F 1624 hub	20	F 7662	Single wheel hub with bearings complete less spindle
	F 7753	Spindle for F 321 dual wheel hub		F 7663	Dual wheel hub with bearings complete less spindle
6	F 1624	Hub with cups for F 211 and F 944 wheels	21	F 7754	Dual wheel hub w/F 7753 spindle complete
	F 321	Hub with cups for F 322 dual wheel (# 82165)		F 7755	Single wheel hub w/F 7752 spindle complete
7	F 1653	Inner cup for F 1624 hub (LM29710)	22	F 7758	Bolt for Spindle, 5/8" x 1-7/8" N.F.H.T.
	F 1382	Inner cup for F 321 dual wheel hub (3720)		F 7780	Tandem wheel assembly to replace single assy., including 1-F7757 plate, 1-F7755 hub & spindle, 1-F7901 wheel & tire.
8	F 1625	Inner wheel bearing for F 1624 hub (LM29749)		F 7782	Tandem wheel assembly to replace dual assy., including 1-F7757 plate, 2-F7755 hub & spindle, 2-F944 wheel.
	F 323	Inner wheel bearing for F321 dual wheel hub (3780)		F 7902	Tandem wheel assembly complete, including 1-F7757 plate, 2-F7755 spindle & hub, 2-F7901 wheel & tire.
9	F 1627	Grease retainer for F 1624 hub (54605K.H.)			
	F 325	Grease retainer for F 321 dual wheel hub (5875)			
10	F 1654	Outer cup for F 1624 hub (L44610)			
	F 1383	Outer cup for F321 dual wheel hub (3320)			
11	F 1626	Outer wheel bearing for F1624 hub, (L44640)			
	F 324	Outer wheel bearing for F 321 dual wheel hub (3379)			




PICKUP FEEDER HOUSE

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7482	Support angle for guard pipes	15	F 7152	Feeder house back sheet
2	F 7158	Hay hold down, outside	16	F 7145	Feeder house bottom wear plate
3	F 7299	Guard angle	17	F 7166	Catch for access door
4	F 7472	Guard pipe, outside with latch mounting plate	18	F 7633	Access door for F 7551 shield
5	F 7163	Guard pipe, center	19	F 7634	Shield over pickup, rear
6	F 7164	Guard pipe, inside	20	F 7551	Shield over pickup complete
7	F 7159	Hay hold down, center	21	F 7635	Tool box lid
8	F 7160	Hay hold down, inside	22	F 853	Catch for tool box cover
9	F 7157	Angle brace for feeder house bottom sheet	23	F 7517	Shield for needle yoke drive arm and brake
10	F 7394	Pickup stop	24	F 7579	Bracket knotter drive arm shield
11	F 7143	Feeder house end plate	25	F 7654	Brace for F 7579 bracket
12	F 7713	Feeder house bottom	26	F 7714	Feeder house bottom end shim, R.H.
13	F 7142	Feeder house rear and top section	27	F 7789	Shim for top of feeder house end plate
14	F 7127	Upright shield under hood			




PICKUP CYLINDER ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7598	Roller for F 7597 cam lever	25	F 7185	Stripper, outside
2	F 7599	Cam lever only		F 7741	Stripper, outside, special for F 7730
	F 7597	Cam lever with roller (6 used)	26	F 7186	Tooth bar (6 used)
3	F 1226	Pickup finger 6-1/2" shank (54 used)	27	F 7382	Bearing, R.H. pickup mounting pull type
4	F 101	Pipe, pickup finger guide pipe (42 used)	28	F 117	Pickup fender guard spacer (40 used)
5	F 7187	Tooth bearing (12 used)	29	F 7181	Top stripper bar
6	F 98	Pin, tooth bar (6 used)		F 7730	Top stripper bar (formed)
7	F 7584	Bearing, pickup shaft L.H.	30	F 7182	Pickup joint sheet
8	F 7583	Bearing, pickup shaft R.H.		F 7731	Pickup joint sheet, special, for F 7730
9	F 7179	Pickup shaft	31	F 7156	Spring plate
10	F 100	Pickup finger guide (60 used)	32	F 7154	Spring for pickup balance (2 used)
11	F 7189	Pickup flange R.H.	33	F 7155	Eyebolt for pickup balance spring (2 used)
12	F 7188	Pickup flange L.H.	34	F 7146	Skirt for fender
13	F 7573	Fender, outside	35	F 7149	Fender extension
14	F 7148	Fender flare, outside	36	F 97	Key 1/4" x 1/4" x 1-1/2" flange to shaft
	F 7355	Fender flare extension, outside	37		5/16" x 2" N.C. cap screw
15	F 7193	Fender mounting clip (4 used)	38		5/16" x 2-1/4" N.C. cap screw
16	F 7180	Bottom stripper bar	39		5/16" x 1" N.C. cap screw
17	F 7190	Pickup cam	40		5/16" x 1" C. S. machine screw
18	F 7572	Fender, inside	41		1/4" x 1/2" R. H. machine screw
19	F 7194	Pickup lift bracket, pull type	42		5/16" x 1-3/4" C. S. machine screw
20	F 7151	Fender flare, inside	43		7/16" x 1-1/2" N.C. cap screw
	F 7356	Fender flare extension, inside	44		1/2" x 2-1/2" N. C. cap screw
21	F 7176	Bearing, L.H. pickup mounting	45		5/16" x 3/4" N. C. cap screw
22	F 7177	Pickup frame			
23	F 7184	Stripper, inside			
	F 7732	Stripper, inside, special, for F 7730			
24	F 7183	Stripper, center (17 used)			
	F 7734	Stripper, center, special, for F 7730			
				F 7760	Pickup complete, less balance springs, lift bracket and mounting bearings




PICKUP DRIVE

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7304	Pickup drive shaft shield, 300 & 330 23\"	10	F 669	Pickup shaft bearing cage with bearing and seal
	F 7706	Pickup drive shaft shield, 300 & 330 22\"	11	F 99	Set collar, 1-3/8\"
	F 7305	Pickup drive shaft shield, 200	12	F 8A	Pickup driven sheave
2	F 7829	Brace for pickup drive shaft shield	13	F 7	Pickup clutch ring
3	F 7051	Universal drive shaft complete, 300 & 330	14	F 126	Pickup clutch spring
	F 7302	Universal drive shaft complete, 200	15	F 1264	Pickup drive shaft, hardened and ground
4	F 7053	Universal with square tube, 300 & 330	16	F 122	Key, 1/4\"
	F 7301	Universal with square tube, 200	17	F 418	Pickup clutch spring cap
5	F 7052	Universal with square shaft, 300 & 330	18		1/2\"
	F 7300	Universal with square shaft, 200	19	F 7535	Pickup drive belt (CX105) for pull type balers
6	F 318	Universal joint repair kit	20	F 7546	Pickup drive belt tightener bracket
7	F 4136	Washer (2 used)	21		1/2\"
8	F 671	Grease seal for F 669 (40169) (2 used)	22	F 840	Idler pulley, pickup belt tightener
9	F 672	Needle bearing for F 669 (BH2216) (2 used)	23	F 129	Spring, pickup belt tightener
			24		1/2\"




FEED ARM DRIVE

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1386	Lock nut (1" jam)	12	F 7602	1" nut with thrust washer
2	F 1260	Hardened washer 1-3/8" x 2-1/2" x .025 (4 used)	13	F 7603	Thrust washer for F 7578 block
3	F 1071	Inner race for F 480 bearing I.R. 1812 (4 used)	14	F 7578	Thrust bearing block
4	F 1306	Crank pin only	15	F 7612	Bushing for F 7578 block, 1-3/16" x 1-5/16" x 1-1/4"
5	F 1259	Spacer for F 1071	16	F 1735	Feed arm conn rod only, pull type balers
6	F 1261	Hardened washer 1" x 2-1/2" x .065 (2 used)	17	F 1739	Feed arm conn rod assembly
7	F 1385	Lock nut (1" full)	18	F 482	Universal joint complete RH thread
8	F 486	Bearing block with bearings (2 used)	19	F 354	Adjusting block RH thread
9	F 485	Bearing pin in F 484 strap (4 used)	20	F 484	Strap for universal (4 used)
10	F 481	Bearing in F 486 block (small) B 1212 (4 used)	21	F 1450	Crank pin with races, washers and nuts complete
11	F 480	Bearing in F 486 block (large) B2212 (4 used)	22	F 802	Washer, bearing pin
			23		3/4" star lock washer




FEED ARM AND FEED FORK

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7710	Feed fork complete 300 & 330 only	28	F 7660	Torque shaft bearing with bushing
	F 7530	Feed fork complete 200 only	29	F 1235	Bushing for torque shaft bearing (2" x 2-1/2" x 1")
2	F 7265	Tine, trailing, inside 2-1/2" offset	30	F 7275	Roll pin (1/2" x 2") (2 used)
3	F 1191	Tine, trailing, center	31	F 7239	Roll pin (3/8" x 1-1/2")
4	F 7264	Tine, trailing, outside 2-1/2" offset	32	F 7276	Ferrule for F 1563
5	F 1603	Tine, leading, short (2 used)	33		7/16" x 1-1/2" N. F. H. T. cap screw
6	F 1189	Tine, outside center	34	F 281	Spring latch
7	F 1195	Clip for tines	35	F 1563	Catch for torque shaft
8	F 1193	Bushing and stop for tines	36	F 1648	Shim for straddle mount, 16 ga.
9	F 7532	Bottom plate		F 1649	Shim for straddle mount, 22 ga.
10	F 7534	Bolt, 3/8" x 2-3/4" N. F. H. T. C. S.	37	F 1634	Straddle mount plate for pivot shaft
11	F 7533	Roller plate	38		Bolt, 1/2" x 3" NF with nut, straddle mount plate clamp
12	F 4050	Latch roller			
13	F 7604	Latch	39		5/8" x 1-3/4" N.C. cap screw, straddle mount plate
14	F 7607	Bushing for F 7604 latch	40	F 1673	1/2" x 3" N.F. cap screw with lock nut, grade 8, feed arm clamp
15	F 7605	Latch hinge pin	41		1/2" x 4-1/4" N.F. cap screw with lock nut, clamp for feed arm pin
16	F 7606	Trip arm	42		1/2" x 3 N.F. cap screw with lock nut, torque shaft
17	F 1556	Trip arm bushing	43		5/16" x 2-1/2" N.C. cap screw, for spring and stop latch
18	F 1557	O ring (2 used)	44		7/16" x 1-1/2" N.C. cap screw, latch hinge pin
19	F 1558	Trip arm sleeve	45		3/8" x 2-1/2" N. F. H. T. cap screw (5 used)
20	F 1559	Trip arm pin			
21	F 1635	Trip arm spring			
22	F 1643	Trip arm spring rod			
23	F 1561	Trip arm spring rod clevis pin			
24	F 822	Cam follower for spring arm (CF1-S)			
25	F 7610	Quad ring for F 7604 latch			
26	F 7577	Feed arm			
27	F 7529	Torque shaft, 1-1/2"			



FEED ARM PIVOT SHAFT


REF. NO.	PART NO.	DESCRIPTION
1	F 1244	Feed arm bearing housing w/2-F5445 bearing cups
2	F 1248	Plug cap (HP 3750-134)
3	F 1247	Retaining ring (RR 375)
4	F 1245	Nut, bearing takeup (N-10) (2 used)
5	F 1246	Lock washer (W-10)
6	F 5445	Bearing cup (362A) (2 used)
7	F 5446	Bearing cone (368A) (2 used)
8	F 1428	Oil seal, used with F 1427 shaft (nat. 55093)
9	F 1239	Dust cap
10	F 1427	Pivot shaft
11	F 1250	Pivot shaft plate, 16" chamber
	F 1251	Pivot shaft plate, 17" chamber
12	F 1661	Hydraulic shut-off fitting # 1940B



KNOTTER BRAKE ASSEMBLY


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7528	Brake disc with hard notch, 1-3/8" for wire balers	12	F 7586	Bushing for saddle lever 3/4" x 1" x 1-1/2"
	F 7897	Brake disc with hard notch, 1-1/8" for twine balers	13	F 7585	Saddle lever sleeve
2	F 7450	Outside brake plate with lining	14	F 1572	Cam follower, saddle lever
3	F 7451	Brake plate stud (2 used)	15	F 7448	Saddle lever spring eyebolt
4	F 7453	Brake plate spring (2 used)	16	F 7559	Saddle lever spring
5	F 7449	Inside brake plate with lining	17	F 7452	Brake plate bolt, 1/4" x 3-1/2" N.C.
6	F 7454	Brake lining with rivets (2 used)	18	F 7904	3/8" x 3/8" x 2" key for brake disc
7		Rivets for brake lining (6 used)	19		1/2" x 3-1/4" N.C. cap screw w. fibre lock nut for brake clamp
8	F 246	Saddle lever washer	20		5/16" x 1-1/4" N.C. cap screw w. fibre lock nut for saddle lever
9	F 7587	Seal for saddle lever anchor (63123 Victor)	21		3/8" x 3-1/2" N.C. cap screw w. fibre lock nut for saddle lever anchor
10	F 7561	Saddle lever lower half with bushing			
11	F 7560	Saddle lever upper half with spring anchor			






WIRE KNOTTER

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7519	Clutch w/pawl 1-3/8"	21	F 4138	Clamp collar
2	F 1622	Clutch pawl	22	F 7570	Knotter mount R.H.
	F 1623	Washer each side of pawl 7/16 I.D. x 7/8" O.D. x .025	23	F 7247	Bushing for F 7072 frame 7/8" x 1" x 1"
3	F 1633	Clutch pawl pin	24	F 7431	Pinion, used with F 7432 gear
4	F 4115	Spring, clutch pawl	25	F 7257	Twister drive sprocket, 25T
5	F 4133	Notched clutch disc with F 4134 bearing 1-3/8"	26	F 7069	Pinion shaft
6	F 4134	Bearing for F 4133 disc	27	F 7076	Roll pin, pinion to shaft 1/4" x 1-1/2"
7	F 4135	Inner race for F 4134 bearing		F 4030	Roll pin, sprocket to shaft 1/4" x 2"
	F 4136	Hardened washer between F 7519 and F 4133	28	F 7334	Chain tightener rod, 200W only
8	F 755	Clutch sprocket (32T-#60)	29	F 7332	Angle for chain tightener rod, rear, 200 only
9	F 7456	Knotter shaft, 300W & 330W	30	F 7333	Angle for chain tightener rod, 200 only
	F 7457	Knotter shaft, 200W	31	F 7335	Block for chain tightener rod, 200 only
10	F 7461	Needle yoke drive arm 300W & 330W	32	F 1576	Adapter for zerk, end of knotter shaft 3/8" S. A. E.
11	F 1620	Clutch pawl pin lock	33	F 246	Knotter shaft end washer, L.H.
12	F 7349	Brace w/angle L.H. 300W & 330W	34	F 1577	Shield for knotter clutch
13	F 7346	Brace w/angle center, 300W & 330W	35	F 4159	Washer spacer, 10 ga., 1-3/8" I.D.
14	F 7345	Brace w/angle R.H., 300W & 330W		F 4160	Washer spacer, 14 ga., 1-3/8" I.D.
15	F 440	Ferrule for F 7346 brace, 300W & 330W		F 4161	Washer spacer, 18 ga., 1-3/8" I.D.
16	F 7571	Knotter mount L.H.	36		3/8" x 1-1/2" NC cap screw
17	F 7432	Intermittent gear, used with F 7431 pinion	37		1/2" x 3" NC cap screw
18	F 7072	Pinion frame	38		3/8" x 3/8" x 2-3/4" Key
19	F 7063	Bearing, knotter shaft (2 used)	39		1/2" x 2-3/4" NC cap screw
20	F 4137	Bushing for F 7072 frame, 1-3/8" x 1-1/2" x 2"	40		3/8" x 3/8" x 2" key
			41		1/8" straight grease fitting




WIRE BOX AND WIRE GUIDES

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 4014	Roller for wire guide and needle	23	F 7642	Wire box divider angle
2	F 4015	Bushing for F 4014 roller	24	F 7643	Wire box base with end plate
3	F 4222	Wire guide frame only (lower rear)	25	F 7644	Angle for wire alarm mounting bracket, L.H.
4	F 857	Snap ring for F 856 bushing	26	F 7645	Angle for wire alarm mounting bracket, R.H.
5	F 856	Wire guide bushing	27	F 4191	Mounting bracket for wire alarm rod L.H.
6	F 4205	Wire guide complete, lower rear	28	F 4190	Mounting bracket for wire alarm rod R.H.
7	F 4068	Bushing for F 4067 roller	29	F 7608	Rod for wire alarm 3 tie only
8	F 4067	Roller, lower front wire guide		F 7716	Rod for wire alarm 2 tie only
9	F 4223	Wire guide frame only, lower front	30	F 946	Switch only for wire alarm
10	F 4069	Wire guide complete, lower front	31	F 7555	Wire box mounting bracket
11		Bolt with lock nut 1/4" x 1" N. C. C. S.	32	F 7556	Bottom support plate for F 7555
12	F 4203	Upper wire guide complete with pin	33		Bolt with nut 1/2" x 5-1/2" N. C. C. S.
13	F 4204	Upper wire guide wear pin	34	F 7557	Wire box mounting bracket R.H.
14	F 5159	Snap ring for wear pin	35	F 7705	Brace for F 7557 RH wire box bracket
15	F 4225	Upper wire guide, bracket only	36	F 7515	6 compartment wire box complete with braces and harness
16	F 4163	Wire guide bracket, rear		F 7717	4 compartment wire box complete with braces and harness
17	F 4224	Wire guide bracket complete with ;bushing	37	F 4210	Spring for wire alarm rod
18	F 7637	Wire box divider			
19	F 7638	Wire box side (front)			
20	F 7639	Wire box side (rear)			
21	F 7640	Wire box bottom slats			
22	F 7641	Wire box end (left)			




NEEDLE AND YOKE ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7569	Needle guard L.H.	16	F 7554	Needle yoke drive rod wire only
2	F 7568	Needle guard R.H.		F 4081	Needle yoke drive rod, 2-twine only
3	F 153	Needle twine guide		F 1548	Needle yoke drive rod, 3-twine only
4	F 7558	Needle yoke, 200 wire only	17	F 1550	Needle yoke drive rod end L.H. thread
	F 7899	Needle yoke, 200 twine only	18	F 1549	Needle yoke drive rod end R.H. thread
	F 7520	Needle yoke, 300 wire only	19	F 1552	Bolt, drive rod to needle yoke with nut
	F 7574	Needle yoke, 300 twine only	20	F 1551	Bolt, drive rod to clutch with nut
	F 7903	Needle yoke, 330 wire only		F 1574	Bolt, drive rod to R.H. needle yoke drive arm, 3 tie only
5	F 7522	Needle yoke bearing complete L.H. wire only	21	F 172	Spacer collar used on twine tie only
6	F 7521	Needle yoke bearing complete R.H. wire only	22	F 7552	Bolt, needle to yoke with nut 1/2" x 3-1/4" carriage
7	F 7523	Bearing for F 7521 and F 7522 KP12A	23	F 7652	Plunger dog return lever
8	F 4150	Needle yoke bearing, R.H. and L.H. twine only	24	F 7845	Bushing for plunger dog return lever 7/8" x 1" x 7/8"
9	F 898	Spacer for needle yoke bearing, used w/F 333 needles	25	F 1517	Plunger dog return spring
10	F 7711	Needle, wide base, wire only	26	F 7524	Plunger dog return rod
11	F 1611	Needle, cast iron curved	27	F 7526	Clevis for dog return rod
	F 333	Needle, Mag. straight	28	F 7527	Clevis pin for F 7526 clevis
12	F 1702	Shim for wire needle yoke bearing	29	F 7547	Plunger stop dog
	F 1701	Shim for twine needle yoke bearing	30	F 7588	Plunger dog pin
13	F 4014	Roller for needle and wire guide 21/32" bore	31	F 1660	Pin for twine needle
14	F 4015	Bushing for F 4014 roller	32		1/2" x 1-3/4" NC cap screw
15	F 4016	Bolt, needle roller			1/2" x 2-1/4" NC cap screw




TWINE KNOTTER

REF. NO.	PART NO.	DESCRIPTION
1	F 7850	Knotter shaft bearing, 1-1/8"
2	F 602	Washer, hard (each side of retaining ring)
3	F 543	Retaining ring, 2-tie only
4	F 7851	Knotter frame complete
5	F 83	Woodruff key, 3/8" x 1-1/4", 2 tie
	F 4104	Key, 3/8" x 3/8" x 1-1/2", cam gears on 3 tie
	F 7904	Key, 3/8" x 3/8" x 2", clutch on 3 tie
6	F 247	Knotter shaft spacer washer, 10 ga.
	F 248	Knotter shaft spacer washer, 14 ga.
	F 249	Knotter shaft spacer washer, 18 ga.
	F 1678	Washer, spring steel, 1-1/8" x .025" for knotter shaft
	F 1679	Washer, spring tempered copper, 1-1/8" x .010", for knotter shaft
7	F 7852	Knotter cam gear
8	F 7853	Knotter frame only
9	F 466	Knotter shaft spacer 1", (200 only)
10	F 7854	Bolt, twine finger drive roller
11	F 7855	Knotter shaft, 2 twine
	F 7856	Knotter shaft, 3 twine
12		1/8" x 1-1/4" cotter key
13	F 7884	Knife arm pin
14	F 7857	Knife arm complete
15	F 7858	Twine knife
16	F 7859	Twine knife screw
17	F 7860	Knife arm washer
18	F 7861	Knotter bill hook
19	F 570	Roller, twine finger drive (6200-22)
20	F 7862	Pinion, knotter hook
	F 1700	Pinion, knotter hook, steel cut
21	F 7863	Knotter hook cam adjusting screw
22	F 7864	Knotter hook cam adjusting spring
23	F 7894	Washer, bill hook cam adj. spring
24	F 7865	Knotter hook cam adj. screw nut
25	F 7866	Knotter hook cam
26	F 7867	Twine holder bolt
27	F 7868	Twine holder
28	F 7869	Twine disc
29	F 7870	Twine disc cleaner
30	F 7871	Pinion, twine holder disc
31	F 7872	Roll pin
32	F 7873	Pinion, knotter worm
33	F 7874	Knotter worm shaft
34	F 1680	Washer, knotter worm shaft, 28 ga.
	F 657	Washer, knotter worm shaft, 10 ga.
	F 658	Washer, knotter worm shaft, 14 ga.
	F 659	Washer, knotter worm shaft, 18 ga.
35	F 7875	Knotter worm only
36	F 7876	Knotter worm and shaft complete
37	F 7877	Twine holder spring
38	F 7878	Twine knotter mount, L.H.
39	F 7879	Twine knotter mount, R.H.
40	F 1576	Adapter for Zerk, end of knotter shaft
41	F 246	Knotter shaft end washer
42	F 7880	Clutch w/pawl, 1-1/8" shaft
43	F 1620	Clutch pawl pin lock
44	F 1633	Clutch pawl pin
45	F 1622	Clutch pawl
46	F 4115	Spring clutch pawl
47	F 4076	Notched clutch disc w/F4077 bearing
48	F 4077	Bearing, GR22 S.S.
49	F 4078	Inner race, M.I. 18
50	F755	Sprocket, knotter clutch, 60A32
51		3/8" x 1" N.C. cap screw
52	F 7881	Knotter head anchor, 2 twine
	F 7886	Knotter head anchor, 3 twine
53	F 1577	Shield for knotter clutch
54	F 7882	Zerk, 90°
55	F 7883	Zerk, straight
56	F 1623	Washer, clutch pawl
57		3/8" x 1" N. C. cap screw
58	F 7892	Knife arm shaft washer
59	F 7893	Knife arm shaft nut
60	F 766	Washer, harden, each side of clutch bearing, 1-1/8", 16 ga.
61		1/8" Straight grease fitting
62		3/8" x 1-1/4" N.C. cap screw
63	F 7905	Knotter shaft spacer, 5/8"
	F 7906	2 twine knotter assembly complete with mounts, clutch assembly and brake assembly, serial # 20698-
	F 7907	3 twine knotter assembly complete with mounts, clutch assembly and brake assembly, serial # 30876-
	F 7908	2 twine knotter shaft assembly with clutch and brake disc.
	F 7909	3 twine knotter shaft assembly with clutch and brake disc.




TWINE FINGERS, GUIDES AND BOX

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1295	Ball joint, twine finger drive, L.H. thread	11		1/2" x 1-1/2" N.C. cap screw
	F 1343	Ball only, for F 1295	12	F 570	Roller, twine finger drive, 6200-22
	F 1345	Body only, L.H. threads for F 1295	13	F 7854	Bolt, twine finger drive roller
	F 1346	Threaded plug for F 1295	14		1/4" x 1" N.C. cap screw
	F 1347	Half bearing & spring for F 1295	15	F 7887	Twine finger drive rod
2	F 181	Bushing, twine finger	16	F 1465	Twine box, (4 compartment), 2 tie
3	F 1672	3/8" x 2-1/2", Grade 8 carriage bolt with nut		F 7690	Twine box, (8 compartment)
4	F 7885	Twine finger		F 7485	Twine box, (6 compartment) 3 tie
5		1/4" x 1-1/4" N.C. Cap screw	17	F 7136	Bracket for mounting twine box 4 and 6 compartment box
6	F 1294	Ball joint, twine finger drive, R.H. thread		F 7691	Bracket for mounting 8 compartment twine box
	F 1343	Ball only, for F 1294	18	F 7889	Twine tension base
	F 1344	Body only, R.H. threads for F 1294	19	F 7890	Twine tension top
	F 1346	Threaded plug for F 1294	20	F 7541	Twine tension spring
	F 1347	Half bearing & spring for F 1294	21	F 7891	Twine tension assembly
7	F 747	Spring, twine finger return	22	F 857	Snap ring for F 856
8	F 1290	Bearing, twine finger drive rod	23	F 856	Twine guide bushing
9	F 7895	Twine finger drive shaft assembly, 2 tie	24	F 524	Holder for twine guide bushing, 200T
	F 7896	Twine finger drive shaft assembly, 3 tie		F 525	Holder for twine guide bushing, 300T
10	F 7888	Twine finger stop bracket	25	F 153	Needle twine guide
			26	F 7898	Twine guide bushing holder




BALE CHUTE AND WEIGHT INDICATOR

REF. NO.	PART NO.	DESCRIPTION
1	F 7600	Bale chute, combination, 3 tie
	F 7601	Bale chute, combination, 2 tie
2	F 7655	Bale turner
3	F 7656	Bale skid
4	F 7657	Bale skid bracket, 2 used
5	F 7624	Flat chute adapter for combination chute
6	F 7658	Button head bolt 1/2" x 1-1/2"
7	F 7659	Chain, bale chute
8	F 108	Spring, bale chute, 2 tie turning
	F 985	Spring, bale chute 2-tie flat and 3-tie turning
	F 987	Spring, bale chute, 3-tie flat
9	F 988	Shock absorber
10	F 993	Bushing for shock absorber
11	F 1638	Shock absorber support
12	F 1639	Cable bracket
13	F 997	Weight indicator bracket
14	F 998	Indicator hand
15	F 268	Indicator return spring
16	F 999	Mounting angle for F 7236 sheave
17	F 994	Shield for F 4067 roller
18	F 4068	Bushing for F 4067 roller
19	F 4067	Roller for F 7236 sheave
20	F 995	Plate for F 4067 roller
21	F 990	Cable clamp 1/8" (2 used)
22	F 7661	Indicator cable 1/8" aircraft 65"
23	F 7236	Sheave complete, bale weight indicator




THROTTLE AND TENSION CONTROL STAND

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	F 1025	Control box complete, baler mounted	17.	F 1006	Adjusting rod
	F 1026	Control box complete, tractor mounted	18.	F 1131	Thrust bearing
	F 1451	Control box complete less cable and standard	19.	F 1007	Control knob for F 1006
2.	F 1658	Standard only	20.	F 1017	Mounting base angle
3.	F 1015	Chain, throttle control 4"	21.	F 1018	Mounting base plate
4.	F 5080	Cable stop, throttle control	22.	F 1020	Clevis pin 3/8" x 1"
5.	F 5559	Beech nut with nut and washer	23.	F 1019	Hairpin cotter key
6.	F 1003	Friction disc	24.	F 1453	Cable complete for throttle control
7.	F 1130	Cable complete for tension control 24 feet		F 1454	Conduit, throttle control, 7 feet
	F 1013	Conduit, tension control 24 feet		F 1455	Wire, throttle control, 8 feet
	F 1014	Wire, tension control 25 feet	25.	F 1447	Throttle control box only
8.	F 1129	Cable complete for throttle control 12 feet	26.	F 1456	Standard only for throttle control
	F 1011	Conduit, throttle control 12 feet	27.	F 7207	Angle bracket for VG4D throttle
	F 1012	Wire, throttle control, 13 feet	28.	F 1016	Angle bracket for VH4D, VE4D and VF4D
9.	F 5554	Knob for throttle lever	29.	F 7013	Throttle cable bracket VG4D and V461D
10.	F 1433	Throttle lever	30.	F 1021	Throttle cable bracket VH4D, VE4D and VF4D
11.	F 1002	Conical washer	31.	F 5264	Clamp, throttle cable
12.	F 5545	Swivel fasteners (throttle)	32.	F 1371	Throttle control complete with cable and standard
13.	F 1005	Adjusting stud nut (tension)		F 1458	Throttle complete with standard, less cable
14.	F 1004	Indicator tension control		F 1459	Throttle box complete with cable, less standard
15.	F 1008	Control box		F 1446	Throttle box complete less cable and standard
16.	F 1452	Control box cover			




TENSION CONTROL RAM ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	FT 182	Dual ram assy., complete 23" chamber	6	FT 14	Cylinder bottom with bushing
	FT 183	Dual ram assy., complete 22" chamber	7	FT 11	Piston
	FT 153	Single ram assy., complete 18" chamber	8	FT 137	Back up ring for FT 12 (MS-28782 -37)
2	FT 198	3" cylinder complete with top and bottom	9	FT 12	O-ring for piston
3	FT 199	Cylinder frame (dual and single ram) 18" chamber	10	FT 10	Cylinder
	FT 181	Cylinder frame (dual and single ram) 22" chamber	11	FT 16	Tie bolt 3/8" x 7" N. F. H. T. with nut (4 used)
	FT 180	Cylinder frame (dual and single ram) 23" chamber	12	FT 15	O-ring top seal
4	FT 201	Receptical for rams, 2 tie balers	13	FT 13	Cylinder top
	FT 202	Receptical for rams 3-tie balers	14	FT 73	Nipple, 1-1/2"
5	FT 19	Bushing for FT 14 (1" x 1-1/4" x 5/8")	15	FT 74	Tee
			16	FT 75	Pipe plug
			17	FT 107	Union Swivel
			18	FT 163	Pressure hose, ram to ram 13-1/4", 3 tie
				FT 200	Pressure hose, ram to ram 8", 2 tie
			19	FT 136	Pressure hose, bypass to ram 24"
			20	FT 18	Street elbow




TENSION CONTROL BYPASS BOX

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	FT 192	Bypass box complete with 1/2" return hose, less pressure hose	19	FT 72	Pipe nipple 3"
2	FT 50	Bypass box cover	20	FT 74	Tee
3	FT 194	Bypass box	21	FT 150	Pressure hose, pump to bypass 90"
4	FT 67	Bypass lever	22	FT 191	Bypass return hose 1/2" x 93"
5		Key 3/16" x 3/16" x 1"		FT 208	Bypass return hose 1/2" x 105" SP balers
6	FT 68	Spacer, penetration wheel arm	23	FT 187	Hose clamp, 1/2"
7	FT 177	Penetration wheel arm (tapped)	24	FT 185	Bypass assembly complete for 1/2" return hose (Sq. stock)
8	FT 178	Penetration wheel with bearing	25	FT 193	Hose nipple (1/2" hose)
9	FT 209	Washer 14 ga. 3/8" x 5/8"	26	FT 188	3/8" street elbow, weatherhead (3400 x 3/8")
10	FT 210	Washer 18 ga. 3/8" x 5/8"	27	FT 184	Bypass cylinder, 1/2" hose (sq. stock)
11	FT 179	Bearing, penetration wheel (BR 9904)	28	FT 87	Bypass check pin
12	FT 123	Washer 3/8"	29	FT 63	Spring, bypass check pin
13	FT 211	Button head bolt 3/8" x 1"	30	FT 53	O-ring, bypass
14	FT 65	Adjusting screw tension spring	31	FT 54	Plunger, less nuts
15	FT 61	Adjusting screw (eyebolt)	32	FT 55	Jamb nut 5/8"
16	FT 62	Wing nut for adjusting screw	33		1/4" x 1-1/4" N.C. cap screw
17	FT 136	Pressure hose, bypass to ram 24"	34	FT 58	U-bolt
18	FT 107	Union swivel			




TENSION CONTROL PUMP ASSEMBLY

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	FT 537	Pump and tank assembly complete, less hose 1/2"	29		Allen screws for retaining ring 1/4" x 3/4"
2	FT 536	Tank only for 1/2" hose	30	FT 500	Connecting rod
3	FT 193	Hose nipple 1/2" hose	31	FT 506	Piston pin
4	FT 187	Hose clamp 1/2"	32	FT 505	Piston
5	FT 191	Return hose 1/2"	33	FT 524	Head
6	FT 101	Sprocket, driven 22T	34	FT 521	Head gasket
7		Flat washer 9/16"	35	FT 535	1/4" x 6" nipple
8		Nut 5/8 SAE jam	36	FT 18	Street elbow, 1/4"
9	FT 528	Tank cover gasket	37		7/16" high collar lock washer
10	FT 542	Tank cover	38		7/16" Allen screw
11		Cap screw 5/16" x 3/4" N.C.	39	FT 534	1/4" x 2" nipple
12	FT 538	Washer seal for tank cover bolts 5/16"	40	FT 82	90° elbow
13		Cap screw 7/16" x 3/4" N.C.	41	FT 517	Check valve pin (intake)
14		7/16" flat washer	42	FT 513	Check ball spring (2 used)
15	FT 539	Washer seal for pump mounting bolts 7/16"	43	FT 512	Check ball (2 used)
16	FT 197	Chain, pump drive, 69P. # 41	44	FT 514	Gasket (3 used)
17	FT 114	Connecting link, # 41	45	FT 519	Plug
18	FT 113	1/2 (offset) link, # 41	46	FT 518	Check valve pin (outlet)
19	FT 527	Pump base gasket	47	FT 530	Filter assembly
20	FT 525	Crankcase, 7/16" tapped hole	48	FT 150	Pressure hose, pump to bypass
21	FT 508	Crankshaft bushing, inner	49	FT 107	Union swivel
22	FT 510	Anchor pin for FT 508 bushing	50	FT 529	Outlet gasket
23	FT 503	Crankshaft	51	FT 533	Washer for FT 529
24	FT 509	Crankshaft bushing, outer	52	FT 157	Sprocket, drive for hydraulic pump
25	FT 511	Anchor pin for FT 509 bushing	53		Woodruff Key, 1/4" x 3/4"
26	FT 541	Gasket for FT 504 retaining ring	54	FT 523	Pump complete less tank (Ref. No's. 20 to 46 incl.)
27	FT 507	Oil seal (450045)	55		3/8" street elbow
28	FT 504	Retaining ring			




P. T. O. GEAR BOX

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1076	Cap, drive shaft bearing (open end)	11	F 1417	Gasket (.005 thick) for F 1409
2	F 1085	Seal, drive shaft (CR186112)		F 1418	Gasket (.010 thick) for F 1409
3	F 1084	Bearing cup, pinion and drive shaft (LM 48510)		F 1419	Gasket (.015 thick) for F 1409
4	F 1083	Bearing cone, pinion and drive shaft (LM 48548)	12	F 1078	Housing, pinion shaft bearing
5	F 1095	Gasket, (.005 thick) for F 1076 and F 1078	13	F 1087	Snap ring, pinion shaft
	F 1414	Gasket, (.010 thick) for F 1076 and F 1078	14	F 1421	Grease seal for pinion shaft (CR256112)
	F 1415	Gasket, (.015 thick) for F 1076 and F 1078	15	F 1420	Steel shim (.003 thick)
	F 1416	Gasket, (1/32" thick) for F 1076 and F 1078	16	F 1409	Cap, drive shaft bearing (closed end)
6	F 1601	Drive shaft	17	F 1720	Vent
7	F 1093	Key, drive shaft and sheave, 5/16" x 5/16" x 2"		F 1412	Gear box complete less sheave, 540 rpm
8	F 1411	Bevel gear, 39T, for 540 rpm box		F 1413	Gear box complete with sheave, 540 rpm
	F 1778	Bevel gear, 34T, for 1000 rpm box		F 1780	Gear box complete less sheave, 1000 rpm
9	F 1407	Case for gear box		F 1781	Gear box complete with sheave, 1000 rpm
10	F 1410	Pinion and shaft, 13T for 540 rpm box			
	F 1779	Pinion and shaft 21T for 1000 rpm box			




P.T.O. DRIVE SHEAVE AND CLUTCH

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1161	Sheave, PTO single groove (540 RPM)	13	F 960	Thrust washer
2		1/2" x 1-1/2" N.F.H.T. cap screw	14	F 901	Clutch for F 1165 hub
3	F 952	Cap for F 1165	15	F 961	Snap ring (RR 350)
4		1/4" x 1" socket head cap screw	16	F 1165	Hub for F 1161 sheave
5	F 958	Filler plug (DP6)	17	F 951	Hub for over-running clutch
6	F 959	Gasket, filler plug	18	F 954	Seal for clutch (CR/28635)
7	FT 25	O ring seal	19	F 955	Bearing, inner w/seal (SKF 6211-RSJ)
8		3/8" x 1" N.F.H.T. cap screw	20	F 962	Snap ring (RR 393)
9		3/8" external star lock	21	F 1063	Shield for sheave
10	F 246	Washer, drive shaft end	22	F 1221	Shield for PTO flywheel
11	F 963	Gasket, drive shaft end	23	F 1222	Bracket for F 1221 shield
12	F 956	Bearing, outer (SKF 6211)			




P. T. O. DRIVE LINE

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 7365	Universal joint assembly	22	F 7372	Bearing assembly adjusting bracket
2	F 890	Yoke, 1-3/8" spline (2 used)	23	F 7692	Bearing assembly swivel bracket
3	F 1104	Yoke and tube assembly (welded)	24	F 889	Universal cross repair kit
4	F 1103	Yoke and square shaft assembly (welded)	25	F 1106	Lock pin
5	F 1101	Outer shield and bell assembly	26	F 1108	Spring for F 1106 lock pin
6	F 1102	Inner shield and bell assembly	27	F 1107	Lock pin washer
7	F 1727	Nylon support bearing	28		1/2" x 1-1/4" N.C.H.T. cap screw
8	F 7361	Snap ring, external for PTO shaft	29		1/2" x 3" N.C. cap screw w/nut
9	F 7371	Snap ring for bearing holder	30	F 7735	Grommet
10	F 7369	Bearing holder	31	F 7694	Shield mounting bracket for drive line
11	F 7370	Bearing for holder (8507)	32	F 7695	Shield mounting bracket
12	F 7367	Drive line spline shaft	33	F 892	Nylon brg. for shield
13	F 7368	Bearing assembly for PTO drive line	34	F 891	Thrust washer for shield
14	F 7366	Drive line slip tube	35	F 1728	Shield snap ring
15	F 1105	Yoke only, 1-3/8" bore (2 used)	36	F 7374	Telescoping Universal drive line, 1/3/8" spline x 1-3/8" spline for 540 rpm
16	F 7377	Front universal joint shield		F 7910	Telescoping Universal drive line, 1-3/8 - 6 spline x 1-3/8" - 21 involute spline for 1000 rpm
17	F 7379	Front mounting bracket for drive line shield	37	F 7375	Half drive line w/square tube
18	F 7378	Drive line shield	38	F 7376	Half drive line w/square shaft
19	F 1066	Shield for universal joint			
20	F 1064	Bracket for F 1066 shield, short			
21	F 1065	Bracket for F 1066 shield, long			




P.T.O. BALL SLIP DRIVE LINE

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1755	Shaft, splined w/welded yoke	12	F 1744	Ball
2	F 1752	Tube w/welded yoke	13	F 1754	Guard tube and bell, inner
3	F 1743	Ball cage	14	F 1753	Guard tube bell outer
4	F 889	Cross assembly,	15	F 1746	Snap ring, internal
5	F 1756	U-joint, and tube assembly	16	F 1728	Snap ring
6	F 1757	U-joint, and spline shaft assembly	17	F 891	Thrust washer
7	F 1758	U-joint, tube & free-wheeling guard assy.	18	F 1747	Ball stop washer
8	F 1759	U-joint, spline shaft & free-wheeling guard assy.	19	F 1745	Ball stop washer
9	F 890	Yoke, quick-detachable, w/1 3/8"-6B splined bore	20	F 1727	Nylon support bearing
10	F 892	Bearing, nylon	21	F 1751	Grease fitting (5042)
11	F 1749	Seal, rubber		F 7724	Ball slip telescoping shaft assembly, 540 rpm




EXTRA ITEMS

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1698	Trailer hitch frame only (2-tie)	16	F 7722	Grease can clamp base
	F 1699	Trailer hitch frame only 3-tie	17	F 7673	Nylon tubing, pull-type baler 20"
2	F 736	Trailer hitch angle for clevis pin		F 7674	Nylon tubing, S.P. baler 30"
3	F 1697	Holland hitch for trailer hitch	18	F 777	Adapter, 2 used (51942)
4	F 800	Hydraulic gauge (2000 lbs.)	19	F 7677	90° brass elbow (2 used)
5	F 1511	Oil filter cartridge 4 thread base (VH4D and VG4D)	20	F 7728	1/4" x 5-1/2" pipe nipple (2 used) 23" bale chamber
	F 5922	Oil filter cartridge (V461D)		F 7727	1/4" x 5" pipe nipple (2 used) 22" bale chamber
6	F 664	Bullgear grease (2 lb. can)	FT 72		1/4" x 3" pipe nipple (2 used) 18" bale chamber
	F 874	Bullgear grease (1 gal.) 10 lbs.	21	FT 74	1/4" pipe tee
7	F 649	Freeman red baler paint (1 gal.)	22	F 7723	Clip for grease nipple (125 jiffy)
	F 942	Freeman red baler paint (1 qt.)	23	F 7676	90° nylon elbow 2 used
	F 1675	Freeman white baler paint (1 gal.)	24	F 7609	Quickset lubricant 1 qt.
	F 1676	Freeman white baler paint (1 qt.)		F 7626	Quickset lubricant 1 gal.
8	F 770	Freeman red baler paint, spray can	25	F 7617	Bullgear luber kit, 200 and 300 state which
	F 1677	Freeman white baler paint, spray can	26	F 732	Trailer hitch frame with Holland hitch, 2-tie
9	F 4193	Wire splicer		F 734	Trailer hitch frame with Holland hitch, 3-tie
10	F 7391	Bale counter mounting angle	27	F 733	Trailer hitch frame with pin hitch, 2-tie
11	F 304	Bale counter (Veeder Root)		F 735	Trailer hitch frame with pin hitch, 3-tie
	F 635	Arm w/screw for F 304	28	F 7735	Grommet
	F 636	Reset knob for F 304			
12	F 638	Spring, bale counter			
13	F 637	Chain, bale counter			
14	F 7671	Oil can with pump			
	F 7729	Spring for pump			
15	F 7721	U bolt, grease can			



FUEL TANK, BATTERY AND LIGHTS

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1688	Fuel tank with cap	12	F 5499	Battery hold down bracket
2	F 1689	Fuel tank cap for F 1688 and F 5947 tanks	13	F 7742	Battery cable (ground) 12 volt
3	F 7046	Fuel tank strap (2 used)	14	F 7743	Battery cable (insulated) 12 volt
4	F 7048	Fuel tank mounting bracket, 23" chamber (2 used)	15	F 1497	Horn, wire alarm, 12 volt
	F 7212	Fuel tank mounting bracket, 22" chamber (2 used)	16	F 1505	Light, flush mounted, 12 volt
	F 7295	Fuel tank mounting bracket, 18" chamber (2 used)	17	F 5842	Sealed beam unit, 12 volt
5	F 893	Felt for tank straps - set of four		F 5941	Sealed beam unit, 12 volt (comb. red & clear)
6	F 5232	Straight fitting for gas line (268P-1/4" x 1/8")	18	F 1645	Light, front and center, 12 volt (sealed beam)
7	F 7049	Fuel line only 62"		F 1644	Light, rear combination, 12 volt (sealed beam)
8	F 5233	Elbow fitting for gas line (269P-1/4" x 1/8")	19	F 862	Switch for light kit
9	F 1736	Ball hitch complete with ball	20	F 1777	Wiring harness for F 1667 light kit
10	F 1691	Bolt for battery box (3/8" x 9")	21	F 1667	Light Kit, 12 volt, with 2 - F 1645 1 - F 1644, 1 - F1505, 1 - F 862 and F 1777 wire harness
11	F 1499	Battery 12 volt			



MULTI-LUBER CENTRALIZED LUBRICATION SYSTEM

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	F 1760	Stop plug for Multi-luber	13	F 1772	Coupler, 90° snap on for Multi-luber
2	F 1761	Gasket for Multi-luber			
3	F 1762	Cap for Multi-luber	14	F 1773	Lubricant reservoir for Multi-luber
4	F 1763	Lock washer for Multi-luber			
5	F 1764	Hex screw for Multi-luber	15	F 1774	Injector pump for Multi-luber
6	F 1765	Plug for Multi-luber	16	F 1775	Mounting bracket for multi-luber
7	F 1766	Compression nut for Multi-luber			
8	F 1767	Plug for Multi-luber			
9	F 1768	Gasket for Multi-luber			
10	F 1769	Adapter for Multi-luber		F 1776	Multi-luber complete w/reservoir,
11	F 1770	Tubing, 1/8" L.P. Nylon (60 ft. used)			60 ft. tubing & 12 couplers
12	F 1771	Coupler, straight snap on for Multi-luber			