



FREEMAN



MODEL 8000 BALE WAGON
PARTS MANUAL

PB0008000B

CAUTION PRUDENCE



ACHTUNG PRUDENZA

1. Keep all shields in place.
2. Always stop engine before leaving operator's position and in any case, make sure precautions are taken.
3. Wait for all movement to stop before servicing this Machine.
4. Keep hands, feet and clothing away from power driven parts.
5. Never adjust, lubricate, clean or unclog unless engine is stopped.
6. Read operator's manual before operating machine. Illustrated parts listing is available from your dealer.
7. After servicing, make sure that tools and parts are stored and reinstall shields.
8. Make certain everyone is clear of machine before starting engine or operation.
9. Contact with moving parts or with any material which can be drawn into moving parts can result in serious injury.
10. Use flashing warning lights when operating on highways except when prohibited by law.

1. Maintenir tous les protecteurs en place.
2. Toujours arrêter le moteur avant de quitter le poste de conduite et, d'une façon générale, s'assurer que toutes les précautions sont prises.
3. Attendre l'arrêt de toutes les pièces en mouvement avant d'intervenir sur la machine.
4. Ne pas approcher mains, pieds, vêtements des parties en mouvement.
5. Ne jamais régler, graisser, nettoyer ou déboucher la machine sans que le moteur soit arrêté.
6. Prendre connaissance du manuel d'utilisation avant de travailler avec la machine. Le catalogue pièces de rechanges est disponible chez votre concessionnaire.
7. Après intervention, veiller à ce que les outils et pièces soient rangés et remettre les carter en place.
8. S'assurer que personne n'est près de la machine avant de démarrer le moteur ou de travailler.
9. Risque de dégâts importants si quelqu'un ou quelque chose est happé par des pièces en mouvement.
10. Utiliser les feux de détresse pour la conduite sur routes, sauf si la loi l'interdit.


1. Bevor mit der Maschine gearbeitet wird, sind die Bedienungsanleitung und die angebrachten Hinweismarker zu lesen. Alle Sicherheitsvorschriften sind einzuhalten.
2. Vor Inbetriebnahme ist darauf zu achten, dass alle Schutzeinrichtungen angebracht sind, und dass sich keine Person im Gefahrenbereich der Maschine aufhält.
3. Instandsetzungs, Einstellungs, Wartungs und Reinigungsarbeiten nur bei abgeschaltetem Antrieb und stillstehender Maschine vornehmen.
4. Werkzeuge oder andere lose Teile nicht in oder auf der Maschine belassen.
5. Bei Fahrten auf öffentlichen Strassen sind die in Ihrem Lande geltende Vorschriften und Regelungen einzuhalten.

1. Tenere tutte le protezioni al loro posto.
2. Spegner sempre il motore prima di lasciare il posto di guida e, in linea di massima, assicurarsi che siano prese tutte le precauzioni.
3. Attendere l'arresto completo di tutti gli organi prima di intervenire sulla macchina.
4. Non avvicinare mani, piedi, vestiti agli organi in movimento.
5. Solo a motore spento si può registrare, ingrassare, pulire o eliminare gli ingolfamenti.
6. Consultare attentamente il manuale d'istruzione prima di iniziare il lavoro con la macchina. Il catalogo parti di ricambio è disponibile presso il vostro concessionario.
7. Dopo qualsiasi intervento sistemare attrezzi e pezzi e rimettere a posto le protezioni.
8. Assicurarsi che non ci sia nessuno nelle vicinanze della macchina prima di metterla in moto o iniziare il lavoro.
9. Rischio e gravi infortuni subiscono coloro che sono agganciati da parti in movimento.
10. Utilizzare i fari lampeggianti durante i trasferimenti su strada.

2004 PARTS LIST

for

MODEL 8000 BALE WAGON



POLICY

It is policy of J.A. Freeman & Son, Inc. to constantly improve its products whenever it is practical to do so. J.A. Freeman & Son, Inc. reserves the right to redesign or change its equipment or component parts thereof without incurring any obligation to install or furnish such changes on equipment previously delivered. Unauthorized changes or additions to equipment manufactured by J.A. Freeman & Son, Inc. relieves the company of further responsibility for warranted operation and breakage replacement.

INTENTIONALLY BLANK

SAFETY

J.A. Freeman & Son is greatly concerned with safety. The Freeman Roadsider is furnished with safety features. Even with these safety features, personal injury can still occur if the operator is careless, negligent or thoughtless when maintaining, lubricating, operating, unclogging, or servicing the machine.

Your Freeman Equipment has safety shields to help prevent personal injury. Do not operate the machine unless all shields are in place. There are also **"CAUTION," "DANGER," and "BE CAREFUL"** decals on the machine. Read and pay attention to the decals.

Following is a list of precautions that should be taken to help prevent personal injury:

1. SHUT OFF ENGINE BEFORE ADJUSTING, LUBRICATING, CLEANING OR SERVICING THE ROADSIDER.
2. KEEP HANDS, FEET, AND CLOTHING AWAY FROM POWER DRIVEN PARTS.
3. USE APPROPRIATE SIGNS OR WARNING LIGHTS WHEN OPERATING ON PUBLIC ROADWAYS.
4. MAKE CERTAIN EVERYONE IS CLEAR OF AND OFF THE ROADSIDER BEFORE OPERATING ANY PART OF THE MACHINE
5. ALWAYS USE LIGHTS FOR NIGHT WORK.
6. DO NOT LEAVE THE OPERATOR'S SEAT WHILE THE EQUIPMENT IS IN OPERATION OR WHILE ANY OF THE MOVING PARTS REMAIN IN MOTION.
7. KEEP ALL SHIELDS IN PLACE AND IN SERVICEABLE CONDITION.
8. DO NOT GO NEAR ANY EQUIPMENT UNTIL ALL MOVING PARTS ARE STOPPED.
9. DO NOT GO UNDER ANY RAISED COMPONENTS UNTIL THEY ARE SAFELY BLOCKED.
10. DO NOT ALLOW ANYONE UNDER OR NEAR LOAD WHILE IT IS BEING RAISED.
11. AT ALL TIMES CARRY AN "A"B"C" FIRE EXTINGUISHER ON THE MACHINE.
12. REMEMBER 'SAFETY' IS ONLY A WORD UNTIL IT IS PUT INTO PRACTICE.




WARNING: SOME ILLUSTRATIONS IN THIS PARTS LIST SHOW THE ROADSIDER WITHOUT SHIELDS TO ALLOW FOR A BETTER VIEW OF THE AREA BEING ADDRESSED. THE ROADSIDER SHOULD **NEVER** BE OPERATED WITH ANY OF THE SAFETY SHIELDS REMOVED.

SERIAL NUMBER LOCATION AND IDENTIFICATION

SERIAL NUMBER LOCATION

The serial number is an important piece of information about the machine and it may be necessary to know it before obtaining the correct replacement part. The serial number is located on the right front tongue brace as shown.




WARNING: SOME ILLUSTRATIONS IN THIS PARTS LIST SHOW THE ROADSIDER WITHOUT SHIELDS TO ALLOW FOR A BETTER VIEW OF THE AREA BEING ADDRESSED. THE ROADSIDER SHOULD NEVER BE OPERATED WITH ANY OF THE SAFETY SHIELDS REMOVED.

NOTE: ILLUSTRATIONS ARE FOR "ORDERING" INFORMATION ONLY, AND ARE NOT INTENDED FOR USE AS AN ASSEMBLY GUIDE.

TABLE OF CONTENTS

Air Tanks, Dryer	7,8
Axle & Springs, Front	10,11
Bale Guide, Front	24,25
Conveyor Assembly	5,6
Conveyor Mount	3,4
Cross Feed	1,2
Driveline Assembly	22,23
Engine Right Side	20,21
Load Bed	18,19
Load Rack	18,19
Pickup Apron	3,4
Push off Feet & Bars	12,13
Roller Rack	18,19
Side Rack Assemblies	26,27
Side Shift	3,4
Stack Guide	26,27
Switches, Conveyor Bale Count Assembly	8,9
Table Assembly	14,15
Tires - Wheels	16,17


1



DRAW BAR ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	BLT0028638	RIGHT CROSS FEED BELT-A/94 -8K	2	38	SCC0050006	HEX HD CS 1/2-13 X 2"GRADE 5	4
2	BLT0031091	BELT,LEFT CROSS FEED-8000	2	39	SCC0070019	HEX HD CS NC 5/8 X 6-1/2 - PLATED	2
3	PIN0026723	BELT LACING PIN - 8000	4	40	NCE0000625	ESNA NUT NC 5/8" - PLATED	2
4	NCE0000832	ESNA NUT NC 8-32 - PLATED	8	41	BKT0028746	CYL ADJUSTMENT BKT-AF/94 -8000	2
5	MNT0026325	CROSS FEED ROLLER MOUNT -8000	4	42	SQS5003000	1/2-13 X 3 SH SET SCREW-CUP POINT 2	2
6	WCT0000250	FLAT WASHER 1/4 - PLATED	4	43	WLK0000500	1/2" LOCKWASHER - PLATED	19
7	WLK0000250	LOCKWASHER 1/4" - PLATED	11	44	NCH0000500	HEX NUT 1/2-13 - PLATED	19
8	NCH0000250	HEX NUT NC 1/4 - PLATED	11	45	SPK50SH171	50SH17T SPROCKET F/8000	1
9	SCC0010002	HEX HD CS 1/4-20 X 1 - PLATED	7	46	BSH0000100	SH X 1 BORE 1/4 KW BUSHING	1
10	WIP0028213	CROSS FEED ROLLER WIPER -8000	2	47	NCH0000375	HEX NUT NC 3/8 - PLATED	11
11	ROL0026225	CROSS FEED ROLLER W/TUBE ASSY	2	48	MNT0026335	CROSS FEED MTR/BRG MNT-BF/2/96	1
12	BRGRA100RR	BEARING & LOCK COLLAR	4	49	MTR00RSAK1	WHITE HYD MOTOR -ELEV BW	1
13	STS2500500	1/4 X 1/2 SOCKET SET SCREW	12	50	BRC0028559	CROSS FEED MOUNT BRACE -8000	1
14	SHF0027028	CROSS FEED ROLLER SHAFT -8000	2	51	ROL0026227	CROSS FEED BLT DRV ROLLER ASSY	2
15	SCC0030003	HEX HD CS 3/8-16 X 1-1/4 - PLATED	39	52	SCC0000302	HEX HEAD CS,3/8-16 X 1"GRD 5	4
16	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	43	53	F000000883	IDLER PULLEY F/KNOT CHAIN DRIV	3
17	WCT0000375	FLAT WASHER 3/8 USS - PLATED	39	54	SCC0050009	HEX HD CS NC 1/2 X 2-3/4	1
18	SQS5002500	SETSCREW,SQ HEAD 1/2-13 X 2-1/2	8	55	MNT0026337	RR CROSS FEED BRG MNT-BF/2/96	1
19	NCJ0000500	JAM NUT-HEX 1/2-13 PLATED	10	56		RC 50 CHAIN	
20	FRM0026309	FRONT CROSS FEED FRM ASSY-8000	1	57	F000000123	RC 50 OFFSET LINK	A/R
21	MNT0028556	CROSS FEED RLR MNT-A/5-94-8000	8	58	F000000025	CONNECTING LINK-RC50	1
22	ZZ00000406	1/4" X 1/4" X 1" KEY	7	59	BRG0003064	1" 2-BOLT PILLOW BLOCK BEARING	2
23	SPK50JA121	50JA 12 TOOTH SPROCKET	5	60	SCC0030004	HEX CS 3/8-16 X 1-1/2"GRADE 5	3
24	BSH0010000	MARTIN BUSHING JA 1"BORE	5	61	SCC0030005	HEX HD CS NC 3/8 X 1-3/4	1
25	F000008095	TWINE FING DRIVE SHF BRG-COMP	12	62	GUD0026851	CROSS CONVEYOR CHN GUIDE/8000	2
26	F000006004	FLANGETTE-PLATED F/F8095	12	63	SCC0050010	HEX HD CS NC 1/2 X 3 - PLATED	2
27	ROL0026223	CROSS FEED RLR'S W/SHAFT ASSY	4	64	SCC0010008	HEX HD CS NC 1/4 X 2-1/2 - PLATED	4
28	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	25	65	FRM0026302	REAR CROSS FEED FRM ASSY -8000	1
29	NCH0000313	HEX NUT NC 5/16 - PLATED	24	66	MNT0026544	BALE GUIDE SWI MNT-BF/96 -8000	1
30	CRB3130100	CARRIAGE BOLT NC 5/16 X 1 -PLATED	24	67	OPR0029875	BALE GUIDE LIM SWI OPER-A/4/95	1
31	CYL0030072	BALE FEEDER CYLINDER-8000A & B	2	68	CYL0026214	BALE GUIDE CYL TC2X6 1-1/8"ROD	1
32	MNT0028558	CROSS FEED DRV BRG MNT-AF/5-94	4	69	GUD0029871	X-FEED BALE GUIDE HEAD-AF/4/95	1
33	SHF0026348	CROSS FEED DRIVE SHAFT -8000	1	70	NFH0000750	GRADE 8 HEX NUT NF 3/4 - PLATED	1
34	ZZ00000405	1/4 X 1/4 X 1-1/2 KEY	4	71		RC 50 CHAIN	
35	SCC0050003	HEX HEAD CAP SCREW 1/2-13 X 1-1/4	12	72	F000000246	KNOTTER BRAKE DISC WASHER	1
36	WCT0000500	FLAT WASHER 1/2 USS -PLATED	26	73	SCC0020001	HEX HD CS NC 5/16 X 3/4 - PLATED	1
37	MNT0030036	CROSS FEED CYLINDER MNT -8000A	2				


CONVEYOR TABLE AND PICKUP MOUNT



CONVEYOR TABLE AND PICKUP MOUNT

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	NCH0000750	HEX NUT NC 3/4 - PLATED	15
2	SHM0163090	SHIM FOR 3/4 BOLT 16 GA	A/R
2	SHM0163091	SHIM FOR 3/4 BOLT 20 GA	A/R
2	SHM0163092	SHIM FOR 3/4 BOLT 10 GA	A/R
3	SCC0080808	GRD 8 HEX HD CS NC 3/4 X 2-1/2	6
4	SUP0030270	P/U MOUNT SUPT-BF/2/96 -8K00	1
5	PIN0024509	P.U. LIFT CYL.PIN 5K/8K	2
6	COT0000808	COTTER PIN 3/16 X 3	2
7	ZZ00000213	1"X 1-1/2" X 10 GA MACHINE BSH	2
8	NCC0001000	CASTLE NUT NC 1	2
9	CYL0009012	SIDE SHIFT CYL F/PICKUP -8000B	1
10	BSH00VG400	1.25"OD X 1"ID X 1"LG TENSION BSH	2
11	ZZ00000103	1/8 NPT STR 7/16 HEX ZERK	4
12	MNT0030269	PICKUP MOUNT ASSY-AF/8/95-8K00	1
13	PLT0031473	PICKUP MOUNT TIE PLATE -8000	1
14	SCC0080805	GRD 8 HEX HD CS NC 3/4 X 2	13
15	OPR0027062	SIDE PUSHER SW.OPERATOR -8000	2
16	WCT0000313	FLAT WASHER 5/16 -PLATED	1
17	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	1
18	SCC0020001	HEX HD CS NC 5/16 X 3/4 -PLATED	1
19	NFH0001032	HEX NUT 10-32 ZINC	4
20	WLK0000100	LOCK WASHSER #10 - PLATED	4
21	WCT0000100	FLAT WASHER #10 - PLATED	4
22	SUP0030877	FRT BALE CONVEYOR SUPT-AF2/96	1
23	SMR1032175	RND HD MS 10-32 X 1-3/4 PLATED	4
24	ARM0005084	3" LEVER ARM W/3/4" ROLLER	2
25	SWI0005079	LIMIT SWITCH -4 POST	2
26	WLK0000313	1/2" CORD CONNECTOR (.250-.375)	2


BALE CONVEYOR TANLE ASSEMBLY



BALE CONVEYOR TABLE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	BLT0028323	REAR BALE CONVEYOR BELT -8000	1	28	BRG0001001	2 BOLT 1"FLUSHMOUNT BALL BRG	7
2	BLT0028322	FRONT BALE CONVEYOR BELT-8000	1	29	NCH0000313	HEX NUT NC 5/16 - PLATED	16
3	NCE0000832	ESNA NUT NC 8-32 - PLATED	4	30	SCC0050004	HEX HEAD CS 1/2-13 X 1-1/2 PLT	2
4	PIN0026724	BELT LACING PIN	2	31	MNT0030314	LOWER CONVEYOR TBL MNT-AF/8/95	2
5	ZZ00000406	1/4" X 1/4" X 1" KEY	3	32	NCE0000500	ESNA NUT NC 1/2" - PLATED	6
6	ROL0026219	REAR BALE DRIVE ROLLER ASSY-8K	3	33	SCO0000201	SOCKET CS,5/16-18 X 3/4 FH -PLAIN	6
7	ROL0026221	TABLE ROLLER ASSEMBLY -8000	2	34	SQS5003000	1/2-13 X 3" SQ HD SET SCREW-CUP	3
8	F000000123	RC 50 OFFSET LINK	A/R	35	TBL0026418	BALE CONVEYOR TABLE ASB -8000	1
9	F000000025	CONNECTING LINK-RC50	2	36	SBH0001001	BUTTON HEAD CS NC 1/4 X 3/4 - PLT	4
10	SCC0030002	HEX HEAD CAP SCREW 3/8-16 X 1"	24	37	GUD0026526	FRONT CONVEYOR BALE GUIDE-8K	1
11	WCT0000375	FLAT WASHER 3/8 USS - PLATED	22	38	MNT2642601	RH CONVEYOR TABLE BRG MNT-8000	1
12	BAR0027064	CONVEYOR BRG ADJUST BAR -8000	2	39	CVR0029438	BALE CONVEYOR SIDE COVER -8K	1
13	NCJ0000500	JAM NUT-HEX 1/2-13 PLATED	5	40	//////////	RC 50	4
14	BRG0000100	FAFNIF PB1 1" PILLOW BLOCK BRG	2	41	WCT0000250	FLAT WASHER 1/4 - PLATED	10
15	NCH0000500	HEX NUT 1/2-13 - PLATED	4	42	WLK0000250	LOCKWASHER 1/4" - PLATED	10
16	WLK0000500	1/2" LOCKWASHER - PLATED	3	43	SCC0010001	HEX CS,1/4-20 X 3/4 -PLATED	10
17	WCT0000500	FLAT WASHER 1/2 USS -PLATED	24	44	F000000883	IDLER PULLEY F/KNOT CHAIN DRIV	2
18	SCC0050018	HEX HD CS NC 1/2 X 6 - PLATED	1	45	SCC0050014	HEX HD CS 1/2-13 X 4"GRD 5- PLTD	2
19	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	26	46	SCC0030001	HEX HD CS NC 3/8 X 3/4 - PLATED	4
20	NCH0000375	HEX NUT NC 3/8 - PLATED	16	47	//////////	RC 50	1
21	MTR00RSAK1	WHITE HYD MOTOR -ELEV BW	1	48	MNT0027031	CONVEYOR TABLE BRG MOUNT -8K	1
22	SPK50SH171	50SH17T SPROCKET F/8000	1	49	SHD0027125	LOCK WAHSER #10 - PLATED	2
23	BSH0000100	SH X 1 BORE 1/4 KW BUSHING	1	50	F000006004	FLANGETTE-PLATED F/F8095	4
24	F000000246	KNOTTER BRAKE DISC WASHER	1	51	F000008095	TWINE FINGER DRIVE SHAFT BRG	1
25	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	13	52	BSH0010000	MARTIN BUSHING JA 1"BORE	3
26	SCC0020001	HEX HD CS NC 5/16 X 3/4 - PLATED	1	53	SPK50JA121	50JA 12 TOOTH SPROCKET	3
27	MNT2642600	LH CONVEYOR TABLE BRG MNT-8000	1	54	SCC0050003	HEX HEAD CS 1/2-13 X 1-1/4	2

AIR TANKS AND DRYER ASSEMBLIES




AIR TANKS AND DRYER ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	HOS0027086	AIR COMPRESS GOVENOR TO TANK	1	32	ABF0014688	3/8NPTX1/2 STR CONN. TBE BRASS	2
2	HYD2501023	1/4" JIC 3/8" NPT 90* MALE ELBOW	1	33	ABF0360060	3/8" MALE BRANCH TEE	2
3		1/2" AIR BRAKE TUBE X 17"	2	34	SWI0228750	LOW AIR PRESS. INDICATOR	2
4	ABF0146988	1/2NPTX1/2 90* ELBOW TBE BRASS	3	35	ABF0014728	1/2X1/2X3/8NPT SIR BRK TEE TUB	1
5	VLV0227788	CHECK VALVE, SC-1 227788	2	36	TNK0112394	AIR TANK 7-1/2 X 12-1/2 112394	1
6	ABF3220128	3/4 NPT X 1/2 NPT BRASS BSHG	3	37	SCC0030003	HEX HD CS 3/8-16 X 1-1/4 - PLATED	2
7	TNK0112387	AIR TANK 8 1/2 X 24 1/2	2	38	CLP1120130	AIR TNK MTG CLAMPS W/4" BOLTS	2
8		1/2" AIR BRAKE TUBE X 170"	1	39	SCC0030014	HEX HD CS NC 3/8 X 4	2
9	NCH0000375	HEX NUT NC 3/8 - PLATED	18	40	VLV0284142	SAFETY RELIEF VLV, ST-3	1
10	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	19	41	ABF0148080	1/2 X 38 45° MALE ELB BRASS	1
11	ABF0146966	3/8NPTX3/8 90* ELBOW TBE BRASS	4	42		1/2" AIR BRAKE TUBE A 47"	1
12		3/8" AIR BRAKE TUBE X 166"	1	43	BKT0027660	AIR DRYER MOUNTING BRACKET	1
13		3/8" AIR BRAKE TUBE X 30"	1	44	WCT0000375	3/8" FLATWASHER PLT	8
14	VLV0278599	DOUBLE CHECK VLV, DC-4 278599	1	45	HOS0027087	AIR COMP DISCHARGE HOSE	1
15	ABF0322064	3/8" X 1/4" BUSHING	4	46	WLK0000250	LOCKWASHER 1/4" - PLATED	8
16	ABF0146944	1/4NPTX1/4 90* BRK ELBOW BRASS	1	47	HYD5205044	1/2 JIC X 1/2 NPT MALE CONN	1
17		1/4" AIR BRAKE TUBE X 150"	1	48	SCC0030001	HEX HD CS NC 3/8 X 3/4	3
18	ABF0146860	3/8 TUBE X 1/4 MACH BUSING	1	49	NCE0000313	ESNA NUT NC 5/16 - PLATED	2
19		3/8" AIR BRAKE TUBE X 39"	1	50	BKT0030159	A/B LINE LUBRICATOR BKT -8K	1
20	ABF0014698	3/8" NPT X 1/2" 90DEG. TUBE ELBO	1	51	LUB0000363	AIR LINE LUBRICATOR ARROW	1
21	VLV006W184	1/4" BRASS BALL VALVE	1	52		3/8" AIR BRAKE TUBE X 49"	1
22	HYD3750020	1/4" BRASS STREET PIPE TEE	3	53	SUP0030158	A/B LINE LUBRICATOR SUPT -8K	1
23	VLV0118181	PRESSURE PROTECTION VLV,	1	54	HOS0027058	AIR COMP GOVERNOR TO DRYER	1
24	ABF0332540	1/4" HEX NIPPLE	1	55	HYD5405020	1/4 JIC X 1/8 NPT 90* MALE ELB	1
25	CLP0112013	AIR TANK MTG CLAMP KIT WM298	4	56	ARDDA33100	AIR DRYER/AFT.09/13/94	1
26	NCE0000375	ESNA NUT 3/8-16 PLATED	6	57	FIL0033100	FILTER F/ARDDA33100	1
27	SCC0030019	HEX HD CS 3/8-16 X 6-1/2" GRADE 5	4	58	ABF0146060	3/8" SLEEVE	A/R
28	VLV0DCR601	1/4" DRAIN COCK	3	58	ABF0146080	1/2" SLEEVE	A/R
29	CPL0003503	1/4" QD FEMALE HOSE COUPLER	2	59	ABF0148460	3/8" INSERT	A/R
30	HYD3209022	1/4 X 1/4 NPT ADAPTER	2	59	ABF0148480	1/2" INSERT	A/R
31		1/2 AIR BRAKE TUBE X 187"	1				

1/4" AIR BRAKE TUBING (PER FOOT) - TUB0010004
3/8" AIR BRAKE TUBING (PER FOOT) - TUB0010006
3/2" AIR BRAKE TUBING (PER FOOT) - TUB0010008


FRONT TIE AND BALE COUNTER SWITCHES AND CROSS FEED CONTROL AND REAR TIE SWITCH



FRONT TIE AND BALE COUNTER SWITCHES AND CROSS FEED CONTROL AND REAR TIE SWITCH

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	SCC0020003	HEX HD CS NC 5/16 X 1-1/4	2
2	MNT0026846	BALE SWITCH OPERATOR MNT -8000	2
3	NCE0000313	ESNA NUT NC 5/16 - PLATED	2
4	NCH0000313	HEX NUT NC 5/16 - PLATED	8
5	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	8
6	OPR0026844	FRT BALE SWITCH OPERATOR -8000	1
7	MNT0026739	SWITCH OPERATOR SHAFT BRG MNT 3	3
8	F000001618	METER WHEEL SHFT BRG W/CLAMPS 4	4
9	F000001890	LOCKING COLLAR F/F1619 BEARING	1 PER ASSEMBLY
10	F000001889	FLANGETTE F/F1618 BEARING	2 PER ASSEMBLY
11	F000001619	METER WHEEL SHF-BRG & COLLAR	1 PER ASSEMBLY
12	CRB3130075	5/16X 3/4 CARRIAGE BOLT-PLTD	8
13	SHF0026843	CONVEYOR SWI OPERATOR SHAFT	2
14	ZZ00000445	1/4 X 1/4 X 1-1/4 KEY	2
15	NFH0001032	HEX NUT 10-32 ZINC	6
16	WLK0000100	LOCK WAHSER #10 - PLATED	6
17	MNT0026850	CONVEYOR TABLE SWITCH MNT-8K	1
18	SWI0005079	LIMIT SWITCH -4 POST	3
19	CNR0000193	1/2" CORD CONNECTOR (.250-.375)	3
20	SMR1032150	RND HD MS NF 10-32X1-1/2	6
21	ARM0005001	1-1/2" LEVER ARM W/3/4" ROLLER	2
22	SCC0020005	HEX HD CS NC 5/16 X 1-3/4	2
23	CAM0026769	FRT BALE CONVEYOR SWITCH CAM	1
24	CYL1611891	GAS STRUT CYLINDER W/CLEVIS	2
25	NMS0000117	WHIZ NUT 5/16-18 PLATED	10
26	ANC0026736	REAR GAS SPRING ANCHOR -8000	1
27	SMS0000184	WHIZ BOLT 5/16 X 3/4 NC-PLATED	10
28	CAM0026770	REAR BALE CONVEYOR SWITCH CAM1	1
29	ARM0005084	3" LEVER ARM W/3/4" ROLLER	1
30	SCC0050018	HEX HD CS NC 1/2 X 6	1
31	NCH0000500	HEX NUT 1/2-13 - PLATED	2
32	WCT0000500	FLAT WASHER 1/2 USS -PLATED	2
33	WLK0000500	1/2" MEDIUM LOCKWASHER - PLATED	1
34	OPR0027200	REAR BALE SWITCH OPERTOR-AF/93	1


FRONT AXLE AND SPRINGS



FRONT AXLE AND SPRINGS

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	AXL0026676	FRONT AXLE W/HOLE PATTERN	1	26	SPG2982109	9TH LEAF F/SPG0029821	1
2	NFH0007500	HEX NUT 3/4-16 PLAIN	8	27	SPG2982108	8TH LEAF F/SPG0029821	1
3	NFJ0007500	JAM NUT NF 3/4	8	28	SPG2982107	7TH LEAF F/SPG0029821	1
4	SPG0020383	9 LEAF FRONT SPRING	1	29	SPG2982106	6TH LEAF F/SPG0029821	1
5	SMS0000168	CTR BOLT 7/16 X 5 F/LEAF SPG	1	30	SPG2982105	5TH LEAF F/SPG0029821	1
6	SPG2038309	9TH LEAF F/SPG 20383	1	31	SPG2982104	4TH LEAF F/SPG0029821	1
7	SPG2038308	8TH LEAF F/ SPG20383	1	32	SPG2982103	3RD LEAF F/SPG0029821	1
8	SPG2038307	7TH LEAF F/ SPG20383	1	33	SPG2982102	2ND LEAF F/SPG0029821	1
9	SPG2038306	6TH LEAF F/ SPG20383	1	34	SPG2982101	MAIN LEAF F/ SPG20383	1
10	SPG2038305	5TH LEAF FOR SPG20383/20384	1	35	HGR0030069	FRT FORWARD SPG HANGER-AF/7/95	2
11	SPG2038304	4TH LEAF F/ SPG20383	1	36	HFB0080005	3/4 UNC X 1-3/4 HEX HD FLNG BOLT	24
12	SPG2038303	3RD LEAF F/ SPG20383	1	37	NFX0001125	FLEX-LOCK NUT NF 1-1/8	6
13	SPG2038302	2ND LEAF F/ SPG20383	1	38	SFC0080823	GRD 8 HEX HD CS NF 3/4 X 8-1/2	4
14	SPG2038301	MAIN LEAF F/SPG20383/20384	1	39	STO4180000	FRONT AXLE STOP PAD	2
15	BSH0000193	1-1/8"X 1-3/8"X 3 LEAF SPG BUSHING	2	40	SPC0027374	FRONT SPRING STOP SPACER-8000	1
16	SCC0030015	HEX HD CS NC 3/8 X 4-1/2	8	41	HFN0000750	3/4" UNC HEX FLANGE NUT	24
17	PLT0019878	SPRING LEAF CLAMP PLT -4000/44	8	42	WLK0000500	1/2" MEDIUM LOCKWASHER	4
18	NCE0000375	ESNA NUT 3/8-16 PLATED	8	43	SCC0050004	HEX HEAD CAP SCREW 1/2-13 X 1-1/2	4
19	PLT0022102	R. H. SPRING PLATE	2	44	NCH0000500	HEX NUT 1/2-13	2
20	SFC0080821	GRD 8 HEX HD CS NF 3/4 X 7-1/2	4	45	SCC0050003	HEX HEAD CAP SCREW 1/2-13 X 1-1/4	2
21	ZZ00000104	1/8 NPT 90° 7/16 HEX ZERK	6	46	MNT0026598	FRONT SPRING BUMPER MOUNT	1
22	19-110	FRONT SHACKLE BOLT-5300,5400	6	47	SHK0026675	FRONT SPRING SHACKLE ASSY-8000	2
23	SPG0029821	RH FRONT SPRING 8000	1	48	HGR0026669	FRNT AFT SPG HANGER-5400-LH	2
24	CYL1611891	7/16 X 6 CTR BOLT F/LEAF SPG	1	49	F000004027	BUSHING 1-1/8 X 1-3/8 X 1-1/2	2
25	SPG2982110	7/16 X 6 CTR BOLT F/LEAF SPG	1				


LOAD PUSHOFF BAR AND FOOT ASSEMBLIES



LOAD PUSH-OFF BAR AND FOOT ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	PSH0026959	LH LOAD PUSH-OFF ASSY -8000	1
2	PSH0026960	RH LOAD PUSH-OFF ASSY -8000	1
3	SCC0050007	1/2-13 X 2-1/4 CAP SCREW	4
4	NCE0000500	ESNA NUT NC 1/2"	4
5	ARM0027037	LOAD PUSH-OFF ARM ASSEMBLY -RS	2
6	NCH0000750	HEX NUT NC 3/4 - PLATED	8
7	WLK0000250	LOCKWASHER MEDIUM 3/4"-PLATED	8
8	SCC0020002	HEX HEAD CAP SCREW 5/16-18 X 1	4
9	BKT0027407	LIMIT SWITCH MNT PUSH OFF FEET	2
10	BKT0020397	PUSH BACK SWITCH BRACKET	2
11	SWI0005079	LIMIT SWITCH -4 POST	2
12	ARM0005084	BEARING & LOCK COLLAR	2
13	WLK0000100	LOCK WASHES #10 - PLATED	4
14	SMR1032125	RND HD MS NF 10-32X1-1/4	4
15	WCT0000313	FLAT WASHER 5/16 -PLATED	8
16	NCH0000313	HEX NUT NC 5/16 - PLATED	8
17	ZZ00000214	1"X 1-1/2"OD X 14 GA MACHINE BSH	A/R
18	CYL0026206	PUSH OFF CYLINDER -8000	2
19	SUP2662800	LH PUSH-OFF CYLINDER SUPPORT	1
19	SUP2662801	RH PUSH -OFF CYLINDER SUPT-800	1
20	F000006804	2-1/4"H.D. EXHAUST CLAMP	2
21	SCC0050009	HEX HD CS NC 1/2 X 2-3/4 - PLATED	8
22	PLT0018525	BAR WEAR PLATE 1/4 X 1-1/4	8
23	SPC0018726	BAR GUIDE SPACER -P/OFF BBRS	8
24	SCC0080006	HEX HD CS NC 3/4 X 2" - PLATED	8
25	WLK0000500	1/2" MEDIUM LOCKWASHER - PLATED	8
26	NCH0000500	HEX NUT 1/2-13 - PLATED	8
27	BRG000CF2S	BEARING-CAM FOLLOWER	4
28	ZZ00000225	7/8 X 10 GA MACHINE BUSHING	4
29	GUD2662500	LH LOAD PUSH-OFF GUIDE	1
29	GUD2662501	RH LOAD PUSH-OFF GUIDE	1
30	07-114	SET COLLAR 7/8" STEEL	4
31	ZZ00000208	7/8 X 18 GA MACHINE BUSHING	4
32	NEJ0008750	ESNA JAM NUT NF 7/8" - PLATED	4
33	OPR0027196	LOAD PUSH-OFF RETURN OPER ASY	2
34	SCO0000503	FLAT HD SOC CS NC1/2 X 1-1/4	2

BALE TILT TABLE ASSEMBLY



BALE TILT TABLE ASSEMBLY


REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	TBL0026180	BALE TILT TBL ASSY-A/5/95-B/96	1
2	PSH0026960	RH LOAD PUSH-OFF ASSY -8000	2
3	SBH0001001	BUTTON HEAD CS NC 1/4 X 3/4	29
4	GUD0027360	LEFT TILT TBL BALE GUIDE-AF/93	1
5	ZZ00000100	1/4-28 STR 5/16 HEX ZERK	3
6	02-106	BUSHING (REAMED BSH1507)	2
7	BSH00VG400	1.25"OD X 1"ID X 1"LG TENSION BSH	2
8	NCE0000250	ESNA NUT NC 1/4" - PLATED	29
9	SCC0001019	HEX HD CS NC 1 X 6-1/2	1
10	NCE0001000	ESNA NUT NC 1" - PLATED	2
11	GUD0026248	RIGHT TILT TBL BALE GUIDE-8000	1
12	NCJ0000500	JAM NUT-HEX 1/2-13 PLATED	4
13	SCC0050005	HEX HD CS 1/2-13 X 1-3/4"GRADE 5	2
14	SBH0003001	BUTTON HEAD CS NC 3/8 X 3/4	3
15	SBH0002001	BUTTON HEAD CS NC 5/16 X 3/4	8
16	WCT0000313	FLAT WASHER 5/16	4
17	EXT0029797	CONV TBL EXTENSION PLT-BF/96	1
18	NMS0000117	WHIZ NUT 5/16-18	4
19	NMS0000375	WHIZ NUT NC 3/8	3
20	SUP0026331	TBL SUPT & BALE GUIDE-BF/1/96	1
21	SCC0050004	HEX HEAD CAP SCREW 1/2-13 X 1-1/2	10
22	WCT0000500	FLAT WASHER 1/2 USS	12
23	STP0027370	BALE TABLE STEP	1
24	NCH0000500	HEX NUT 1/2-13 - PLATED	12
25	WLK0000500	1/2"MEDIUM LOCKWASHER - PLATED	12
26	20-112	MOTOR MOUNT/STOP PAD - BBRS	2
27	SCC0050003	HEX HEAD CAP SCREW 1/2-13 X 1-1/4	2
28	CYL0029816	TABLE CYLINDER -8000	1
29	SUP0027033	FRONT LOAD BED SUPPORT -8000	1
30	SCC0000806	HEX HD CS NC 3/4 X 2	2
31	SCC0000805	HEX HD CS NC 3/4 X 1-3/4	16
32	MNT0028750	RH TILT TBL PIVOT MNT-AFT/94	1
33	WLK0000750	LOCKWASHER MEDIUM 3/4"-PLATED	2
34	NCH0000750	HEX NUT NC 3/4 - PLATED	20
35	SQS5001750	1/2 X 1-3/4" SQ HEAD SET SCREW	2
36	BRC0026659	TILT TBL PIVOT MNT BRACE -8000	2
37	MNT0028749	LFT TILE TBL PIVOT MNT-AF/94	1
38	SHF0026240	TILT TABLE PIVOT SHAFT -8000	1
39	BRC0029450	TABLE CYL BRACE -AF/1-95 -8000	2
40	SCC0001021	HEX HD CS NC 1 X 7-1/2	1



TIRES AND WHEELS

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	WHL4019195	FRONT WHL/TIR SA	2
2	TIR4019195	TIRE 40X19X19.5 14-PLY	4
3	WHL2109315	FRT.WHL.F/40X19X19.5 6000/8000 14" 2	2
4	19-109	VALVE STEM TR416	4
5	FD00023951	DECAL LUG NUT 1592	4
6	WHL4019194	RR WHL/TIR SA 40X19X19.5 BBRS	2
7	WHL1239316	RR WHL F/40X19X19.5 TIRE-A/93 14" 2	2


LOAD BED AND ROLLER RACK ASSEMBLIES



LOAD BED AND ROLLER RACK ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	BED0028251	BED ASSEMBLY -8000	1	26	SCC0080012	3/4-10 X 3-1/2" GRADE 5 CS-PLATED	2
2	FD00023894	DANGER DECAL -1000	4	27	SHM0027092	ROLLER RACK ARM ADJUST SHIM	A/R
3	CYL0026290	BED TILT CYL	2	28	PLT0026274	ROLLER RACK ARM ADJ PLATE-8000	1
4	BSH00VG400	1.25"OD X 1"ID X 1"LG TENSION BSH	2	29	NCH0000500	HEX NUT 1/2-13 - PLATED	6
5	SCC0030001	HEX HD CS NC 3/8 X 3/4 - PLATED	4	30	WLK0000500	1/2" MEDIUM LOCKWASHER - PLATED	6
6	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	4	31	SCO0000201	SOCKET CS, 5/16-18 X 3/4 FH-PLAIN	12
7	RET0023733	RETAINER - BED PIVOT PIN	2	32	PAD0018932	SIDE GUIDE PAD -R/RACK BBRS	4
8	PIN0023732	BED PIVOT PIN-AFT/7-90-86 BBRS	1	33	SPC0018937	SIDE GUIDE SPACER -R/RACK BBRS	A/R
9	BSH00VG690	BED PIVOT BUSHING 5K/8K	2	34	NFX0001125	FLEX-LOCK NUT NF 1-1/8	2
10	ZZ00000214	1"X 1-1/2"OD X 14 GA MACHINE BSH	A/R	35	BRG0002112	CAM FOLLOWER-2-1/2"SEALED	2
11	PIN0026286	ROLLER RACK SUPT ARM PIVOT PIN	6	36	PAD0018931	VERTICAL STOP PAD -R/RACK BBRS	2
12	COT0000805	3/16 X 2 COTTER PIN PLATED	12	37	SCC0050011	HEX HD CS NC 1/2 X 3-1/4 - PLATED	2
13	RAK0028791	ROLLER RACK ASSY-AF/7-94 -8000	1	38	SCC0050006	HEX HD CS 1/2-13 X 2"GRADE 5	4
14	ARM0026277	LH ROLLER RACK BALE SUP ARM-8K	1	39	TRK2880300	LH RLR RACK TRACK EXT-AF/94	1
15	ARM0026276	RLR RAK BALE SUP ARM-NO NOTCH	3	39	TRK2880301	RH RLR RACK TRACK EXT-AF/94	1
16	ARM0026279	RLR RAK BALE SUP ARM W/NOTCH	1	40	CYL0028716	ROLLER RACK CYLINDER -8000	1
17	ARM0026278	RH ROLLER RACK BALE SUP ARM-8K	1	41	F000006804	2-1/4"H.D. EXHAUST CLAMP	1
18	SCC0000203	HEX HD CS 5/16-18 X 1-1/4"PLAIN	12	42	CNK0000802	CONNECTING LINK - 80H IMPORT	2
19	PLT0026273	ROLLERRACK ARM ADJ.PLATE -8000	5	43	CHN0080109	CHAIN - #80 X 109 PITCH	1
20	SHM0026275	ROLLER BACK ARM ADJUST SHIM	A/R	44	NFJ0000750	JAM NUT NF 3/4 - PLATED	2
21	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	12	45	07-123	CHAIN ANCHOR #80 CHAIN-TILT BED	1
22	NCH0000313	HEX NUT NC 5/16 - PLATED	12	46	CYL0029840	ROLLER RACK CYL HEAD ASSY	1
23	NCH0000750	HEX NUT NC 3/4 - PLATED	2	47	NCJ0000500	JAM NUT-HEX 1/2-13 PLATED	1
24	WLK0000750	LOCKWASHER MEDIUM 3/4"-PLATED	3	48	SQS5001250	SET SCREW,SQ HD 1/2-13 X 1-1/4"	1
25	F000000775	PLUNGER ROLLER BEARING	2	49			
				50	ZZ00000206	3/4 X 14 GA MACHINE BUSHING	A/R
				51	SPK128012S	SPROCKET-ROLLR CHAIN IDLER-12T	1


ENGINE, RIGHT SIDE



ENGINE, RIGHT SIDE

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	ENG0000659	6BT5.9 6 CYL CUM F/AUTO	1	27	WCT0000375	FLAT WASHER 3/8 USS	3
2	SUP0026965	TRANSM DIP STICK TBE SUPT-8000	1	28	WLKM100120	12 MM LOCKWASHER - PLATED	7
3	NCHM010150	GR 8.8 HEX NUT 10M X 1.50 MC	1	29	SCCM012035	GRD 8.8 HEX HD CS 12M X 35MM MC	7
4	NCHM005080	GR 8.8 HEX NUT 5M X .80 MC	1	30	NCJ0003750	JAM NUT NC 3/8"	2
5	03-132	SENDING UNIT-OIL PRESSURE	1	31	WCTM100080	FLATWASHER 8 MM - PLATED	2
6	SWI0007508	PRESSURE SWITCH-#R7508	1	32	WLKM100080	8 MM DIN 127 LOCKWASHER	5
7	PPE0040125	1/8 STD BLK PIPE TEE	1	33	SCCM108035	8M X 1.25 X 35 HEX HEAD CS	4
8	HYD3069021	1/8 NPT STEEL HEX NIPPLE	1	34	CUM3908560	ALTERNATOR PULLEY -CUMMINS	1
9	HYD0001571	3/8 HOS X 1/4 NPT 90* MALE ELBOW	1	35	CUM3908563	3/4" BUSHING	1
10	HYD3109042	1/2 X 1/4 STEEL PIPE BUSHING	1	36	F000008147	TWINE FINGER DRIVE ROD BSH	1
11	HYD3709040	1/2 STEEL FEMALE NPT TEE	1	37	CUM3903922	ALTERNATOR BRACE	1
12	HYD3109043	1/2 X 3/8 STEEL PIPE BUSHING	2	38	ALT1002116	NIPPONDENSO ALTERNATOR	1
13	HYD0211280	SHUT-OFF VALVE F/CAB HEATER	2	39	NCHM010150	GR 8.8 HEX NUT 10M X 1.50 MC	1
14	PPE5005500	1/2 X 5-1/2 STD BLK PIPE NIPPL	1	40	WCTM100100	FLATWASHER 10 MM - PLATED	2
15	FIL3903264	OIL FILTER -CUMMINS 6BT5.9	1	41	WLKM100100	10 MM DIN 127 LOCKWASHER	3
16	CUM3911588	FAN BELT F/ 6BT5.9	1	42	SCCM010090	10M X 90M MC HEX HD CS-GR-8.8	2
17	HYD5405044	1/2 JIC X 1/2 NPT 90* MALE ELB	1	43	ZZ00002016	SET COLLAR 3/8" DIA	2
18	MNT2641101	RH FRONT ENGINE MNT ASSY -8000	1	44	CNK0000802	A/C COMPRESS TIGHTENER MNT BKT1	1
19	MNT0026310	REAR ENGINE MOUNT ASS	1	45	BKT0023364	COMPRESSOR BELT TIGHTENER BKT 1	1
20	F000006830	RADIATOR HOSE CLAMP #36	1	46	SCC0030004	HEX CAP SCREW 3/8-16 X 1-1/2"G- 5	3
21	HOS0007587	INLET ENGINE HOSE	1	47	BKT0016388	A/C COMPRESSOR MNT BKT F/BW-RS 1	1
22	BLT2515505	AIR COND DRIVE BELT -CUMMINS	1	48	CUM3903086	ALTERNATOR BRACKET - CUMMINS	1
23	NCH0000375	HEX NUT NC 3/8 - PLATED	6	49	BKT0017929	AUTO TRANS FILTER BRACKET-BBRS 1	1
24	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	6	50	PLT0019528	AIR COND MNT PLT-CUMMINS ENG	1
25	WCTM100120	FLATWASHER 12 MM - PLATED	4	51	CMP75R8232	COMPRESSOR MOUNT PLATE	1
26	SCC0030002	HEX HEAD CAP SCREW 3/8-16 X 1"	3				

DRIVE LINE ASSEMBLY




NOTE: REFERENCE #7 IS NOT
INCLUDED IN DRV2668600

DRIVE LINE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	DRV2668600	DRIVE LINE ASSEMBLY -8000	1
2	DRV0026686	DRV LINE 1-9/16X16 SPLINE-8000	1
3	19-124	U-JOINT REPAIR KIT	2
4	CVR0000D3J	CAP,WASHER,CORK ASSY	1
5	DRV0331701	SLIP YOKE F/DRV0240480 BBRS	1
6	19-209	FLANGE YOKE	1
7	19-125	"U"BOLT	2


CONVEYOR BALE GUIDE ASSEMBLY



CONVEYOR BALE GUIDE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	PSH0026821	BALE PUSHER ASSEMBLY -8000	1
2	LNK0026814	BALE PUSHER ARM LINK PLATE -8000	2
3	SCC0050002	1/2-13 X 1" HEX CAP SCREW G5	4
4	WLK0000500	1/2" MEDIUM LOCKWASHER - PLATED	12
5	WCT0000500	FLAT WASHER 1/2 USS -PLATED	4
6	NCH0000500	HEX NUT 1/2-13 - PLATED	8
7	SHF0027044	PUSHER CYLINDER ARM SHAFT-8000	1
8	LNK0026817	BALE PUSHER ARM LINK PLT -8000	2
9	SCC0050004	HEX HEAD CAP SCREW 1/2-13 X 1-1/2	4
10	MNT0026804	BALE PUSHER MOUNT ASSY -8000	1
11	SCC0030002	HEX HEAD CAP SCREW 3/8-16 X 1"G5	14
12	BRG0026810	BALE PUSHER PIVOT BEARING-8000	2
13	NCH0000375	HEX NUT NC 3/8 - PLATED	14
14	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	14
15	SCC0030002	HEX HEAD CAP SCREW 3/8-16 X 1"G5	2
16	BAR0028829	CONVEYOR BALE GUIDE BAR -8000	1
17	GUD0026825	CONVEYOR BALE GUIDE ASSY -8000	1
18	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	2
19	NCH0000313	HEX NUT NC 5/16 - PLATED	2
20	MNT0027042	BALE PUSHER CYLINDER MNT -8000	1
21	BRG0027045	BALE PUSHER PIVOT BEARING-8000	2
22	SCC0050003	HEX HEAD CAP SCREW 1/2-13 X 1-1/4	4
23	F000005049	CLEVIS PIN 1/2" PLATED F/SP	2
24	F000006724	HYDRAULIC CYLINDER-P/U LIFT SP	1
25	COT0000502	1/8 X 1 COTTER PIN	2
26	BSH0000088	INNER RACE	4

SIDE RACK ASSEMBLIES



SIDE RACK ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	BRC3124100	LH SID RACK DECAL MNT BRACE-96	1	49	F000005992	1/2 RH MALE ROD END	3
1	BRC3124101	RH SID RACK DECAL MNT BRACE-	1	50	RAK0034794	R. SIDE RACK PIVOT TUBE ASSY	1
2	FD00028831	DECAL-7-1/2X70 WHITE "FREEMAN"	2	51	NCE0000750	ESNA NUT NC 3/4" - PLATED	8
3	SCC0030002	HEX HEAD CAP SCREW 3/8-16 X 1"G5	84	52	WCT0000750	FLATWASHER 3/4 - PLATED	8
4	WCT0000375	FLAT WASHER 3/8 USS - PLATED	172	53	SCC0080008	HEX HD CS NC 3/4 X 2-1/2 - PLATED	2
5	BRC2840000	L. DIAGONAL SIDE RACK BRACE	1	54	ROD0029593	SIDE RACK ADJUST ROD ASSY-8000	1
5	BRC2840001	R. DIAGONAL SIDE RACK BRACE	1	55	F000001550	LH NEEDLE YOKE DRV ROD F/370	1
6	NCE0000375	ESNA NUT 3/8-16 PLATED	104	56	ROD0027603	SIDE RACK ADJUSTMENT ROD -8000	1
7	SCC0030001	HEX HD CS NC 3/8 X 3/4 - PLATED	20	57	NFH0007500	HEX NUT 3/4-16 PLAIN	1
8	ZZ00000100	1/4-28 STR 5/16 HEX ZERK	4	58	ROD0027602	SIDE RACK ADJUST ROD ASSY-8000	1
9	SCC0030017	HEX HD CS NC 3/8 X 5-1/2 - PLATED	4	59	NFL0007500	LEFT HAND HEX NUT 3/4-16 PLATED	1
10	BRG0028614	SIDE RACK PIVOT BRG-AF/94-8000	2	60	ROD0027604	SIDE RACK ADJUSTING ROD -8000	1
11	SMR1032150	RND HD MS NF 10-32X1-1/2 - PLATED	2	61	F000001549	RH NEEDLE YOKE DRIVE ROD	1
12	CNR0000193	1/2" CORD CONNECTOR (.250-.375)	1	62	NCE0000500	ESNA NUT NC 1/2" - PLATED	3
13	WCT0000100	FLAT WASHER #10 - PLATED	2	63	WCT0000500	FLAT WASHER 1/2 USS -PLATED	15
14	NFH0001032	HEX NUT 10-32 ZINC	2	64	SCC0050008	HEX HD CS NC 1/2 X 2-1/2	3
15	WLK0000100	LOCK WAHSE #10 - PLATED	2	65	SQS5002500	SETSCREW,SQ HEAD 1/2-13 X 2-1/2	6
16	SWI0005079	LIMIT SWITCH -4 POST	1	66	SCC0000814	HEX HD CS NC 3/4 X 4	6
17	ARM0005001	1-1/2" LEVER ARM W/3/4" ROLLER	1	67	DOG0028823	TOP BALE DOG -AF/8/1/94 -8000	6
18	MNT0029811	FRONT SIDE RACK MOUNT -8000	2	68	MNT0026740	SIDE RACK UPPER MAST ASSY -8000	1
19	LIN0026722	SIDE RACK WEAR LINER -8000	16	69	SCC0030003	HEX HD CS 3/8-16 X 1-1/4 - PLATED	8
20	SCO0000101	FLAT HD SOCKET CS 1/4-20 X 3/4	64	70	SBH0030002	BUTTON HEAD CS NC 3/8 X 1	32
21	SCC0000805	HEX HD CS NC 3/4 X 1-3/4	8	71	BRC0027937	LFT BALE HOLD BACK BRACE-AF/93	1
22	BRC0028752	RHT FRT SIDE RACE BRACE-AF/94	1	71	BRC0027938	RHT BALE HOLD BACK BRACE -8000	1
23	BRC0028751	LFT FRT SIDE RACK BRACE-A/7-94	1	72	BRC0028383	RHT RR SIDE ROD BRACE-A/4-94	1
24	SCC0050004	HEX HEAD CAP SCREW 1/2-13 X 1-1/2	4	73	SUP0034797	SIDE RACK REAR SUPPORT- 8000	1
25	MNT0028754	LOWER RIGHT SIDE RACK MNT	1	74	BRC0028382	LFT RR SIDE RACK BRACE-AF/4-94	1
26	WLK0000500	1/2" MEDIUM LOCKWASHER - PLATED	4	75	BRC0029800	LH REAR SIDE RACK BRACE-A/2/96	1
27	NCH0000500	HEX NUT 1/2-13 - PLATED	16	75	BRC0029802	RH RR SIDE RACK BRACE-B-12/95	1
28	MNT0028753	LOWER LEFT SIDE RACK MOUNT-8K	1	76	SCC0030005	HEX HD CS NC 3/8 X 1-3/4	4
29	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	4	77	LNK0026726	SIDE RACK ADJ. LINK -8000	2
30	NCH0000313	HEX NUT NC 5/16 - PLATED	4	78	MNT0034784	LH REAR SIDE RACK BRACE MNT-8K	1
31	WLK0000750	LOCKWASHER MEDIUM 3/4"-PLATED	2	78	MNT0034780	REAR SIDE RACK BRC RH MOUNT	1
32	NCH0000750	HEX NUT NC 3/4 - PLATED	2	79	NCE0000313	ESNA NUT NC 5/16 - PLATED	20
33	WCT0000313	FLAT WASHER 5/16 -PLATED	8	80	PLT0028639	SIDE RACK RAIL END PLATE -8000	10
34	GUD0030195	SIDE RACK SWITCH CAM GUIDE -8K	1	81	SBH0020001	BUTTON HEAD CS NC 5/16 X 3/4	20
35	SCC0020003	HEX HD CS NC 5/16 X 1-1/4 - PLTD	4	82	BRC2992200	L. #5 HORIZONTAL SIDE RACK BRACE	1
36	MNT0030196	SIDE RACK SWITCH MOUNT -8000	1	82	BRC2992201	R. #5 HORIZONTAL SIDE RACK BRACE	1
37	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	6	83	BRC2992100	L #4 HORIZONTAL SIDE RACK BRACE	1
38	NCH0000375	HEX NUT NC 3/8 - PLATED	6	83	BRC2992101	R. #4 HORIZONTAL SIDE RACK BRACE	1
39	CAM0030197	SIDE RACK CAM -8000	1	84	BRC2991900	L. HORIZONTAL SIDE RACK BRACE	1
40	RAK0029817	LH FRNT SIDE RACK SUPP ASSY-8K	1	84	BRC2992001	R. HORIZONTAL SIDE RACK BRACE	1
41	CYL0030667	SIDE RACK CYLINDER-AF2/96	1	85	BRC2991900	L. HORIZONTAL SIDE RACK BRACE	1
42	MNT2860700	LH TOP SIDE RACK MOUNT -8000	1	85	BRC2991901	R. HORIZONTAL SIDE RACK BRACE	1
43	MNT2860701	RH TOP SIDE RACK MOUNT -8000	1	86	BRC2991800	L. HORIZONTAL SIDE RACK BRACE	1
44	RAK0029818	RH FRONT SIDE RACK SUPPORT -8K	1	86	BRC2991801	R. HORIZONTAL SIDE RACK BRACE	1
45	02-153	1/2" LH MALE ROD END	3	87	RAK0030728	LH RACK PIVOT TUBE-A/96 -8000B	1
46	NFL0005000	LH JAM NUT NF 1/2	3	88	MNT0026790	SIDE RACK ADJ CYL MNT ASSY-8000	1
47	ROD0026795	SIDE RACK PIVOT CONN ROD -8000	3	88	BSH00VG200	TENSION BUSHING F/5400,5500,8000	1
48	NFH0005000	HEX NUT NF 1/2	3				

INTENTIONALLY BLANK