



FREEMAN



MODEL 1390, 16" (406 mm)
AUTOMATIC HAY BALER

PARTS MANUAL

PB 13902002

CAUTION PRUDENCE



ACHTUNG PRUDENZA

1. Keep all shields in place.
2. Always stop engine before leaving operator's position and in any case, make sure precautions are taken.
3. Wait for all movement to stop before servicing this Machine.
4. Keep hands, feet and clothing away from power driven parts.
5. Never adjust, lubricate, clean or unclog unless engine is stopped.
6. Read operator's manual before operating machine. Illustrated parts listing is available from your dealer.
7. After servicing, make sure that tools and parts are stored and reinstall shields.
8. Make certain everyone is clear of machine before starting engine or operation.
9. Contact with moving parts or with any material which can be drawn into moving parts can result in serious injury.
10. Use flashing warning lights when operating on highways except when prohibited by law.

1. Bevor mit der Maschine gearbeitet wird, sind die Bedienungshinweise und die angebrachten Hinweisschilder zu lesen. Alle Sicherheitsvorschriften sind einzuhalten.
2. Vor Inbetriebnahme ist darauf zu achten, dass alle Schutzeinrichtungen angebracht sind, und dass sich keine Person im Gefahrenbereich der Maschine aufhält.
3. Instandsetzungs, Einstellungs, Wartungs und Reinigungsarbeiten nur bei abgeschaltetem Antrieb und stillstehender Maschine vornehmen.
4. Werkzeuge oder andere lose Teile nicht in oder auf der Maschine belassen.
5. Bei Fahrten auf öffentlichen Strassen sind die in Ihrem Lande geltende Vorschriften und Regelungen einzuhalten.

1. Maintenir tous les protecteurs en place.
2. Toujours arrêter le moteur avant de quitter le poste de conduite et, d'une façon générale, s'assurer que toutes les précautions sont prises.
3. Attendre l'arrêt de toutes les pièces en mouvement avant d'intervenir sur la machine.
4. Ne pas approcher mains, pieds, vêtements des parties en mouvement.
5. Ne jamais régler, graisser, nettoyer ou déboucher la machine sans que le moteur soit arrêté.
6. Prendre connaissance du manuel d'utilisation avant de travailler avec la machine. Le catalogue pièces de rechanges est disponible chez votre concessionnaire.
7. Après intervention, veiller à ce que les outils et pièces soient rangés et remettre les carters en place.
8. S'assurer que personne n'est près de la machine avant de démarrer le moteur ou de travailler.
9. Risque de dégâts importants si quelqu'un ou quelque chose est happé par des pièces en mouvement.
10. Utiliser les feux de détresse pour la conduite sur routes, sauf si la loi l'interdit.

1. Tenere tutte le protezioni al loro posto.
2. Spegner sempre il motore prima di lasciare il posto di guida e, in linea di massima, assicurarsi che siano prese tutte le precauzioni.
3. Attendere l'arresto completo di tutti gli organi prima di intervenire sulla macchina.
4. Non avvicinare mani, piedi, vestiti agli organi in movimento.
5. Solo a motore spento si può registrare, ingrassare, pulire o eliminare gli ingolfamenti.
6. Consultare attentamente il manuale d'istruzione prima di iniziare il lavoro con la macchina. Il catalogo parti di ricambio è disponibile presso il vostro concessionario.
7. Dopo qualsiasi intervento sistemare attrezzi e pezzi e rimettere a posto le protezioni.
8. Assicurarsi che non ci sia nessuno nelle vicinanze della macchina prima di metterla in moto o iniziare il lavoro.
9. Rischio e gravi infortuni subiscono coloro che sono agganciati da parti in movimento.
10. Utilizzare i fari lampeggianti durante i trasferimenti su strada.

INTRODUCTION

HOW TO USE THE MANUAL

This manual contains illustrations and parts list of components and assemblies which make up the machine. Each page consist of the name of the assembly or component, a reference number, part number, part name and the quantities of the part used.

Assemble or component name helps identify the illustration and parts list for each figure. This name also helps locate the general area of the machine where the assemble or component can be located.

Reference numbers shown in a column refers to the numbered parts in the illustration. This ties the part in the illustration to

Part numbers are used to identify individual parts or part assemblies

Part descriptions provide the name of the part, plus additional information such as dimensional specification and what parts are grouped together to form part assemblies, which helps you identify the part(s).

Quantities listed for each illustration are only for that assemble or component and not the total used per machine.

This parts manual is not intended to be a complete guide for machine service or repairs. Contact your dealer for any of your service or technical requirements.

UPDATING AN REORDERING MANUALS

The parts lists, illustrations and specifications in this manual are based on the latest information available at the time of publication. Your machine may have product improvement and options no yet contained in this manual.

J.A. Freeman & Son, Inc. reserves the right to make changes at any time without notice or obligation to you.

Your dealer will receive notice of these changes and can assist you with accurate parts identification when ordering.


A copy of this manual is supplied with each machine. Additional copies are available through you dealer. When ordering additional manuals, use the reorder number listed on the front cover and the quantity needed.

SERIAL NO. 137 -
ORDER NO. PB 13902002
ISSUE DATE 6/26/2002
Copyright Reserved 2002-2003

PARTS LIST

FOR

MODEL 1390 BALER



1. It is the policy of J.A. Freeman & Son, Inc. to constantly improve it's products whenever it is practical to do so.
2. J.A. Freeman & Son, Inc. reserves the right to redesign or change it's equipment or component parts thereof without incurring any obligation to install or furnish such changes on equipment previously delivered.
3. Unauthorized changes or additions to equipment manufactured by J.A. Freeman & Son Inc. relieves the company of further responsibility for warranted operation and breakage replacement.

A schematic diagram of a circular cell culture dish. The dish is divided into two main regions. The top region is labeled 'A' and contains a cluster of cells. The bottom region is labeled 'B' and contains a cluster of cells. The cells are represented by small circles. The dish is labeled 'A' and 'B' at the top and bottom respectively.



INSTRUCTIONS FOR ORDERING

1. Order by part number and description of part.
 - (a) Parts should NOT be ordered from illustration only.
 - (b) Parts should NOT be ordered from numbers on castings.
2. Order by baler serial number and model.
3. Much delay and confusion can be avoided if part numbers are arranged in sequence on all orders.
4. State how to ship: whether by truck, stage, parcel post, air parcel post, UPS, or air freight.
5. Claims for shortage or error in handling of an order for parts must be made upon receipt of goods.
6. Address all orders for parts as follows:

J.A. Freeman & Son, Inc.
Parts Department,
2034 N.W. 27th Avenue,
Portland, Oregon 97210

Place serial number of machine here for your convenience:

Model 1390 Baler Serial No. _____

Left and right of machine are understood to mean from a position facing in the direction of travel.

Permission must be secured before any parts are returned for credit. When parts are returned, the freight must be prepaid or arrangements made so that they can be brought in by our trucks.

"NOTE"

Parts are identified by reference numbers.

DO NOT USE REFERENCE NUMBERS AS PART NUMBERS.

See parts list for correct part numbers.

TABLE OF CONTENTS


AUTOMATIC KNOTTER LUBER	72
AUXILLARY DRIVE ASSEMBLY	46
BALE CHUTE ASSEMBLY	84
BATTERY,LIGHTS AND WIRING HARNESSSES	94
BELT DRIVE ASSEMBLY	60
BONDIOLI GEARBOX ASSEMBLY	40
CHAIN DRIVE ASSEMBLIES	48
CHAMBER ASSEMBLY	26
CHAMBER LINERS AND STATIONARY KNIFE	30
CONTROL BOXES WITH MOUNTS	92
DECAL LOCATIONS	98-101
DEUTZ ENGINE AIR SCREEN ASSEMBLIES	56
DEUTZ ENGINE, FILTERS AND ASSEMBLIES	54
DRAWBAR AND FRAME ASSEMBLIES	12
DRIVE BELT IDLER ASSEMBLY	38
FEEDER ASSEMBLY	24
FLYWHEEL,DRIVE BELT AND GUIDES	34
FLYWHEEL SHIELD ASSEMBLY	36
FUEL AND HYDRAULIC TANK ASSEMBLIES	52
HYDRAULIC MANIFOLD ASSEMBLY	88
HYDRAULICS SYSTEM	90
INSTRUCTIONS FOR ORDERING	8
INTRODUCTION	3
KNOTTER ASSEMBLY KNT006006A	66
KNOTTER BRAKE ASSEMBLY	62
KNOTTER CLUTCH ASSEMBLY	58
KNOTTER FAN ASSEMBLY	74
KNOTTER SHAFT ASSEMBLY	64
KNOTTER TRIP ASSEMBLY	68
NEEDLES AND PLUNGER STOP ASSEMBLIES	76
NEEDLE YOKE SHOCK ASSEMBLY	78
PARTS INDEX	102-117
PICKUP ASSEMBLY	18
PICKUP ASSEMBLY	20
PICKUP DRIVE COMPONENTS	22
PICKUP REEL ASSEMBLY	16
PLUNGER AND CONNECTING ROD ASSEMBLIES	42
PLUNGER, DOUBLE ROLLER	44
SAFETY	6
SERIAL NUMBER LOCATION AND IDENTIFICATION	7
SIDE HAYDOG ASSEMBLY	28
SPINDLES,TIRES AND WHEELS	96
STEP AND TOOL BOX ASSEMBLIES	82
TENSION BEAMS,RAILS AND SQUEEZE ASSEMBLIES	32
TENSION CYLINDERS HYDRAULICS	86

TABLE OF CONTENTS

TOP SHIELD ASSEMBLY	48
TWINE BOX ASSEMBLY	80
TWINE FINGER DRIVE ASSEMBLY	70
WARRANTY	5
WIND GUARD ASSEMBLY	14

NOTES:


DRAWBAR AND FRAME ASSEMBLY



DRAWBAR AND FRAME ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	DRB0031783	DRAWBAR ASSEMBLY - 1390	1
2	JCK0178203	JACK,5000LB,SIDEWIND-1390	1
3	HTH0031000	2-5/16 BALL W/NUT-WSHR,HVY DTY	1
4	HTH0021097	BALL HITCH W/FLAT PLT -NO BALL	1
5	HGR0016785	HYDRAULIC HOSE HANGER	1
6	CYL0000324	DRAWBAR SWING CYLINDER-1390	1
7	CAP0000002	ELEC PROTECTIVE CAP- 1390	1
8	BKT0034638	PLUG BRACKET- 1390	1
9	PIN0031833	DRAWBAR PIVOT PIN 1390	1
10	PIN0000002	DRAWBAR LATCH PIN- 1390	1
11	LAT0034428	DRAWBAR LATCH- 1390	1
12	SHM0034430	DRAWBAR LATCH SHIM- 1390	1
13	SPC0031714	DRAWBAR BEARING SPACER-1390	4
14	RNG0002133	PARKER O'RING-NITRILE COMPOUND	2
15	BRG015SF24	DRAWBAR MOUNT BEARING -1390	2
16	RNG5000244	INTERNAL RETAINING RING- 1390	1
17	NCE0015000	1-1/2" NC ESNA NUT-PLATED	2
18	FRM0031309	FRAME, SUPPORT, BALER - 1390	1
19	CRB5000125	1/2 X 1-1/2 CARRIAGE BOLT-PLTD	1
20	NMS0005000	1/2 UNC WHIZ NUT PLATED	1
21	WCT0000500	1/2" FLATWASHER - PLATED	1
22	SCC0050005	1/2 X 1-3/4 NC HT CS - PLATED	4
23	NCH0000500	1/2 HEX NUT NC PLATED	4
24	WLK0000500	1/2" LOCKWASHER - PLATED	4
25	NMS0000375	WHIZ NUT, 3/8 NC, PLTD	2

WIND GUARD ASSEMBLY




 FRONT

WIND GUARD ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	GRD0034649	WIND GUARD- 1390	1
2	F 0001517	TRIP SPRING	2
	NMS0000117	NUT, WHIZ, 5/16 UNC, PLATED	8
	WCT0000313	5/16" FLATWASHER-PLATED	8
	SCC0020006	SCREW, CAP, 5/16 X 2 UNC, PLATED	4
3	STO0034879	STOP, GUARD, WIND, LEFT-1390	1
	SCC0050005	1/2 X 1-3/4 NC HT CS - PLATED	1
	NMS0000252	NUT, WHIZ, 1/2 UNC, PLATED	1
	WCT0000500	1/2" FLATWASHER - PLATED	2
	BSH0034650	WIND GUARD BUSHING- 1390	1
4	STO0034880	STOP, GUARD, WIND, RIGHT - 1390	1
	SCC0050005	1/2 X 1-3/4 NC HT CS - PLATED	1
	NMS0000252	NUT, WHIZ, 1/2 UNC, PLATED	1
	WCT0000500	1/2" FLATWASHER - PLATED	2
	BSH0034650	WIND GUARD BUSHING- 1390	1
5	YOK0034643	WIND GUARD YOKE- 1390	1
	BSH0034650	WIND GUARD BUSHING- 1390	2
6	CHN035830A	WIND GUARD CHAIN	1
	WCT0000375	3/8" FLATWASHER - PLATED	2
	SCC0030004	SCREW, CAP, 3/8 X 1 1/2 UNC, PLATED	1
	NMS0000375	NUT, WHIZ, 3/8 UNC	2
7	SCC0050005	SCREW, CAP, 1/2 X 1 3/4 UNC, PLATED	2
	WCT0000500	WASHER, FLAT, 1/2, PLATED	2


PICKUP REEL ASSEMBLY



PICKUP REEL ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	PCY0032551	FRAME, PICKUP 1390	1	12	LEV0034020	PICKUP RIGHT CAM LEVER	4
2	PCY0032248	REEL, PICKUP 1390	1		WCT0000375	3/8" FLATWASHER - PLATED	12
3	BRGRA106RR	P/U REEL BEARING 1-3/8"-1390	2		SCC0030007	3/8 X 2-1/4 NC HT CS - PLATED	4
4	F 0008383	FLANGETTE-NO ZERK F/F8102	4		NCE0000375	3/8" NC ESNA NUT - PLATED	4
	NCH0000375	HEX NUT NC PLATED 3/8	6	13	PCY0034017	PICKUP TINE BAR - 1390	8
	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	6	14	BRG4164PP2	TINE BAR BEARING 1"BORE -1390	8
5	CAM0034129	LEFT PICKUP CAM- 1390	1		SCC0020001	5/16 X 3/4 NC HT CS - PLATED	16
	NCH0000375	HEX NUT NC PLATED 3/8	3		NCH0000313	HEX NUT NC PLATED 5/16	16
	SCC0030002	3/8 X 1 NC HT CS - PLATED	3		WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	16
	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	3		NCH0000250	HEX NUT NC PLATED 1/4"	8
6	LEV0034019	PICKUP LEFT CAM LEVER	4		SCC0010005	1/4 X 1-3/4 NC HT CS - PLATED	8
	WCT0000375	3/8" FLATWASHER - PLATED	12	15	SHF0034018	TINE BAR CENTER SHAFT- 1390	8
	SCC0030007	3/8 X 2-1/4 NC HT CS - PLATED	4		WCT0000375	3/8" FLATWASHER - PLATED	24
	NCE0000375	3/8" NC ESNA NUT - PLATED	4		SCC0030007	3/8 X 2-1/4 NC HT CS - PLATED	8
7	STR0032387	LEFT END STRIPPER-PICKUP- 1390	1		NCE0000375	3/8" NC ESNA NUT - PLATED	8
	SMS0000198	5/16 X 1/2 NC WHIZ BOLT-PLATED	3	16	PCY0034008	PICKUP TINE - 1390	64
8	STR0032060	STRIPPER, CENTER, PICKUP-1390	31		CRB3750100	3/8 X 1 CARRIAGE BOLT-PLTD	48
	SMS0000198	5/16 X 1/2 NC WHIZ BOLT-PLATED	93		CRB3752000	3/8 X 2 CARRIAGE BOLT-PLTD	16
9	STR0032388	RIGHT END STRIPPER-PICKUP-1390	1		WCT0000375	3/8" FLATWASHER - PLATED	64
	SMS0000198	5/16 X 1/2 NC WHIZ BOLT-PLATED	3		NCE0000375	3/8" NC ESNA NUT - PLATED	64
10	CAM0034130	RIGHT PICKUP CAM- 1390	1	17	BRG0034014	TINE BAR CENTER BEARING	8
	NCH0000375	HEX NUT NC PLATED 3/8	3		SCC0020001	5/16 X 3/4 NC HT CS - PLATED	16
	SCC0030002	3/8 X 1 NC HT CS - PLATED	3		NCH0000313	HEX NUT NC PLATED 5/16	16
	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	3		WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	16
11	BRGCRSBC20	1-1/4"STUD CAM FOLLOWER-1390	8				
	WCT0000500	1/2" FLATWASHER - PLATED	8				
	WLK0000500	1/2" LOCKWASHER - PLATED	4				
	NFH0000500	1/2" NF HEX NUT - PLATED	4				

PICKUP ASSEMBLY




PICKUP ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	WHL0401530	WHL/TIR ASSY 4 X 8	2	22	ARM0032537	PICKUP WHEEL ARM- 1390	2
2	TIR0004008	TIRE F/1500 P/U(400X8 4 PLY)	2		CRB3750150	3/8 X 1-1/2 CARRIAGE BOLT-PLTD	4
3	TIR0199128	4.00 X 8 TUBE F/TIR4008	2		NCH0000500	HEX NUT NC PLATED 1/2	4
	NMS0001023	LUG NUT F/STD0165981-SP,53,54	8		WCT0000500	1/2" FLATWASHER - PLATED	4
4	WHL0412530	WHEEL-8 X 3.75(4 ON 4)P/U	2	23	SHD0032702	LEFT PICKUP SHIELD 1390	1
5	HUB0000348	HUB W/BRGS & SEALS -BBRS P/U	2	24	HAN0000150	PLATED DOOR HANDLE	2
6	CAP0046749	CAP FOR HUB348	2		SMF1032500	10-32 X 1/2 FH MACHINE SCREW	4
7	NFC0010000	1" NF CASTLE NUT	2		WLK0000100	#10 LOCKWASHER - PLATED	4
8	ZZ 0000219	1 X 2 X 14 GA MACHINE BUSHING	8		NFH0001032	10-32 NF HEX NUT - PLATED	4
9	F 0001909	BEARING CONE	4	25	GRD0034122	PICKUP CHAIN GUARD- 1390	1
10	F 0001654	OUTER BEARING CUP	4		SCC0010001	1/4 X 3/4 NC HT CS - PLATED	1
11	HUB000BT12	HUB ONLY	2		WLK0000250	1/4" LOCKWASHER - PLATED	1
12	SEL0034823	SEAL FIHUB	2		WCT0000250	1/4" FLATWASHER - PLATED	1
13	SPN0034103	PICKUP WHEEL SPINDLE - 1390	2		CRB3750100	3/8 X 1 CARRIAGE BOLT-PLTD	2
	SCC0030007	3/8 X 2-1/4 NC HT CS - PLATED	2		NCH0000375	HEX NUT NC PLATED 3/8	2
	NCH0000375	HEX NUT NC PLATED 3/8	2		WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	2
	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	2		WCT0000375	3/8" FLATWASHER - PLATED	2
14	COT0000505	1/8 X 1-3/4 COTTER PIN	2	26	PCY0032376	RH PICKUP SWING PLATE 1390	1
15	FEN0032430	FENDER FLARE, PICKUP, RH 1390	1		SCC0050008	1/2 X 2-1/2 NC HT CS - PLATED	2
	NCH0000313	HEX NUT NC PLATED 5/16	4		NCH0000500	HEX NUT NC PLATED 1/2	2
	NCE0000250	1/4 ESNA NUT	2	27	LNK0032711	P/U LIFT FLOATING LINK- 1390	1
	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	4	28	F 0006498	CYLINDER PIVOT PIN	2
	SCC0010001	1/4 X 3/4 NC HT CS - PLATED	2	29	F 0006519	2 X 8 HYDRAULIC CYLINDER	1
	SMT0002001	5/16 X 3/4 TH MACH SCREW-PLT	4	30	COT0000704	5/32 X 1-3/4 COTTER PIN	6
	WCT0000313	5/16" FLATWASHER-PLATED	4	31	CHU0032300	FRONT FEEDCHUTE 1390	1
16	AUG0032567	LEFT AUGER TROUGH 1390	1		CRB3750100	3/8 X 1 CARRIAGE BOLT-PLTD	8
	SCC0020006	5/16 X 2 NC HT CS - PLATED	4		NCH0000375	HEX NUT NC PLATED 3/8	8
	NCH0000313	HEX NUT NC PLATED 5/16	4		WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	8
	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	4		WCT0000375	3/8" FLATWASHER - PLATED	8
	CRB3750100	3/8 X 1 CARRIAGE BOLT-PLTD	5	32	LNK0032708	PICKUP BALANCE LINK- 1390	1
	NCH0000375	HEX NUT NC PLATED 3/8	5		NCE0001000	1" NC ESNA NUT - PLATED	2
	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	5		SCC0010110	1" X 3-1/4" NC CAP SREW-PLATED	2
	WCT0000375	3/8" FLATWASHER - PLATED	5	33	BSH00VG400	1.25"OD X 1"ID X 1"LG TEN BUSH	2
17	AUG0032793	SCRAPER, AUGER 1390	2	34	SPC0034229	PICKUP SPRING SPACER- 1390	3
	CRB3750100	3/8 X 1 CARRIAGE BOLT-PLTD	6		SCC0080017	3/4 X 5-1/2 NC HT CS - PLATED	1
	NCH0000375	HEX NUT NC PLATED 3/8	6		WAS0000118	3/4 A325 STRUCTURAL WASHER-ZP	2
	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	6		NCE0000750	3/4" NC ESNA NUT - PLATED	1
	WCT0000375	3/8" FLATWASHER - PLATED	6	35	04-123	PICKUP COUNTERBALANCE SPRING	2
18	FEN0032427	FENDER FLARE, PICKUP, LH 1390	1	36	PIN0001390	P/U STOP PIN 3/4"X 3-1/2"1390	1
	FST0010401	MED DUTY FOLDING HANDLE FASTNR	5	37	ANC0016029	PICKUP LIFT SPRING ANCHOR-1500	2
	SCC0010001	1/4 X 3/4 NC HT CS - PLATED	2		WCT0000625	5/8" FLATWASHER -PLATED	2
	WLK0000250	1/4" LOCKWASHER - PLATED	2		NCH0000625	HEX NUT NC PLATED 5/8	2
	SMT0002001	5/16 X 3/4 TH MACH SCREW-PLT	4	38	LNK0032663	LH SPRING BALANCE LINK- 1390	1
	NCE0000250	1/4 ESNA NUT	2	39	LNK0032695	RH SPRING BALANCE LINK- 1390	1
	NCH0000313	HEX NUT NC PLATED 5/16	4	40	BSH00VG290	VOGELSANG VG-290 BUSHING	1
	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	4	41	CRA0032662	CRANK, BALANCE, PICKUP-1390	1
	WCT0000313	5/16" FLATWASHER-PLATED	4		NCE0000750	3/4" NC ESNA NUT - PLATED	1
20	GUD0032696	GUIDE, BOTTOM, SHIELD 1390	2		SCC0080010	3/4 X 3 NC HT CS - PLATED	1
	SMT0002001	5/16 X 3/4 TH MACH SCREW-PLT	6				
	NMS0000117	NUT, WHIZ, 5/16, UNC, PLATED	6				
	WCT0000313	WASHER, FLAT, 5/16, PLATED	6				
21	GUD0032697	GUIDE, REAR, SHIELD 1390	2				
	SMT0002001	5/16 X 3/4 TH MACH SCREW-PLT	6				
	NCH0000313	HEX NUT NC PLATED 5/16	6				
	WCT0000313	WASHER, FLAT, 5/16, PLATED	6				

CONTINUE ON NEXT PAGE


PICKUP ASSEMBLY CONT.



PICKUP ASSEMBLY CONT.

REF NO.	PART NO.	DESCRIPTION	QTY. USED
42	MNT0032800	PICKUP MOUNT 1390	2
	SCC0050009	1/2 X 2-3/4 NC HT CS - PLATED	4
	SCC0050003	1/2 X 1-1/4 NC HT CS - PLATED	4
	WLK0000500	1/2" LOCKWASHER - PLATED	8
	NCH0000500	HEX NUT NC PLATED 1/2	8
	WCT0000500	1/2" FLATWASHER - PLATED	8
43	F 0004161	1-3/8 X 18 GA MACHINE BUSHING	2
44	F 0007988	SNAP RING F/KNOTTER SHAFT	2
45	PCY0032375	L.H. PICKUP SWING PLATE 1390	1
	SCC0050008	1/2 X 2-1/2 NC HT CS - PLATED	2
	NCH0000500	HEX NUT NC PLATED 1/2	2
46	AUG0032568	RIGHT AUGER TROUGH - 1390	1
	SCC0020006	5/16 X 2 NC HT CS - PLATED	4
	NCH0000313	HEX NUT NC PLATED 5/16	4
	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	4
	CRB3750100	3/8 X 1 CARRIAGE BOLT-PLTD	5
	NCH0000375	HEX NUT NC PLATED 3/8	5
	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	5
	WCT0000375	3/8" FLATWASHER - PLATED	5
47	SHD0032703	RIGHT PICKUP SHIELD 1390	1
48	F 0006498	CONNECTING PIN	3
49	COT0000704	PIN, COTTER, 5/32 X 1 3/4	6


PICKUP DRIVE COMPONENTS



PICKUP DRIVE COMPONENTS

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	CAM0034129	CAM, PICKUP, LEFT	1	34	F000007559	SPRING, LEVER, SADDLE	1
2	SCC0000302	SCREW, CAP, HEX, 3/8 X 1, UNC	3	35	SCC0020004	SCREW, CAP, HEX, 5/16 X 1 1/2, UNC,	1
3	NCH0000375	NUT, HEX, 3/8, UNC	2	36	WCT0000313	WASHER, FLAT, 5/16, PLATED	1
4	NMS0000375	NUT, WHIZ, 3/8, UNC, PLATED	20	37	F000007448	EYEBOLT, LEVER, SADDLE	1
5	CAM0034130	CAM, PICKUP, RIGHT	1	38	F000007397	SPK, IDLER, 60 CHAIN, 15 T, 1/2 BORE	3
6	PCY0032248	REEL, PICKUP	1	39	SCC0050008	SCREW, CAP, HEX, 1/2 X 2 1/2, UNC PLT 6	6
7	BRGRA106RR	BEARING, REEL, PICKUP	2	40	NCE0000500	NUT, ESNA, 1/2, UNC, PLATED	5
8	F 0008383	FIANGETTE, BEARING	8	41	SCC0050019	SCREW, CAP, HEX, 1/2 X 6 1/2, UNC	1
9	SMS0000181	BOLT, WHIZ, 3/8 X 3/4, UNC, PLATED	6	42	SHF0032786	SHAFT, DRIVE, PICKUP	1
10	SPK0050B32	SPROCKET, RIGHT, REEL, PICKUP	1	43	BRGRA104RR	BEARING, SHAFT, DRIVE, PICKUP	2
11	SPK60BTB24	SPROCKET, LEFT, REEL, PICKUP	1	44	SPK0050B24	SPROCKET, AUGER, RIGHT	1
12	ZZ0000428	KEY, 5/16 X 5/16 X 1"	2	45	CRB3750300	BOLT, CARRAIGE, 3/8 X 3, UNC,	3
13	WCT0000500	WASHER, FLAT, 1/2, PLATED	A/R	46	SPK0033912	SPROCKET, PICKUP, DRIVEN	1
14	SCC0030007	SCREW, CAP, HEX, 3/8 X 2 1/4, UNC,	3	47	HYD3169030	3/8 SOCKET HEAD STEEL PIPE PLUG	2
15	NMS0000117	NUT, WHIZ, 5/16, UNC, PLATED	26	48	F000001790	SPRING, PIN, CLUTCH	2
16	NCE0000375	NUT, ESNA, 3/8, UNC, PLATED	6	49	F000001791	PIN, CLUTCH	2
17	WCT0000375	WASHER, FLAT, 3/8, PLATED	6	50	CLH0017849	DISC, CLUTCH, PICKUP	1
18	BRG0032234	BRG HOUSING, AUGER SHAFT, PICKUP	2	51	F000001793	DISC, FRICTION, CLUTCH	2
19	CRB3750225	BOLT, CARRAIGE, 3/8 X 2 1/4, UNC,	8	52	CLH0017767	CLUTCH, DRIVE	1
20	AUG0032222	AUGER, LEFT PICK UP	1	53	CLH0017773	ADAPTER, CLUTCH	1
21	BRG0067000	BEARING COMPLETE	4	54	ZZ00000454	KEY, 1/4 X 1/4 X 2	1
22	F000008011	OUTER BEARING CUP	4	55	SCC0050011	SCREW, CAP, HEX, 1/2 X 3 1/4, UNC,	1
23	WAS0015783	HARDENED ZZ228 MACHINE BUSHING	13	56	SCC0050015	SCREW, CAP, 1/2 X 4 1/2 UNC, PLATED	1
24	SPK0060B18	SPROCKET, AUGER, LEFT	1	57	NMS0000252	NUT, WHIZ, 1/2, UNC, PLATED	1
25	ZZ00000418	KEY, 1/4 X 1/4 X 3/4	3	58	CLH0PU1390	CLUTCH, PICKUP, 1390	2
26	NEJ0001250	NUT, JAM, ESNA, 1 1/4, UNF	2	59	F000001797	SPRING, PLATE, CLUTCH	6
27	NEJ0001250	NUT, JAM, ESNA, 1 1/4, UNF	1	60	SCC0030011	SCREW, CAP, HEX, 3/8 X 3 1/4, UNC,	6
28	SPK0050B24	SPROCKET, AUGER, RIGHT	1	61	SPC0032740	SPACER, IDLER, PICKUP	3
29	TNS0033671	TENSIONER, CHAIN, PICKUP	1	62	CRB5000450	BOLT, CARRAIGE, 1/2 X 4 1/2, UNC,	2
30	BSHP141812	BUSHING, LEVER	2	63	SPK0002416	SPROCKET, IDLER, 50 CHAIN, 17 T	2
31	RNG0002212	CAM LEVER O-RING, PARKER #2-212,	2	64	BRG0020016	GARLOCK DX BRG, NO. 020 DX R016	2
32	ZZ00000208	WASHER, MACHINE, 7/8 X 18 GA	2	65	CHN0006081	MAIN PU DRVE CHAIN, RC #60, 81 P	1
33	COT0000704	PIN, COTTER, 5/32 X 1 3/4	2	66	F000000760	LINK, CONNECTING, 60 CHAIN	2
				67	CHN0060109	LEFT PU DRIVE CHAIN, RC #60, 109 P	1
				68	CHN0050107	RIGHT PU DRIVE CHAIN, RC #50, 107 P	1
				69	F000000025	LINK, CONNECTING, 50 CHAIN	1
				70	F000000123	LINK, OFFSET, 50 CHAIN	1
				71	F000000759	LINK, OFFSET, 60 CHAIN	3


FEEDER ASSEMBLY



FEEDER ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	CHU0035519	RH FEED CHUTE SIDE PLATE ASSY	1	28	SPK060SK33	P/U DRIVE SPROCKET-1390	1
2	CHU0035518	LH FEED CHUTE SIDE PLATE ASSY	1	29	BSHSK21875	BSH-QD-TYPE	1
3	CHU0031517	FEED CHUTE BACK ASSY - 1390	1	30	SCC0070006	5/8 X 2 NC HT CS - PLATED	8
4	DOR0031542	FEED CHUTE ACCESS DOOR - 1390	1	31	NMS0000253	WHIZ NUT, 5/8 NC, PLTD	4
5	CHU0031541	FEED CHUTE TOP SECTION - 1390	1	32	NMS0000253	WHIZ NUT, 5/8 NC, PLTD	16
6	HSG0032183	FEEDER BEARING HOUSING -1390	1	33	SCC0070007	5/8 X 2-1/4 NC HT CS - PLATED	12
7	BRG0507910	BEARING CUP-L507910	2	34	SCC0030004	CAP SCREW HEX 3/8 X 1 1/2 UNC	4
8	BRG0507949	BEARING-TAPERED ROLLER L507949	2	35	SCC0050004	HEX CAP SCREW, 1/2 X 1 1/2 NC, PLTD	4
9	SELV507949	BRG SEAL-USE W/SPC34397- 1390	2	36	NMS0000252	WHIZ NUT, 1/2 NC, PLTD	8
10	RNG0023161	BEARING THRUST RING	2	37	WLK000O500	SPLIT LOCK WASHER, 1/2	8
11	CRA0032174	CRANK, FEEDER - 1390	2	38	SCC0030002	3/8 X 1 NC HT CS - PLATED	30
12	LOK0017500	1-3/4 STD THD LOCK COLLAR-16L	2	39	CRB3750013	3/8 X 1-1/4 CARRIAGE BOLT-PLTD	4
13	SHF0032317	R.H.FEEDER DRIVE SHAFT -1390	1	40	NMS0000375	WHIZ NUT, 3/8 NC, PLTD	38
14	BRG0021135	4 BOLT FLANGE BEARING-1390	2	41	SCC0050003	HEX CAP SCREW, 1/2 X 1 1/4 NC, PLTD	4
15	SPK0100E30	SPROCKET-FEEDER ASSEMBLY-1390	1	42	SCC0050008	1/2 X 2-1/2 NC HT CS - PLATED	10
16	BSH0E21875	2-3/16"QD BUSHING F/SPK100E30	1	43	FRM0031522	REAR GEAR BOX CROSS FRM - 1390	1
17	TIN0034001	TINE, FEEDER - 1390	2	44	STR0035596	RH FEEDER STRIPPER	1
18	NFH0000750	3/4" NF HEX NUT - PLATED	2	45	STR0035597	CENTER FEEDER STRIPPER	2
19	TIN0034907	FEEDER PIVOT TINE ASSY- 1390	1	46	STR0035595	LH FEEDER STRIPPER	1
20	LNK0032823	FEEDER LINK ASSY 1390	1	47	STR0035574	FEEDER CENTER STRIPPER MNT ASSY	1
21	PIN0033506	FEEDR LNK FRONT PIVOT PIN-1390	1	48	ZZ 0000451	1/2 X 1/2 X 1-1/2 KEY	2
22	SHF0032318	L.H.FEEDER DRIVE SHAFT —1390	1	49	F 0000225	KNTR DR SHF KEY 1/2 X 2	3
23	F 0007523	NEEDLE YOKE BEARING	2	50	RNG5000162	1-5/8"INTERNAL RETAINING RING	4
24	NFJ0000750	3/4" NF HEX JAM NUT-PLAIN	1	51	LUB0323060	PRESSURE FITTING VALVE, 1/8 NPT	1
25	WAS0000118	3/4 A325 STRUCTURAL WASHER-ZP	1	52	SPC0034397	FEEDER BRG SEAL SPACER- 1390	2
26	ZZ 0000103	GREASE ZERK, 1/8 NPT STRAIGHT	1	53	FLT0034591	FEEDER BEARING SEAL FELT-1390	2
27	SHF0032184	FEEDER TINE PIVOT SHAFT-1390	1				


CHAMBER ASSEMBLY



CHAMBER ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	FRM0031616	FRONT MAIN FRAME ASSY - 1390	1
2	CHM0035493	CHAMBER SIDE ASSY, LH	1
3	CHM0035494	CHAMBER SIDE ASSY, RH	1
4	SUP0035489	GEAR BOX SUP ASSY, UPPER REAR	1
5	CHM0035454	FRT CHM TOP PLATE 15 1/2 ASSY	1
	CHM0032445	FRT TOP CHM PLATE 15" CHAMBER-	1
6	CHM0035474	REAR CHAMBER TOP PLATE ASSY	1
7	CHM0033528	CHAMBER STIFFENER BAR-1390	2
8	CHM0032660	UPPER CHAMBER STIFFENER 1390	2
9	CHM0035598	LOWER CHAMBER STIFFENER	2
10	MNT0035541	RH SIDE TNS RAIL MNT ASSY-1390	1
11	LIN0035569	RH SIDE CHAMBER LINER ASSY	1
12	LIN0035568	LH SIDE CHAMBER LINER ASSY	1
13	MNT0035286	LH SIDE TNS RAIL MNT ASSY-1390	1
14	FRM0031536	BOTTOM FRAME CROSS MEMBER-1390	1
15	FRM0031522	REAR GEAR BOX CROSS FRM - 1390	1
16	MNT0033924	TENSION VALVE MOUNT 1390	1


SIDE HAY DOG ASSY



SIDE HAY DOG ASSY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	DOG0035241	SIDE HAY DOG	2
2	F 008264	RUBBER BUMPER	2
3	UBL0034520	U BOLT, 5/16 UNF	2
4	NMS0000375	WHIZ NUT, 3/8 NC, PLTD	2
5	SMS0000182	WHIZ BOLT, 3/8 X 1 1/4 NC, PLTD	8
6	BLK0034519	OUTER BEARING BLOCK	4
7	BLK0034521	SPRING CLAMP BLOCK	2
8	SPG0035335	LEAF SPRING, 8"	2
9	SPG0035334	LEAF SPRING, 6 1/2"	2
10	SPG0035333	LEAF SPRING, 5"	2
11	SPG0035332	LEAF SPRING, 3 1/2"	2
12	BLK0035426	SPRING SUPPORT BLOCK	2
13	WLK0000313	SPLIT LOCK WASHER, 5/16, PLTD	4
14	NFH0000313	HEX NUT, 5/16 NF, PLTD	4


CHAMBER LINERS AND STATIONARY KNIFE



CHAMBER LINERS AND STATIONARY KNIFE

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	PLG0031038	PLUNGER FRNT ROLLER RAIL UPPER	2
2	PLG0032677	RAIL,ROLLER,PLNGR,FRONT,LOW,LH	1
3	PLG0032678	RAIL,ROLLER,PLNGR,FRONT,LOW,RH	1
4	BLK0032668	LOWER PLG ROLLER BLOCK-1390	2
5	SCC0000204	HEX CAP SCREW, 5/16 X 1 1/2 NC	2
6	NCJ0000313	5/16" NC JAM NUT - PLATED	2
7	SCC0000308	HEX CAP SCREW, 3/8 X 2 1/2 NC	4
8	NCJ0000375	3/8" NC JAM NUT - PLATED	4
9	BLK036268B	UPPER SLIDE RAIL JACK BLOCK ASSY	2
	SFC0080304	HEX CAP SCREW, 3/8 X 1 1/2 NF, GR 8	4
	WAS0000106	FLAT STRUCTURAL WASHER, 3/8,	4
	NFH0000375	HEX NUT, 3/8 NF, PLTD	4
10	KNF0035527	STATIONARY KNIFE- 1390	1
11	LIN0035564	LH BOTTOM CHAMBER LINER ASSY	1
12	LIN0035563	CNTR BOTTOM CHAMBER LINER ASSY	2
13	LIN0035562	RH BOTTOM CHAMBER LINER ASSY	1
14	PLG0035353	PLUNGER ROLLER RAIL, UPPER REAR	2
15	PLG0031042	PLUNGER ROLLER RAIL, LOWER REAR	2
16	LIN0035569	RH SIDE CHAMBER LINER ASSY	1
17	LIN0035568	LH SIDE CHAMBER LINER ASSY	1
18	SHM0031948	BOTTOM CHAMBER LINER SHIM	4
19	RST0032128	RESTRICTOR,CHAMBER	A/N




TENSION BEAMS, RAILS AND SQUEEZE ASSEMBLIES



TENSION BEAMS, RAILS AND SQUEEZE ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	ANG0035558	LH LOWER CHMBER EXT ANG ASSY	1	16	TNS0033601	SIDE TENSION RAIL - 1390	2
2	ANG0035559	RH LOWER CHAMBER EXT ANG ASSY	1	17	CHM0035460	FRT TOP CHM PLATE 14.5" CHAMBER-	1
3	ANG0031915	ANGLE,EXT,CHMBR, L., TOP-1390	1	18	CHM0035454	FRT CHM TOP PLATE 15.5" CHAMBER	1
4	ANG0031916	ANGLE,EXT, CHMBR R. TOP-1390	1	19	CHM0035474	CHM TOP PLATE ASSY, 15.5 "	1
5	YOK0035572	TOP REAR CHAMBER YOKE ASSY	1	20	BSH0034240	TOP TNS RAIL PIVOT BSH- 1390	4
6	F 0006519	2 X 8 HYDRAULIC CYLINDER	1	21	BSH0031605	TNS RAIL PIVOT BSH 15.5" CHAMBER	8
7	TNS0033588	BEAM, RAIL, TENSION - 1390	2	22	SPC0034242	TOP TENSION RAIL SPACER- 1390	2
8	CYL0033749	VERTICAL TENSION CYLINDER-1390	2	23	LIN0034231	FRONT TOP CHM LINER ASSY- 1390	1
9	HAN0000817	CHROME GRAB HANDLE-#817	2	24	LIN0034233	REAR TOP CHAMBER LINER- 1390	1
10	BRC0035614	LH REAR CHAMBER BRACE ASSY	1	25	FRM0031536	BOTTOM FRAME CROSS MEMBER-1390	1
11	BRC0035615	RH REAR CHAMBER BRACE ASSY	1	26	PLT035870D	REAR CHAMBER YOKE TIE PLATE	2
12	TNS0033587	TOP R.H. TENSION RAIL - 1390	1	27	PLT035901D	MIDDLE CHAMBER YOKE TIE PLATE	1
13	TNS0033586	TOP (LH ONLY) & BTM TNS RAIL	3	28	YOK035878D	MIDDLE CHAMBER YOKE	2
14	TNS0035577	HORIZONTAL TNS RAIL SQZ	2	29	MNT0035557	REAR CHM BRACE CROSSMEMBER	1
15	YOK0031895	BOTTOM REAR CHAMBER YOKE—1390	1	30	PLT035870B	REAR CHAMBER YOKE TIE PLATE	1


FLYWHEEL, DRIVE BELT AND GUIDES



FLYWHEEL, DRIVE BELT AND GUIDES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	PIN0034696	FLYWHEEL BELT GUIDE PIN- 1390	9	15	BRG072DU32	GARLOCK DU BRG F/BLT DRVE-1390	2
2	NCH0000375	HEX NUT NC PLATED 3/8	10	16	BSH0031143	FLYWHEEL SHEAR BUSHING HUB END	1
3	WCT0000375	3/8" FLATWASHER - PLATED	10	17	NCE0000375	3/8" NC ESNA NUT - PLATED	1
4	BLT000D210	MAIN DRIVE BELT- 1390	1	18	F 0000072	1/2 X 1/2 X 3 1/2"L.KEYSTOCK	1
5	BKT0034705	MIDSPIN BLT GUIDE BRACKET-1390	1	19	HUB0031140	FLYWHEEL SHEAR HUB -1390	1
6	GUD0033425	CENTER BELT GUIDE ASSY- 1390	1	20	NMS0000375	3/8 NC WHIZ NUT - PLTD	4
7	GUD0033484	REAR BELT GUIDE ASSY- 1390	1	21	PLT0033418	BELT GUIDE PLATE- 1390	1
8	BKT0033451	BKT,GUIDE,BELT,REAR,LOWER-1390	1	22	NFC0015000	CASTLE NUT, 1 1/2 NF	1
9	BKT0033444	BTM BELT GUIDE BRACKET- 1390	1	23	COT0000808	COTTER PIN, 3/16 X 3	1
10	FLW0031112	FLYWHEEL -1390	1				
11	BSH0031142	FLYWHEEL SHEAR BSH & END -1390	1				
12	SCC0030019	3/8 X 6-1/2 NC HT CS - PLATED	1				
13	RET0031144	FLYWHEEL RETAINER WASHER -1390	1				
14	SEL0045025	OIL SEAL C/R 45025 -1380	2				


FLYWHEEL SHIELD ASSEMBLY



FLYWHEEL SHIELD ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	SHD0034378	LEFT FRONT SHIELD	1
2	SHD0034377	RIGHT FRONT SHIELD	1
3	SHD0033743	MAIN SHIELD	1
4	SHD0035079	FRONT SHIELD STIFFENER	1
5	SHD0035084	CONTROL BOX SHADE	1
6	SHD0035085	FRONT SHIELD CORNER	1
7	SHD0035133	RIGHT FRONT SHIELD GUSSET	1
8	SHD0035134	LEFT FRONT SHIELD GUSSET	1
9	MNT0035192	MAIN SHIELD SPRING MOUNT	1
10	MNT0035355	MAIN SHIELD BUMPER MOUNT	2
11	BKT0035354	MAIN SHIELD SPRING BRACKET	1
12	HAN0000817	CHROME GRAB HANDLE	1
13	NMS0000375	NUT, WHIZ, 3/8 UNC, PLATED	2
14	NCC0002500	NUT, CAGE, 1/4 UNC	30
15	SMS0000173	BOLT, WHIZ, 1/4 X 1/2 UNC, PLATED	30
16	20-112	MOTOR MOUNT PAD	2
17	LAT0000201	RUBBER DRAW LATCH	2
18	NMS0000117	NUT, WHIZ, 5/16 UNC, PLATED	14
19	SCC0000201	SCREW, CAP, 5/16 X 3/4 UNC, PLATED	14
20	SMS0000172	BOLT, WHIZ, 1/4 X 3/4 UNC, PLATED	4
21	NMS0000250	NUT, WHIZ, 1/4 UNC, PLATED	4
22	WCT0000313	WASHER, FLAT, 5/16, PLATED	4
23	SOK0000002	GAS SPRING BALL SOCKET	2
24	STD0000M13	GAS SPRING BALL STUD #9416K83	2
25	RIV0000604	RIVET, GRIP, 3/16 X 1/4 SS	4
26	SPG0000002	GAS SPRING, McMaster-Carr	1
27	CLP0000005	GAS SPRING SAFETY CLIP	2


DRIVE BELT IDLER ASSEMBLY



DRIVE BELT IDLER ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	MNT0035734	BELT IDLER MOUNT ASSEMBLY	1	21	WAS0000128	1/2 SAE FLATWASHER	4
2	PUL0030770	IDLER PULLEY ASSEMBLY	1	22	SMS0000403	BOLT, WHIZ, 1/2 X 1 1/4 UNC, PLATED	4
3	CRA0035739	BELT IDLER BELL CRANK	1	23	F 0000246	KNOTTER BRAKE DISC WASHER	1
4	CYL0034537	CLUTCH BELT CYLINDER- 1390	1	24	SMS0000181	3/8 X 3/4 NC WHIZ BOLT -PLATED	3
5	BSH00VG400	1.25"OD X 1"ID X 1"LG TEN BUSH	4	25	NMS0000250	NUT, WHIZ, 1/4 UNC, PLATED	2
6	PIN0033395	PIN,CYLINDER,CLUTCH,BELT -1390	1	26	NMS0000252	NUT, WHIZ, 1/2 UNC, PLATED	2
7	ZZ 0000214	1X1-1/2X14 GA MACHINE BUSHING	1	27	SCC0050016	1/2 X 5 NC HT CS - PLATED	2
8	BRG00205PP	BALL BEARING 1390	2	28	GUD0035745	INNER BELT IDLER GUIDE	1
9	RET0516098	RETAINING RING 1390	1	29	SHD0034308	SHIELD, BELT - 1390	1
10	SPG0020662	PLUNGER LATCH SPRING 370	1	30	SMS0000184	BOLT, WHIZ, 3/8 X 1 UNC, PLATED	3
11	NCE0000500	NUT, ESNA, 1/2 UNC	1	31	SHF0034539	CLUTCH BELLCRANK PIVOT ASSMBLY	2
12	SCC0050006	1/2 X 2 NC HT CS - PLATED	1	32	WAS0000138	3/8" SAE FLATWASHER-PLATED	10
13	F 0000883	IDLER PULLEY F/KNOT CHAIN DRIV	1	33	BKT0034532	LOWER REAR BLT GUIDE BKT- 1390	1
14	CHN035828A	CLUTCH CYLINDER SPRING CHAIN	1	34	PIN0034696	FLYWHEEL BELT GUIDE PIN- 1390	1
15	FT 0000113	CONNECTING LINK - #41 CHAIN	1	35	NMS0000375	NUT, WHIZ, 3/8 UNC, PLATED	11
16	GUD0035742	BELT IDLER OUTER GUIDE	1	36	HYD7230040	1/2" O-RING HEX HEAD PLUG	2
17	SMS0001390	OPEN EYE STEEL WIRE EYEBOLT-ZP	1	37	HYD5315034	3/8 JIC X 1/2 O-RNG ST THD CON	1
18	COT0000805	3/16 X 2 COTTER PIN	1	38	SFC0050003	1/2 X 1-1/4 NF HT CS - PLATED	1
19	SPC0034170	BELT IDLER OUTER GUD SPC- 1390	2	39	NFH0005000	1/2" NF HEX NUT	1
20	PLT0033259	BELT IDLER NUT PLATE -1390	4	40	PIN0035759	SHORT BELT GUIDE PIN	2
				41	COT0000504	COTTER PIN, 1/8 X 1 1/2	2


BONDIOLI GEARBOX ASSEMBLY



BONDIOLI GEARBOX ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	GER0033083	BONDIOLI GEARBOX- 1390	1
2	BON0000001	GEARBOX CRANK ARM HUB- 1390	2
3	BON0000002	SNAP RING- 1390	2
4	BON0000003	CRANK ARM RETAINING RING- 1390	2
5	BON0000004	GEARBOX GREASE ZERK- 1390	2
6	BON0000005	GEARBOX CRANK ARM BEARING-1390	2
7	BON0000006	GEARBOX DIRT EXCLUDER- 1390	1
8	BON0000007	GEARBOX MAIN SHF OIL SEAL-1390	2
9	BON0000008	INPUT SHAFT OIL SEAL- 1390	1
10	BON0000009	GEARBOX RH CRANK ARM SEAL-1390	1
11	BON0000010	CRANK ARM BEARING SEAL- 1390	2
12	BON0000011	LH BEARING CLOSURE CAP- 1390	1
13	BON0000012	GEARBOX DRAIN PLUG- 1390	1
14	BON0000013	OIL LEVEL SIGHT GLASS- 1390	1
15	BON0000014	PRESSURE/BREATHER PLUG- 1390	1
16	BON0000015	GEARBOX LH CRANK ARM- 1390	1
17	BON0000016	GEARBOX RH CRANK ARM- 1390	1


PLUNGER AND CONNECTING ROD ASSEMBLIES



PLUNGER AND CONNECTING ROD ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	PLG036190F	PLUNGER WELDMENT	1	17	PLG0031037	PLUNGER HARD SLIDE SHIM, 20 GA	4
2	SHF0035705	REAR PLNGER ROLLER SHAFT BLOCK	2	18	BRG203KRR3	FRONT PLUNGER ROLLER BEARING,	2
3	EXT036224B	LH UPPER PLG FACE EXT ASSY. 16"	1	19	SCC0050005	HEX CAP SCREW, 1/2 X 1 3/4 NC	6
4	EXT036225A	RH UPPER PLG FACE EXT ASSY, 16"	1	20	WLK0000500	SPLIT LOCK WASHER, 1/2, PLTD	6
5	EXT036206B	MIDDLE UPPER PLG FACE EXT ASSY	2	21	PLG0034588	FRONT PLUNGER ROLLER BOLT	2
6	EXT036226A	CENTER SIDE PLG FACE EXTENSION	2	22	SCO0030003	HEX SOC HEAD CS, 3/8 X 1 1/4NC, PLTD	2
7	EXT036227A	LOWER SIDE PLG FACE EXT	2	23	PWB3751500	PLOW BOLT, 3/8 X 1 1/2 NC	8
8	PLT035839A	PLUNGER FACE CAP PLATE	2	24	PWB3751500	PLOW BOLT, 3/8 X 1 1/2 NC	8
9	KNF036235B	LH OUTER PLUNGER KNIFE	1	25	NMS0000375	WHIZ NUT, 3/8 NC	8
10	KNF036236B	RH OUTER PLUNGER KNIFE	1	26	SMS0000181	WHIZ BOLT, 3/8 X 3/4 NC, PLTD	20
11	KNF036242B	INNER PLUNGER KNIFE	2	27	SMS0080319	FLNG 12 POINT CS, 3/8 X 2 1/2 NC	4
12	SHM036237A	OUTER PLUNGER KNIFE SHIM, 16 GA	4	28	CLP0030878	PLUNGER CONN ROD PIN CLAMP BLK	4
13	BRG0000013	REAR PLUNGER ROLLER BEARING,	2	29	RNG5100196	RETAINING RING, EXT N5100-196	4
14	SHM036238A	OUTER PLUNGER KNIFE SHIM, 30 GA	4	30	PIN0030841	PLUNGER CONNECTING ROD PIN	2
15	NEJ0001000	ESNA HEX JAM NUT, 1 NC, PLTD	8	31	ROD0030844	CONNECTING ROD	2
16	PLG0031035	PLUNGER HARD SLIDE, 5/8 X 2	2	32	SCC0070007	HEX CAP SCREW, 5/8 X 2 1/4 NC	4
				33	WLK0000625	SPLIT LOCK WASHER, 5/8, PLTD	4
				34	BRG0040310	CONN ROD.BELT DRIVE BRG	2


DOUBLE ROLLER PLUNGER



DOUBLE ROLLER PLUNGER

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	PLG036231E	PLUNGER ASSY, 16" CHAMBER - 1390	1
2	PLG036523D	LH FRONT PLNGR ROLLER MNT ASSY	1
3	PLG036524D	RH FRONT PLNGR ROLLER MNT ASSY	1
4	BRG0000013	SPLIT LOCK WASHER, 1/2, PLTD	4
5	NEJ0001000	ESNA JAM NUT NC 1" - PLATED	4
6	SHM036648A	REAR PLG ROLLER BLOCK SHIM 16GA	4
7	SHM036649A	REAR PLG ROLLER BLOCK SHIM 20GA	4
8	SHM036650A	REAR PLG ROLLER BLOCK SHIM 28GA	4
9	SHF036537D	CENTER REAR PLG ROLLER SHFT BLK	2
10	SHF036507D	REAR ROLLER SHAFT BLOCK	4
11	SFC0050001	HEX CS, 1/2-20 UNF 3/4	8
12	WLK0000500	1/2" LOCKWASHER - PLATED	20
13	PLG0034588	FRONT PLUNGER ROLLER BOLT-1390	6
14	BRG0000005	PLUNGER ROLLER, 2" DIA YOKE STYLE	2
15	SCC0070006	HEX HD CS NC 5/8 X 2"	2
16	SCC0050005	HEX HD CS 1/2-13 X 1-3/4" GRADE 5	16
17	BRG203KRR3	FRONT PLUNGER ROLLER BEARING	6
18	SFC0050003	HEX HD CS NF 1/2 X 1-1/4	2
19	NFJ0050000	LH JAM NUT NF 1/2"	2
20	PLG036517D	LH FRONT PLG ROLLER MOUNT	1
	PLG036535D	RH FRONT PLG ROLLER MOUNT	1


AUXILLARY DRIVE ASSEMBLY



AUXILLARY DRIVE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	ARM0031341	AUXILIARY DRIVE CRANK ARM ASSY	1	17	RNG0002239	O RING, 3.609 ID X .139W, 2-239	2
2	PLT0031348	AUXILIARY CRANK LINK PLATE	2	18	BRG0000019	FEEDER DRIVE SPROCKET BEARING,	1
3	LNK0031503	AUXILIARY DRIVE DRAG LINK	1	19	SPK0031501	FEEDER DRIVE SPROCKET	1
4	PIN0031504	DRAG LINK PIN	1	20	HUB0031350	AUXILIARY DRIVE SHEAR HUB	1
5	ZZ 0000201	MACHINERY BSH, 3/4 X 1 1/4 X 18 GA	1	21	SPK0033113	KNOTTER DRIVE SPROCKET	1
6	RNG5160075	RETAINING RING, 5160-075	2	22	BSH0031351	FEEDER DRIVE SHEAR BUSHING	2
7	SFC0030003	HEX CAP SCREW, 3/8 X 1 1/4 NF, PLTD	4	23	SCC0030007	HEX CAP SCREW, 3/8 X 2 1/4 NC, PLTD	1
8	NFX0003750	HEX JAM NUT, 3/8 NF, FLEX LOCK	4	24	NCE0000375	ESNA NUT, 3/8 NC, PLTD	1
9	ZZ 0000463	KEY, 3/8 X 1/2 X 3 3/4	1	25	SFC0010000	HEX CAP SCREW, 1/4 X 1 3/4 NF, PLTD	2
10	BRG395LA90	TAPERED ROLLER BEARING CONE,	2	26	NFE0000250	ESNA NUT, 1/4 NF, PLTD	2
11	BRG000394A	TAPERED ROLLER BEARING CUP, 394A	2	27	NCE0000375	3/8" NC ESNA NUT - PLATED	1
12	HSN0031353	AUXILIARY DRIVE BRG HOUSING ASSY	1	28	WAS00TW113	BEARING LOCKWASHER, TW 113	1
13	PLT0031352	AUXILIARY DRIVE BRG MOUNTING PLT	1	29	NMS000TN13	BEARING LOCKNUT, TN13	1
14	SCC0050003	HEX CAP SCREW, 1/2 X 1 1/4 NC, PLTD	4	30	NMS0000375	WHIZ NUT, 3/8 NC, PLTD	2
15	NMS0000252	WHIZ NUT, 1/2 NC, PLTD	4				
16	SCC0030002	HEX CAP SCREW, 3/8 X 1 NC, PLTD	8				


CHAIN DRIVE ASSEMBLIES



CHAIN DRIVE ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	WLK0000500	1/2" LOCKWASHER - PLATED	5	23	MNT0032296	FEEDER CHAIN GUIDE MOUNT- 1390	2
2	NCH0000500	HEX NUT NC PLATED 1/2	5	24	DOC0032298	FEEDER CHAIN GUIDE ASSY	1
3	CHN0032297	FEEDER CHAIN GUIDE WEAR STRIP	2	25	SCC0070006	5/8 X 2 NC HT CS - PLATED	1
4	SMS0000201	SMS #8 X 5/8 HEX HEAD TYPE AB	20	26	WLK0000625	5/8" MEDIUM LOCKWASHER - PLTD	2
5	ANG0034583	KNT CHAIN GUD ANGLE ASSY- 1390	1	27	NCH0000625	HEX NUT NC PLATED 5/8	2
6	SCC0030004	3/8 X 1-1/2 NC HT CS - PLATED	2	28	SCC0070008	5/8 X 2-1/2 NC HT CS - PLATED	1
7	WCT0000375	3/8" FLATWASHER - PLATED	4	29	WCT0000625	5/8" FLATWASHER -PLATED	1
8	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	2	30	SPC0035239	KNT LUBER PMP MNT SPACER- 1390	1
9	NCH0000375	HEX NUT NC PLATED 3/8	2	31	SCC0050005	1/2 X 1-3/4 NC HT CS - PLATED	1
10	MNT0034786	KNT CHN IDLER MOUNT ASSY- 1390	1	32	ANG0032292	FEEDER CHAIN GUIDE ANGLE	2
11	SCC0050004	1/2 X 1-1/2 NC HT CS - PLATED	2	33	NMS0000375	WHIZ NUT, 3/8 NC, PLTD	2
12	WCT0000500	1/2" FLATWASHER - PLATED	5	34	ANG0034585	MOUNT ANGLE	1
13	SCC0050018	1/2 X 6 NC HT CS - PLATED	1	35	CHN0034582	KNOTTER CHAIN GUIDE ASSY	1
14	SPK0002416	IDLER SPROCKET-1/2"BR,17T	2	36	ROD0035081	CHAIN IDLER ADJUSTING ROD	1
15	CHN0000291	AUTO LUBER CHAIN F/1390	1		F 005048	CLEVIS, 1/2"	1
16	F 0000025	CONNECTING LINK-RC50	1		CLV0120018	CLEVIS PIN, 1/2 X 1 1/2	1
17	F 0000123	RC 50 OFFSET LINK	1		F 0001019	HAIRPIN COTTER, SIZE 21-07	1
18	CHN0010097	MAIN DRIVE CHAIN- 1390	1		SFH0000500	WHIZ NUT, 1/2 NF	2
19	CNK0001000	CONN LINKS, #100, COTTER PIN	1		NFH0000500	HEX NUT, 1/2 NF, PLTD	1
	OFL0001000	OFFSET LINKS, #100	2		WAS0000128	FLAT WASHER, 1/2, PLTD	2
20	SPK0000100	FDR DRV IDLER SPROCKET- 1390	1	37	MNT0032288	FEEDER CHAIN IDLER MOUNT	1
21	SCC0100010	1" X 3 NC HT CS - PLTD	1	38	SPC0032289	SPACER, 1 1/4 OD X 5/16 W X 13/16 LG	1
22	WAS0000110	1" SAE FLAT WASHER	A/R		SCC0070004	HEX CAP SCREW, 5/8 X 1 1/2 NC, PLTD	1
					SCC0070008	HEX CAP SCREW, 5/8 X 2 1/2 NC, PLTD	1
					NMS0000253	WHIZ NUT, 5/8 NC, PLTD	2


TOP SHIELD ASSEMBLY



TOP SHIELD ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	SHD0035677	TOP SHIELD	1
2	SHD0035123	TOP SHIELD STIFFENER	1
3	SHD0035348	TOP SHIELD CORNER	1
4	HAN0000817	CHROME GRAB HANDLE	1
5	SHD0035693	TOP SHIELD SIDE	1
6	MNT0035342	SHIELD PROP MOUNT	1
7	F 0000440	FERRULE	1
8	SCC0020002	SCREW, CAP, 5/16 X 1 UNC, PLATED	1
9	NMS0000117	NUT, WHIZ, 5/16 UNC, PLATED	3
10	NCC0002500	NUT, CAGE, 1/4 UNC	18
11	SMS0000173	BOLT, WHIZ, 1/4 X 1/2 UNC, PLATED	18
12	SMS0000172	BOLT, WHIZ, 1/4 X 3/4 UNC, PLATED	4
13	SCC0000201	SCREW, CAP, 5/16 X 3/4 UNC, PLATED	2
14	NMS0000250	NUT, WHIZ, 1/4 UNC, PLATED	4
15	PRP0035351	TOP SHIELD PROP	1


FUEL AND HYDRAULIC TANK ASSEMBLIES



FUEL AND HYDRAULIC TANK ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	TNK0032767	30 GAL. FUEL TANK/AFT 12/99	1
2	F 0001689	FUEL TANK CAP	1
3	SDR0RA9320	FUEL LEVEL SENDER - 1390	1
4	CLP0708501	FUEL TANK STRAP	2
5	F 0000893	TANK FELTS , SET OF 3	1
6	HYD3169020	1/4 SOCKET HD STEEL PIPE PLUG	2
7	F 0008189	SHUT-OFF VALVE	2
8	HYD1069022	1/4HOS X 1/4NPT 90* MINI-BARB	1
9	CLP7051170	MINI HOSE CLAMP	1
10	HSE0001875	3/16"ID FUEL LINE HOSE-BULK	5
11	SMF0002001	5/16 X 3/4 FH MACH. SCR - PLTD	2
12	HYD5405045	3/8 JIC X 3/8 NPT 90* MALE ELB	1
13	HOS0034415	ENGINE FUEL INLET TO TNK FRONT	1
14	CAP0001390	PRESSURE VENT CAP ONLY	1
15	TNK004Z980	HYD RESERVOIR W/FILL NECK-5GAL	1
16	HYD5405070	1" JIC X 1" NPT 90* MALE ELB	1
17	FILS1510V3	HYD TANK FILTER- 1390	1
18	HYD5405060	3/4 JIC X 3/4 NPT 90* MALE ELB	1
19	SHD0034802	SHIELD MANIFOLD, HYDRAULIC 1390	1


DEUTZ ENGINE, FILTERS AND ASSEMBLIES



DEUTZ ENGINE, FILTERS AND ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	DTZ0001390	DTZ 4 CYLINDER ENG- 1390 ONLY	1	21	SCC0020002	5/16 X 1 NC HT CS - PLATED	1
2	DTZ0272326	V BELT FAILURE SWITCH KIT	1	22	WLK0000313	5/16" MEDIUM LOCKWASHER - PLTD	3
3	DTZ2235178	ALTERNATOR BELT F/DEUTZ ENG	1	23	BSH0032160	BSH, ACCEL RATOR, THROTTLE 1390	1
4	DTZ1236291	OIL FILLER CAP-DEUTZ ENGINE	1	24	F 0006781	43/64 X 1-1/8" WAVE WASHER	2
5	FIL1160024	OIL FILTER, DEUTZ	1	25	ACT00A330R	ADDCO ELECTRIC ACTUATOR ERC330	1
6	FIL1160243	FUEL FILTER - DEUTZ	1	26	MNT0032161	MNT, SWIVEL, ACCEL THROTTLE-1390	1
7	DTZ1176023	OIL PRESSURE SENDER -DEUTZ	1	27	SMF0001001	1/4 X 3/4 FH MACH SCREW-PLT	2
8	DTZ0271160	OIL TEMPERATURE SWITCH	1	28	ACT0012409	ADDCO ACTUATOR MNTNG KIT- 1390	1
9	DTZ1173470	TEMPERATURE SENSOR	1	29	DTZ2235175	COOLING FAN BELT-DEUTZ	1
10	HYD5355030	3/8 JIC X 1/4 NPT 45° MALE ELB	1	30	PMP12S8XG2	HYDRAULIC GEAR PUMP F/1390	1
11	DTZ1119246	BANJO BOLT	1	31	FILCF90081	INLINE HYD PRESSURE FIL- 1390	1
12	DTZ1118688	WASHER	2	32	SCC0020009	5/16 X 2-3/4 NC HT CS - PLATED	2
13	DTZ1290579	BANJO FITTING	1	33	WCT0000313	5/16" FLATWASHER-PLATED	2
14	DTZ9990172	FUEL SHUTDOWN SOLENOID KIT	1	34	NCH0000313	HEX NUT NC PLATED 5/16	2
15	NCE0000250	1/4" NC ESNA NUT - PLATED	2	35	MNT0034401	HYD PRESSURE FILTER MNT- 1390	1
16	LEV0032159	LVR ADAPTOR, ROD, ACCEL THROTTLE	1	36	SCCM210025	10M X 25M MC HEX HD CS-PLT-8.8	4
17	F 0000169	BALE COUNTER ROD SPRING -SP	2	37	WCTM100100	10 MM FLATWASHER - PLTD	2
18	ROD0032162	ROD, ACCELERATOR THROTTLE-1390	1	38	WLKM000100	10 MM LOCKWASHER	4
19	DPT0032158	THROTTLE ROD ACCEL ADAPTR-1390	1	39	SHD0034301	ENGINE DRV BELT SHIELD- 1390	1
20	SUP0032163	THROTTLE ACCEL SWIVEL SUP-1390	1				


DEUTZ ENGINE AIR SCREEN ASSEMBLY



DEUTZ ENGINE AIR SCREEN ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	ACL0080372	AIR CLEANER, DONALDSON # G080372	1
2	MNT0035326	SCREEN MOUNT STIFFENER	1
3	MNT0035327	AIR CLEANER SUPPORT MOUNT	1
4	SUP0035328	AIR CLEANER SUPPORT	1
5	SCR0028976	SCREEN ATTACHMENT PANEL ASSY	1
6	SUP0035476	SCREEN PANEL SUPPORT	2
7	DCT0035695	COOLING AIR DUCT WELDMENT	1
8	HNG9610500	INLINE HINGE ASSY	2
9	SHD0035692	ALTERNATOR BELT SHIELD ASSY	1
10	SPC0035701	HINGE SPACER	4
11	HAN0000817	CHROME GRAB HANDLE	2
12	LAT0000201	RUBBER DRAW LATCH	2
13	MNT0035702	COOLING AIR DUCT LATCH MOUNT	2
14	SPC0035689	AIR SCREEN SPACER	2
15	MNT0035706	AIR CLEANER MOUNT	1
16	ACL0000440	PRE CLEANER, ENGINEAIRE # EA440S	1
17	TUB0035709	INTAKE TUBE, 4" OD X 34" LG	1
18	SPC0035477	SCREEN PANEL SPACER TUBE PLATE	1
19	DTZ0272401	BRUSH RING F/DEUTZ AIR SCREEN	1
20	DTZ2234942	BRUSH ONLY F/DTZ0272401	1
21	SCCM11080	HEX CAP SCREW, M10 X 1.5 X 80mm,	1
22	WLKM100100	SPLIT LOCK WASHER, M10, PLTD	1
23	WCTM100100	FLAT WASHER, M10, PLTD	1
24	CLP7051029	HOSE CLAMP, 3"-5", #72	2
25	ACL0080372	AIR CLEANER, DONALDSON # G080372	1
26	ACL0002251	RESTRICTION INDICATOR,	1
27	ACL0112003	VACTUATOR VALVE F/DTZ AIR	1
28	ACL0119410	SAFTY ELEMENT F/DTZ AIR	1
29	ACL0101870	AIR CLEANER NUT ASSY	2
30	ACL0119711	OUTER CUP F/DTZ AIR CLEANER	1
31	ACL0149573	PRIMARY ELEMENT F/DTZ AIR	1
32	CLP7335752	MUFFLER CLAMP, 4"	2


BELT DRIVE ASSEMBLY



BELT DRIVE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	CPL0031253	BELT DRIVE COUPLING ASSY -1390	1
2	SPC035827A	BELT DRIVE SPINDLE SPACER	1
3	F 00007904	KEY, 3/8 X 3/8 X 2	1
4	SCCM110020	10M X 20M MC HEX HD CS-ZP 8.8	7
5	SCCM110030	10M X 30M MC HEX HD CS-PLT-8.8	5
6	WLKM100100	10 MM LOCKWASHER - PLTD	12
7	PLT0030665	FLYWHEEL HSG BEARING PLT-1390	1
8	SHV0030660	DRIVE BELT SHEAVE -1390	1
9	SCC0030002	3/8 X 1 NC HT CS - PLATED	4
10	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	8
11	BRG0040310	CONN ROD.BELT DRIVE BRG-1390	1
12	SPN0030661	BELT DRIVE SPINDLE ASSY -1390	1
13	SCC0030003	3/8 X 1-1/4 NC HT CS - PLATED	4
14	PLT0030664	BEARING CLAMP PLATE -1390	1
15	SCOM110040	10M X 40M 1.5 SOCKET HD CS-8.8	8


KNOTTER CLUTCH ASSEMBLY



KNOTTER CLUTCH ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	BSH0035200	CLUTCH PAWL PIVOT BUSHING	2
2	ZZ 0000220	MACHINERY BSH, 3/4 X 1 1/4 X 10 GA	2
3	PIN0035199	PAWL PIVOT PIN	1
4	ZZ 0000411	KEY, 3/8 X 5/16 X 2	1
5	CLH0032045	KNOTTER CLUTCH DRIVEN HUB ASSY	1
6	NMS0000252	WHIZ NUT, 1/2 NC, PLTD	1
7	SCC0050013	HEX CAP SCREW, 1/2 X 3 3/4 NC, PLTD	1
8	SPGE758535	SPRNG, 3/4 OD X 3 1/2 LG X .085 WIRE,	1
9	CLH0032034	KNOTTER CLUTCH PAWL	1
10	SCO0000202	F H SOCKET SCREW, 5/16 X 1, NC	2
11	CLH0032044	STOP CLEAT	1
12	CLH0033112	KNOTTER CLUTCH DRIVE HUB ASSY	1
13	NMS0000117	WHIZ NUT, 5/16 NC, PLTD	2
14	BRGER20722	BEARING, KNOTTER CLUTCH 1390	1
15	RNG5002281	RETAINING RING, BEVELED, N5002-281	1
16	SCC0050013	HEX CAP SCREW, 1/2 X 3 3/4 NC, PLTD	1
17	NMS0000252	WHIZ NUT, 1/2 NC, PLTD	1
18	ZZ 0000411	3/8 X 5/16 X 2 KEY (HITON SHV)	1
19	ARM0032481	NDL YOKE DRV CRANK ARM ASY1390	1


KNOTTER BRAKE ASSEMBLY



KNOTTER BRAKE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	NCE0000250	1/4" NC ESNA NUT - PLATED	8	18	WCT0000375	3/8" FLATWASHER - PLATED	1
2	WCT0000250	1/4" FLATWASHER - PLATED	6	19	F 0001572	CAM FOLLOWER-RESET-SADDLE LEV	1
3	F 0007453	BRAKE PLATE SPRING	6	20	LEV0032483	LEVER ASSY, SADDLE 1390	1
4	F 0007450	OUTSIDE BRAKE PLATE W/LINING	3	21	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	1
5	RIV0000106	RIVET F/KNOTTER BRAKE LINING	9	22	F 0007448	SADDLE LEVER SPRING EYEBOLT	1
6	F 0007454	BRAKE LINING W/RIVETS	3	23	F 0007559	SADDLE LEVER SPRING	1
7	NMS0000252	WHIZ NUT, 1/2 NC, PLTD	2	24	SCC0020003	5/16 X 1-1/4 NC HT CS - PLATED	2
8	KNT0032478	KNOTTER BRAKE DISC ASSY -1390	1	25	WCT0000313	5/16" FLATWASHER-PLATED	2
9	SCC0050011	1/2 X 3-1/4 NC HT CS - PLATED	2	26	NCE0000375	3/8" NC ESNA NUT - PLATED	1
10	F 0007449	INSIDE BRAKE PLATE W/LINING	3	27	F 0000246	KNOTTER BRAKE DISC WASHER	2
11	F 0007451	BRAKE PLATE STUD	6	28	F 0007587	SADDLE LEVER ANCHOR SEAL	1
12	ZZ 0000434	3/8 X 5/16 X 3 LONG KEY	1	29	LEV0025133	LOWER SADDLE LEVER ASSY-A/1-92	1
13	NFH0003750	3/8" NF HEX NUT	13	30	F 0000802	1-3/8 FEED ARM WASHER -200/270	1
14	NCH0003750	HEX NUT NC 3/8-PLAIN	4	31	F 0007585	SLEEVE F/SADDLE LEVER ANCHOR	1
15	SCC0030004	3/8 X 1-1/2 NC HT CS - PLATED	1	32	NCE0000313	5/16" NC ESNA NUT - PLATED	2
16	SCC0010012	1/4 X 3-1/2 NC HT CS - PLATED	6	33	F 0007586	BUSHING F/SADDLE LEVER ANCHOR	1
17	SCC0030012	3/8 X 3-1/2 NC HT CS - PLATED	1	34	MNT0034860	KNOTTER DUAL BRAKE MOUNT-1390	1


KNOTTER SHAFT ASSEMBLY



KNOTTER SHAFT ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	ZZ 0000434	3/8 X 5/16 X 3 LONG KEY	1	21	NCE0000500	1/2" NC ESNA NUT - PLATED	1
2	SHF0032455	KNOTTER SHAFT- 1390	1	22	ARM0032481	NDL YOKE DRV CRANK ARM ASY1390	1
3	NCH0000437	HEX NUT NC PLATED 7/16"	4	23	ZZ 0000435	3/8 X 5/16 X 1-1/4 LONG KEY	1
4	WLK0000438	7/16" LOCKWASHER - PLATED	4	24	KNT0035528	KNOTTER MOUNT, RH, 15 1/2" CHM	1
5	KNT0035531	KNOTTER MOUNT, LH, 15 1/2" CHM	1	25	WLK0000500	1/2" LOCKWASHER - PLATED	1
6	WCT0000438	7/16" FLATWASHER - PLATED	8	26	NCH0000500	HEX NUT NC PLATED 1/2	1
7	SCC0040004	7/16 X 1-1/2 NC HT CS - PLATED	4	27	SCC0030004	3/8 X 1-1/2 NC HT CS - PLATED	3
8	F 0007063	1-3/8" KNOTTER SHAFT BEARING	2	28	WCT0000375	3/8" FLATWASHER - PLATED	7
9	CLP0034840	KNOTTER SHAFT CLAMP- 1390	2	29	NCE0000375	3/8" NC ESNA NUT - PLATED	3
10	ZZ 0000440	3/8 X 5/16 X 3/4 LONG KEY	1	30	NCE0000250	1/4" NC ESNA NUT - PLATED	8
11	CAM0034586	TWN FINGER DRV CAM ASSY- 1390	1	31	CUS0032524	BLACK HAY DOG CUSHION 1390	8
12	F 0004161	1-3/8 X 18 GA MACHINE BSHING	A/R	32	CLP0032525	HAY DOG CUSHION CLAMP 1390	8
13	F 0004160	1-3/8 X 14 GA MACHINE BUSHING	A/R	33	SCC0010004	1/4 X 1-1/2 NC HT CS - PLATED	8
14	F 0004159	1-3/8 X 10 GA MACHINE BUSHING	A/R	34	DOG0032523	DOG, HAY 1390	4
15	F 0007977	1-3/8X1-7/8X.010 SPACER WASHER	A/R	35	F 0000220	HAY DOG PIN (1/2 X 3 CLEVIS)	4
	F 0007978	1-3/8X1-7/8X.005 SPACER WASHER	A/R	36	WCT0000500	1/2" FLATWASHER - PLATED	8
	SHM0000103	1-3/8 X 1-7/8 X.015 STEEL SHIM	A/R	37	SPG0023160	SIDE HAY DOG SPRING-A/95 -1590	4
	SHM0000105	1-3/8"X 1-7/8 X.020 STEEL SHIM	A/R	38	COT0000502	1/8 X 1 COTTER PIN	4
16	KNT006006A	HEAD ASSY-W/F7661,F7869,F8049	3	39	SFC0080513	1/2"X 3.75"NF GRD 8 CS-PLTD	4
17	ZZ 0000433	3/8 X 5/16 X 1-1/2 KEY	4	40	NCJ0000375	3/8" NC JAM NUT - PLATED	2
18	GER0006068	MODULAR CAM GEAR - WAS:GER7942	3	41	SQS3751000	3/8 X 1"SQUARE HD SET SCREW	2
19	CAM0032465	KNT TRIP RESET CAM ASSY 1390	1	42	NFH0080500	1/2"-20 GRADE 8 HEX NUT-PLATED	4
20	SCC0050013	1/2 X 3-3/4 NC HT CS - PLATED	2	43	WAS0000104	1/2"A-325 STRUCTURAL WASHER	4

KNOTTER ASSEMBLY KNT006006A



KNOTTER ASSEMBLY KNT006006A

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	KNT0060060	KNOTTER FRAME ONLY	1	22	RS 0006003	TWINE DISC BUSHING F/KNT60060	1
2	F 0008050	KNIFE ARM COMP(WAS:F7857&7945)	1	23	RS 5227344	SPIRAL PIN F/KNOTTER GEARS	3
3	F 0008275	SNAP RING F/KNIFE ARM ROLLER	1	24	SCCM008030	8MM X 30MM MC HEX HD CS	1
4	F 0008274	ROLLER F/KNIFE ARM	1	25	F 0008052	TWINE HOLDER SPRING	3
5	F 0008280	1 MM WASHER-WORM SHF & KNF ARM	3	26	F 0007871	TWINE HOLDER DISC PINION	1
6	F 0007893	NUT F/KNIFE ARM PIN	1	27	F 0007976	SNAP RING F/KNIFE ARM SHAFT	1
7	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	1	28	F 0007860	KNIFE ARM WASHER 25 X 20 X .5M	A/R
8	F 0007892	SPACER WASHER F/KNIFE ARM PIN	1	29	NCHM008125	8MM X 1.25 MC HEX HUT - GR 8.8	1
9	F 0007884	KNIFE ARM PIN	1	30	WLKM000080	8 MM LOCKWASHER	2
10	F 0008049	TWINE KNIFE	1	31	SCCM108025	8MM X 25MM MC HEX HD CS	2
11	F 0007859	TWINE KNIFE SCREW	2	32	F 0007948	KNOT HOOK CAM ADJUSTING SCREW	1
12	RS 0006022	KNIFE ARM BUSHING F/KNT60060	1	33	F 0007947	KNOTTER HOOK CAM ADJUST SPRING	1
13	F 0007868	TWINE HOLDER -WAS: F 78 RA	1	34	WCT0000313	5/16" FLATWASHER-PLATED	1
14	F 0007869	TWINE DISC	1	35	F 0007949	KNOTTER HOOK CAM ADJ SCREW-NUT	1
15	F 0007870	TWINE DISC CLEANER	2	36	F 0008051	KNOTTER HOOK CAM	1
16	RS00006002	BILL HOOK BUSHING F/KNT60060	1	37	GER0007862	HARDENED BILL HOOK PINION	1
17	F 0007861	KNOTTER BILL HOOK	1	38	GER0007873	HARDENED KNOTTER WORM PINION	1
18	F 0008071	PIN FOR BILL HOOK TRIGGER	1	39	F 0008068	SPACER F/BILL HOOK PIN - .020	A/R
19	F 0008070	TRIGGER F/KNOTTER BILL HOOK	1		F 0008069	SPACER F/BILL HOOK PIN - .032	A/R
20	F 0007876	KNT WORM & SHAFT (COMPL ONLY)	1	40	RS 3451926	PIN F/BILL HOOK CAM & SPRING	2
21	F 0000658	14 GA. KNOTTER WORM WASHER	A/R	41	SPG0025466	KNT HOOK CAM ADJ SPRING	1
	F 0000659	18 GA. KNOTTER WORM WASHER	A/R				
	F 0001680	28 GA. KNOTTER WORM WASHER	A/R				
	RS 0010500	.5MM WASHER-WORM SHF & KNF ARM	A/R				


(3 KNOTTERS PER BALER)

Note: REF # 17,18, 19 WILL BE OBSOLETE AFTER 4-1-02

PLEASE ORDER:

- 17. RS00006015 KNOTTER BILL HOOK
- 18. RS00001416 PIN FOR BILL HOOK TRIGGER
- 19. RS00003786 TRIGGER F/KNOTTER BILL HOOK


KNOTTER TRIP ASSEMBLY



KNOTTER TRIP ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	KNT0032132	BAR ASSY, TRIP, METER, KNOTTER	1	18	F 0000440	FERRULE	1
2	F 0008023	GUIDE WASHER	2	19	F 0000278	SPRING F/KNOTTER TRIP ARM	1
3	F 0001687	KNURLED FRICTION DISC	1	20	F 0001517	TRIP SPRING	1
4	MNT0031918	METER WHL BRG MNT-16" CHAMBER	2	21	COT0000803	3/16 X 1-1/2 COTTER PIN	2
	MNT0034642	METER WHL BRG MNT-15" CHAMBER	2	22	SCC0030003	3/8 X 1-1/4 NC HT CS - PLATED	7
5	F 0001618	METER WHEEL SHAFT BRG W/CLAMPS	2	23	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	14
	F 0001889	FLANGETTE F/F1618 BEARING	2	24	NCJ0000375	3/8" NC JAM NUT - PLATED	3
	F 0001619	METER WHEEL SHAFT-BEARING ONLY	1	25	NCH0000375	HEX NUT NC PLATED 3/8	15
	F 0001890	LOCKING COLLAR F/F1619 BEARING	1	26	CRB7375100	3/8 X 1 GR 5 CARR BOLT-PLT	4
6	F 0008022	METER WHEEL SHAFT ONLY - 3 TIE	1	27	SCC0050008	1/2 X 2-1/2 NC HT CS - PLATED	4
7	CAM0032464	STOP CAM	1	28	STO0035484	METER TRIP BAR STOP ASSY	1
8	STS2500313	SET SCREW, SOCKET, 1/4 X 5/16	2	29	NCJ0000500	1/2" NC JAM NUT - PLATED	2
9	KNT0024098	METER WHEEL ASSY	1	30	WLK0000500	1/2" LOCKWASHER - PLATED	5
10	ZZ 0002003	1" STEEL SET COLLAR	1	31	NCH0000313	HEX NUT NC PLATED 5/16	4
11	BRG64F64PP	1"SINGLE ROW FLANGED BEARING	2	32	SCC0030005	3/8 X 1-3/4 NC HT CS - PLATED	1
12	KNT0035546	BEARING MOUNT	1	33	SCC0030004	3/8 X 1-1/2 NC HT CS - PLATED	1
13	F 0001572	CAM FOLLOWER-RESET-SADDLE LEV	1	34	SCC0050013	1/2 X 3-3/4 NC HT CS - PLATED	1
14	KNT0032459	KNOTTER TRIP BELLCRNK ASY-1390	1	35	NMS0000375	WHIZ NUT, 3/8 NC, PLTD	1
15	KNT0035544	KNOTTER TRIP SHAFT ASSY	1				
16	CAM0032465	KNT TRIP RESET CAM ASSY 1390	1				
17	LEV0032456	STOP CLUTCH LEVER 1390	1				


TWINE FINGER DRIVE ASSEMBLY



TWINE FINGER DRIVE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	KNT0034212	TWINE FINGER DRIVE SHAFT ASSY	1	23	BRG51FLMX8	BRG, 2 BOLT FLANGE 1-1/4" BORE	2
2	NCH0000250	HEX NUT, 1/4 NC, PLTD	2	24	SCC0020003	HEX CS, 5/16 X 1 1/4NC, PLTD	3
3	NMS0000117	WHIZ NUT, 5/16 NC, PLTD	3	25	NCH0000250	HEX NUT NC PLATED 1/4"	2
4	WIS0003125	INTERNAL STAR WASHER, 5/16, PLTD	3	26	NCX0000250	FLEXLOC NUT NC PLATED 1/4"	1
5	BRG0001300	ROD END BEARING, 5/16, LH	3	27	WLK0000375	3/8" MEDIUM LOCKWASHER - PLTD	2
6	SFC0020001	HEX CAP SCREW, 5/16 X 3/4 NF, PLTD	3	28	F 0001572	CAM FOLLOWER-RESET-SADDLE LEV	1
7	ROD0034894	TWINE FINGER DRIVE ROD	3	29	F 0001517	TRIP SPRING	1
8	NFL0003125	HEX NUT, 5/16 NF, LH, PLTD	3	30	WCT0000375	3/8" FLATWASHER - PLATED	1
9	BRG0001301	ROD END BEARING, 5/16, RH	3	31	TUB0037500	3/8" BUNDY TUBING, 1" LONG	1
10	F 0008144	TWINE FINGER BUSHING NUT	3	32	SCC0020007	5/16 X 2-1/4 NC HT CS - PLATED	1
11	NCH0000313	HEX NUT NC PLATED 5/16	6	33	SCC0010003	HEX CS, 1/4 X 1 1/4 NC, PLTD	1
12	WLK0000375	SPLIT LOCK WASHER, 3/8	1	34	WCT0000313	FLAT WASHER, 5/16, PLTD	3
13	SCC0020002	5/16 X 1 NC HT CS - PLATED	2	35	BKT0032972	LUBER MOUNT BRACKET	1
14	KNT0035344	TWINE FINGER	1	36	NFH0003125	HEX NUT, 5/16 NF, PLTD	3
15	F 0008146	TWINE FINGER WASHER	3	37	F 0001572	CAM FOLLOWER 6522H	1
16	CRB3750100	CARRIAGE BOLT, 3/8 X 1 NC, PLTD	3	38	LEV0032483	SADDLE LEVER ASSY	1
17	SCC0020004	5/16 X 1-1/2 NC HT CS - PLATED	3	39	NCE0000375	ESNA NUT, 3/8 NC, PLTD	1
18	HTB0030006	3/8"-16 X 2" HEX TAP BOLT-PLTD	1	40	SCC0010003	HEX CAP SCREW, 1/4 X 1 1/4 NC, PLTD	1
19	NCH0000375	HEX NUT NC PLATED 3/8	2	41	NCE0000250	ESNA NUT, 1/4 NC, PLTD	1
20	BKT0034727	TWINE FNGR STOP BRACKET- 1390	1	42	SCC0030003	HEX CAP SCREW, 3/8 X 1 1/4 NC, PLTD	1
21	NCH0000500	HEX NUT NC PLATED 1/2	2	43	NFH0000375	HEX NUT, 3/8 NF, PLTD	1
22	WCT0000313	5/16" FLATWASHER-PLATED	4				


AUTOMATIC KNOTTER LUBER



AUTOMATIC KNOTTER LUBER

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	VLV0000003	KNOTTER LUBE VALVE ASSY-1390	1	22	NMS0000117	WHIZ NUT, 5/16 NC, PLTD	4
2	SCC0010007	1/4 X 2-1/4 NC HT CS - PLATED	2	23	PLT0032291	FEEDER CHAIN GUIDE PLATE 1390	1
3	WCT0000250	1/4" FLATWASHER - PLATED	14	24	MNT0033111	MOUNT,PUMP,LUBE,KNTR - 1390	1
4	NMS0000250	WHIZ NUT, 1/4 NC, PLTD	2	25	SCO0000202	FLAT SH CS, 5/16 X 1 NC, PLTD	4
5	HYD3459030	3/8"90°ST THREAD O'RING MALE L	1	26	SPK0033110	PUMP SPROCKET, #60A14, 1" BORE	1
6	TNK035761D	KNOTTER LUBER TANK	1	27	SCC0030001	HEX CAP SCREW, 3/8 X 3/4 NC, PLTD	2
7	F 0008209	3/8" X 1/4 NPT MALE, 90° ELB, BRASS	1	28	HOS0034754	DRAWBAR & LUBER TO PUMP HOSES	1
	IMP0026106	3/8" NUT AND SLEEVE ASSEMBLY	1	29	F 0008287	STR AUTO LUBER FITTING	6
	IMP0026006	3/8" PLASTIC SLEEVE	1	30	PMP4731107	AUTO LUBER PUMP -WAS:F 8200	1
8	F 0008199	SITE TUBE FOR AUTO LUBER TANK	1	31	HOS0034791	HOSE,HYD,PORT 2 KNT SOL-KNT MF	1
9	HYD0001207	HOSE BARB, 3/8 NPT X 3/8 HOSE, STR	2	32	HYD5525020	1/4 JIC X 90° BLKHD UNION ELB	1
10	FT 0000252	5/16 - 7/8 MINI WORM CLAMP	2	33	HOS0034842	HOSE,HYD,BLKHD-KNT LUBER 1390	1
11	HOS0034788	HOSE,KNT LUB.SOL.VAL. RTN	1	34	HYD5355022	1/4 JIC X 1/8 NPT 45° MALE ELB	1
12	F 0006673	MALE 90° ELBOW, 3/8 JIC X 1/2 NPT	2	35	HYD3069021	1/8 NPT STEEL HEX NIPPLE	2
13	SCC0030009	3/8 X 2-3/4 NC HT CS - PLATED	2	36	HYD5205020	1/4 JIC X 1/8 NPT MALE CONN	1
14	WCT0000375	3/8" FLATWASHER - PLATED	4	37	HYD5129020	1/4" JIC CAP	1
15	NMS0000375	WHIZ NUT, 3/8 NC, PLTD	4	38	LUB0833116	LUBER MANIFOLD ASSY,	3
16	FILCF90081	INLINE HYD PRESSURE FIL- 1390	1	39	LUB0083313	INJECTOR, REPLACEMENT ONLY	A/R
17	HYD5315034	3/8 JIC X 1/2 O-RNG ST THD CON	2	40	BKT0032972	BRACKET, LUBER, MANIFOLD 1390	1
18	TUB0034789	HYD TUBE ASSY	1	41	F 0007401	1/8" NYLAFLOW TUBING 40"	18
19	HYD5716666	3/8 TUB X 3/8 O-RING RUN TEE	1	42	F 0008306	FERRULE F/AUTO LUBER FITTING	18
20	HYD5405045	3/8 JIC X 3/8 NPT 90° MALE ELB	1	43	F 0008288	90° AUTO LUBER FITTING	12
21	HOS0034787	HOSE, HYD, KNT LUB.PUMP-FILTER	1	44	F 0008209	3/8" X 1/4 NPT MALE, 90° ELB, BRASS	1
					IMP0026106	3/8" NUT AND SLEEVE ASSEMBLY	1
					IMP0026006	3/8" PLASTIC SLEEVE	1
				45	FIL0010003	FILTER CAP, COMPLETE WITH SCREEN	1
				46	BSH0001390	TRANS TORQUE 9/16	1


KNOTTER FAN ASSEMBLY



KNOTTER FAN ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	SHD0035683	FAN SHROUD TOP	1
2	SHD0035684	FAN SHROUD BACK	1
3	SHD0035685	FAN SHROUD STIFFENER	1
4	FAN0000001	16" KNOTTER FAN, DUST/MOISTURE	1
5	MNT0035342	SHIELD PROP MOUNT	1
6	PRP0035703	FAN SHROUD PROP	1
7	F 0000440	FERRULE	1
8	HNG0000810	TWINE BOX HINGE	2
9	CLP0000120	3/4 DIA VINYL CLAMP	2
10	NCC0002500	NUT, CAGE, 1/4 UNC	20
11	NMS0000250	NUT, WHIZ, 1/4 UNC, PLATED	18
12	SCC0010001	SCREW, CAP, 1/4 X 3/4 UNC, PLATED	2
13	SCC0010002	SCREW, CAP, 1/4 X 1 UNC, PLATED	4
14	SCC0020002	SCREW, CAP, 5/16 X 1 UNC, PLATED	1
15	SCC0020003	SCREW, CAP, 5/16 X 1 1/4 UNC, PLTED	1
16	NMS0000117	NUT, WHIZ, 5/16 UNC, PLATED	3
17	SMS0000173	BOLT, WHIZ, 1/4 X 1/2 UNC, PLATED	20
18	WCT0000313	WASHER, FLAT, 5/16, PLATED	2
19	SCC0010000	SCREW, CAP, 1/4 X 1/2 UNC, PLATED	12
20	SHD0035336	KNOTTER FAN SHROUD REST, 15 1/2"	2
21	20-112	MOTOR MOUNT PAD	2


NEEDLES AND PLUNGER STOP ASSEMBLIES



NEEDLES AND PLUNGER STOP ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	NDL035831D	1390 NEEDLE	3	23	SPG1500800	PLUNGER STOP CAM SPRING-1390	1
2	NCH0000500	HEX NUT NC PLATED 1/2	6	24	WAS0034578	WASHER, STOP, PLUNGER 1390	1
3	F 0007552	NEEDLE TO YOKE CARR BOLT W/NUT	6	25	RNG5000156	PLG STOP SPRING SNAP RNG- 1390	1
4	YOK0034479	NEEDLE YOKE ASSY, RASSPE	1	26	CRA0033485	PLUNGER STOP CRANK - 1390	1
5	SFC0034796	LOWER R. NDL YOKE BOLT- 1390	4	27	F 0007448	SADDLE LEVER SPRING EYEBOLT	2
6	ZZ 0000220	1-1/4"X 3/4"X 10GA MACH BUSHIG	4	28	NCH0000375	HEX NUT NC PLATED 3/8	4
7	F 0001549	RH NEEDLE YOKE DRIVE ROD END	2	29	F 0001517	KNOTTER TRIP RETURN SPRING	1
8	NFH0000750	3/4" NF HEX NUT - PLATED	2	30	SHM0033448	PLUNGER STOP SHIM - 1390	A/R
9	F 0001550	LH NEEDLE YOKE DRIVE ROD END	2	31	BMP0001390	PLUNGER STOP BUMPER-1390	2
10	NFL0000750	3/4" NF LH HEX NUT - PLATED	2	32	LNK0033487	PLUNGER STOP LINK - 1390	2
11	F 0007554	NEEDLE YOKE DRIVE ROD	2	33	F 0000440	FERRULE	4
12	NFH0000500	1/2" NF HEX NUT - PLATED	5	34	SHF0033346	PLUNGER STOP SHAFT - 1390	1
13	F 0005048	1/2" ADJ CLEVIS TAPPED 1/2"-20	2	35	DOG0033340	PLUNGER STOP DOG -1390	2
14	F 0004050	ROLLER-SHUTTLE BAR DRIVE	1	36	ROD0034872	PLG STOP SPG ADJ ROD- 1390	2
15	WLK0000500	1/2" LOCKWASHER - PLATED	1	37	SPG1000175	PLUNGER STOP DOG SPRING-1390	2
16	LEV0033378	PLUNGER STOP CAM LEVER - 1390	1	38	ARM0033362	LH PLUNGER STOP ARM ASSY -1390	1
17	CAM0033377	PLUNGER STOP CAM - 1390	1	39	ARM0033363	RH PLUNGER STOP ARM ASSY -1390	1
18	BRG0020618	2-BOLT, NEEDLE YOKE BRG-1390	2	40	SPC0033343	SPACER, STOP, PLUNGER-1390	2
19	BKT0034663	ROD GUIDE BRACKET- 1390	1	41	F 0007973	HOLDER F/NEEDLE TWN GUIDE BUSH	6
20	CLP0100075	3/4 HYDRA ZORB HOSE CLAMP	1	42	F 0000856	TWINE & WIRE GUIDE BUSHING	6
21	ROD0034577	PLGR STOP SPRING HOUSING- 1390	1	43	F 0000857	SNAP RING F/TWN GUIDE BUSHING VM6	
22	ROD0034579	ROD, STOP, FRONT 1390	1				


NEEDLE YOKE SHOCK ASSY



NEEDLE YOKE SHOCK ASSY


REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	YOK0034479	NEEDLE YOKE ASSY, RASSPE	1
2	MNT0035286	LH SIDE TENSION RAIL MOUNT ASSY	1
3	MNT0035541	RH SIDE TENSION RAIL MOUNT ASSY	1
4	CAM0035104	PLUNGER STOP CAM	1
5	MNT0034476	NEEDLE YOKE BEARING MOUNT	2
6	F 0007523	BEARING, 3/4", FAFNIR KP12A	2
7	ZZ 0000220	M B, 3/4 ID X 1 1/4 OD X 10 GA, 37-01	2
8	ANC0034889	NEEDLE YOKE SHOCK ANCHOR ASSY	2
9	SHO0144279	SHOCK ABSORBER, 144279	2
10	PLT0035285	NEEDLE YOKE SHOCK LEVER PLATE	2
11	PIN0035288	N YOKE SHOCK PIVOT PIN, UPPER	2
12	NEJ0005000	ESNA JAM NUT, 1/2 NF, PLTD	4
13	WAS5710199	WSHER, .566 ID X 1.05 OD X .06 TH, SS,	8
14	BRG0000001	FLANGE BRG, 14mm ID X 17mm OD,	8
15	WAS0000141	FLAT WASHER, 5/8, PLTD	4
16	PIN0034892	N YOKE SHOCK PIVOT PIN, LOWER	2
17	SMS0000611	FLANGED 12 POINT CS, 1/2 X 1 3/4 NC	4
18	SCO0050004	FLAT SH, CS, 1/2 X 1 1/2 NC, PLTD	8
19	NMS0000252	WHIZ NUT, 1/2 NC, PLTD	15
20	SCC0050004	HEX CAP SCREW, 1/2 X 1 1/2 NC, PLTD	6
21	SCC0050005	HEX CAP SCREW, 1/2 X 1 3/4 NC, PLTD	1
22	WLK0000625	SPLIT LOCK WASHER, 5/8, PLTD	2
23	NFH0000625	HEX NUT, 5/8 NF, PLTD	2
24	ANG0035559	RH LOWER CHMBER EXT ANGLE ASSY	1
25	ANG0035558	LH LOWER CHMBER EXT ANGLE ASSY	1
26	WLK0000500	SPLIT LOCK WASHER, 1/2, PLTD	4
27	NCH0000500	HEX NUT, 1/2 NC, PLTD	4

TWINE BOX ASSEMBLY




TWINE BOX ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	BOX0034897	TWINE BOX LID- 1390	1	18	BOX0033413	TWINE BOX FRONT	1
2	BOX0034656	RIGHT TWINE BOX LID GUSSET	1	19	BOX0033415	TWINE BOX BOTTOM	1
3	BOX0034652	LEFT TWINE BOX LID GUSSET	1	20	COMES WITH REF #4		1
4	LAT0000201	RUBBER DRAW LATCH	1	21	BOX0034898	TWINE BOX LEFT END	1
5	HAN0000817	CHROME GRAB HANDLE	1	22	STD0000M10	10mm BALL STUD FOR SPG0000090	4
6	HNG0000810	TWINE BOX HINGE	3	23	SOK0000001	METAL BALL SOK END FITTING	4
	SMT0001000	SCREW, TRUSS HEAD, 1/4 X 1/2 UNC	18	24	CLP0000002	SAFETY CLIPS F/10MM BALL- 1390	4
	NMS0000250	NUT, WHIZ, 1/4 UNC, PLATED	18	25	MNT0033417	REAR TWINE BOX MOUNT	1
7	BKT0034965	TWINE TENSIONER BRACKET	3	26	UBL0034451	4 X 5 U-BOLT	2
	SMT0001000	SCREW, TRUSS HEAD, 1/4 X 1/2 UNC	6	27	NMS0000252	NUT, WHIZ, 1/2 UNC, PLATED	4
	NMS0000250	NUT, WHIZ, 1/4 UNC, PLATED	6	28	MNT0033416	FRONT TWINE BOX MOUNT	4
8	F 0000856	TWINE GUIDE BUSHING	6	29	BOX0035235	TWINE BOX DIVIDER	6
9	F 0000857	TWINE GUIDE SNAP RING	6	30	NMS0000250	NUT, WHIZ, 1/4 UNC, PLATED	12
10	F 0007889	TWINE TENSIONER BASE ASSEMBLY	3	31	SCC0010000	SCREW, CAP, 1/4 X 1/2 UNC, PLATED	12
11	F 0007890	TWINE TENSIONER TOP	3	32	F 0007891	TWINE TENSIONER ASSEMBLY	3
12	F 0007541	TWINE TENSIONER SPRING	3	33	FD 035805D	DECAL: "NEEDLE TIMING CHECK"	1
13	WCT0000313	WASHER, FLAT, 5/16, PLATED	3	34	NMS0000117	NUT, WHIZ, 5/16 UNC, PLATED	16
14	NCE0000313	NUT, ESNA, 5/16 UNC, PLATED	3	35	FD 0007113	36" X 5" WHITE "FREEMAN" DECAL	1
15	SPG0000090	TWINE BOX LID GAS SPRING	2				
16	BOX0034900	TWINE BOX BACK	1				
17	BOX0034899	TWINE BOX RIGHT END	1				




STEP AND TOOL BOX ASSEMBLIES



STEP AND TOOL BOX ASSEMBLIES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	STP0035717	LEFT STEP ASSEMBLY	1	12	SCC0020001	SCREW, CAP, 5/16 X 3/4 UNC, PLATED	8
2	STP0035718	RIGHT STEP ASSMBLY	1	13	NMS0000117	NUT, WHIZ, 5/16 UNC, PLATED	4
3	HAN0034446	STEP HANDLE- 1390	2	14	CLP0000130	HOOK-TYPE FASTENER	2
4	LID0034553	TOOLBOX LID ASSEMBLY- 1390	1	15	BKT0034708	TWINE STEP GUIDE BRACKET- 1390	2
5	UBL0034451	4 X 5, 1/2 NC SQ BEND U-BOLT	4	16	F 0000856	TWINE & WIRE GUIDE BUSHING	6
6	NMS0000252	NUT, WHIZ, 1/2, UNC PLATED	8	17	F 0000857	SNAP RING F/TWN GUIDE BUSHING VM6	6
7	SCC0030005	3/8 X 1-3/4 NC HT CS - PLATED	8	18	NMS0000375	NUT, WHIZ, 3/8, UNC PLATED	8
8	NMS0000117	NUT, WHIZ, 5/16 UNC, PLATED	8				
9	HNG0034552	TOOL BOX HINGE- 1390	1				
10	RIV0000122	SS RIVET-3/16 X .126-250 GRIP	14				
11	SUP0034447	LIGHT SUPPORT- 1390	2				


BALE CHUTE ASSEMBLY



BALE CHUTE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	CHU0034420	WELDED BALE CHUTE ASSY- 1390	1
2	GUD0034394	BALE CHUTE ANGEL GUIDE- 1390	3
3	GUD0034395	BALE CHUTE ROTATION GUIDE-1390	1
4	ANC0035090	BALER CHUTE CHN ANCHOR- 1390	1
5	SCC0020001	5/16 X 3/4 NC HT CS - PLATED	13
6	NMS0000117	NUT, WHIZ, 5/16 UNC, PLATED	14
7	WCT0000313	5/16" FLATWASHER-PLATED	4
8	SCC0050004	1/2 X 1-1/2 NC HT CS - PLATED	2
9	NMS0000252	NUT, WHIZ, 1/2, UNC PLATED	2
10	SCC0050004	1/2 X 1-1/2 NC HT CS - PLATED	3
11	WCT0000500	WASHER,FLAT,1/2	3
12	NCE0000500	NUT, ESNA, 1/2 UNC, PLATED	3
13	BSH0034459	BALE CHUTE BUSHING	2
14	CHN0034460	BALE CHUTE CHAIN	3
15	CLV0007721	CLEVIS WITH PIN AND COTTER PIN	1
16	GUD0035666	BALE CHUTE FLAT GUIDE	1
17	SCC0020011	SCREW, CAP, 5/16 X 3 3/4 UNC, PLATED	1

TENSION CYLINDERS HYDRAULICS




TENSION CYLINDERS HYDRAULICS


REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	CYL0033749	VERTICAL TENSION CYLINDER-1390	2
2	HYD5405045	3/8 JIC X 3/8 NPT 90° MALE ELB	2
3	HOS0034418	TOP TNS CYL ROD END TO RH CYL	1
4	HYD5715033	3/8 TUB X 1/2 O-RING BRNCH TEE	2
5	F 0006519	2 X 8 HYDRAULIC CYLINDER	1
6	HOS0034841	TENSION CYLINDER HOSE- 1390	1
7	HOS0034417	TENSION CYLINDER HOSE- 1390	1
8	HYD5605035	3/8 JIC X 3/8 NPT MALE BR TEE	2
9	HOS0034416	TOP TNS CYL BUTT END TO LH TNS	1
10	HOS0034419	TENSION CYLINDER HOSE- 1390	2
11	HYD5924030	3/8 BULKHEAD NUT	2
12	WIS0005625	9/16 INTERNAL STAR WASHER-PLT	2
13	HYD5325030	3/8 JIC BULKHEAD UNION	2
14	CLP0010951	3/8"STD HYCON TUBE CLAMP	2
15	TUB0034834	HYD TUBE,TNS TO CYL ROD END	1
16	TUB0034839	HYD TUBE,TNS REL VLV TO CYL	1
17	HYD5755030	3/8"JIC X 1/4 NPT MALE RUN TEE	1
18	HYD3109042	1/2 TO 1/4 STEEL PIPE BUSHING	1
19	VLV0000500	SELECTOR VALVE -WAS:01-504	1
20	HYD5405034	3/8 JIC X 1/2 NPT 90° MALE ELB	2
21	HOS0034750	TENSION RETURN HOSE-59"LG 1390	1
22	HOS0034749	TENSION SUPPLY HOSE-76"LG 1390	1
23	HOS0034790	HOSE,HYD,TENS GAGE-F PORT MANI	1
24	GAG0000001	4"3000PSI TENSION GUAGE-1390	1

MAIN HYDRAULIC VALVE ASSEMBLY

TOP VIEW



FRONT VIEW




FRONT

MAIN HYDRAULIC VALVE ASSEMBLY

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	VLV3175100	MAIN HYD VALVE COMPLETE- 1390	1
	VLV0031751	VALVE MANIFOLD BLOCK, 6061-T6511	1
2	VLVCNCC132	1/32 FIXED ORIFICE RESTRIC CAR	1
3	VLVCNCC116	1/16 FIXED ORIFICE RESTIRC CAR	2
4	VLVCNCC164	SUN CNCC-XEN 1/64 FIXED RSTRCR	1
5	VLVQCDALANDIFFERENTIAL UNLOAD PILOT CART		1
6	VLVCXCDXCNCHECK VALVE CARTRIDGE		1
7	VLVCP5081B	POPPET SOLENOID VALVE,NC	9
8	VLVRVCALAN PILOTED RELIEF CARTRIDGE-1390		1
9	VLVPVDALEN PILOTED PRESS REDUCING VALVE		1
10	VLVCXDAXCNSUN CHECK VALVE CARTRIDGE-1390		4
11	VLVCP5082B	POPPET SOLENOID VALVE.NO	2
12	VLVCP55820	PROPORTIONAL RELIER VALVE	1
13	VLV7114920	PROP/CONTROLLER/AMPLIFIER-1390	1
14	HYD5129020	1/4" JIC CAP	1
15	HYD5015042	1/2 TO 1/4 JIC TUBE REDUCER	1
16	HYD5716030	3/8 O-RING X 1/2M JIC RUN TEE	1
17	HYD5716666	3/8 TUB X 3/8 O-RING RUN TEE	3
18	HYD5315043	1/2JIC X 3/8 O-RNG ST THD CONN	2
19	HYD5315033	3/8JIC X 3/8 O-RNG ST THD CONN	4
20	HYD7231030	3/8" O-RING SOCKET HEAD PLUG	1

MAIN HYDRAULICS




FRONT

MAIN HYDRAULICS

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	TUB0034835	HYD.TUBE, TANK TO FILTER	1	19	CLP2110692	MNTG CLP FOR HYDAC ACCUM- 1390	1
2	HYD5205060	3/4 JIC X 3/4 NPT MALE CONN	1	20	ACMSBO2102	HYDAC HYD ACCUMULATOR- 1390	1
3	VLV002X611	CHECK VALVE 3/4" NPT - 1390	1	21	CLP0010951	3/8"STD HYCON TUBE CLAMP	4
4	HYD6806060	3/4"O'RING X 3/4M 90°PIPE	1	22	TUB0034843	HYD TUBE,PORT B TO BULKHEAD	1
5	FIL0HH6935	HYDRAULIC FILTER HEAD- 1390	1	23	HOS0034754	DRAWBAR & LUBER TO PUMP HOSES	2
6	FIL0HF6613	FILTER ELEMENT-SYNTHETIC- 1390	1	24	HYD5515034	3/8 JIC X 1/2 O-RING 90° ELBOW	3
7	HYD5515046	1/2 JIC X 3/4 O-RING 90° ELBOW	2	25	CYL0000324	DRAWBAR SWING CYLINDER-1390	1
8	CLP0021301	1/2"HYCON STD TUBE CLAMP	2	26	HYD5375030	3/8 JIC 45° BLKHD UNION ELBOW	2
9	HOS0034752	PUMP SUCTION HOSE-1"X 25" 1390	1	27	WIS0005625	9/16 INTERNAL STAR WASHER-PLT	2
10	HYD5515068	1" JIC X 3/4" O-RING 90° ELB	1	28	HYD5924030	3/8 BULKHEAD NUT	2
11	PMP12S8XG2	HYDRAULIC GEAR PUMP F/1390	1	29	TUB0034839	HYD TUBE, LOWER TENSION	1
12	HYD5515040	1/2 JIC X 1/2 O-RING 90° ELBOW	2	30	HOS0034405	BUTT END P/U CYL TO PORT D	1
13	HYD5315040	1/2JIC X 1/2 O-RNG ST THD CONN	1	31	CYL0034537	CLUTCH CYLINDER, 2" X 6",	1
14	FILCF90081	INLINE HYD PRESSURE FIL- 1390	1	32	HYD7230040	1/2" O-RING HEX HEAD PLUG	2
15	TUB0034679	HYD.TUBE, PUMP TO FILTER	1	33	HOS0034751	HYD HOSE, CLUTCH,3/8 X 21,	1
16	HOS0034753	MANIFOLD SUPPLY HOSE-30" 1390	1	34	HOS0034404	ROD END P/U CYL TO PORT C-1390	1
17	TUB0034871	HYD TUBE, PORT G-PORT IN	1	35	HYD5315034	3/8 JIC X 1/2 O-RNG ST THD CON	2
18	TUB0034833	HYD TUBE, H PORT-ACCUM.	1	36	F 0006519	2 X 8 HYDRAULIC CYLINDER	1


CONTROL BOXES WITH MOUNTS



CONTROL BOXES WITH MOUNTS

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED	
1	REMOTE1390	TRACTOR REMOTE CONTROL-	1390	1	26	ELC7531010	POTENTIOMETER, 5 WATT, 10K	2
2	BOX0035757	BALER CONTROL BOX ASSEMBLY	1	27	KOB0001P2B	POTENTIOMETER KNOB, EHC #1P2B	2	
3	PNL0035754	CONTROL BOX PANEL WIRING /COMP	1	28	ELC0SL100B	SHAFT SEAL LOCK NUT,	2	
	PNL0035729	CONTROL BOX PANEL COMPONENTS		29	HRN0035728	WORK LIGHT HARNESS RECEPTACLE	1	
4	BKT0033245	FRONT CONTROL BOX MOUNT	1	30	NMR6320500	MACHINE SCREW RH, 10-32 X 1/2 NF	8	
5	BKT0033246	REAR CONTROL BOX MOUNT	1	31	NCE0000632	ESNA NUT, #6-32, PLTD	8	
6	ACT00CA112	THROTTLE CONTROLLER W/ CON	1	32	HRN0035727	THROTTLE HARNESS RECEPTACLE	1	
7	TER0491022	BLOCK SPADE, #6 STUD, 18/22 GA	3	33	SMR4405000	MACHINE SCREW, #4-40 X 1/2, PLT	8	
8	WIS0000600	WASHER, INTERNAL STAR, #6	12	34	NCE0000440	ESNA NUT, #4-40, PLTD	8	
9	SMR1032750	MACHINE SCREW, 10-32 X 3/4 NF, PLTD	5	35	HRN0035726	SENSOR HARNESS RECEPTACLE	1	
10	WIS0001000	WASHER, INTERNAL STAR, #10	20	36	HRN0035725	ENGINE HARNESS RECEPTACLE	1	
11	CBK0014520	CIRCUIT BREAKER, 20 AMP, COLE HER	1	37	SWI0000007	ROCKER SWITCH, 3 POS, MMENTARY,	3	
12	REL0041F11	RELAY, SPST, 70 AMP, 12 VDC SIEM	3	38	HRN0035724	REMOTE HARNESS RECEPTACLE	1	
13	MNT0035548	RELAY BRACKET	1	39	SWI0000003	ROCKER SWITCH, 2 POS, MAINTAINED	2	
14	NFH0010320	HEX NUT, 10-32 NF, PLTD	8	40	LITXVLA124	LED INDICATOR LAMP, 12 VDC, SQ	3	
15	SMR1032500	MACHINE SCREW, RH, 10-32 X 1/2 NF,	22	41	SWI0ZA2BG3	KEYSWITCH OPERATOR, 3 POSITION,	1	
16	REL5058963	RELAY, SPDT, 40 AMP, 12 VCD SIEM	7	42	SWIZA2BZ10	SWITCH CONTACT BLOCK ASSY	1	
17	REL0001002	RELAY SOCKET, 40 AMP SIEM	7	43	SWI0000004	PUSHBUTTON SWITCH, SPST, NO,	2	
18	CBK0001456	CIRCUIT BREAKER, 6 AMP COLE	1	44	GAG0009090	FUEL GAUGE, ISSPRO #R9090	1	
19	CIR0034658	AUTO SHUT DOWN MODULE ASSY	1	45	GAG0001133	HOOR METER, LCD, 12 V, NON RESET,	1	
20	SWIZA2BZ10	SWITCH CONTACT BLOCK ASSY	1	46	FD 0035719	GRAPHIC OVERLAY	1	
21	BLK0005050	SWITCH CONTACT BLOCK,	2	47	BOX0035756	CONTROL BOX DOOR WIRING & COMP	1	
22	SWI0ZA2BG3	KEYSWITCH OPERATOR, 3 POSITION	1	48	FUS0000061	FUSE, AGC 20 AMP	3	
23	TEB0002140	TERMINAL BLOCK, 2 POS, #2-140	1	49	FUS0000025	FUSE HOLDER, 30 AMP, HKCC	4	
24	TER0491022	SPADE TERMINAL, #6, 18/22 GA	2	50	FUS0000065	FUSE, AGC 30 AMP	1	
25	DIO0046003	DIODE, #IN5404	4	51	BCO0001133	COUNTR, LCD, 12 V, NOT RESET, ENM	1	


BATTERY, LIGHTS AND WIRING HARNESSES



BATTERY, LIGHTS AND WIRING HARNESSSES

REF NO.	PART NO.	DESCRIPTION	QTY. USED	REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	HRN0034684	REMOTE TO DRAWBAR HARNESS-1390	1	12	LIT5805C86	KNT FLOOD LIGHT W/ SWITCH-1390	1
2	HRN0035741	BALER BOX TO DRAWBAR WIRING	1		LIT0000001	REPLACEMENT BULB	1
3	HRN0034730	DRAW BAR RUNNING LIGHTS- 1390	1	13	LIT5205D18	REAR SPOT PATTERN LIGHT- 1390	2
4	HRN0035751	ENGINE WIRING HARNESS ASSY	1		LIT0000001	REPLACEMENT BULB	1
	HRN0034818	KNOTTER FAN HARNESS- 1390	1	14	SWI8UMT12P	INDUCTIVE PROXIMITY SENSOR	2
	HRN0034868	HYD SOLENOID VLV HARNESS- 1390	1	15	MNT0034837	PROXIMITY SWITCH MOUNT- 1390	1
	HRN0034863	DRB LH VALVE JUMPER WIRE- 1390	1	16	03-181	SWITCH-MICRO 1TL1-3	1
	HRN0034864	P/U "UP" VLV JUMPER WIRE- 1390	1		CAP0001030	CAP (BOOT) F/SWI5025	1
	HRN0034865	DRB RH VLV JUMPER WIRE- 1390	1	17	ANC0033255	ANCHOR ASSY, BATTERY - 1390	1
	HRN0034866	P/U "DOWN" VLV JUMPER WIR-1390	1	18	BAT0074XHD	BATTERY GRP 74,HEAVY DUTY-1390	1
	HRN0034867	CLH "ENGAGE" JUMPER WIRE- 1390	1	19	CBL0712054	4GA 20"SIDE MOUNT BATTERY CBL	1
5	HRN0034729	BALER RUNNING LIGHT HARN.-1390	1	20	CBLPOS1390	POSITIVE POST BATTERY CBL-1390	1
6	CBL080459A	MICRO-CHG SINGLE KWY PLUG/ASSY	1	21	CBLGND1390	ENGINE GROUND CABLE- 1390	1
7	HRN0035746	WORK LIGHT HARNESS ASSY	1	22	SOK0012310	ELECTRICAL SOCKET, 7 POLE	1
8	CBL88A3115	MICRO CHNG IN-LINE SPLITTER	1	23	SOK0000007	SOCKET BOOT FOR 7 CONDUCTOR	1
9	LIT1105D19	P/U AND FEEDER LIGHT- 1390	2	24	BKT0034733	WORK LIGHT BRACKET- 1390	1
	LIT0000001	REPLACEMENT BULB	1				
10	LIT7191511	TRAPEZOID HALOGEN HEADLIGHT	1				
11	LIT0000012	TAIL LAMP HOUSING - SP	2				
	LIT1410112	DIRECTIONAL LAMP-COMplete	2				
	LIT1410122	STOP/TAIL LAMP-COMplete	2				


SPINDLES, TIRES AND WHEELS





SPINDLES, TIRES AND WHEELS

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	TIR4060155	FIELD TIRE AND WHEEL ASSY-1390	1
	WHLHWY1390	HIWAY TIRE AND WHEEL ASSY	1
2	TIR4006020	FIELD TIRE ONLY	1
	TIR14175F3	HIWAY TIRE 14 X 17.5-14 PLY	1
3	WHL0000001	FIELD WHEEL ONLY	1
	WHL0175105	HIWAY WHEEL 17.5 X 10.5	1
4	VLV0000415	VALVE STEM	1
5	F 0008001	LUG BOLT F/8-HOLE HUB	8
6	F 0008003	HUB & SPINDLE ASSY - 8-HOLE	1
7	F 0008000	HUB CAP- 8-HOLE HUB	1
8	F 0007999	NUT F/WHEEL SPINDLE	1
9	COT0000504	1/8 X 1-1/2 COTTER PIN	1
10	F 0007998	WASHER F/WHEEL SPINDLE	1
11	F 0007997	OUTER WHL BRG CONE- 8-HOLE HUB	1
12	F 0007992	HUB W/CUPS - 8-HOLE	1
13	F 0007996	OUTER BEARING CUP	1
14	F 0007993	INNER WHEEL BEARING CUP	1
15	F 0007994	INNER WHL BRG CONE- 8-HOLE HUB	1
16	F 0007995	GREASE RETAINER- 8-HOLE HUB	1
17	SPN0034224	FIELD TIRE BALER SPINDLE-1390	1
	SPN0033158	HIWAY TIRE BALER SPINDLE	1


DECAL LOCATIONS



DECAL LOCATIONS



DECAL LOCATIONS



DECAL LOCATIONS

REF NO.	PART NO.	DESCRIPTION	QTY. USED
1	FD 0023572	"SHLDS ARE F/YOUR PROTECT..."	5
2	FD 0023573	"STAY CLEAR OF FAN WHILE..."	3
3	FD 0030291	DECAL-WARNG CALIF PROPOSITION 65	1
4	FD 0025126	PICKUP HAZARD WARNING DECAL	2
5	FD 0023534	"KEEP SHIELDS IN PLACE..."	2
6	FD 0023576	"DANGER!LOOK & LISTEN FOR..."	4
7	FD 0023473	"CAUTION!1...2...3...8 WARNINGS"	1
8	NP 0000100	SERIAL NO. ID PLATE	1
9	FD 0023581	"CAUTION! SHUT OFF MOTOR WHEN"	1
10	FD 0000035	DECAL"DIESEL FUEL ONLY"1-1/2X4	1
11	FD 0034275	TENSION RAIL SELECTOR DECAL	1
12	FD 0034273	"CAUTION" JACK WILL SUP VERT..	1
13	FD 0034276	DECAL,"1390" INLINE BALER	2
14	FD 0007113	36" X 5" WHITE "FREEMAN" DECAL	2
15	FD 0007111	25" X 4" WHITE "FREEMAN" DECAL	2
16	FD 0023538	"WARNING!DO NOT RIDE ON..."	3
17	FD 0023951	DECAL LUG NUT 1592	2
18	FD 0034738	DECAL-"KNOTTER FAN SWITCH"	1
19	FD 0034756	DECAL-"RECOMMENDED TIRE....."	2
20	FD 0034821	DECAL-"NO LIFT "- 1390	1
21	FD 0034824	DECAL-"KNOTTER LUBER TANK.....	1
22	FD 0018808	HYDRAULIC FLUID DECAL -1500	1
23	FD 0023583	DECAL-"KEEP HANDS CLEAR....."	2

PARTS INDEX

03-181	SWITCH-MICRO 1TL1-3	page93	BAT0074XHD	BATTERY GRP 74,HEAVY DUTY-1390	page93
04-123	PICKUP COUNTERBALANCE SPRING	page19	BCO0001133	COUNTER, LCD, 12 V, NOT RESET, ENM	page91
20-112	MOTOR MOUNT PAD	page37,73	BKT0032972	LUBER MOUNT BRACKET	page69,71
ACL0000440	PRE CLEANER, ENGINEAIRE # EA440S	page55	BKT0033245	FRONT CONTROL BOX MOUNT	page91
ACL0002251	RESTRICTION INDICATOR,	page55	BKT0033246	REAR CONTROL BOX MOUNT	page91
ACL0080372	AIR CLEANER, DONALDSON # G080372	page55	BKT0033444	BTM BELT GUIDE BRACKET- 1390	page35
ACL0101870	AIR CLEANER NUT ASSY	page55	BKT0033451	BKT,GUIDE,BELT,REAR,LOWER-1390	page35
ACL0112003	VACTUATOR VALVE F/DTZ AIR	page55	BKT0034532	LOWER REAR BLT GUIDE BKT- 1390	page39
ACL0119410	SAFTY ELEMENT F/DTZ AIR	page55	BKT0034638	PLUG BRACKET- 1390	page13
ACL0119711	OUTER CUP F/DTZ AIR CLEANER	page55	BKT0034663	ROD GUIDE BRACKET- 1390	page75
ACL0149573	PRIMARY ELEMENT F/DTZ AIR	page55	BKT0034705	MIDSPIN BLT GUIDE BRACKET-1390	page35
ACMSBO2102	HYDAC HYD ACCUMULATOR- 1390	page89	BKT0034708	TWINE STEP GUIDE BRACKET- 1390	page81
ACT0012409	ADDCO ACTUATOR MNTNG KIT- 1390	page53	BKT0034727	TWINE FNGR STOP BRACKET- 1390	page69
ACT00A330R	ADDCO ELECTRIC ACTUATOR ERC330	page53	BKT0034733	WORK LIGHT BRACKET- 1390	page93
ACT00CA112	THROTTLE CONTROLLER W/ CON	page91	BKT0034965	TWINE TENSIONER BRACKET	page79
ANC0016029	PICKUP LIFT SPRING ANCHOR-1500	page19	BKT0035354	MAIN SHIELD SPRING BRACKET	page37
ANC0033255	ANCHOR ASSY, BATTERY - 1390	page93	BLK0005050	SWITCH CONTACT BLOCK,	page91
ANC0034889	NEEDLE YOKE SHOCK ANCHOR ASSY	page77	BLK0032668	LOWER PLG ROLLER BLOCK-1390	page31
ANC0035090	BALER CHUTE CHN ANCHOR- 1390	page83	BLK0032966	BLOCK, JACK, RAIL, PLGR 1390	page31
ANG0031915	ANGLE,EXT,CHMBR, L., TOP-1390	page33	BLK0034519	OUTER BEARING BLOCK	page29
ANG0031916	ANGLE,EXT, CHMBR R. TOP-1390	page33	BLK0034521	SPRING CLAMP BLOCK	page29
ANG0032292	FEEDER CHAIN GUIDE ANGLE	page47	BLK0035426	SPRING SUPPORT BLOCK	page29
ANG0034583	KNT CHAIN GUD ANGLE ASSY- 1390	page47	BLT000D210	MAIN DRIVE BELT- 1390	page35
ANG0034585	MOUNT ANGLE	page47	BMP0001390	PLUNGER STOP BUMPER-1390	page75
ANG0035558	LH LOWER CHMBER EXT ANG ASSY	page33,77	BON0000001	GEARBOX CRANK ARM HUB- 1390	page41
ANG0035559	RH LOWER CHAMBER EXT ANG ASSY	page33,77	BON0000002	SNAP RING- 1390	page41
ARM0031341	AUXILIARY DRIVE CRANK ARM ASSY	page45	BON0000003	CRANK ARM RETAINING RING- 1390	page41
ARM0032481	NDL YOKE DRV CRANK ARM ASY1390	page59,63	BON0000004	GEARBOX GREASE ZERK- 1390	page41
ARM0032537	PICKUP WHEEL ARM- 1390	page19	BON0000005	GEARBOX CRANK ARM BEARING-1390	page41
ARM0033362	LH PLUNGER STOP ARM ASSY -1390	page75	BON0000006	GEARBOX DIRT EXCLUDER- 1390	page41
ARM0033363	RH PLUNGER STOP ARM ASSY -1390	page75	BON0000007	GEARBOX MAIN SHF OIL SEAL-1390	page41
AUG0032222	AUGER, LEFT PICK UP	page23	BON0000008	INPUT SHAFT OIL SEAL- 1390	page41
AUG0032567	LEFT AUGER TROUGH 1390	page19	BON0000009	GEARBOX RH CRANK ARM SEAL-1390	page41
AUG0032568	RIGHT AUGER TROUGH - 1390	page21	BON0000010	CRANK ARM BEARING SEAL- 1390	page41
AUG0032793	SCRAPER, AUGER 1390	page19	BON0000011	LH BEARING CLOSURE CAP- 1390	page41

PARTS INDEX CONT.

BON0000012	GEARBOX DRAIN PLUG-	1390	page41		
BON0000013	OIL LEVEL SIGHT GLASS-	1390	page41	BRG51FLMX8	BRG, 2 BOLT FLANGE 1-1/4" BORE page69
BON0000014	PRESSURE/BREATHER PLUG-	1390	page41	BRG64F64PP	1"SINGLE ROW FLANGED BEARING page67
BON0000015	GEARBOX LH CRANK ARM-	1390	page41	BRG4164PP2	TINE BAR BEARING 1"BORE -1390 page 17
BON0000016	GEARBOX RH CRANK ARM-	1390	page41	BRGCRSBC20	1-1/4"STUD CAM FOLLOWER-1390 page17
BOX0033413	TWINE BOX FRONT		page79	BRGER20722	BEARING,KNOTTER CLUTCH 1390 page59
BOX0033415	TWINE BOX BOTTOM		page79	BRGRA104RR	BEARING, SHAFT, DRIVE, PICKUP page23
BOX0034652	LEFT TWINE BOX LID GUSSET		page79	BRGRA106RR	P/U REEL BEARING 1-3/8"-1390 page17,23
BOX0034656	RIGHT TWINE BOX LID GUSSET		page79	BSH0031142	FLYWHEEL SHEAR BSH & END -1390 page35
BOX0034897	TWINE BOX LID-	1390	page79	BSH0031143	FLYWHEEL SHEAR BUSHING HUB END page35
BOX0034898	TWINE BOX LEFT END		page79	BSH0031351	FEEDER DRIVE SHEAR BUSHING page45
BOX0034899	TWINE BOX RIGHT END		page79	BSH0031605	TNS RAIL PIVOT BSH 15.5" CHAMBER page33
BOX0034900	TWINE BOX BACK		page79	BSH0032160	BSH, ACCELATOR, THROTTLE 1390 page53
BOX0035235	TWINE BOX DIVIDER		page79	BSH0034240	TOP TNS RAIL PIVOT BSH- 1390 page33
BOX0035756	CONTROL BOX DOOR WIRING & COMP		page91	BSH0034459	BALE CHUTE BUSHING page83
BOX0035757	BALER CONTROL BOX ASSEMBLY		page91	BSH0034650	WIND GUARD BUSHING- 1390 page15
BRC0035614	LH REAR CHAMBER BRACE ASSY		page33	BSH0035200	CLUTCH PAWL PIVOT BUSHING page59
BRC0035615	RH REAR CHAMBER BRACE ASSY		page33	BSH00VG290	VOGELSANG VG-290 BUSHING page19
BRG0000001	FLANGE BEARING, 14mm ID X 17mm OD,		page77	BSH00VG400	1.25"OD X 1"ID X 1"LG TEN BUSH page19,39
BRG0000019	FEEDER DRIVE SPROCKET BEARING,		page45	BSH0E21875	2-3/16"QD BUSHING F/SPK100E30 page25
BRG0001300	ROD END BEARING, 5/16, LH		page69	BSHP141812	BUSHING, LEVER page23
BRG0001301	ROD END BEARING, 5/16, RH		page69	BSHSK21875	BSH-QD-TYPE page25
BRG000394A	TAPERED ROLLER BEARING CUP,		page45	CAM0032464	STOP CAM page67
BRG0020016	GARLOCK DX BRG, NO. 020 DX R016		page23	CAM0032465	KNT TRIP RESET CAM ASSY 1390 page63
BRG00205PP	BALL BEARING 1390		page39	CAM0032465	KNT TRIP RESET CAM ASSY 1390 page67
BRG0020618	2-BOLT,NEEDLE YOKÉ BRG-1390		page75	CAM0033377	PLUNGER STOP CAM - 1390 page75
BRG0021135	4 BOLT FLANGE BEARING-1390		page25	CAM0034129	LEFT PICKUP CAM- 1390 page17,23
BRG0032234	BRG HOUSING, AUGER SHAFT, PICKUP		page23	CAM0034130	RIGHT PICKUP CAM- 1390 page17,23
BRG0034014	TINE BAR CENTER BEARING		page 17	CAM0034586	TWN FINGER DRV CAM ASSY- 1390 page63
BRG0040310	CONN ROD.BELT DRIVE BRG-1390		page57	CAM0035104	PLUNGER STOP CAM page77
BRG0067000	BEARING COMPLETE		page23	CAP0000002	ELEC PROTECTIVE CAP- 1390 page13
BRG015SF24	INTERNAL RETAINING RING- 1390		page13	CAP0001030	CAP (BOOT) F/SWI5025 page93
BRG0507910	BEARING CUP-L507910		page25	CAP0001390	PRESSURE VENT CAP ONLY page51
BRG0507949	BEARING-TAPERED ROLLER L507949		page25	CAP0046749	CAP FOR HUB348 page19
BRG072DU32	GARLOCK DU BRG F/BLT DRVE-1390		page35	CBK0001456	CIRCUIT BREAKER, 6 AMP COLE page91
BRG395LA90	TAPERED ROLLER BEARING CONE,		page45	CBK0014520	CIRCUIT BREAKER, 20 AMP, COLE HER page91
				CBL0712054	4GA 20"SIDE MOUNT BATTERY CBL page93

PARTS INDEX CONT.

CBL080459A	MICRO-CHG SINGLE KWY PLUG/ASSY	page93	CLH0033112	KNOTTER CLUTCH DRIVE HUB ASSY	page59
CBL88A3115	MICRO CHNG IN-LINE SPLITTER	page93	CLH0PU1390	CLUTCH, PICKUP, 1390	page23
CBLGND1390	ENGINE GROUND CABLE- 1390	page93	CLP0000002	SAFETY CLIPS F/10MM BALL- 1390	page79
CBLPOS1390	POSITIVE POST BATTERY CBL-1390	page93	CLP0000005	GAS SPRING SAFETY CLIP	page37
CHM0032445	FRT TOP CHM PLATE 15" CHAMBER-	page27	CLP0000120	3/4 DIA VINYL CLAMP	page73
CHM0032660	UPPER CHAMBER STIFFENER 1390	page27	CLP0000130	HOO-K-TYPE FASTENER	page81
CHM0033528	CHAMBER STIFFENER BAR-1390	page27	CLP0010951	3/8"STD HYCON TUBE CLAMP	page85,89
CHM0035454	FRT CHM TOP PLATE 15 1/2 ASSY	page27,33	CLP0021301	1/2"HYCON STD TUBE CLAMP	page89
CHM0035460	FRT TOP CHM PLATE 14.5" CHAMBER-	page33	CLP0030878	PLUNGER CONN ROD PIN CLAMP BLK	page43
CHM0035474	REAR CHAMBER TOP PLATE ASSY	page27,33	CLP0032525	HAY DOG CUSHION CLAMP 1390	page63
CHM0035493	CHAMBER SIDE ASSY, LH	page27	CLP0034840	KNOTTER SHAFT CLAMP- 1390	page63
CHM0035494	CHAMBER SIDE ASSY, RH	page27	CLP0100075	3/4 HYDRA ZORB HOSE CLAMP	page75
CHM0035598	LOWER CHAMBER STIFFENER	page27	CLP0708501	FUEL TANK STRAP	page51
CHN0000291	AUTO LUBER CHAIN F/1390	page47	CLP2110692	MNTG CLP FOR HYDAC ACCUM- 1390	page89
CHN0006081	MAIN PICKUP DRIVE CHAIN, RC #60, 81 P	page23	CLP7051029	HOSE CLAMP, 3"-5", #72	page55
CHN0032297	FEEDER CHAIN GUIDE WEAR STRIP	page47	CLP7051170	MINI HOSE CLAMP	page51
CHN0034460	BALE CHUTE CHAIN	page83	CLV0007721	CLEVIS WITH PIN AND COTTER PIN	page83
CHN0034582	KNOTTER CHAIN GUIDE ASSY	page47	CLV0120018	CLEVIS PIN, 1/2 X 1 1/2	page47
CHN0050107	RIGHT PU DRIVE CHAIN, RC #50, 107 P	page23	CNK0001000	CONN LINKS, #100, COTTER PIN	page47
CHN0060109	LEFT PU DRIVE CHAIN, RC #60, 109 P	page23	COT0000001	HAIR PIN CLIP F/1" DIA CLV PIN	page21
CHN035828A	CLUTCH CYLINDER SPRING CHAIN	page39	COT0000502	1/8 X 1 COTTER PIN	page63
CHN035830A	WIND GUARD CHAIN	page15	COT0000504	COTTER PIN, 1/8 X 1 1/2	page39,95
CHU0031517	FEED CHUTE BACK ASSY - 1390	page25	COT0000505	1/8 X 1-3/4 COTTER PIN	page19
CHU0031541	FEED CHUTE TOP SECTION - 1390	page25	COT0000704	5/32 X 1-3/4 COTTER PIN	page19,23
CHU0032300	FRONT FEEDCHUTE 1390	page19	COT0000805	3/16 X 2 COTTER PIN	page39
CHU0034420	WELDED BALE CHUTE ASSY- 1390	page83	CPL0031253	BELT DRIVE COUPLING ASSY -1390	page57
CHU0035518	LH FEED CHUTE SIDE PLATE ASSY	page25	CRA0032174	CRANK, FEEDER - 1390	page25
CHU0035519	RH FEED CHUTE SIDE PLATE ASSY	page25	CRA0032662	CRANK, BALANCE, PICKUP-1390	page19
CIR0034658	AUTO SHUT DOWN MODULE ASSY	page91	CRA0033485	PLUNGER STOP CRANK - 1390	page75
CLH0017767	CLUTCH, DRIVE	page23	CRA0035739	BELT IDLER BELL CRANK	page39
CLH0017773	ADAPTER, CLUTCH	page23	CRB3750013	3/8 X 1-1/4 CARRIAGE BOLT-PLTD	page25
CLH0017849	DISC, CLUTCH, PICKUP	page23	CRB3750100	3/8 X 1 CARRIAGE BOLT-PLTD 17,19,21,69	page
CLH0032034	KNOTTER CLUTCH PAWL	page59	CRB3750150	3/8 X 1-1/2 CARRIAGE BOLT-PLTD	page19
CLH0032044	STOP CLEAT	page59	CRB3750225	BOLT, CARRAIGE, 3/8 X 2 1/4, UNC,	page23
CLH0032045	KNOTTER CLUTCH DRIVEN HUB ASSY	page59	CRB3750300	BOLT, CARRAIGE, 3/8 X 3, UNC,	page23

PARTS INDEX CONT.

CRB3752000	3/8 X 2 CARRIAGE BOLT-PLTD	page 17	EXT036225A	RH UPPER PLG FACE EXT ASSY, 16"	page43
CRB5000125	1/2 UNC WHIZ NUT PLATED	page13	EXT036226A	CENTER SIDE PLG FACE EXTENSION	page43
CRB5000450	BOLT, CARRAIGE, 1/2 X 4 1/2, UNC,	page23	EXT036227A	LOWER SIDE PLG FACE EXT	page43
CRB7375100	3/8 X 1 GR 5 CARR BOLT-PLT	page67	F 0007861	KNOTTER BILL HOOK	page65
CUS0032524	BLACK HAY DOG CUSHION 1390	page63	F 0008070	TRIGGER F/KNOTTER BILL HOOK	page65
CYL0000324	DRAWBAR SWING CYLINDER-1390	page13,89	F 0008071	PIN FOR BILL HOOK TRIGGER	page65
CYL0033749	VERTICAL TENSION CYLINDER-1390	page33,85	F 0000025	CONNECTING LINK-RC50	page47
CYL0034537	CLUTCH BELT CYLINDER- 1390	page39,89	F 0000072	1/2 X 1/2 X 3 1/2"L.KEYSTOCK	page35
DCT0035695	COOLING AIR DUCT WELDMENT	page55	F 0000123	RC 50 OFFSET LINK	page47
DIO0046003	DIODE, #IN5404	page91	F 0000169	BALE COUNTER ROD SPRING -SP	page53
DOC0032298	FEEDER CHAIN GUIDE ASSY	page47	F 0000220	HAY DOG PIN (1/2 X 3 CLEVIS)	page63
DOG0032523	DOG, HAY 1390	page63	F 0000225	KNTR DR SHF KEY 1/2 X 2	page25
DOG0033340	PLUNGER STOP DOG -1390	page75	F 0000246	KNOTTER BRAKE DISC WASHER	page39,61
DOG0035241	SIDE HAY DOG	page29	F 0000440	FERRULE	page49,73,75
DOR0031542	FEED CHUTE ACCESS DOOR - 1390	page25	F 0000658	14 GA. KNOTTER WORM WASHER	page65
DPT0032158	THROTTLE ROD ACCEL ADAPTR-1390	page53	F 0000659	18 GA. KNOTTER WORM WASHER	page65
DRB0031783	DRAWBAR ASSEMBLY - 1390	page13	F 00007904	KEY, 3/8 X 3/8 X 2	page57
DTZ0001390	DTZ 4 CYLINDER ENG- 1390 ONLY	page53	F 0000802	1-3/8 FEED ARM WASHER -200/270	page61
DTZ0271160	OIL TEMPERATURE SWITCH	page53	F 0000856	TWINE & WIRE GUIDE BUSHING	page75,79,81
DTZ0272326	V BELT FAILURE SWITCH KIT	page53	F 0000857	SNAP RING F/TWN GUIDE BUSHING VM	page75,79,81
DTZ0272401	BRUSH RING F/DEUTZ AIR SCREEN	page55	F 0000883	IDLER PULLEY F/KNOT CHAIN DRIV	page39
DTZ1118688	WASHER	page53	F 0000893	TANK FELTS , SET OF 3	page51
DTZ1119246	BANJO BOLT	page53	F 0001019	HAIRPIN COTTER, SIZE 21-07	page47
DTZ1173470	TEMPERATURE SENSOR	page53	F 0001517	TRIP SPRING	page15,69
DTZ1176023	OIL PRESSURE SENDER -DEUTZ	page53	F 0001549	RH NEEDLE YOKE DRIVE ROD END	page75
DTZ1236291	OIL FILLER CAP-DEUTZ ENGINE	page53	F 0001550	LH NEEDLE YOKE DRIVE ROD END	page75
DTZ1290579	BANJO FITTING	page53	F 0001572	CAM FOLLOWER-RESET-SADDLE LEV	page61,67,69
DTZ2234942	BRUSH ONLY F/DTZ0272401	page55	F 0001611	TWINE NEEDLE - CURVED	page75
DTZ2235175	COOLING FAN BELT-DEUTZ	page53	F 0001618	METER WHEEL SHAFT BRG W/CLAMPS	page67
DTZ2235178	ALTERNATOR BELT F/DEUTZ ENG	page53	F 0001619	METER WHEEL SHAFT-BEARING ONLY	page67
DTZ9990172	FUEL SHUTDOWN SOLENOID KIT	page53	F 0001654	OUTER BEARING CUP	page19
ELC0SL100B	SHAFT SEAL LOCK NUT,	page91	F 0001680	28 GA. KNOTTER WORM WASHER	page65
ELC7531010	POTENTIOMETER, 5 WATT, 10K	page91	F 0001687	KNURLED FRICTION DISC	page67
EXT036206B	MIDDLE UPPER PLG FACE EXT ASSY	page43	F 0001689	FUEL TANK CAP	page51
EXT036224B	LH UPPER PLG FACE EXT ASSY, 16"	page43	F 0001889	FLANGETTE F/F1618 BEARING	page67

PARTS INDEX CONT.

F 0001890	LOCKING COLLAR F/F1619 BEARING	page67	F 0007890	TWINE TENSIONER TOP	page79
F 0001909	BEARING CONE	page19	F 0007891	TWINE TENSIONER ASSEMBLY	page79
F 0004050	ROLLER-SHUTTLE BAR DRIVE	page75	F 0007892	SPACER WASHER F/KNIFE ARM PIN	page65
F 0004159	1-3/8 X 10 GA MACHINE BUSHING	page63	F 0007893	NUT F/KNIFE ARM PIN	page65
F 0004160	1-3/8 X 14 GA MACHINE BUSHING	page63	F 0007947	KNOTTER HOOK CAM ADJUST SPRING	page65
F 0004161	1-3/8 X 18 GA MACHINE BUSHING	page21,63	F 0007948	KNOT HOOK CAM ADJUSTING SCREW	page65
F 0005048	1/2" ADJ CLEVIS TAPPED 1/2"-20	page75	F 0007949	KNOTTER HOOK CAM ADJ SCREW-NUT	page65
F 0006498	CYLINDER PIVOT PIN	page19	F 0007973	HOLDER F/NEEDLE TWN GUIDE BUSH	page75
F 0006519	2 X 8 HYDRAULIC CYLINDER	p19,33,85,89	F 0007976	SNAP RING F/KNIFE ARM SHAFT	page65
F 0006781	43/64 X 1-1/8" WAVE WASHER	page53	F 0007977	1-3/8X1-7/8X.010 SPACER WASHER	page63
F 0007063	1-3/8" KNOTTER SHAFT BEARING	page63	F 0007978	1-3/8X1-7/8X.005 SPACER WASHER	page63
F 0007401	1/8" NYLAFLOW TUBING 40"	page71	F 0007988	SNAP RING F/KNOTTER SHAFT	page21
F 0007448	SADDLE LEVER SPRING EYEBOLT	page61,75	F 0007992	HUB W/CUPS - 8-HOLE	page95
F 0007449	INSIDE BRAKE PLATE W/LINING	page61	F 0007993	INNER WHEEL BEARING CUP	page95
F 0007450	OUTSIDE BRAKE PLATE W/LINING	page61	F 0007994	INNER WHL BRG CONE- 8-HOLE HUB	page95
F 0007451	BRAKE PLATE STUD	page61	F 0007995	GREASE RETAINER- 8-HOLE HUB	page95
F 0007453	BRAKE PLATE SPRING	page61	F 0007996	OUTER BEARING CUP	page95
F 0007454	BRAKE LINING W/RIVETS	page61	F 0007997	OUTER WHL BRG CONE- 8-HOLE HUB	page95
F 0007523	NEEDLE YOKE BEARING	page25,77	F 0007998	WASHER F/WHEEL SPINDLE	page95
F 0007541	TWINE TENSIONER SPRING	page79	F 0007999	NUT F/WHEEL SPINDLE	page95
F 0007552	NEEDLE TO YOKE CARR BOLT W/NUT	page75	F 0008000	HUB CAP- 8-HOLE HUB	page95
F 0007554	NEEDLE YOKE DRIVE ROD	page75	F 0008001	LUG BOLT F/8-HOLE HUB	page95
F 0007559	SADDLE LEVER SPRING	page61	F 0008003	HUB & SPINDLE ASSY - 8-HOLE	page95
F 0007585	SLEEVE F/SADDLE LEVER ANCHOR	page61	F 0008022	METER WHEEL SHAFT ONLY - 3 TIE	page67
F 0007586	BUSHING F/SADDLE LEVER ANCHOR	page61	F 0008023	GUIDE WASHER	page67
F 0007587	SADDLE LEVER ANCHOR SEAL	page61	F 0008049	TWINE KNIFE	page65
F 0007859	TWINE KNIFE SCREW	page65	F 0008050	KNIFE ARM COMP(WAS:F7857&7945)	page65
F 0007860	KNIFE ARM WASHER 25 X 20 X .5M	page65	F 0008051	KNOTTER HOOK CAM	page65
F 0007868	TWINE HOLDER -WAS: F 78 RA	page65	F 0008052	TWINE HOLDER SPRING	page65
F 0007869	TWINE DISC	page65	F 0008068	SPACER F/BILL HOOK PIN - .020	page65
F 0007870	TWINE DISC CLEANER	page65	F 0008069	SPACER F/BILL HOOK PIN - .032	page65
F 0007871	TWINE HOLDER DISC PINION	page65	F 0008144	TWINE FINGER BUSHING NUT	page69
F 0007876	KNT WORM & SHAFT (COMPL ONLY)	page65	F 0008146	TWINE FINGER WASHER	page69
F 0007884	KNIFE ARM PIN	page65	F 0008189	SHUT-OFF VALVE	page51
F 0007889	TWINE TENSIONER BASE ASSEMBLY	page79			

PARTS INDEX CONT.

F 0008199	SITE TUBE FOR AUTO LUBER TANK	page71	FD 0023581	"CAUTION! SHUT OFF MOTOR WHEN"	page99
F 0008209	3/8" X 1/4 NPT MALE, 90° ELB, BRASS	page71	FD 0023951	DECAL LUG NUT 1592	page99
F 0008209	3/8" X 1/4 NPT MALE, 90° ELB, BRASS	page71	FD 0025126	PICKUP HAZARD WARNING DECAL	page99
F 0008274	ROLLER F/KNIFE ARM	page65	FD 0030291	DECAL-WARNG CALIF PROPOSITION 65	page99
F 0008275	SNAP RING F/KNIFE ARM ROLLER	page65	FD 0034273	"CAUTION" JACK WILL SUP VERT..	page99
F 0008280	1 MM WASHER-WORM SHF & KNF ARM	page65	FD 0034275	TENSION RAIL SELECTOR DECAL	page99
F 0008287	STR AUTO LUBER FITTING	page71	FD 0034276	DECAL, "1390" INLINE BALER	page99
F 0008288	90° AUTO LUBER FITTING	page71	FD 0034738	DECAL-"KNOTTER FAN SWITCH"	page99
F 0008306	FERRULE F/AUTO LUBER FITTING	page71	FD 0034756	DECAL-"RECOMMENDED TIRE....."	page99
F 0008383	FLANGETTE-NO ZERK F/F8102	page17,23	FD 0034821	DECAL-"NO LIFT "- 1390	page99
F 005048	CLEVIS, 1/2"	page47	FD 0034824	DECAL-"KNOTTER LUBER TANK....."	page99
F 008264	RUBBER BUMPER	page29	FD 0035719	GRAPHIC OVERLAY	page91
F000000025	LINK, CONNECTING, 50 CHAIN	page23	FEN0032427	FENDER FLARE, PICKUP, LH 1390	page19
F000000123	LINK, OFFSET, 50 CHAIN	page23	FEN0032430	FENDER FLARE, PICKUP, RH 1390	page19
F000000759	LINK, OFFSET, 60 CHAIN	page23	FIL0010003	FILTER CAP, COMPLETE WITH SCREEN	page71
F000000760	LINK, CONNECTING, 60 CHAIN	page23	FIL0HF6613	FILTER ELEMENT-SYNTHETIC- 1390	page89
F000001790	SPRING, PIN, CLUTCH	page23	FIL0HH6935	HYDRAULIC FILTER HEAD- 1390	page89
F000001791	PIN, CLUTCH	page23	FIL1160024	OIL FILTER, DEUTZ	page53
F000001793	DISC, FRICTION, CLUTCH	page23	FIL1160243	FUEL FILTER - DEUTZ	page53
F000001797	SPRING, PLATE, CLUTCH	page23	FILCF90081	INLINE HYD PRESSURE FIL- 1390	page53,71,89
F000007397	SPK, IDLER, 60 CHAIN, 15 T, 1/2 BORE	page23	FILS1510V3	HYD TANK FILTER- 1390	page51
F000007448	EYEBOLT, LEVER, SADDLE	page23	FLT0034591	FEEDER BEARING SEAL FELT-1390	page25
F000007559	SPRING, LEVER, SADDLE	page23	FLW0031112	FLYWHEEL -1390	page35
F000008011	OUTER BEARING CUP	page23	FRM0031309	1/2 X 1-1/2 CARRIAGE BOLT-PLTD	page13
FAN0000001	16" KNOTTER FAN, DUST/MOISTURE	page73	FRM0031522	REAR GEAR BOX CROSS FRM - 1390	page25,27
FD 0000035	DECAL"DIESEL FUEL ONLY"1-1/2X4	page99	FRM0031536	BOTTOM FRAME CROSS MEMBER-1390	page27,33
FD 0007111	25" X 4" WHITE "FREEMAN" DECAL	page99	FRM0031616	FRONT MAIN FRAME ASSY - 1390	page27
FD 0007113	36" X 5" WHITE "FREEMAN" DECAL	page99	FST0010401	MED DUTY FOLDING HANDLE FASTNR	page21
FD 0018808	HYDRAULIC FLUID DECAL -1500	page99	FT 0000113	CONNECTING LINK - #41 CHAIN	page39
FD 0023473	"CAUTION!1..2..3..8 WARNINGS"	page99	FT 0000252	5/16 - 7/8 MINI WORM CLAMP	page71
FD 0023534	"KEEP SHIELDS IN PLACE..."	page99	FUS0000025	FUSE HOLDER, 30 AMP, HKCC	page91
FD 0023538	"WARNING!DO NOT RIDE ON..."	page99	FUS0000061	FUSE, AGC 20 AMP	page91
FD 0023572	"SHLDS ARE F/YOUR PROTECT..."	page99	FUS0000065	FUSE, AGC 30 AMP	page91
FD 0023573	"STAY CLEAR OF FAN WHILE..."	page99	GAG0000001	4"3000PSI TENSION GUAGE-1390	page85
FD 0023576	"DANGER!LOOK & LISTEN FOR..."	page99			

PARTS INDEX CONT.

GAG0001133	HOUR METER, LCD, 12 V, NON RESET,	page91	HOS0034753	MANIFOLD SUPPLY HOSE-30" 1390	page89
GAG0009090	FUEL GAUGE, ISSPRO #R9090	page91	HOS0034754	DRAWBAR & LUBER TO PUMP HOSES	page71,89
GER0006068	MODULAR CAM GEAR - WAS:GER7942	page63	HOS0034787	HOSE, HYD, KNT LUB.PUMP-FILTER	page71
GER0007862	HARDENED BILL HOOK PINION	page65	HOS0034788	HOSE,KNT LUB.SOL.VAL. RTN	page71
GER0007873	HARDENED KNOTTER WORM PINION	page65	HOS0034790	HOSE,HYD,TENS GAGE-F PORT MANI	page85
GER0033083	BONDIOLI GEARBOX- 1390	page41	HOS0034791	HOSE,HYD,PORT 2 KNT SOL-KNT MF	page71
GRD0034122	PICKUP CHAIN GUARD- 1390	page19	HOS0034841	TENSION CYLINDER HOSE- 1390	page85
GRD0034649	WIND GUARD- 1390	page15	HOS0034842	HOSE,HYD,BLKHD-KNT LUBER 1390	page71
GUD0032696	GUIDE, BOTTOM, SHIELD 1390	page19	HRN0034684	REMOTE TO DRAWBAR HARNESS-1390	page93
GUD0032697	GUIDE, REAR, SHIELD 1390	page19	HRN0034729	BALER RUNNING LIGHT HARN.-1390	page93
GUD0033425	CENTER BELT GUIDE ASSY- 1390	page35	HRN0034730	DRAW BAR RUNNING LIGHTS- 1390	page93
GUD0033484	REAR BELT GUIDE ASSY- 1390	page35	HRN0034818	KNOTTER FAN HARNESS- 1390	page93
GUD0034394	BALE CHUTE ANGEL GUIDE- 1390	page83	HRN0034863	DRB LH VALVE JUMPER WIRE- 1390	page93
GUD0034395	BALE CHUTE ROTATION GUIDE-1390	page83	HRN0034864	P/U "UP" VLV JUMPER WIRE- 1390	page93
GUD0035666	BALE CHUTE FLAT GUIDE	page83	HRN0034865	DRB RH VLV JUMPER WIRE- 1390	page93
GUD0035742	BELT IDLER OUTER GUIDE	page39	HRN0034866	P/U "DOWN" VLV JUMPER WIR-1390	page93
GUD0035745	INNER BELT IDLER GUIDE	page39	HRN0034867	CLH "ENGAGE" JUMPER WIRE- 1390	page93
HAN0000150	PLATED DOOR HANDLE	page19	HRN0034868	HYD SOLENOID VLV HARNESS- 1390	page93
HAN0000817	CHROME GRAB HANDLE-#817	p33,49,55,79	HRN0035724	REMOTE HARNESS RECEPTACLE	page91
HAN0034446	STEP HANDLE- 1390	page81	HRN0035725	ENGINE HARNESS RECEPTACLE	page91
HGR0016785	HYDRAULIC HOSE HANGER	page13	HRN0035726	SENSOR HARNESS RECEPTACLE	page91
HNG0000810	TWINE BOX HINGE	page73,79	HRN0035727	THROTTLE HARNESS RECEPTACLE	page91
HNG0034552	TOOL BOX HINGE- 1390	page81	HRN0035728	WORK LIGHT HARNESS RECEPTACLE	page91
HNG9610500	INLINE HINGE ASSY	page55	HRN0035741	BALER BOX TO DRAWBAR WIRING	page93
HOS0034404	ROD END P/U CYL TO PORT C-1390	page89	HRN0035746	WORK LIGHT HARNESS ASSY	page93
HOS0034405	BUTT END P/U CYL TO PORT D	page89	HRN0035751	ENGINE WIRING HARNESS ASSY	page93
HOS0034415	ENGINE FUEL INLET TO TNK FRONT	page51	HSE0001875	3/16"ID FUEL LINE HOSE-BULK	page51
HOS0034416	TOP TNS CYL BUTT END TO LH TNS	page85	HSG0032183	FEEDER BEARING HOUSING -1390	page25
HOS0034417	TENSION CYLINDER HOSE- 1390	page85	HSN0031353	AUXILIARY DRIVE BRG HOUSING ASSY	page45
HOS0034418	TOP TNS CYL ROD END TO RH CYL	page85	HTH0021097	BALL HITCH W/FLAT PLT -NO BALL	page13
HOS0034419	TENSION CYLINDER HOSE- 1390	page85	HTH0031000	2-5/16 BALL W/NUT-WSHR,HVY DTY	page13
HOS0034749	TENSION SUPPLY HOSE-76"LG 1390	page85	HUB0000348	HUB W/BRGS & SEALS -BBRS P/U	page19
HOS0034750	TENSION RETURN HOSE-59"LG 1390	page85	HUB000BT12	HUB ONLY	page19
HOS0034751	HYD HOSE, CLUTCH,3/8 X 21,	page89	HUB0031140	FLYWHEEL SHEAR HUB -1390	page35
HOS0034752	PUMP SUCTION HOSE-1"X 25" 1390	page89	HUB0031350	AUXILIARY DRIVE SHEAR HUB	page45

PARTS INDEX CONT.

HYD0001207	HOSE BARB, 3/8 NPT X 3/8 HOSE, STR	page71	HYD7230040	1/2" O-RING HEX HEAD PLUG	page39,89
HYD1069022	1/4HOS X 1/4NPT 90° MINI-BARB	page51	HYD7231030	3/8" O-RING SOCKET HEAD PLUG	page87
HYD3069021	1/8 NPT STEEL HEX NIPPLE	page71	IMP0026006	3/8" PLASTIC SLEEVE	page71
HYD3109042	1/2 TO 1/4 STEEL PIPE BUSHING	page85	IMP0026106	3/8" NUT AND SLEEVE ASSEMBLY	page71
HYD3169020	1/4 SOCKET HD STEEL PIPE PLUG	page51	IMP0026106	3/8" NUT AND SLEEVE ASSEMBLY	page71
HYD3169030	3/8 SOCKET HEAD STEEL PIPE PLUG	page23	JCK0178203	JACK,5000LB,SIDEWIND-1390	page13
HYD3459030	3/8"90°ST THREAD O'RING MALE L	page71	KNF0035527	STATIONARY KNIFE- 1390	page31
HYD5015042	1/2 TO 1/4 JIC TUBE REDUCER	page87	KNF036235B	LH OUTER PLUNGER KNIFE	page43
HYD5129020	1/4" JIC CAP	page71,87	KNF036236B	RH OUTER PLUNGER KNIFE	page43
HYD5205020	1/4 JIC X 1/8 NPT MALE CONN	page71	KNF036242B	INNER PLUNGER KNIFE	page43
HYD5205060	3/4 JIC X 3/4 NPT MALE CONN	page89	KNT0024098	METER WHEEL ASSY	page67
HYD5315033	3/8JIC X 3/8 O-RNG ST THD CONN	page87	KNT0032132	BAR ASSY, TRIP, METER, KNOTTER	page67
HYD5315034	3/8 JIC X 1/2 O-RNG ST THD CON	page39,71,89	KNT0032459	KNOTTER TRIP BELLCRANK ASSY-1390	page67
HYD5315040	1/2JIC X 1/2 O-RNG ST THD CONN	page89	KNT0032478	KNOTTER BRAKE DISC ASSY -1390	page61
HYD5315043	1/2JIC X 3/8 O-RNG ST THD CONN	page87	KNT0034212	TWINE FINGER DRIVE SHAFT ASSY	page69
HYD5325030	3/8 JIC BULKHEAD UNION	page85	KNT0035344	TWINE FINGER	page69
HYD5355022	1/4 JIC X 1/8 NPT 45° MALE ELB	page71	KNT0035528	KNOTTER MOUNT, RH, 15 1/2" CHM	page63
HYD5355030	3/8 JIC X 1/4 NPT 45° MALE ELB	page53	KNT0035531	KNOTTER MOUNT, LH, 15 1/2" CHM	page63
HYD5375030	3/8 JIC 45° BLKHD UNION ELBOW	page89	KNT0035544	KNOTTER TRIP SHAFT ASSY	page67
HYD5405034	3/8 JIC X 1/2 NPT 90° MALE ELB	page85	KNT0035546	BEARING MOUNT	page67
HYD5405045	3/8 JIC X 3/8 NPT 90° MALE ELB	page51,71,85	KNT0060060	KNOTTER FRAME ONLY	page65
HYD5405060	3/4 JIC X 3/4 NPT 90° MALE ELB	page51	KNT006006A	HEAD ASSY-W/F7661,F7869,F8049	page63
HYD5405070	1" JIC X 1" NPT 90° MALE ELB	page51	KOB0001P2B	POTENTIOMETER KNOB, EHC #1P2B	page91
HYD5515034	3/8 JIC X 1/2 O-RING 90° ELBOW	page89	LAT0000201	RUBBER DRAW LATCH	page37,55,79
HYD5515040	1/2 JIC X 1/2 O-RING 90° ELBOW	page89	LAT0034428	DRAWBAR LATCH SHIM- 1390	page13
HYD5515046	1/2 JIC X 3/4 O-RING 90° ELBOW	page89	LEV0025133	LOWER SADDLE LEVER ASSY-A/1-92	page61
HYD5515068	1" JIC X 3/4" O-RING 90° ELB	page89	LEV0032159	LVR ADAPTOR,ROD,ACCEL THROTTLE	page53
HYD5525020	1/4 JIC X 90° BLKHD UNION ELB	page71	LEV0032483	LEVER ASSY, SADDLE 1390	page61,69
HYD5605035	3/8 JIC X 3/8 NPT MALE BR TEE	page85	LEV0033378	PLUNGER STOP CAM LEVER - 1390	page75
HYD5715033	3/8 TUB X 1/2 O-RING BRNCH TEE	page85	LEV0034019	PICKUP LEFT CAM LEVER	page17
HYD5716030	3/8 O-RING X 1/2M JIC RUN TEE	page87	LEV0034020	PICKUP RIGHT CAM LEVER	page 17
HYD5716666	3/8 TUB X 3/8 O-RING RUN TEE	page71,87	LID0034553	TOOLBOX LID ASSEMBLY- 1390	page81
HYD5755030	3/8"JIC X 1/4 NPT MALE RUN TEE	page85	LIN0034231	FRONT TOP CHM LINER ASSY- 1390	page33
HYD5924030	3/8 BULKHEAD NUT	page85,89	LIN0034233	REAR TOP CHAMBER LINER- 1390	page33
HYD6806060	3/4"O-RING X 3/4M 90°PIPE	page89	LIN0035562	RH BOTTOM CHAMBER LINER ASSY	page31

PARTS INDEX CONT.

LIN0035563	CNTR BOTTOM CHAMBER LINER ASSY	page31	MNT0034642	METER WHL BRG MNT-15" CHAMBER	page67
LIN0035564	LH BOTTOM CHAMBER LINER ASSY	page31	MNT0034786	KNT CHN IDLER MOUNT ASSY- 1390	page47
LIN0035568	LH SIDE CHAMBER LINER ASSY	page27,31	MNT0034837	PROXIMITY SWITCH MOUNT- 1390	page93
LIN0035569	RH SIDE CHAMBER LINER ASSY	page27,31	MNT0034860	KNOTTER DUAL BRAKE MOUNT-1390	page61
LIT0000001	REPLACEMENT BULB	page93	MNT0035192	MAIN SHIELD SPRING MOUNT	page37
LIT0000012	TAIL LAMP HOUSING - SP	page93	MNT0035286	LH SIDE TNS RAIL MNT ASSY-1390	page27,77
LIT1105D19	P/U AND FEEDER LIGHT- 1390	page93	MNT0035326	SCREEN MOUNT STIFFENER	page55
LIT1410112	DIRECTIONAL LAMP-COMPLETE	page93	MNT0035327	AIR CLEANER SUPPORT MOUNT	page55
LIT1410122	STOP/TAIL LAMP-COMPLETE	page93	MNT0035342	SHIELD PROP MOUNT	page49,73
LIT5205D18	REAR SPOT PATTERN LIGHT- 1390	page93	MNT0035355	MAIN SHIELD BUMPER MOUNT	page37
LIT5805C86	KNT FLOOD LIGHT W/ SWITCH-1390	page93	MNT0035541	RH SIDE TENSION RAIL MOUNT ASSY	page77,27
LIT7191511	TRAPEZOID HALOGEN HEADLIGHT	page93	MNT0035548	RELAY BRACKET	page91
LITXVLA124	LED INDICATOR LAMP, 12 VDC, SQ	page91	MNT0035557	REAR CHM BRACE CROSSMEMBER	page33
LNK0031503	AUXILIARY DRIVE DRAG LINK	page45	MNT0035702	COOLING AIR DUCT LATCH MOUNT	page55
LNK0032663	LH SPRING BALANCE LINK- 1390	page19	MNT0035706	AIR CLEANER MOUNT	page55
LNK0032695	RH SPRING BALANCE LINK- 1390	page19	MNT0035734	BELT IDLER MOUNT ASSEMBLY	page39
LNK0032708	PICKUP BALANCE LINK- 1390	page19	NCC0002500	NUT, CAGE, 1/4 UNC	page37,49,73
LNK0032711	P/U LIFT FLOATING LINK- 1390	page19	NCE0000250	1/4 ESNA NUT	p19,53,61,63,69
LNK0032823	FEEDER LINK ASSY 1390	page25	NCE0000313	5/16" NC ESNA NUT - PLATED	page61,79
LNK0033487	PLUNGER STOP LINK - 1390	page75	NCE0000375	3/8" NC ESNA NUT - PLATED	p17,23,35,45,61,63,69
LOK0017500	1-3/4 STD THD LOCK COLLAR-16L	page25	NCE0000440	ESNA NUT, #4-40, PLTD	page91
LUB0083313	INJECTOR, REPLACEMENT ONLY	page71	NCE0000500	NUT, ESNA, 1/2, UNC, PLATED	p23,39,63,83
LUB0323060	PRESSURE FITTING VALVE, 1/8 NPT	page25	NCE0000632	ESNA NUT, #6-32, PLTD	page91
LUB0833116	LUBER MANIFOLD ASSY,	page71	NCE0000750	3/4" NC ESNA NUT - PLATED	page19
MNT0031918	METER WHL BRG MNT-16" CHAMBER	page67	NCE0001000	1" NC ESNA NUT - PLATED	page19
MNT0032161	MNT,SWIVEL,ACCEL THROTTLE-1390	page53	NCE0015000	FRAME, SUPPORT, BALER - 1390	page13
MNT0032288	FEEDER CHAIN IDLER MOUNT	page47	NCH0000250	HEX NUT NC PLATED 1/4"	page 17,69
MNT0032296	FEEDER CHAIN GUIDE MOUNT- 1390	page47	NCH0000313	HEX NUT NC PLATED 5/16	17,19,21,53,67,69
MNT0032800	PICKUP MOUNT 1390	page21	NCH0000375	HEX NUT NC PLATED 3/8	p17,19,21,23,35,47,67,69,75
MNT0033111	MOUNT,PUMP,LUBE,KNTR - 1390	page71	NCH0000437	HEX NUT NC PLATED 7/16"	page63
MNT0033416	FRONT TWINE BOX MOUNT	page79	NCH0000500	1/2" LOCKWASHER - PLATED	p13,19,21,47,63,69,75,77
MNT0033417	REAR TWINE BOX MOUNT	page79	NCH0000625	HEX NUT NC PLATED 5/8	page19
MNT0033924	TENSION VALVE MOUNT 1390	page27	NCH0000625	HEX NUT NC PLATED 5/8	page47
MNT0034401	HYD PRESSURE FILTER MNT- 1390	page53	NCH0003750	HEX NUT NC 3/8-PLAIN	page61
MNT0034476	NEEDLE YOKE BEARING MOUNT	page77	NCHM008125	8MM X 1.25 MC HEX HUT - GR 8.8	page65

PARTS INDEX CONT.

NCJ0000313	5/16" NC JAM NUT - PLATED	page31	OFL0001000	OFFSET LINKS, #100	page47
NCJ0000375	3/8" NC JAM NUT - PLATED	page31	PCY0032248	REEL, PICKUP 1390	page17
NCJ0000375	3/8" NC JAM NUT - PLATED	page63	PCY0032248	REEL, PICKUP	page23
NCJ0000375	3/8" NC JAM NUT - PLATED	page67	PCY0032375	L.H. PICKUP SWING PLATE 1390	page21
NCJ0000500	1/2" NC JAM NUT - PLATED	page67	PCY0032376	RH PICKUP SWING PLATE 1390	page19
NCX0000250	FLEXLOC NUT NC PLATED 1/4"	page69	PCY0032551	FRAME, PICKUP 1390	page17
NEJ0001250	NUT, JAM, ESNA, 1 1/4, UNF	page23	PCY0034008	PICKUP TINE - 1390	page 17
NEJ0005000	ESNA JAM NUT, 1/2 NF, PLTD	page77	PCY0034017	PICKUP TINE BAR - 1390	page 17
NFC0010000	1" NF CASTLE NUT	page19	PIN0000001	1"DIA CYL ROD CLEVIS PIN	page21
NFE0000250	ESNA NUT, 1/4 NF, PLTD	page45	PIN0000002	DRAWBAR LATCH- 1390	page13
NFH0000313	HEX NUT, 5/16 NF, PLTD	page29	PIN0001390	P/U STOP PIN 3/4"X 3-1/2"1390	page19
NFH0000375	HEX NUT, 3/8 NF, PLTD	page69	PIN0030841	PLUNGER CONNECTING ROD PIN	page43
NFH0000500	1/2" NF HEX NUT - PLATED	page17,47,75	PIN0031504	DRAG LINK PIN	page45
NFH0000625	HEX NUT, 5/8 NF, PLTD	page77	PIN0031833	DRAWBAR LATCH PIN- 1390	page13
NFH0000750	3/4" NF HEX NUT - PLATED	page25,75	PIN0033395	PIN,CYLINDER,CLUTCH,BELT -1390	page39
NFH0001032	10-32 NF HEX NUT - PLATED	page19	PIN0033506	FEEDR LNK FRONT PIVOT PIN-1390	page25
NFH0003125	HEX NUT, 5/16 NF, PLTD	page69	PIN0034696	FLYWHEEL BELT GUIDE PIN- 1390	page35,39
NFH0003750	3/8" NF HEX NUT	page61	PIN0034892	N YOKE SHOCK PIVOT PIN, LOWER	page77
NFH0005000	1/2" NF HEX NUT	page39	PIN0035199	PAWL PIVOT PIN	page59
NFH0010320	HEX NUT, 10-32 NF, PLTD	page91	PIN0035288	N YOKE SHOCK PIVOT PIN, UPPER	page77
NFH0080500	1/2"-20 GRADE 8 HEX NUT-PLATED	page63	PIN0035759	SHORT BELT GUIDE PIN	page39
NFJ0000750	3/4" NF HEX JAM NUT-PLAIN	page25	PLG0031035	PLUNGER HARD SLIDE, 5/8 X 2	page43
NFL0000750	3/4" NF LH HEX NUT - PLATED	page75	PLG0031037	PLUNGER HARD SLIDE SHIM, 20 GA	page43
NFL0003125	HEX NUT, 5/16 NF, LH,PLTD	page69	PLG0031038	PLUNGER FRNT ROLLER RAIL UPPER	page31
NFX0003750	HEX JAM NUT, 3/8 NF, FLEX LOCK	page45	PLG0031042	PLUNGER ROLLER RAIL, LOWER REAR	page31
NMR6320500	MACHINE SCREW RH, 10-32 X 1/2 NF	page91	PLG0032677	RAIL,ROLLER,PLNGR,FRONT,LOW,LH	page31
NMS0000117	NUT, WHIZ, 5/16 UNC, p15,19,23,37,49,59,69,71,73,81,83		PLG0032678	RAIL,ROLLER,PLNGR,FRONT,LOW,RH	page31
NMS0000250	NUT, WHIZ, 1/4 UNC, PLATED p37,39,49,71,73,79		PLG0034588	FRONT PLUNGER ROLLER BOLT	page43
NMS0000252	NUT, WHIZ, 1/2 UNC, p15,23,25,39,45,59,61,77,79,81,83		PLG0035353	PLUNGER ROLLER RAIL, UPPER REAR	page31
NMS0000253	WHIZ NUT, 5/8 NC, PLTD	page25,47	PLG035924D	REAR PLUNGER SLIDE ASSEMBLY	page43
NMS0000375	WHIZ NUT, 3/8 NC,15,23,25,29,35,37,39,43,45,47,67,71,81		PLG035928A	PLUNGER SLIDE, FRONT	page43
NMS0001023	LUG NUT F/STD0165981-SP,53,54	page19	PLG036190F	PLUNGER WELDMENT	page43
NMS0005000	1/2" FLATWASHER - PLATED	page13	PLT0030664	BEARING CLAMP PLATE -1390	page57
NMS000TN13	BEARING LOCKNUT, TN13	page45	PLT0030665	FLYWHEEL HSG BEARING PLT-1390	page57
NP 0000100	SERIAL NO. ID PLATE	page99	PLT0031348	AUXILIARY CRANK LINK PLATE	page45

PARTS INDEX CONT.

PLT0031352	AUXILIARY DRIVE BRG MOUNTING PLT	page45	RNG5160075	RETAINING RING, 5160-075	page45
PLT0032291	FEEDER CHAIN GUIDE PLATE 1390	page71	ROD0030844	CONNECTING ROD	page43
PLT0033259	BELT IDLER NUT PLATE -1390	page39	ROD0032162	ROD, ACCELERATOR THROTTLE-1390	page53
PLT0033418	BELT GUIDE PLATE- 1390	page35	ROD0034577	PLGR STOP SPRING HOUSING- 1390	page75
PLT0035285	NEEDLE YOKE SHOCK LEVER PLATE	page77	ROD0034579	ROD, STOP, FRONT 1390	page75
PLT035839A	PLUNGER FACE CAP PLATE	page43	ROD0034872	PLG STOP SPG ADJ ROD- 1390	page75
PLT035870B	REAR CHAMBER YOKE TIE PLATE	page33	ROD0034894	TWINE FINGER DRIVE ROD	page69
PLT035870D	REAR CHAMBER YOKE TIE PLATE	page33	ROD0035081	CHAIN IDLER ADJUSTING ROD	page47
PLT035901D	MIDDLE CHAMBER YOKE TIE PLATE	page33	RS 0006003	TWINE DISC BUSHING F/KNT60060	page65
PMP12S8XG2	HYDRAULIC GEAR PUMP F/1390	page53,89	RS 0006022	KNIFE ARM BUSHING F/KNT60060	page65
PMP4731107	AUTO LUBER PUMP -WAS:F 8200	page71	RS 0010500	.5MM WASHER-WORM SHF & KNF ARM	page65
PNL0035729	CONTROL BOX PANEL COMPONENTS	page91	RS 3451926	PIN F/BILL HOOK CAM & SPRING	page65
PNL0035754	CONTROL BOX PANEL WIRING /COMP	page91	RS 5227344	SPIRAL PIN F/KNOTTER GEARS	page65
PRP0035351	TOP SHIELD PROP	page49	RS00006002	BILL HOOK BUSHING F/KNT60060	page65
PRP0035703	FAN SHROUD PROP	page73	RST0032128	RESTRICTOR,CHAMBER	page31
PUL0030770	IDLER PULLEY ASSEMBLY	page39	SCC0000201	SCREW, CAP, 5/16 X 3/4 UNC, PLATED	page37,49
PWB3751500	PLOW BOLT, 3/8 X 1 1/2 NC	page43	SCC0000204	HEX CAP SCREW, 5/16 X 1 1/2 NC	page31
REL0001002	RELAY SOCKET, 40 AMP SIEM	page91	SCC0000302	SCREW, CAP, HEX, 3/8 X 1, UNC	page23
REL0041F11	RELAY, SPST, 70 AMP, 12 VDC SIEM	page91	SCC0000308	HEX CAP SCREW, 3/8 X 2 1/2 NC	page31
REL5058963	RELAY, SPDT, 40 AMP, 12 VCD SIEM	page91	SCC0010000	SCREW, CAP, 1/4 X 1/2 UNC, PLATED	page73,79
REMOTE1390	TRACTOR REMOTE CONTROL- 1390	page91	SCC0010001	1/4 X 3/4 NC HT CS - PLATED	page19,73
RET0031144	FLYWHEEL RETAINER WASHER -1390	page35	SCC0010002	SCREW, CAP, 1/4 X 1 UNC, PLATED	page73
RET0516098	RETAINING RING 1390	page39	SCC0010003	HEX CS, 1/4 X 1 1/4 NC, PLTD	page69
RIV0000106	RIVET F/KNOTTER BRAKE LINING	page61	SCC0010004	1/4 X 1-1/2 NC HT CS - PLATED	page63
RIV0000122	SS RIVET-3/16 X .126-250 GRIP	page81	SCC0010005	1/4 X 1-3/4 NC HT CS - PLATED	page 17
RIV0000604	RIVET, GRIP, 3/16 X 1/4 SS	page37	SCC0010007	1/4 X 2-1/4 NC HT CS - PLATED	page71
RNG0002133	DRAWBAR MOUNT BEARING -1390	page13	SCC0010012	1/4 X 3-1/2 NC HT CS - PLATED	page61
RNG0002212	CAM LEVER O-RING, PARKER #2-212,	page23	SCC0010110	1" X 3-1/4" NC CAP SREW-PLATED	page19
RNG0002239	O RING, 3.609 ID X .139W, 2-239	page45	SCC0020001	5/16 X 3/4 NC HT CS - PLATED	page 17,81,83
RNG0023161	BEARING THRUST RING	page25	SCC0020002	SCREW, CAP, 5/16 X 1 UNC, PLATED	p49,53,69,73
RNG5000156	PLG STOP SPRING SNAP RNG- 1390	page75	SCC0020003	5/16 X 1-1/4 NC HT CS - PLATED	page61,69,73
RNG5000162	1-5/8"INTERNAL RETAINING RING	page25	SCC0020004	SCREW, CAP, HEX, 5/16 X 1 1/2, UNC,	page23,69
RNG5000244	1-1/2" NC ESNA NUT-PLATED	page13	SCC0020006	SCREW, CAP, 5/16 X 2 UNC, PLATED	page15,19,21
RNG5002281	RETAINING RING, BEVELED, N5002-281	page59	SCC0020007	5/16 X 2-1/4 NC HT CS - PLATED	page69
RNG5100196	RETAINING RING, EXT N5100-196	page43	SCC0020009	5/16 X 2-3/4 NC HT CS - PLATED	page53

PARTS INDEX CONT.

SCC0020011	SCREW, CAP, 5/16 X 3 3/4 UNC, PLATED	page83	SCCM110030	10M X 30M MC HEX HD CS-PLT-8.8	page57
SCC0030001	HEX CAP SCREW, 3/8 X 3/4 NC, PLTD	page71	SCCM11080	HEX CAP SCREW, M10 X 1.5 X 80mm,	page55
SCC0030002	3/8 X 1 NC HT CS - PLATED	page17	SCCM210025	10M X 25M MC HEX HD CS-PLT-8.8	page53
SCC0030002	3/8 X 1 NC HT CS - PLATED	page25,45,57	SCO0000202	F H SOCKET SCREW, 5/16 X 1, NC	page59,71
SCC0030003	3/8 X 1-1/4 NC HT CS - PLATED	page57,67,69	SCO0030003	HEX SOCKET CAP SCR, 3/8 X 1 1/4NC,	page43
SCC0030004	SCREW, CAP, 3/8 X 1 1/2 UNC, page15,25,47,61,63,67,		SCO0050004	FLAT SH, CS, 1/2 X 1 1/2 NC, PLTD	page77
SCC0030005	3/8 X 1-3/4 NC HT CS - PLATED	page67,81	SCOM110040	10M X 40M 1.5 SOCKET HD CS-8.8	page57
SCC0030007	3/8 X 2-1/4 NC HT CS -	page17,19,23,45	SCR0028976	SCREEN ATTACHMENT PANEL ASSY	page55
SCC0030009	3/8 X 2-3/4 NC HT CS - PLATED	page71	SDR0RA9320	FUEL LEVEL SENDER - 1390	page51
SCC0030011	SCREW, CAP, HEX, 3/8 X 3 1/4, UNC,	page23	SEL0034823	SEAL F/HUB	page19
SCC0030012	3/8 X 3-1/2 NC HT CS - PLATED	page61	SEL0045025	OIL SEAL C/R 45025 -1380	page35
SCC0030019	3/8 X 6-1/2 NC HT CS - PLATED	page35	SELV507949	BRG SEAL-USE W/SPC34397- 1390	page25
SCC0040004	7/16 X 1-1/2 NC HT CS - PLATED	page63	SFC0010000	HEX CAP SCREW, 1/4 X 1 3/4 NF, PLTD	page45
SCC0050003	1/2 X 1-1/4 NC HT CS - PLATED	page21,25,45,67	SFC0020001	HEX CAP SCREW, 5/16 X 3/4 NF, PLTD	page69
SCC0050004	HEX CAP SCREW, 1/2 X 1 1/2 NC, PLTD	p25,44,77,83	SFC0030003	HEX CAP SCREW, 3/8 X 1 1/4 NF, PLTD	page45
SCC0050005	1/2 HEX NUT NC PLATED	p13,15,43,47,77	SFC0034796	LOWER R. NDL YOKE BOLT- 1390	page75
SCC0050006	1/2 X 2 NC HT CS - PLATED	page39	SFC0050003	1/2 X 1-1/4 NF HT CS - PLATED	page39
SCC0050008	1/2 X 2-1/2 NC HT CS - PLTD	p19,21,23,25,67	SFC0080513	1/2"X 3.75"NF GRD 8 CS-PLTD	page63
SCC0050009	1/2 X 2-3/4 NC HT CS - PLATED	page21	SHD0032702	LEFT PICKUP SHIELD 1390	page19
SCC0050011	SCREW, CAP, HEX, 1/2 X 3 1/4, UNC,	page23,61	SHD0032703	RIGHT PICKUP SHIELD 1390	page21
SCC0050013	HEX CAP SCREW, 1/2 X 3 3/4 NC, PLTD	page59,63,67	SHD0033743	MAIN SHIELD	page37
SCC0050015	SCREW, CAP, 1/2 X 4 1/2 UNC, PLATED	page23	SHD0034301	ENGINE DRV BELT SHIELD- 1390	page53
SCC0050016	1/2 X 5 NC HT CS - PLATED	page39	SHD0034308	SHIELD, BELT - 1390	page39
SCC0050018	1/2 X 6 NC HT CS - PLATED	page47	SHD0034377	RIGHT FRONT SHIELD	page37
SCC0050019	SCREW, CAP, HEX, 1/2 X 6 1/2, UNC	page23	SHD0034378	LEFT FRONT SHIELD	page37
SCC0070004	HEX CAP SCREW, 5/8 X 1 1/2 NC, PLTD	page47	SHD0034802	SHIELD MANIFOLD, HYDRAULIC 1390	page51
SCC0070006	5/8 X 2 NC HT CS - PLATED	page25,47	SHD0035079	FRONT SHIELD STIFFENER	page37
SCC0070007	5/8 X 2-1/4 NC HT CS - PLATED	page25	SHD0035084	CONTROL BOX SHADE	page37
SCC0070008	5/8 X 2-1/2 NC HT CS - PLATED	page47	SHD0035085	FRONT SHIELD CORNER	page37
SCC0080010	3/4 X 3 NC HT CS - PLATED	page19	SHD0035123	TOP SHIELD STIFFENER	page49
SCC0080017	3/4 X 5-1/2 NC HT CS - PLATED	page19	SHD0035133	RIGHT FRONT SHIELD GUSSET	page37
SCC0100010	1" X 3 NC HT CS - PLTD	page47	SHD0035134	LEFT FRONT SHIELD GUSSET	page37
SCCM008030	8MM X 30MM MC HEX HD CS	page65	SHD0035336	KNOTTER FAN SHROUD REST, 15 1/2"	page73
SCCM108025	8MM X 25MM MC HEX HD CS	page65	SHD0035348	TOP SHIELD CORNER	page49
SCCM110020	10M X 20M MC HEX HD CS-ZP 8.8	page57	SHD0035677	TOP SHIELD	page49

PARTS INDEX CONT.

SHD0035683	FAN SHROUD TOP	page73	SMS0000182	WHIZ BOLT, 3/8 X 1 1/4 NC, PLTD	page29
SHD0035684	FAN SHROUD BACK	page73	SMS0000184	BOLT, WHIZ, 3/8 X 1 UNC, PLATED	page39
SHD0035685	FAN SHROUD STIFFENER	page73	SMS0000198	5/16 X 1/2 NC WHIZ BOLT-PLATED	page17
SHD0035692	ALTERNATOR BELT SHIELD ASSY	page55	SMS0000201	SMS #8 X 5/8 HEX HEAD TYPE AB	page47
SHD0035693	TOP SHIELD SIDE	page49	SMS0000403	BOLT, WHIZ, 1/2 X 1 1/4 UNC, PLATED	page39
SHF0032184	FEEDER TINE PIVOT SHAFT-1390	page25	SMS0000611	FLANGED 12 POINT CS, 1/2 X 1 3/4 NC	page77
SHF0032317	R.H.FEEDER DRIVE SHAFT -1390	page25	SMS0001390	OPEN EYE STEEL WIRE EYEBOLT-ZP	page39
SHF0032318	L.H.FEEDER DRIVE SHAFT —1390	page25	SMS0080319	FLNG 12 POINT CS, 3/8 X 2 1/2 NC	page43
SHF0032455	KNOTTER SHAFT- 1390	page63	SMT0001000	SCREW, TRUSS HEAD, 1/4 X 1/2 UNC	page79
SHF0032786	SHAFT, DRIVE, PICKUP	page23	SMT0002001	5/16 X 3/4 TH MACH SCREW-PLT	page19
SHF0033346	PLUNGER STOP SHAFT - 1390	page75	SMT0002001	5/16 X 3/4 TH MACH SCREW-PLT	page19
SHF0034018	TINE BAR CENTER SHAFT- 1390	page 17	SOK0000001	METAL BALL SOK END FITTING	page79
SHF0034539	CLUTCH BELLCRANK PIVOT ASSEMBLY	page39	SOK0000002	GAS SPRING BALL SOCKET	page37
SHM0000103	1-3/8 X 1-7/8 X.015 STEEL SHIM	page63	SOK0000007	SOCKET BOOT FOR 7 CONDUCTOR	page93
SHM0000105	1-3/8"X 1-7/8 X.020 STEEL SHIM	page63	SOK0012310	ELECTRICAL SOCKET, 7 POLE	page93
SHM0031948	BOTTOM CHAMBER LINER SHIM	page31	SPC0031714	PARKER O'RING-NITRILE COMPOUND	page13
SHM0033448	PLUNGER STOP SHIM - 1390	page75	SPC0032289	SPACER, 1 1/4 OD X 5/16 W X 13/16 LG	page47
SHM0034430	DRAWBAR BEARING SPACER-1390	page13	SPC0032740	SPACER, IDLER, PICKUP	page23
SHM0035661	INNER PLUNGER KNIFE SHIM, 16 GA	page43	SPC0033343	SPACER, STOP, PLUNGER-1390	page75
SHM0035662	INNER PLUNGER KNIFE SHIM, 30 GA	page43	SPC0034170	BELT IDLER OUTER GUD SPC- 1390	page39
SHM036237A	OUTER PLUNGER KNIFE SHIM, 16 GA	page43	SPC0034229	PICKUP SPRING SPACER- 1390	page19
SHM036238A	OUTER PLUNGER KNIFE SHIM, 30 GA	page43	SPC0034242	TOP TENSION RAIL SPACER- 1390	page33
SHO0144279	SHOCK ABSORBER, 144279	page77	SPC0034397	FEEDER BRG SEAL SPACER- 1390	page25
SHV0030660	DRIVE BELT SHEAVE -1390	page57	SPC0035239	KNT LUBER PMP MNT SPACER- 1390	page47
SMF0001001	1/4 X 3/4 FH MACH SCREW-PLT	page53	SPC0035477	SCREEN PANEL SPACER TUBE PLATE	page55
SMF0002001	5/16 X 3/4 FH MACH. SCR - PLTD	page51	SPC0035689	AIR SCREEN SPACER	page55
SMF1032500	10-32 X 1/2 FH MACHINE SCREW	page19	SPC0035701	HINGE SPACER	page55
SMR1032500	MACHINE SCREW, RH, 10-32 X 1/2 NF,	page91	SPC035827A	BELT DRIVE SPINDLE SPACER	page57
SMR1032750	MACHINE SCREW, 10-32 X 3/4 NF, PLTD	page91	SPG0000002	GAS SPRING, McMaster-Carr	page37
SMR4405000	MACHINE SCREW, #4-40 X 1/2, PLT	page91	SPG0000090	TWINE BOX LID GAS SPRING	page79
SMS0000172	BOLT, WHIZ, 1/4 X 3/4 UNC, PLATED	page37,49	SPG0020662	PLUNGER LATCH SPRING 370	page39,75
SMS0000173	BOLT, WHIZ, 1/4 X 1/2 UNC, PLATED	page37,49,73	SPG0023160	SIDE HAY DOG SPRING-A/95 -1590	page63
SMS0000179	WHIZ BOLT, 3/8 X 1 NC, PLTD	page31	SPG0025466	KNT HOOK CAM ADJ SPRING	page65
SMS0000181	BOLT, WHIZ, 3/8 X 3/4, UNC, PLATED	page23	SPG0035332	LEAF SPRING, 3 1/2"	page29
SMS0000181	WHIZ BOLT, 3/8 X 3/4 NC, PLTD	page31,39,43	SPG0035333	LEAF SPRING, 5"	page29

PARTS INDEX CONT.

SPG0035334	LEAF SPRING, 6 1/2"	page29	STR0035597	CENTER FEEDER STRIPPER	page25
SPG0035335	LEAF SPRING, 8"	page29	STS2500313	SET SCREW, SOCKET, 1/4 X 5/16	page67
SPG1000175	PLUNGER STOP DOG SPRING-1390	page75	SUP0032163	THROTTLE ACCEL SWIVEL SUP-1390	page53
SPG1500800	PLUNGER STOP CAM SPRING-1390	page75	SUP0034447	LIGHT SUPPORT- 1390	page81
SPGE758535	SPRING, 3/4 OD X 3 1/2 LG X .085 WIRE,	page59	SUP0035328	AIR CLEANER SUPPORT	page55
SPK0000100	FDR DRV IDLER SPROCKET- 1390	page47	SUP0035476	SCREEN PANEL SUPPORT	page55
SPK0002416	SPROCKET, IDLER, 50 CHAIN, 17 T	page23,47	SUP0035489	GEAR BOX SUP ASSY, UPPER REAR	page27
SPK0031501	FEEDER DRIVE SPROCKET	page45	SWI0000003	ROCKER SWITCH, 2 POS, MAINTAINED,	page91
SPK0033110	PUMP SPROCKET, #60A14, 1" BORE	page71	SWI0000007	ROCKER SWITCH, 3 POS, MOMENTARY,	page91
SPK0033113	KNOTTER DRIVE SPROCKET	page45	SWI0000004	PUSHBUTTON SWITCH, SPST, NO,	page91
SPK0033912	SPROCKET, PICKUP, DRIVEN	page23	SWI0ZA2BG3	KEYSWITCH OPERATOR, 3 POSITION	page91
SPK0050B24	SPROCKET, AUGER, RIGHT	page23	SWI0ZA2BG3	KEYSWITCH OPERATOR, 3 POSITION,	page91
SPK0050B32	SPROCKET, RIGHT, REEL, PICKUP	page23	SWI8UMT12P	INDUCTIVE PROXIMITY SENSOR	page93
SPK0060B18	SPROCKET, AUGER, LEFT	page23	SWI2A2BZ10	SWITCH CONTACT BLOCK ASSY	page91
SPK0100E30	SPROCKET-FEEDER ASSEMBLY-1390	page25	TEB0002140	TERMINAL BLOCK, 2 POS, #2-140	page91
SPK060SK33	P/U DRIVE SPROCKET-1390	page25	TER0491022	BLOCK SPADE, #6 STUD, 18/22 GA	page91
SPK60BTB24	SPROCKET, LEFT, REEL, PICKUP	page23	TIN0034001	TINE, FEEDER - 1390	page25
SPN0030661	BELT DRIVE SPINDLE ASSY -1390	page57	TIN0034907	FEEDER PIVOT TINE ASSY- 1390	page25
SPN0033158	HIWAY TIRE BALER SPINDLE	page95	TIR0004008	TIRE F/1500 P/U(400X8 4 PLY)	page19
SPN0034103	PICKUP WHEEL SPINDLE - 1390	page19	TIR0199128	4.00 X 8 TUBE F/TIR4008	page19
SPN0034224	FIELD TIRE BALER SPINDLE-1390	page95	TIR14175F3	HIWAY TIRE 14 X 17.5-14 PLY	page95
SQS3751000	3/8 X 1" SQUARE HD SET SCREW	page63	TIR4006020	FIELD TIRE ONLY	page95
STD0000M10	10mm BALL STUD FOR SPG0000090	page79	TIR4060155	FIELD TIRE AND WHEEL ASSY-1390	page95
STD0000M13	GAS SPRING BALL STUD #9416K83	page37	TNK0032767	30 GAL. FUEL TANK/AFT 12/99	page51
STO0034879	STOP, GUARD, WIND, LEFT-1390	page15	TNK004Z980	HYD RESERVOIR W/FILL NECK-5GAL	page51
STO0034880	STOP, GUARD, WIND, RIGHT - 1390	page15	TNK035761D	KNOTTER LUBER TANK	page71
STO0035484	METER TRIP BAR STOP ASSY	page67	TNS0033586	TOP (LH ONLY) & BTM TNS RAIL	page33
STP0035717	LEFT STEP ASSEMBLY	page81	TNS0033587	TOP R.H. TENSION RAIL - 1390	page33
STP0035718	RIGHT STEP ASSEMBLY	page81	TNS0033588	BEAM, RAIL, TENSION - 1390	page33
STR0032060	STRIPPER, CENTER, PICKUP—1390	page17	TNS0033601	SIDE TENSION RAIL - 1390	page33
STR0032387	LEFT END STRIPPER-PICKUP- 1390	page17	TNS0033671	TENSIONER, CHAIN, PICKUP	page23
STR0032388	RIGHT END STRIPPER-PICKUP-1390	page17	TNS0035577	HORIZONTAL TNS RAIL SQZ	page33
STR0035574	FEEDER CENTER STRIPPER MNT ASSY	page25	TUB0034679	HYD.TUBE, PUMP TO FILTER	page89
STR0035595	LH FEEDER STRIPPER	page25	TUB0034789	HYD TUBE ASSY	page71
STR0035596	RH FEEDER STRIPPER	page25	TUB0034833	HYD TUBE, H PORT-ACCUM.	page89

PARTS INDEX CONT.

TUB0034834	HYD TUBE,TNS TO CYL ROD END	page85	WAS0015783	HARDENED ZZ228 MACHINE BUSHING	page23
TUB0034835	HYD.TUBE, TANK TO FILTER	page89	WAS0034578	WASHER, STOP, PLUNGER 1390	page75
TUB0034839	HYD TUBE,TNS REL VLV TO CYL	page85	WAS00TW113	BEARING LOCKWASHER, TW 113	page45
TUB0034839	HYD TUBE, LOWER TENSION	page89	WAS5710199	WASHER, .566 ID X1.05 OD X .06 TH, SS,	page77
TUB0034843	HYD TUBE,PORT B TO BULKHEAD	page89	WCT0000250	1/4" FLATWASHER - PLATED	page19,61,71
TUB0034871	HYD TUBE, PORT G-PORT IN	page89	WCT0000313	5/16" FLATWASHER-p15,19,23,37,53,61,65,69,73,79,83	
TUB0035709	INTAKE TUBE, 4" OD X 3/4" LG	page55	WCT0000375	3/8" FLATWASHER p15,17,19,21,23,35,47,61,63,69,71	
TUB0037500	3/8" BUNDY TUBING, 1" LONG	page69	WCT0000438	7/16" FLATWASHER - PLATED	page63
UBL0034451	4 X 5, 1/2 NC SQ BEND U-BOLT	page79,81	WCT0000500	1/2 X 1-3/4 NC HT CSp13,15,17,19,21,23,47,63,83	
UBL0034520	U BOLT, 5/16 UNF	page29	WCT0000625	5/8" FLATWASHER -PLATED	page19,47
VLV0000003	KNOTTER LUBE VALVE ASSY-1390	page71	WCT000313	FLAT WASHER, 5/16, PLTD	page69
VLV0000415	VALVE STEM	page95	WCTM100100	10 MM FLATWASHER - PLTD	page53,55
VLV0000500	SELECTOR VALVE -WAS:01-504	page85	WHL0000001	FIELD WHEEL ONLY	page95
VLV002X611	CHECK VALVE 3/4" NPT - 1390	page89	WHL0175105	HIWAY WHEEL 17.5 X 10.5	page95
VLV0031751	VALVE MANIFOLD BLOCK, 6061-T6511	page87	WHL0401530	WHL/TIR ASSY.4 X 8	page19
VLV3175100	MAIN HYD VALVE COMPLETE- 1390	page87	WHL0412530	WHEEL-8 X 3.75(4 ON 4)P/U	page19
VLV7114920	PROP/CONTROLLER/AMPLIFIER-1390	page87	WHLHWY1390	HIWAY TIRE AND WHEEL ASSY	page95
VLVCNCC116	1/16 FIXED ORIFICE RESTIRC CAR	page87	WIS0000600	WASHER, INTERNAL STAR, #6	page91
VLVCNCC132	1/32 FIXED ORIFICE RESTRIC CAR	page87	WIS0001000	WASHER, INTERNAL STAR, #10	page91
VLVCNCC164	SUN CNCC-XEN 1/64 FIXED RSTRCCR	page87	WIS0003125	INTERNAL STAR WASHER, 5/16, PLTD	page69
VLVCP5081B	POPPET SOLENOID VALVE,NC	page87	WIS0005625	9/16 INTERNAL STAR WASHER-PLT	page85,89
VLVCP5082B	POPPET SOLENOID VALVE.NO	page87	WLK0000100	#10 LOCKWASHER - PLATED	page19
VLVCP55820	PROPORTIONAL RELIER VALVE	page87	WLK0000250	1/4" LOCKWASHER - PLATED	page19
VLVCXCDXCN	CHECK VALVE CARTRIDGE	page87	WLK0000313	5/16" MEDIUM LOCKWASHER	p 17,19,21,29,53
VLVCXDAXCN	SUN CHECK VALVE CARTRIDGE-1390	page87	WLK0000375	3/8" MEDIUM LOCKWASHER p17,19,21,47,57,61,65,67,69	
VLVPVDALEN	PILOTED PRESS REDUCING VALVE	page87	WLK0000438	7/16" LOCKWASHER - PLATED	page63
VLVQCDALAN	DIFFERENTIAL UNLOAD PILOT CART	page87	WLK0000500	1/2" LOCKWASHER p13,17,21,43,47,63,67,75,77	
VLVRVCALAN	PILOTED RELIEF CARTRIDGE-1390	page87	WLK0000625	5/8" MEDIUM LOCKWASHER - PLTD	page47,77
WAS0000104	1/2"A-325 STRUCTURAL WASHER	page63	WLK0000500	SPLIT LOCK WASHER, 1/2	page25
WAS0000110	1" SAE FLAT WASHER	page47	WLKM000080	8 MM LOCKWASHER	page65
WAS0000118	3/4 A325 STRUCTURAL WASHER-ZP	page19,25	WLKM000100	10 MM LOCKWASHER	page53
WAS0000128	1/2 SAE FLATWASHER	page39	WLKM100100	SPLIT LOCK WASHER, M10, PLTD	page55,57
WAS0000128	FLAT WASHER, 1/2, PLTD	page47	YOK0031895	BOTTOM REAR CHAMBER YOKE—1390	page33
WAS0000138	3/8" SAE FLATWASHER-PLATED	page39	YOK0034479	NEEDLE YOKE ASSY, RASSPE	page75,77
WAS0000141	FLAT WASHER, 5/8	page43,77	YOK0034643	WIND GUARD YOKE- 1390	page15

PARTS INDEX CONT.

YOK0035572	TOP REAR CHAMBER YOKE ASSY	page33
YOK035878D	MIDDLE CHAMBER YOKE	page33
ZZ 0000103	GREASE ZERK, 1/8 NPT STRAIGHT	page25
ZZ 0000201	MACHINE BUSHING, 3/4 X 1 1/4 X 18 GA	page45
ZZ 0000214	1X1-1/2X14 GA MACHINE BUSHING	page39
ZZ 0000219	1 X 2 X 14 GA MACHINE BUSHING	page19
ZZ 0000220	MACHINERY BSH, 3/4 X 1 1/4 X 10 GA	page59,75,77
ZZ 0000411	KEY, 3/8 X 5/16 X 2	page59
ZZ 0000411	3/8 X 5/16 X 2 KEY (HITON SHV)	page59
ZZ 0000433	3/8 X 5/16 X 1-1/2 KEY	page63
ZZ 0000434	3/8 X 5/16 X 3 LONG KEY	page61,63
ZZ 0000435	3/8 X 5/16 X 1-1/4 LONG KEY	page63
ZZ 0000440	3/8 X 5/16 X 3/4 LONG KEY	page63
ZZ 0000447	KEY 1/2 X 1/2 X 2 1/2	page25
ZZ 0000451	1/2 X 1/2 X 1-1/2 KEY	page25
ZZ 0000463	KEY, 3/8 X 1/2 X 3 3/4	page45
ZZ 0002003	1" STEEL SET COLLAR	page67
ZZ00000208	WASHER, MACHINE, 7/8 X 18 GA	page23
ZZ00000418	KEY, 1/4 X 1/4 X 3/4	page23
ZZ00000454	KEY, 1/4 X 1/4 X 2	page23
ZZ0000428	KEY, 5/16 X 5/16 X 1"	page23

CALIFORNIA

Proposition 65 Warning
Diesel engine exhaust and some
of its constituents are known to
the State of California to cause
cancer, birth defects, and other
reproductive harm.

