

Wheel End And Differential Kit



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
249169 Wheel End And Differential Kit							
1	*a 216149	2	. Internal Gear Hub	29	216156	2	. Oil Seal
2	*a 212114	2	. Internal Gear	30	216146	2	. Bearing Cone
3	201634	6	. Capscrew	33	*d 219240	2	. Hub, Cup, & Stud Assembly
4	200970	2	. Thrust Washer	34	*c 201143	2	. Bearing Cup
5	200968	2	. O-Ring	35	201148	2	. Bearing Cone
13	200963	2	. Sun Gear	37	*c 219233	68	. Stud
14	201093	2	. Snap Ring	37A	-----	68	. Nut (See Axle Installation)
15	211821	2	. O-Ring	37B	-----	68	. Washer (See Axle Installation)
16	*b 201231	2	. Thrust Washer	38	*c 229968	68	. Nut
17	211820	2	. Cover Assembly	39	*c 240437	2	. Bearing Cup
18	211954	2	. Plug	40	* 240438	1	. Differential & Carrier Assembly
19	221616W	18	. Capscrew	41	214145	18	. Stud
20	200762	18	. Washer	42	214146	4	. Stud
21	205722	2	. Plug	43	207488	22	. Washer
22	211960	36	. Capscrew	44	223615	22	. Nut
23	204882	36	. Washer	46	217874	12	. Dowel
24	230705	2	. Nut	48	* 211953	2	. Planet Carrier Assembly
25	*a 212121	12	. Plate	*a Included In 214939 Internal Gear & Hub Assembly.			
26	*a 232340	24	. Capscrew	*b Included In 211820 Cover Assembly.			
27	248619	2	. Spindle	*c Included In 219240 Hub, Cup, & Stud Assembly.			
27A	219246	24	. Stud	*d Not Used on Machines with Dual Wheels. See Axle Parts Page.			
27B	*e -----	24	. Washer	*e Not Included. See Axle Parts Page and Order Separately.			
27C	*e -----	24	. Nut	* See Separate Coverage.			
28	*d 216157	2	. Oil Catcher				