


Joystick Handle



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	<b>251323</b>		<b>Joystick Handle</b>				
1	249900	1	. Faceplate Assy, 2 Button	10	256874	5	. Capscrew
4	250627	2	. . Momentary Switch	11	591312	1	. Wire Harness With Grommet
6	250173	1	. Handle Case, Right	12	259043	1	. Adapter Bushing
7	250174	1	. Handle Case, Left	13	249912	1	. Flex Button Repair Kit
8	249907	1	. Trigger Insert	14	256875	5	. Lockwasher
9	249908	1	. Mounting Pin				