

DATE: June 18, 2013

PAGE: 1 of 1

BULLETIN NO .: WSB0398

SECTION: 3-4 (Axles)

MODEL(S): All Wagner Logstackers,
Chipdozers, and Coal Dozers with
Dana Axles

ATTENTION: WAGNER DEALERS, PARTS AND SERVICE MANAGERS

SUBJECT: WHEEL BEARING PRELOAD CHECK

To protect major components from damage, we have updated our service intervals to ensure proper wheel bearing preload.

At the 2,000 hour service interval, in addition to draining and refilling the differential and planetaries, the wheel bearing preload should be reset.

Please refer to the following Allied Wagner documents for proper procedures:

- 25D axles (Logstackers) refer to [80-1041](#)
- 53R axles (Dozers) refer to [80-790](#)
- 21D axles (Dozers) refer to [80-874](#)

For questions or concerns, please contact your local dealer or Allied Systems Company Service Department at (503) 625-2560.