

Understanding Wagner Parts Pages

Item

Index numbers found in this column correspond to the numbers found on the respective parts location illustration. Some items are shown for reference purposes only to illustrate their relationship to other systems.

Part No

This column lists the Allied Systems Company Part Number.

Qty

This column lists the total number of a specific item required per assembly or subassembly. This number may not necessarily be the number of items used in the end item or system. Only one set of components is listed whenever the components of two assemblies are the same.

“A/R” (as required) identifies bulk items whose length or other dimension must be specified when requisitioning.

“Ref” identifies items shown for reference purposes only to illustrate their relationship to other systems.

“NSS” (not sold separately) identifies items such as valve housings and spools, ring gears and pinions, etc., which must be ordered as a set because they are closely mated at manufacture.

Description

This column lists the item nomenclature along with those modifiers necessary to identify the item. Additionally, cross references for repairable subassemblies are listed in this column.

One dot preceding the description indicates that the item is a component part of the previously listed item or assembly with no dot. Two dots indicate that the item is part of the previously listed item with one dot.

Example:

Electric Swivel

. Collector Ring Assembly

. . Screw

. . Brush Holder Assembly

. . . Brush Spring

The Collector Ring Assembly is a first level subassembly of the Electric Swivel as indicated with one dot. The Screw and the Brush Holder Assembly are second level components of the Collector Ring Assembly as indicated by the two dots. The Brush Spring is a third level component of the Brush Holder Assembly which is indicated with three dots.