

Lubrication L90

Proper and consistent lubrication of articulation points on your Wagner is vital to the longevity of your machine.

An optional central lubrication system will lubricate most of the points on your Wagner, but inspection of these points is still necessary to ensure the system is working properly.

Note: Manual lubrication is always required for the drivelines, and the steering column.

Note: The drivelines require a different grease than the rest of the machine. See Fluids chart in Section 5-2, or the tables on page 2 for details.




Figure 1 Lubrication Points

Lubrication Schedule

Refer to: Figure 1

10 Hours		
Before engine startup, check the following:		
①	Steering Cylinder Pins	Mobilgrease Special No. 2
②	Boom To Chassis Pins	
③	Boom To Carriage Pins *a	
④ & ⑤	Hoist Cylinder Pins *a	
⑥ & ⑦	Tilt Cylinder Pins	
⑧	Holddown Arm Pins	
⑨	Kickoff Arm Pins	
⑩	Holddown Cylinder Pins	
⑪	Kickoff Cylinder Pins	
50 Hours		
⑫	Driveline Cross Assemblies *b*c (refer to service form 80-627)	Mobilith SHC 220 Grease
250 Hours		
⑰	Seat Platform Swivel Bearing *c (grease fitting located under cab)	Mobilith SHC 220 Grease
500 Hours		
⑭	Tailwheel Bearing	Mobilgrease Special No. 2
⑮	Tailpost	
1000 Hours		
⑬	Driveline Slip Yokes *b*c (refer to service form 80-627)	Mobilith SHC 220 Grease
2000 Hours		
⑯	Steering Column U-Joints *c	Mobilgrease Special No. 2

Figure a When operating in water, lubricate submerged points more frequently.

Figure b Use handgun or lower pressure adaptor; lubricate sparingly.

Figure c Not lubricated by optional automatic grease system or central lube system.

3

INTENTIONALLY LEFT BLANK