
OPERATOR'S MANUAL

CHD60 *CHIP DOZER*



Allied *Wagner*

9. Practice moving the machine around the yard. Make several practice stops to develop a “feel” for the brakes. Practice driving and steering in forward and reverse. Always use the brakes to slow and stop the machine - never gear down.



CAUTION

CAUTION: Keep the speed low until you feel comfortable with the machine.

Always bring the machine to a complete stop before changing direction. Changing direction while in motion will put tremendous loads on drivetrain components, especially the drivelines. Premature wear and failure can result.

NOTE: It is recommended that you keep the declutch control in the ON position for normal travelling. In this position, the transmission is “declutched” or disconnected whenever the brake pedal is depressed. If a downgrade is encountered, the declutch control may be placed in the OFF position, and the transmission will remain in gear while braking.



WARNING

WARNING: For greatest productivity the chip dozer is designed to doze; however, it can also be used to pick and carry in limited operations. The dozer should be operated in reverse for greater safety when it is carrying a loaded bucket because of restricted forward vision. Attempting to drive the machine forward when carrying a loaded bucket could result in personal injury and/or damage to equipment.