

Suggested Spares Guide HLT185-615

This suggested spares guide is specifically developed for this serial number. The parts are grouped into 4 tiers, with each tier representing a higher level of support. The items in tier 1 will be required for periodic maintenance within the first year.

Tier 1 - Maintenance - Includes all periodic maintenance items, some wear items, specialized tools, etc.

Tier 2 - Basic - Includes wear items, specialized tools, rebuild kits, etc.

Tier 3 - Intermediate - Includes some key, larger, longer lead-time items.

Tier 4 - Advanced - Includes rebuild kits for major assemblies, complete cylinders, etc.

Tier 1 - Maintenance

Allied P/N	Description	Where Used	Quantity on Machine	Order Quantity
230463	Filter Element, Breather	224744	1	
247429	Filter Element, Spin-On, Brake Cooling and Transmission	605367	3	
		604868		
259470	Service Kit, Return Filter	600875	1	
260916	Primary Fuel Filter	603940	1	
260917	Secondary Fuel Filter	603940	1	
261371	Filter, DEF	261351	1	
600156	Primary Element, Air Cleaner	261357	2	
600157	Secondary Element, Air Cleaner	261357	2	
R12968390	Filter Element, Hydraulic High Pressure	603741	3	
R15593	Element, Filter	603940	1	
R233598	Breather, 1-Way	256298	1	
261342	Belt, Alternator Drive	603940	1	
256059	Accumulator Charging Kit	590154	1	
208136	Air Filter Indicator	603976	1	
602781	Blade, Wiper	604905	1	
605228	Wiper Motor Assy	604905	2	
606270	Blade, Wiper, 24"	604905	1	

Suggested Spares Guide HLT185-615

Tier 2 - Basic

Allied P/N	Description	Where Used	Quantity on Machine	Order Quantity
83246	Resistor, 2700 Ohm	604879	1	
237172	Resistor, 1k Ohm	605366	4	
		605365		
241893	Resistor, 18k Ohm	605376	2	
		605376		
601846	Housing - Receptacle, W/ Diode	605730	2	
246905	Sensor, Press Transducer	604868	1	
246908	Sensor, Temp	604005	1	
251424	Fluid Temp. Sensor	603982	2	
		605509		
587434	Digital Speed Sensor	604868	1	
598644	Linear Position Sensor	603981	1	
600238	Sensor, Coolant Level	603976	1	
598153	Pressure Transducer	603982	10	
		605367		
		605629		
		605507		
		605521		
598718	Pressure Transducer	605509	2	
605405	Relay, Micro, 12v, SPDT	604905	15	
		605376		
258338	Floodlight	603981	2	
602271	Gasket, Hydraulic Tank Dirt Box Cover	605531	1	
505499	Gasket, Pump, SAE C Drive	604005	2	
599410	Pressure Cap, Surge Tank	601066	1	
603762	Vibration Dampener	604005	4	
598449	U-Joint, 8.5C	605059	1	
598449	U-Joint, 8.5C	604435	2	
598451	U-Joint, 9C	604436	1	
606217	U-Joint Bearing	604436	1	
596778	Kit, Brake Lining - Parking	596760	1	
578377	Seal Kit, Hydraulic Cylinder, Suspension	578308	15	
	Seal Kit, Hydraulic Cylinder w/Sensor Mount	605075	1	
009-1508	Seal Kit, Hydraulic Cylinder, Steering	578619	4	

Suggested Spares Guide HLT185-615

Tier 2 - Basic (Continued)

Allied P/N	Description	Where Used	Quantity on Machine	Order Quantity
261590	Seal Ring Sleeve Driver	Service Tools		
261591	Seal Ring Sleeve Driver			
261592	Spanner For Bearing Adjustment Ring			
261593	Seal Ring Sleeve Driver			
261594	Seal Ring Sleeve Driver			
261595	Centering Tool For Disks			
261596	Installation Tool For Face Seal			
596633	Wrench, Spanner			
593471	Piston Loading Sleeve for Accumulator			

Suggested Spares Guide HLT185-615

Tier 3 - Intermediate

Allied P/N	Description	Where Used	Quantity on Machine	Order Quantity
261388	Evaporator	605388	1	
261390	Fan/Motor Assembly		1	
261391	Motor, Double Blower		1	
261395	Thermostat		1	
261400	Valve, Expansion		1	
261402	Kit, Gasket, Air Conditioner		1	
588533	Heater	605152	1	
604007	Wagner Smart Screen	604903	1	
602111	Expansion Module	603981	1	
597011	Pump, Charge	603970	1	
247011	Pump, Tandem	604005	1	
604823	Pump, Tandem	604005	1	
605274	Compressor w/Tank	603966	1	
R16271	Accumulator	603979	4	
221-0100	Motor, Hydraulic	605508	4	
234990	Steering Flow Amplifier	603982	1	
604435	Driveline Assembly	603964	1	
604436	Driveline Assembly		1	
604867	Driveline Assembly		1	
605059	Driveline Assembly		1	

Suggested Spares Guide HLT185-615

Tier 4 - Advanced

Allied P/N	Description	Where Used	Quantity on Machine	Order Quantity
261597	Kit, Service, Front Axle	604809	1	
261601	Kit, Service, Rear Axle	604810	1	
261600	Kit, Service, Differential	261582	1	
261604	Kit, Service, Differential	261518	1	
261598	Lining Kit, Service Brake	261426	2	
261599	Seal Kit, Service Brake	261426	2	
261602	Brake Lining Kit, Service Axle	261510	2	
261603	Seal Kit, Service Brake	261510	2	
596779	Seal Kit, Parking Brake	596760	1	
260904	Kit, Service, Transmission	603695	1	
578308	Hydraulic Cylinder, Suspension	583085	15	
		603971		
578619	Hydraulic Cylinder, Steering	587753	4	
605075	Hydraulic Cylinder w/Sensor Mount	603971	1	