

# Overhead Controls




Figure 2-4-1 Overhead Controls

## 1. Rear Wiper - Wipe/Wash

Three position: Off  
On  
Wash

## 2. Rear Intermittent Wiper Speed

Three position: Intermittent  
Low  
High

## 3. Front Wiper - Wipe/Wash

Three position: Off  
On  
Wash

## 4. Front Intermittent Wiper Speed

Three position: Intermittent  
Low  
High

## 5. Front Defrost Fan

Two position: Off  
On

## 6. Rear Light Switch

Chassis mounted rear lights.

## 7. Front Light Switch

Cab mounted front lights.

## 8. Panel Lights Dimmer Control

Dims and brightens rocker switches and hydraulic oil temperature gauge.

## 9. LED Lights Dimmer Control

Dims and brightens filter indicator and direction/shift lights

## 10. \* Brake System High Pressure Filter Indicator Light

## 11. \* Steering System High Pressure Filter Indicator Light

## 12. \* RAD/CAC Fan Filter Indicator Light

## 13. \* Hydraulic Cooler Fan Filter Indicator Light

## 14. \* Main High Pressure Filter Indicator Light

## 15. \* Hydraulic System Return Filter Indicator

\* These lights indicate the condition of the high pressure supply filters. With the machine running and at operation temperature, the lights should be off. If the indicator light(s) come on and stay on, filter service is required. Indicator lights will illuminate during starting to confirm light operation.

**NOTE:** In cold operating conditions, these lights may come on and flicker until oil reaches operating temperature. This is normal.

## 16. Stereo/CD Player (optional)

AM /FM Radio and CD player.

---

**INTENTIONALLY LEFT BLANK**