


Air Tank Assembly



6 TANK BRACKET NOT SHOWN

VIEW A-A

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	<b>577408</b>		<b>Air Tank Assembly</b>				
1	00119931	1	. Bushing, Reducer	11	209416	1	. Fitting
2	209632	1	. Fitting	12	15280	1	. Fitting
4	207901	1	. Relief Valve	13	* 232914	1	. Expello Valve - 24V
5	207904	1	. Air Tank Assembly	14	209500	1	. Fitting
6	207905	2	. Bracket Assembly	15	210299	1	. Air Cleaner
7	207917	1	. Check Valve	16	00144034	1	. Bushing, Reducer
9	209405	1	. Fitting				

\* See Separate Coverage