

NOTE: WIRES REPRESENTED WITH PHANTOM LINES INDICATE OPTIONAL EQUIPMENT. SEE SALES ORDER FOR SPECIFIC OPTIONS FOR EACH MACHINE.


INSTRUMENT PANEL

TERMINAL PANEL

JUNCTION BOX

COW/CAB

CHASSIS/POWER UNIT/CARRIAGE



**LEGEND**

TERMINAL BLOCK (GENERAL USE)	TERMINAL BLOCK (OPTIONAL)	TERMINAL BLOCK (GENERAL USE)	TERMINAL BLOCK (GENERAL USE)	TERMINAL BLOCK (GENERAL USE)
CONNECTION PREFIX LETTER	CONNECTION PREFIX LETTER	CONNECTION PREFIX LETTER	CONNECTION PREFIX LETTER	CONNECTION PREFIX LETTER
GROUND	GROUND	GROUND	GROUND	GROUND

NOTE: NUMBER ALL DEDICATED GROUND TERMINALS WITH 100 OR 200.