


Kit, Gauge Hydraulic Oil Temperature

Kit, Gauge Hydraulic Oil Temperature

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	586920		Kit,Gauge Hydraulic Oil Temp	5	200247	1	. Terminal Ring
1	586988	1	. Mounting Cup, Gauge	6	236667	3	. Terminal Ring
2	242437	1	. Converter Temp Gauge	7	231708	25'	. Wire
3	243334	1	. Sender, Oil Temp	8	237627	2'	. Wire
4	236924	2	. Terminal Block	9	219437	2'	. Wire
				10	219436	2'	. Wire


NOTES:

1. THREAD SEALANT NOT NECESSARY
ROUTE WIRE ALONG EXISTING HARNESSSES
2. REFER TO SHEET 2 OF 2 FOR WIRING INFORMATION.




GAUGE MOUNTING DETAIL

SEE DETAIL A




MAIN VALVE PLATE

REMOVE 3/8 NPT PLUG
FROM THIS POSITION
AND INSTALL ITEM 3



DETAIL A



LEGEND

	= DEDICATED GROUND TERM. BLOCK
	= CHASSIS GROUND
	= TERM. BLOCK
	= TERMINAL BLOCK CONNECTION
	= 4 TERMINAL BLOCK
	= MANUAL RESET CIRCUIT BREAKER
	= F/M CONNECTION
	= DEUTSCH F/M CONNECTION
	= METRI-PAK F/M CONNECTION
	= WEATHER PACK F/M CONNECTION