


Handle, Joystick; 3 Button



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
588939 Handle, Joystick; 3 Button							
1	253037	4	. Screw	12	256874	6	. Capscrew
2	594022	1	. Switch Pack Assembly, 3 Button	13	249910	1	. Grommet
3	259038	1	. Empty Faceplate	14	587274	1	. Adapter Bushing
4	250627	5	. Switch	15	587277	1	. Wire Harness
5	-----	1	. Button Overlay	16	256875	6	. Washer, Lock
6	249904	6	. Screw	17	587710	5	. Plug
7	587275	1	. Handle, RH Side				
8	587276	1	. Handle, LH Side				
9	588944	1	. Trigger				
10	253042	1	. Leaf Spring For Trigger				
11	249908	1	. Mounting Pin				