


Accumulator; Pre-Charge 975 psi



| Item                                                             | Part No.  | Qty | Description     | Item | Part No. | Qty | Description           |
|------------------------------------------------------------------|-----------|-----|-----------------|------|----------|-----|-----------------------|
| <b>590154                    Accumulator; Pre-Charge 975 psi</b> |           |     |                 |      |          |     |                       |
| 2                                                                | 261605    | 1   | . Hydraulic Cap | 7    | *a ----- | 2   | . End Seal O-Ring     |
| 3                                                                | 261606    | 1   | . Gas Cap       | 7A   | *a ----- | 2   | . Backup Ring         |
| 4                                                                | *b R15676 | 1   | . Piston        | 8    | 261607   | 1   | . Gas Valve Assembly  |
| 5                                                                | *a -----  | 1   | . V O-Ring      | 8B   | 238516   | 1   | . Cap, Valve          |
| 5A                                                               | *a -----  | 2   | . Backup Ring   | 9    | R15065   | 1   | . Gas Valve Protector |
| 6                                                                | *a -----  | 2   | . Wear Ring     | 9A   | R15066   | 2   | . Protective Screw    |

\*a Included in Seal Kit 249129  
\*b Use Piston Loading Sleeve 593471 for assembly into bore