


Seat Assembly

Seat Assembly


Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	596560		Seat Assembly				
1	* 597217	1	. Seat Assembly	18	R13811191	4	. Locknut
2	* 596682	1	. Joystick Assembly, 2-Button	19	221767W	12	. Washer
7	248733	1	. Toggle Switch	20	Y17C-0616	8	. Capscrew
9	236825	4	. Fitting	21	241779	10'	. Cord
10	209482	2	. Fitting	22	R740885	1	. Connector, Wire
11	586709	1	. Plate, LH Mounting	23	R740861	2	. Pin, Male
12	586710	1	. Plate, RH Mounting	24	238142	2	. Seal, Wire
13	597201	1	. Decal, Hoist/Dump/Side Tilt	25	NA	0	. Toggle Switch
14	248734	1	. Plate, Face	26	NA	0	. Switchguard, Toggle
15	249156	1	. Receptacle	27	NA	0	. Decal, Bucket Float
16	249157	1	. Plug	28	NA	0	. Terminal Ring
17	578530	1	. Decal, Implement	29	NA	0	. Insulation, Pipe
				30	244749	1	. Handle, Control
				31	244883	1	. Plate, Panel
				35	596494	4	. Machine Screw
				36	596985	1	. Decal; Steering, Joystick

* See Separate Coverage

NA - Not Applicable



SECTION B-B



SECTION A-A

