


Handle, Joystick, 4 Button, 1 Slider, Double Trigger



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	597684		Handle, Joystick, 4 Button, 1 Slider, Dbl Trigger				
4	598904	6	. Switch, Sealed	11	249908	1	. Mounting Pin
6	253037	10	. Screw	12	256874	5	. Capscrew
7	598905	1	. Case Set, L Handle, Black	13	249910	3	. Grommet
9	598906	1	. Trigger, Double	14	593476	1	. Adapter Bushing
10	598907	2	. Leaf Spring, Light Force	19	256875	5	. Lockwasher