

Front Axle Assembly

Front Axle Assembly

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	597694		Front Axle				
1	598800	1	. Housing, Axle	314	598814	1	.. Gear, Sun
2	*b 592903	1	. Breather	315	598815	1	.. Gear, Sun
3	592994	2	. Plug, Screw	316	*b 598816	1	.. Circlip
4	*b 592996	2	. Ring, Sealing	317	*b 592952	1	.. Circlip
5	592904	1	. Plug, Screw	320	598817	1	.. Ring
6	*b 592905	1	. Ring, Sealing	321	592947	1	.. Ring, Thrust
7	260607	2	. Plug, Screw	322	598818	5	.. Gear, Planetary
8	260608	2	. Ring, Sealing	323	598819	4	.. Gear, Planetary
40	598801	2	. Shaft, Axle	324	*b 598820	10	.. Disk
42	598802	2	. Hub, Wheel	329	*b 598821	5	.. Needle Bearing
43	592908	76	. Stud, Wheel	330	*b 598822	4	.. Bearing
49	598803	2	. Disk	331	598823	5	.. Pin, Planetary
50	*d 598804	4	. Ring, Radial Seal	333	*b 598824	5	.. Pin, Locking
53	*b 598805	2	. Bearing, Tapered-Roller	335	598825	1	.. Gear, Ring
54	*b 598805	2	. Bearing, Tapered-Roller	336	598826	1	.. Carrier, Ring Gear
55	598806	2	. Ring	337	598827	6	.. Retainer
59	*c 598807	2	. Nut	338	598828	12	.. Screw, Hexagon
60	598808	2	. Screw, Socket Hex	340	*b 598829	5	.. O-Ring
140	*b 598809	2	. O-Ring	360	*b 598830	4	.. Circlip
150	*a 598835	2	. Brake Assembly	366	598831	5	.. Cover
	598836	2	. Planetary Gear Drive	400	*a 598832	1	. Differential And Carrier Assembly
300	598811	1	.. Housing, Planetary	589	*b 592935	1	. Ring, Sealing
301	598812	1	.. Carrier, Planetary	600	*a 593014	1	. Parking Brake Assembly
304	*b 592944	1	.. O-Ring	601	593015	1	. Carrier, Brake
305	592945	1	.. Plug, Screw	602	*b 593016	2	. O-Ring
306	*b 592905	1	.. Ring, Sealing	603	593017	1	. Disc, Brake
307	592904	1	.. Plug, Screw	604	593018	12	. Screw
308	*b 592905	1	.. Ring, Sealing	628	593036	8	. Screw
309	592947	1	.. Ring, Thrust	2015	598834	12	. Screw
312	598813	36	.. Screw, Hexagon				

*a See Separate Coverage

*b Included in Service Kit 259605

*c Use Spanner Wrench 598938

*d Use Sleeve Driver 260102

Front Axle Assembly



